## **YASKAWA**

Σ-7-Series AC Servo Drive
Σ-7S SERVOPACK with
400V-Input Power and
EtherCAT (CoE) Communications References
Product Manual

Model: SGD7S-UUDA0UUUUUU

Selecting a SERVOPACK
SERVOPACK Installation
Wiring and Connecting

Basic Functions That Require Setting before Operation

Application Functions

Basic Information on SERVOPACKs

Trial Operation and Actual Operation

Tuning

Monitoring

Fully-Closed Loop Control 10

Safety Functions 1

EtherCAT Communications 12


CiA402 Drive Profile


Object Dictionary

Maintenance

Parameter and Object Lists

Appendices





Copyright © 2015 YASKAWA ELECTRIC CORPORATION
All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

## **About this Manual**

This manual provides information required to select  $\Sigma$ -7S SERVOPACKs with EtherCAT Communications References for  $\Sigma$ -7-Series AC Servo Drives, and to design, perform trial operation of, tune, operate, and maintain the Servo Drives.

Read and understand this manual to ensure correct usage of the  $\Sigma$ -7-Series AC Servo Drives.

Keep this manual in a safe place so that it can be referred to whenever necessary.


## **Outline of Manual**

The contents of the chapters of this manual are described in the following table. Refer to these chapters as required.

Chapter	Chapter Title	Contents	
1	Basic Information on SERVOPACKs	Provides information required to select SERVOPACKs, such as SER-VOPACK models and combinations with Servomotors.	
2	Selecting a SERVOPACK	Provides information required to select SERVOPACKs, such as specifications, block diagrams, dimensional drawings, and connection examples.	
3	SERVOPACK Installation	Provides information on installing SERVOPACKs in the required locations.	
4	Wiring and Connecting SERVOPACKs	Provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.	
5	Basic Functions That Require Setting before Operation	Describes the basic functions that must be set before you start Servo System operation. It also describes the setting methods.	
6	Application Functions	Describes the application functions that you can set before you start Servo System operation. It also describes the setting methods.	
7	Trial Operation and Actual Operation	Provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.	
8	Tuning	Provides information on the flow of tuning, details on tuning functions and related operating procedures.	
9	Monitoring	Provides information on monitoring SERVOPACK product information and SERVOPACK status.	
10	Fully-Closed Loop Control	Provides detailed information on performing fully-closed loop control with the SERVOPACK.	
11	Safety Functions	Provides detailed information on the safety functions of the SERVO-PACK.	
12	EtherCAT Communications	Provides basic information on EtherCAT communications.	
13	CiA402 Drive Profile	Provides detailed information on the CiA402 drive profile.	
14	Object Dictionary	Provides an overview and details on the object dictionary.	
15	Maintenance	Provides information on the meaning of, causes of, and corrections for alarms and warnings.	
16	Parameter and Object Lists	Provides information on parameters and objects.	
17	Appendices	Provides information on interpreting panel displays and tables of corresponding SERVOPACK and SigmaWin+ function names.	

## **Related Documents**

The relationships between the documents that are related to the Servo Drives are shown in the following figure. The numbers in the figure correspond to the numbers in the table on the following pages. Refer to these documents as required.



Classification	Document Name	Document No.	Description	
① Enclosed Document	Σ-7-Series AC Servo Drive Σ-7S SERVOPACK with 400 V-Input Power Safety Precautions	TOMP C710828 02	Provides detailed information for the safe usage of Σ-7-Series SERVOPACKs.	
	Σ-7-Series AC Servo Drive Σ-7S SERVOPACK with 400 V-Input Power and EtherCAT (CoE) Communications References Product Manual	This manual (SIEP S800001 80)		
② Σ-7-Series Σ-7S/Σ-7W	Σ-7-Series AC Servo Drive Σ-7S SERVOPACK with 400-V Input Power and MECHATROLINK-III Communications References RJ-45 Connectors Product Manual	SIEP S8000002 14	Provide detailed information on selecting $\Sigma$ -7-Series SERVOPACKs and information on installing, con-	
Σ-7S/Σ-7W SERVOPACK Product Manual	Σ-7-Series AC Servo Drive Σ-7W SERVOPACK with 400-V Input Power and EtherCAT (CoE) Communications References Product Manual	SIEP S800002 19	necting, setting, performing trial operation for, tuning, monitoring, and maintaining the Servo Drives.	
	Σ-7-Series AC Servo Drive Σ-7W SERVOPACK with 400-V Input Power and MECHATROLINK-III Communications References RJ-45 Connectors Product Manual	SIEP S800002 20		
③	AC Servo Drive Rotary Servomotor Safety Precautions	TOBP C230260 00	Provides detailed information for the safe usage of $\Sigma$ -7-Series Rotary Servomotors and Direct Drive Servomotors.	
Enclosed Documents	AC Servomotor Linear Σ Series Safety Precautions	TOBP C230800 00	Provides detailed information for the safe usage of $\Sigma$ -7-Series Linear Servomotors.	
<ul><li>Φ</li><li>Σ-7-Series</li><li>Rotary Servomotor</li><li>Product Manual</li></ul>	Σ-7-Series AC Servo Drive Rotary Servomotor with 400 V-Input Power Product Manual	SIEP S800001 86	Provide detailed information on selecting, installing, and connecting the $\Sigma$ -7-Series Servomotors.	
⑤ Σ-7-Series Linear Servomotor Product Manual	Σ-7-Series AC Servo Drive Linear Servomotor with 400 V-Input Power Product Manual	SIEP S800001 81		

Continued on next page.

#### Continued from previous page.

Classification	Document Name	Document No.	Description
⑥ Σ-7-Series Operation Interface Operating Manuals	Σ-7-Series AC Servo Drive Digital Operator Operating Manual	SIEP S800001 33	Describes the operating procedures for a Digital Operator for a Σ-7-Series Servo System.
	AC Servo Drive Engineering Tool SigmaWin+ Operation Manual	SIET S800001 34	Provides detailed operating procedures for the SigmaWin+ Engineering Tool for a $\Sigma$ -7-Series Servo System.

## **Using This Manual**

#### ◆ Technical Terms Used in This Manual

The following terms are used in this manual.

Term	Meaning
Servomotor	A Σ-7-Series Rotary Servomotor or Linear Servomotor
Rotary Servomotor	A Σ-7-Series Rotary Servomotor (SGM7J, SGM7A, or SGM7G).
Linear Servomotor	A Σ-7-Series Linear Servomotor (SGLF or SGLT).
SERVOPACK	A $\Sigma$ -7-Series $\Sigma$ -7S servo amplifier with EtherCAT Communications References.
Servo Drive	The combination of a Servomotor and SERVOPACK.
Servo System	A servo control system that includes the combination of a Servo Drive with a host controller and peripheral devices.
servo ON	Supplying power to the motor.
servo OFF	Not supplying power to the motor.
Servo ON command (Enable Operation command)	A command that is used to turn ON the servo (i.e., supply power to the motor) when bit 3 of controlword (6040 hex) is changed to 1 (ON) while the control power supply and main circuit power supply are ON.  Refer to the following section for details.  3.1 Device Control (page 13-3)
Servo OFF command (Disable Operation command)	A command that is used to turn OFF the servo (i.e., power not supplied to the motor) when bit 3 of controlword (6040 hex) is changed to 0 (OFF) while the control power supply and main circuit power supply are ON.  Refer to the following section for details.  13.1 Device Control (page 13-3)
base block (BB)	Shutting OFF the power supply to the motor by shutting OFF the base current to the power transistor in the SERVOPACK.
servo lock	A state in which the motor is stopped and is in a position loop with a position reference of 0.
Main Circuit Cable	One of the cables that connect to the main circuit terminals, including the Main Circuit Power Supply Cable, Control Power Supply Cable, and Servomotor Main Circuit Cable.
SigmaWin+	The Engineering Tool for setting up and tuning Servo Drives or a computer in which the Engineering Tool is installed.

#### ◆ Differences in Terms for Rotary Servomotors and Linear Servomotors

There are differences in the terms that are used for Rotary Servomotors and Linear Servomotors. This manual primarily describes Rotary Servomotors. If you are using a Linear Servomotor, you need to interpret the terms as given in the following table.

Rotary Servomotors	Linear Servomotors
torque	force
moment of inertia	mass
rotation	movement
forward rotation and reverse rotation	forward movement and reverse movement
CW and CCW pulse trains	forward and reverse pulse trains
rotary encoder	linear encoder
absolute rotary encoder	absolute linear encoder
incremental rotary encoder	incremental linear encoder
unit: min <sup>-1</sup>	unit: mm/s
unit: N·m	unit: N

#### Notation Used in this Manual

#### ■ Notation for Reverse Signals

The names of reverse signals (i.e., ones that are valid when low) are written with a forward slash (/) before the signal abbreviation.


Notation Example

BK is written as /BK.

#### ■ Notation for Parameters


The notation depends on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting functions).

#### · Parameters for Numeric Settings



#### Notation Example

Notation Examples for Pn002



#### ◆ Engineering Tools Used in This Manual

This manual uses the interfaces of the SigmaWin+ for descriptions.

#### **♦** Trademarks

- EtherCAT is a registered trademark of Beckhoff Automation GmbH, Germany.
- QR code is a trademark of Denso Wave Inc.
- Other product names and company names are the trademarks or registered trademarks of the respective company. "TM" and the ® mark do not appear with product or company names in this manual.

#### ◆ Visual Aids

The following aids are used to indicate certain types of information for easier reference.



Indicates precautions or restrictions that must be observed. Also indicates alarm displays and other precautions that will not result in machine damage.



Indicates definitions of difficult terms or terms that have not been previously explained in this

Indicates operating or setting examples.

Information Indicates supplemental information to deepen understanding or useful information.

## **Safety Precautions**

#### Safety Information

To prevent personal injury and equipment damage in advance, the following signal words are used to indicate safety precautions in this document. The signal words are used to classify the hazards and the degree of damage or injury that may occur if a product is used incorrectly. Information marked as shown below is important for safety. Always read this information and heed the precautions that are provided.

#### DANGER

• Indicates precautions that, if not heeded, are likely to result in loss of life, serious injury, or fire.

## WARNING

• Indicates precautions that, if not heeded, could result in loss of life, serious injury, or fire.

## **M** CAUTION

• Indicates precautions that, if not heeded, could result in relatively serious or minor injury, or in fire.

#### NOTICE

• Indicates precautions that, if not heeded, could result in property damage.

#### Safety Precautions That Must Always Be Observed

#### General Precautions

## DANGER

- Read and understand this manual to ensure the safe usage of the product.
- Keep this manual in a safe, convenient place so that it can be referred to whenever necessary.
   Make sure that it is delivered to the final user of the product.
- Do not remove covers, cables, connectors, or optional devices while power is being supplied to the SERVOPACK.

There is a risk of electric shock, operational failure of the product, or burning.

## **WARNING**

- Use a power supply with specifications (number of phases, voltage, frequency, and AC/DC type) that are appropriate for the product.
  - There is a risk of burning, electric shock, or fire.
- ullet Connect the ground terminals on the SERVOPACK and Servomotor to ground poles according to local electrical codes. (Connect to 10  $\Omega$  or less for the SERVOPACK.) There is a risk of electric shock or fire.
- Do not attempt to disassemble, repair, or modify the product.
   There is a risk of fire or failure.
   The warranty is void for the product if you disassemble, repair, or modify it.

## **CAUTION**

The SERVOPACK heat sinks, Regenerative Resistors, Servomotors, and other components can
be very hot while power is ON or soon after the power is turned OFF. Implement safety measures, such as installing covers, so that hands and parts such as cables do not come into contact with hot components.

There is a risk of burn injury.

• For a 24-VDC power supply, use a power supply device with double insulation or reinforced insulation.

There is a risk of electric shock.

- Do not damage, pull on, apply excessive force to, place heavy objects on, or pinch cables. There is a risk of failure, damage, or electric shock.
- The person who designs the system that uses the hard wire base block safety function must have a complete knowledge of the related safety standards and a complete understanding of the instructions in this document.

There is a risk of injury, product damage, or machine damage.

• Do not use the product in an environment that is subject to water, corrosive gases, or flammable gases, or near flammable materials.

There is a risk of electric shock or fire.

- Do not attempt to use a SERVOPACK or Servomotor that is damaged or that has missing parts.
- Install external emergency stop circuits that shut OFF the power supply and stops operation immediately when an error occurs.
- In locations with poor power supply conditions, install the necessary protective devices (such as AC Reactors) to ensure that the input power is supplied within the specified voltage range.
   There is a risk of damage to the SERVOPACK.
- Use a Noise Filter to minimize the effects of electromagnetic interference. Electronic devices used near the SERVOPACK may be affected by electromagnetic interference.
- Always use a Servomotor and SERVOPACK in one of the specified combinations.
- Do not touch a SERVOPACK or Servomotor with wet hands.
   There is a risk of product failure.

#### Storage Precautions

## **M** CAUTION

 Do not place an excessive load on the product during storage. (Follow all instructions on the packages.)

There is a risk of injury or damage.

## **NOTICE**

- Do not install or store the product in any of the following locations.
  - Locations that are subject to direct sunlight
  - Locations that are subject to ambient temperatures that exceed product specifications
  - Locations that are subject to relative humidities that exceed product specifications
  - · Locations that are subject to condensation as the result of extreme changes in temperature
  - Locations that are subject to corrosive or flammable gases
  - · Locations that are near flammable materials
  - · Locations that are subject to dust, salts, or iron powder
  - Locations that are subject to water, oil, or chemicals
  - Locations that are subject to vibration or shock that exceeds product specifications
  - · Locations that are subject to radiation

If you store or install the product in any of the above locations, the product may fail or be damaged.

#### ■ Transportation Precautions

## **M** CAUTION

- Transport the product in a way that is suitable to the mass of the product.
- Do not use the eyebolts on a SERVOPACK or Servomotor to move the machine. There is a risk of damage or injury.
- When you handle a SERVOPACK or Servomotor, be careful of sharp parts, such as the corners. There is a risk of injury.
- Do not place an excessive load on the product during transportation. (Follow all instructions on the packages.)

There is a risk of injury or damage.

- Do not hold onto the front cover or connectors when you move a SERVOPACK.
   There is a risk of the SERVOPACK falling.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Do not subject connectors to shock.

  There is a risk of faulty connections or damage.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, plywood, or pallets, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.

Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.

If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.

Do not overtighten the eyebolts on a SERVOPACK or Servomotor.
 If you use a tool to overtighten the eyebolts, the tapped holes may be damaged.

#### ■ Installation Precautions

## **⚠** CAUTION

- Install the Servomotor or SERVOPACK in a way that will support the mass given in technical documents.
- Install SERVOPACKs, Servomotors, and Regenerative Resistors on nonflammable materials. Installation directly onto or near flammable materials may result in fire.
- Provide the specified clearances between the SERVOPACK and the control panel as well as with other devices.

There is a risk of fire or failure.

- Install the SERVOPACK in the specified orientation.
  - There is a risk of fire or failure.
- Do not step on or place a heavy object on the product. There is a risk of failure, damage, or injury.
- Do not allow any foreign matter to enter the SERVOPACK or Servomotor. There is a risk of failure or fire.

- Do not install or store the product in any of the following locations.
  - · Locations that are subject to direct sunlight
  - · Locations that are subject to ambient temperatures that exceed product specifications
  - · Locations that are subject to relative humidities that exceed product specifications
  - · Locations that are subject to condensation as the result of extreme changes in temperature
  - Locations that are subject to corrosive or flammable gases
  - · Locations that are near flammable materials
  - · Locations that are subject to dust, salts, or iron powder
  - Locations that are subject to water, oil, or chemicals
  - · Locations that are subject to vibration or shock that exceeds product specifications
  - · Locations that are subject to radiation

If you store or install the product in any of the above locations, the product may fail or be damaged.

- Use the product in an environment that is appropriate for the product specifications. If you use the product in an environment that exceeds product specifications, the product may fail or be damaged.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Always install a SERVOPACK in a control panel.
- Do not allow any foreign matter to enter a SERVOPACK or a Servomotor with a Cooling Fan and do not cover the outlet from the Servomotor's cooling fan.
   There is a risk of failure.

#### Wiring Precautions

## DANGER

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

## **WARNING**

- Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.
- Check all wiring and power supplies carefully.
   Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.
- Connect the AC and DC power supplies to the specified SERVOPACK terminals.
  - Connect an AC power supply to the L1, L2, and L3 terminals on the SERVOPACK.
  - Connect a DC power supply to the B1 and ⊝2 terminals and the 24 V and 0 V terminals on the SER-VOPACK.

There is a risk of failure or fire.

## **CAUTION**

- Wait for six minutes after turning OFF the power supply and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK.
  - There is a risk of electric shock.
- Observe the precautions and instructions for wiring and trial operation precisely as described in this document.
  - Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the equipment, or cause an accident resulting in death or injury.
- Check the wiring to be sure it has been performed correctly.
   Connectors and pin layouts are sometimes different for different models. Always confirm the pin layouts in technical documents for your model before operation.
   There is a risk of failure or malfunction.
- Connect wires to power supply terminals and motor connection terminals securely with the specified methods and tightening torque.
   Insufficient tightening may cause wires and terminal blocks to generate heat due to faulty contact, possibly resulting in fire.
- Use shielded twisted-pair cables or screened unshielded multi-twisted-pair cables for I/O Signal Cables and Encoder Cables.
- Observe the following precautions when wiring the SERVOPACK's main circuit terminals.
  - Turn ON the power supply to the SERVOPACK only after all wiring, including the main circuit terminals, has been completed.
  - If a connector is used for the main circuit terminals, remove the main circuit connector from the SER-VOPACK before you wire it.
  - Insert only one wire per insertion hole in the main circuit terminals.
  - When you insert a wire, make sure that the conductor wire (e.g., whiskers) does not come into contact with adjacent wires.
- Install molded-case circuit breakers and other safety measures to provide protection against short circuits in external wiring.
  - There is a risk of fire or failure.

#### NOTICE

- Whenever possible, use the Cables specified by Yaskawa. If you use any other cables, confirm the rated current and application environment of your model and use the wiring materials specified by Yaskawa or equivalent materials.
- Securely tighten cable connector screws and lock mechanisms.
   Insufficient tightening may result in cable connectors falling off during operation.
- Do not bundle power lines (e.g., the Main Circuit Cable) and low-current lines (e.g., the I/O Signal Cables or Encoder Cables) together or run them through the same duct. If you do not place power lines and low-current lines in separate ducts, separate them by at least 30 cm. If the cables are too close to each other, malfunctions may occur due to noise affecting the low-current lines.
- Install a battery at either the host controller or on the Encoder Cable.

  If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.
- When connecting a battery, connect the polarity correctly.
   There is a risk of battery rupture or encoder failure.
- If you use an External Regenerative Resistor or External Dynamic Brake Resistor, use cable ties, clamps, or other means to secure the resistor so that the connectors or terminal blocks inside the SERVOPACK will not be affected even if the resistor is subjected to vibration or shock.
   There is a risk of SERVOPACK damage.

#### Operation Precautions

## **MARNING**

- Before starting operation with a machine connected, change the settings of the switches and parameters to match the machine.
  - Unexpected machine operation, failure, or personal injury may occur if operation is started before appropriate settings are made.
- Do not radically change the settings of the parameters.

  There is a risk of unstable operation, machine damage, or injury.
- Install limit switches or stoppers at the ends of the moving parts of the machine to prevent unexpected accidents.

There is a risk of machine damage or injury.

- For trial operation, securely mount the Servomotor and disconnect it from the machine. There is a risk of injury.
- Forcing the motor to stop for overtravel is disabled when the Jog (Fn002), Origin Search (Fn003), or Easy FFT (Fn206) utility function is executed. Take necessary precautions. There is a risk of machine damage or injury.
- When an alarm occurs, the motor will coast to a stop or stop with the dynamic brake according
  to a setting in the SERVOPACK. The coasting distance will change with the moment of inertia of
  the load. Check the coasting distance during trial operation and implement suitable safety measures on the machine.
- Do not enter the machine's range of motion during operation. There is a risk of injury.
- Do not touch the moving parts of the Servomotor or machine during operation.
   There is a risk of injury.

## **⚠** CAUTION

- Design the system to ensure safety even when problems, such as broken signal lines, occur.
   For example, the P-OT and N-OT signals are set in the default settings to operate on the safe side if a signal line breaks. Do not change the polarity of this type of signal.
- When overtravel occurs, the power supply to the motor is turned OFF and the brake is released.
   If you use the Servomotor to drive a vertical load, set the Servomotor to enter a zero-clamped state after the Servomotor stops. Also, install safety devices (such as an external brake or counterweight) to prevent the moving parts of the machine from falling.
- Always turn OFF the servo before you turn OFF the power supply. If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor will stop as follows:
  - If you turn OFF the main circuit power supply during operation without turning OFF the servo, the Servomotor will stop abruptly with the dynamic brake or it will coast to a stop.
  - If you turn OFF the control power supply during operation without turning OFF the servo, the Servomotor will stop abruptly with the dynamic brake or it will coast to a stop. For details, refer to the manual for the SERVOPACK.
  - If you use an External Dynamic Brake Resistor, the Servomotor stopping method will be different from when the built-in dynamic brake resistor is used. For details, refer to the product manual for your SERVOPACK.
- Do not use the dynamic brake for any application other than an emergency stop.

  There is a risk of failure due to rapid deterioration of elements in the SERVOPACK and the risk of unexpected operation, machine damage, burning, or injury.

- When you adjust the gain during system commissioning, use a measuring instrument to monitor the torque waveform and speed waveform and confirm that there is no vibration.
   If a high gain causes vibration, the Servomotor will be damaged quickly.
- Do not frequently turn the power supply ON and OFF. After you have started actual operation, allow at least one hour between turning the power supply ON and OFF (as a guideline).
   Do not use the product in applications that require the power supply to be turned ON and OFF frequently.

The elements in the SERVOPACK will deteriorate quickly.

- An alarm or warning may occur if communications are performed with the host controller while the SigmaWin+ or Digital Operator is operating.
- If an alarm or warning occurs, it may interrupt the current process and stop the system.
- After you complete trial operation of the machine and facilities, use the SigmaWin+ to back up
  the settings of the SERVOPACK parameters. You can use them to reset the parameters after
  SERVOPACK replacement.

If you do not copy backed up parameter settings, normal operation may not be possible after a faulty SERVOPACK is replaced, possibly resulting in machine or equipment damage.

■ Maintenance and Inspection Precautions

## **A** DANGER

Do not change any wiring while power is being supplied.
 There is a risk of electric shock or injury.

## WARNING

• Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.

## **M** CAUTION

- Wait for six minutes after turning OFF the power supply and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK.
  - There is a risk of electric shock.
- Before you replace a SERVOPACK, back up the settings of the SERVOPACK parameters. Copy
  the backed up parameter settings to the new SERVOPACK and confirm that they were copied
  correctly.

If you do not copy backed up parameter settings or if the copy operation is not completed normally, normal operation may not be possible, possibly resulting in machine or equipment damage.

## **NOTICE**

 Discharge all static electricity from your body before you operate any of the buttons or switches inside the front cover of the SERVOPACK.

There is a risk of equipment damage.

#### ■ Troubleshooting Precautions

## DANGER

If the safety device (molded-case circuit breaker or fuse) installed in the power supply line operates, remove the cause before you supply power to the SERVOPACK again. If necessary, repair or replace the SERVOPACK, check the wiring, and remove the factor that caused the safety device to operate.

There is a risk of fire, electric shock, or injury.

## **WARNING**

The product may suddenly start to operate when the power supply is recovered after a momentary power interruption. Design the machine to ensure human safety when operation restarts.
 There is a risk of injury.

## **CAUTION**

- When an alarm occurs, remove the cause of the alarm and ensure safety. Then reset the alarm or turn the power supply OFF and ON again to restart operation.
   There is a risk of injury or machine damage.
- If the Servo ON signal is input to the SERVOPACK and an alarm is reset, the Servomotor may suddenly restart operation. Confirm that the servo is OFF and ensure safety before you reset an alarm

There is a risk of injury or machine damage.

- Always insert a Magnetic Contactor in the line between the main circuit power supply and the main circuit power supply terminals on the SERVOPACK so that the power supply can be shut OFF at the main circuit power supply.
  - If a Magnetic Contactor is not connected when the SERVOPACK fails, a large current may flow, possibly resulting in fire.
- If an alarm occurs, shut OFF the main circuit power supply.
   There is a risk of fire due to a Regenerative Resistor overheating as the result of regenerative transistor failure.
- Install a ground fault detector against overloads and short-circuiting or install a molded-case circuit breaker combined with a ground fault detector.
   There is a risk of SERVOPACK failure or fire if a ground fault occurs.
- The holding brake on a Servomotor will not ensure safety if there is the possibility that an external force (including gravity) may move the current position and create a hazardous situation when power is interrupted or an error occurs. If an external force may cause movement, install an external braking mechanism that ensures safety.

#### ■ Disposal Precautions

When disposing of the product, treat it as ordinary industrial waste. However, local ordinances
and national laws must be observed. Implement all labeling and warnings as a final product as
required.

#### ■ General Precautions

- Figures provided in this document are typical examples or conceptual representations. There may be differences between them and actual wiring, circuits, and products.
- The products shown in illustrations in this document are sometimes shown without covers or protective guards. Always replace all covers and protective guards before you use the product.
- If you need a new copy of this document because it has been lost or damaged, contact your nearest Yaskawa representative or one of the offices listed on the back of this document.
- This document is subject to change without notice for product improvements, specifications changes, and improvements to the manual itself.
   We will update the document number of the document and issue revisions when changes are made.
- Any and all quality guarantees provided by Yaskawa are null and void if the customer modifies
  the product in any way. Yaskawa disavows any responsibility for damages or losses that are
  caused by modified products.

## Warranty

#### Details of Warranty

#### ■ Warranty Period

The warranty period for a product that was purchased (hereinafter called the "delivered product") is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

#### ■ Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the above warranty period.

This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

- Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
- · Causes not attributable to the delivered product itself
- Modifications or repairs not performed by Yaskawa
- Use of the delivered product in a manner in which it was not originally intended
- Causes that were not foreseeable with the scientific and technological understanding at the time of shipment from Yaskawa
- · Events for which Yaskawa is not responsible, such as natural or human-made disasters

#### Limitations of Liability

- Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
- Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
- The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
- Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

#### Suitability for Use

- It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
- The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
- Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
  - •Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
  - •Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
  - •Systems, machines, and equipment that may present a risk to life or property
  - •Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or systems that operate continuously 24 hours a day
  - •Other systems that require a similar high degree of safety
- Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
- The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
- Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.

#### Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

## Compliance with UL Standards, EU Directives, and Other Safety Standards

Certification marks for the standards for which the product has been certified by certification bodies are shown on nameplate. Products that do not have the marks are not certified for the standards.

#### North American Safety Standards (UL)





Product	Model	III Standarda (III Eila Na )
Product	Model	UL Standards (UL File No.)
SERVOPACKs	• SGD7S • SGD7W	UL 61800-5-1 (E147823), CSA C22.2 No.274
Rotary Servomotors	• SGM7A • SGM7J • SGM7G	UL 1004-1 UL 1004-6 (E165827)
Linear Servomotors	• SGLFW <sup>*1</sup> • SGLFW2 <sup>*2</sup> • SGLTW <sup>*1</sup>	UL 1004 (E165827)

<sup>\*1.</sup> There are usage restrictions. Contact your Yaskawa representative for details.

#### European Directives





Product	Model	European Directive	Harmonized Standards
SERVOPACKs	• SGD7S • SGD7W	Machinery Directive 2006/42/EC	EN ISO13849-1: 2015
		EMC Directive 2004/108/EC	EN 55011 group 1, class A EN 61000-6-2 EN 61000-6-4 EN 61800-3
		Low Voltage Directive 2006/95/EC	EN 50178 EN 61800-5-1
Rotary Servomotors	• SGM7J • SGM7A • SGM7G	EMC Directive 2004/108/EC	EN 55011 group 1, class A EN 61000-6-2 EN 61000-6-4 EN 61800-3
		Low Voltage Directive 2006/95/EC	EN 60034-1 EN 60034-5
Linear Servomotors	• SGLF • SGLFW2 • SGLT	EMC Directive 2004/108/EC	EN 55011 group 1, class A EN 61000-6-2 EN 61000-6-4
		Low Voltage Directive 2006/95/EC	EN 60034-1

Note: We declared the CE Marking based on the harmonized standards in the above table.

<sup>\*2.</sup> Certification is pending.

## ◆ Safety Standards



Product	Model	Safety Standards	Standards
		Safety of Machinery	EN ISO13849-1: 2015 IEC 60204-1
SERVOPACKs	• SGD7S • SGD7W	Functional Safety	IEC 61508 series IEC 62061 IEC 61800-5-2
		EMC	IEC 61326-3-1

## ♦ Safety Parameters

Item	Standards	Performance Level
Safety Integrity Level	IEC 61508	SIL3
Safety integrity Level	IEC 62061	SILCL3
Probability of Dangerous Failure per Hour	IEC 61508 IEC 62061	PFH = $4.60 \times 10^{-9}$ [1/h] (4.60% of SIL3)
Performance Level	EN ISO 13849-1	PLe (category 3)
Mean Time to Dangerous Failure of Each Channel	EN ISO 13849-1	MTTFd: High
Average Diagnostic Coverage	EN ISO 13849-1	DCavg: Medium
Stop Category	IEC 60204-1	Stop category 0
Safety Function	IEC 61800-5-2	STO
Mission Time	IEC 61508	10 years
Hardware Fault Tolerance	IEC 61508	HFT = 1
Subsystem	IEC 61508	В

## Contents

About this Manual . . . . . . iii

B	Butline of Manual
	SIC IIIOIIIIAIOII OII OLIIVOI AONS
1.1	The $\Sigma$ -7 Series
1.2	ntroduction to EtherCAT 1-3
	.2.1 Introduction to CANopen
1.3	nterpreting the Nameplate
1.4	Part Names1-7
1.5	Model Designations1-9.5.1 Interpreting SERVOPACK Model Numbers.1-9.5.2 Interpreting Servomotor Model Numbers.1-10
1.6	Combinations of SERVOPACKs and Servomotors 1-11
	.6.1 Combinations of Rotary Servomotors and SERVOPACKs1-11 .6.2 Combinations of Linear Servomotors and SERVOPACKs1-12
1.7	functions
2 s	ecting a SERVOPACK
2.1	Ratings and Specifications2-2
	.1.1 Ratings.2-2.1.2 SERVOPACK Overload Protection Characteristics.2-3.1.3 Specifications.2-4
2.2	Block Diagrams
	.2.1 SERVOPACKs without Built-in Servomotor Brake Control
2.3	external Dimensions
	.3.1 Front Cover Dimensions and Connector Specifications
2.4	xamples of Standard Connections between SERVOPACKs and Peripheral Devices 2-18

3	SI	ERVOPACK Installation
	3.1	Installation Precautions
	3.1	installation Frecautions
	3.2	Mounting Types and Orientation
	3.3	Mounting Hole Dimensions 3-4
	3.4	Mounting Interval
		3.4.1 Installing One SERVOPACK in a Control Panel
		3.4.2 Installing More Than One SERVOPACK in a Control Panel
	3.5	Monitoring the Installation Environment 3-6
	3.6	EMC Installation Conditions 3-7
4	W	iring and Connecting SERVOPACKs
	4.1	Wiring and Connecting SERVOPACKs 4-3
		4.1.1 General Precautions       4-3         4.1.2 Countermeasures against Noise       4-5         4.1.3 Grounding       4-8
	4.2	Basic Wiring Diagrams
	4.3	Wiring the Power Supply to the SERVOPACK 4-11
		4.3.1       Terminal Symbols and Terminal Names       4-11         4.3.2       Connector Wiring Procedure       4-13         4.3.3       Power ON Sequence       4-14         4.3.4       Power Supply Wiring Diagrams       4-15         4.3.5       Wiring Regenerative Resistors       4-18         4.3.6       Wiring DC Reactors       4-18
	4.4	Wiring Servomotors
		4.4.1Terminal Symbols and Terminal Names4-194.4.2Pin Arrangement of Encoder Connector (CN2)4-194.4.3Wiring the SERVOPACK to the Encoder4-204.4.4Wiring the SERVOPACK to the Holding Brake4-25
	4.5	Connecting I/O Signals 4-28
		4.5.1       I/O Signal Connector (CN1) Names and Functions       4-28         4.5.2       I/O Signal Connector (CN1) Pin Arrangement       4-30         4.5.3       I/O Signal Wiring Examples       4-31         4.5.4       I/O Circuits       4-33
	4.6	Connecting Safety Function Signals 4-35
		4.6.1Pin Arrangement of Safety Function Signals (CN8)4-354.6.2I/O Circuits4-35
	4.7	Connecting Dynamic Brake Resistors 4-37
		4.7.1 Terminal Symbols and Terminal Names

	4.8	Connecting EtherCAT Communications Cables	4-39
		I.8.1EtherCAT Connectors (RJ45)I.8.2Ethernet Communications Cables	
	4.9	Connecting the Other Connectors	4-41
		I.9.1 Serial Communications Connector (CN3)	
5	В	sic Functions That Require Setting before	Operation
	5.1	Manipulating SERVOPACK Parameters (Pn□□	□)5-3
		5.1.1 Classifications of SERVOPACK Parameters	5-4 5-5 s5-7
	5.2	Power Supply Type Settings for the Main Circu	it 5-12
	5.3	Automatic Detection of Connected Motor	5-13
	5.4	Motor Direction Setting	5-14
	5.5	Setting the Linear Encoder Pitch	5-15
	5.6	Writing Linear Servomotor Parameters	5-16
	5.7	Selecting the Phase Sequence for a Linear Ser	vomotor 5-20
	5.8	Polarity Sensor Setting	5-22
	5.9	Polarity Detection	5-23
		5.9.1 Restrictions	
		to Perform Polarity Detection	
	5.10	Overtravel and Related Settings	5-26
		5.10.1 Overtravel Signals 5.10.2 Setting to Enable/Disable Overtravel 5.10.3 Motor Stopping Method for Overtravel 5.10.4 Overtravel Warnings 5.10.5 Overtravel Release Method Selection 6.10.6 Overtravel Status 6.10.7 Overtravel Operation by Mode	
	5.11	Holding Brake	5-32
		5.11.1 Brake Operating Sequence	

	5.12	Motor	r Stopping Methods for Servo OFF and Alarms 5-	-37
			Stopping Method for Servo OFF	
	5.13	Motor	r Overload Detection Level 5-	-40
			Detection Timing for Overload Warnings (A.910)	
	5.14	Settin	ng Unit Systems	-42
		5.14.2 5.14.3	Setting the Position Reference Unit	5-47 5-48
	5.15	Reset	ting the Absolute Encoder 5-	-49
		5.15.2	Precautions on Resetting	5-49
	5.16	Settin	ng the Origin of the Absolute Encoder 5-	-52
			Absolute Encoder Origin Offset	
	5.17	Settin	ng the Regenerative Resistor Capacity 5-	-55
	5.18	Setting	the Energy Consumption and Resistance of the Dynamic Brake Resistor 5	5-56
	0110	Cotting	, , , , , , , , , , , , , , , , , , ,	
			· · · · · · · · · · · · · · · · · · ·	
6			tion Functions	_
6		pplica	· · · · · · · · · · · · · · · · · · ·	_
6	A	pplica	gnal Allocations	<b>6-4</b> 6-4
6	A	I/O Si 6.1.1 6.1.2 6.1.3	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal	<b>6-4</b> 6-4 6-5 6-7
6	A	I/O Si 6.1.1 6.1.2	gnal Allocations	6-4 6-4 6-5 6-7 6-7
6	A	I/O Si 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal	6-4 6-4 6-5 6-7 6-7 6-8 6-8
6	A	Pplica 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6 6.1.7 6.1.8	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal /V-CMP (Speed Coincidence Detection) Signal /COIN (Positioning Completion) Signal	6-4 6-4 6-5 6-7 6-7 6-8 6-8 6-9 6-10
6	A	I/O Si 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6 6.1.7	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal /V-CMP (Speed Coincidence Detection) Signal	6-4 6-4 6-5 6-7 6-8 6-8 6-9 3-10 6-11
6	A	I/O Si 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6 6.1.7 6.1.8 6.1.9 6.1.10	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal /V-CMP (Speed Coincidence Detection) Signal /COIN (Positioning Completion) Signal /NEAR (Near) Signal	6-4 6-4 6-5 6-7 6-8 6-8 6-9 6-10 6-11 6-12
6	A 6.1	I/O Si 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6 6.1.7 6.1.8 6.1.9 6.1.10  Opera	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal /V-CMP (Speed Coincidence Detection) Signal /COIN (Positioning Completion) Signal /NEAR (Near) Signal Speed Limit during Torque Control	6-4 6-4 6-5 6-7 6-8 6-8 6-9 6-10 6-11 6-12
6	6.1 6.2	I/O Si 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6 6.1.7 6.1.8 6.1.9 6.1.10 Opera	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal /V-CMP (Speed Coincidence Detection) Signal /COIN (Positioning Completion) Signal /NEAR (Near) Signal Speed Limit during Torque Control  ation for Momentary Power Interruptions  6-	6-4 6-4 6-5 6-7 6-8 6-8 6-9 6-10 6-11 6-12 -14
6	6.1 6.2 6.3	I/O Si 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6 6.1.7 6.1.8 6.1.9 6.1.10  Opera  SEMI  Settin	gnal Allocations  Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal /V-CMP (Speed Coincidence Detection) Signal /COIN (Positioning Completion) Signal /NEAR (Near) Signal Speed Limit during Torque Control ation for Momentary Power Interruptions 6- F47 Function 6- Get Motor Maximum Speed 6- Get Divided Pulse Output 6-	6-4 6-4 6-5 6-7 6-7 6-8 6-9 6-10 6-11 6-12 -14 -15
6	6.1 6.2 6.3 6.4	I/O Si 6.1.1 6.1.2 6.1.3 6.1.4 6.1.5 6.1.6 6.1.7 6.1.8 6.1.9 6.1.10  Opera  SEMI  Settin	gnal Allocations Input Signal Allocations Output Signal Allocations ALM (Servo Alarm) Signal /WARN (Warning) Signal /TGON (Rotation Detection) Signal /S-RDY (Servo Ready) Signal /V-CMP (Speed Coincidence Detection) Signal /COIN (Positioning Completion) Signal /NEAR (Near) Signal Speed Limit during Torque Control ation for Momentary Power Interruptions 6- F47 Function 6- Ing the Motor Maximum Speed 6-	6-4 6-4 6-5 6-7 6-8 6-8 6-9 6-10 6-11 6-12 -14 -15

6.7	Selec	ting Torque Limits	6-26
	6.7.1 6.7.2 6.7.3	Internal Torque Limits	.6-27
6.8	Abso	lute Encoders	6-31
	6.8.1 6.8.2 6.8.3 6.8.4 6.8.5 6.8.6 6.8.7 6.8.8	Connecting an Absolute Encoder	.6-32 .6-33 .6-34 .6-35 .6-36
6.9	Abso	lute Linear Encoders	6-40
	6.9.1 6.9.2 6.9.3 6.9.4 6.9.5 6.9.6	Connecting an Absolute Linear Encoder.  Structure of the Position Data of the Absolute Linear Encoder.  Output Ports for the Position Data from the Absolute Linear Encoder.  Reading the Position Data from the Absolute Linear Encoder.  Transmission Specifications.  Calculating the Current Position in Machine Coordinates.	.6-40 .6-41 .6-42 .6-42
6.10	Softw	vare Reset	6-44
		Preparations	.6-44
6.11	Initial	izing the Vibration Detection Level	6-46
	6.11.3	Preparations	.6-46 .6-47
6.12	Adjus	sting the Motor Current Detection Signal Offset	6-50
		Automatic Adjustment	
6.13	Forci	ng the Motor to Stop	6-55
	6.13.1 6.13.2 6.13.3	FSTP (Forced Stop Input) Signal	.6-55
6.14	ZONE	Outputs (FT64 Specification)	6-58
	6.14.3 6.14.4	ZONE Table and ZONE Signals  ZONE Table Settings  ZONE Signals 1 to 4 Outputs (/ZONE0 to /ZONE3)  nZONE Signal Output  ZONE Output Application Example	.6-59 .6-60 .6-61

7.1	Flow of Trial Operation
	7.1.1 Flow of Trial Operation for Rotary Servomotors
7.2	Inspections and Confirmations before Trial Operation 7-6
7.3	Trial Operation for the Servomotor without a Load 7-7
	7.3.1 Preparations       7-7         7.3.2 Applicable Tools       7-7         7.3.3 Operating Procedure       7-8
7.4	Trial Operation with EtherCAT (CoE) Communications 7-10
7.5	Trial Operation with the Servomotor Connected to the Machine 7-11
	7.5.1 Precautions       7-11         7.5.2 Preparations       7-11         7.5.3 Operating Procedure       7-12
7.6	Convenient Function to Use during Trial Operation 7-13
	7.6.1 Program Jogging       7-13         7.6.2 Origin Search       7-19         7.6.3 Test without a Motor       7-21
8	ning
8.1	Overview and Flow of Tuning
	3.1.1Tuning Functions8-53.1.2Diagnostic Tool8-6
8.2	Monitoring Methods8-7
8.3	Precautions to Ensure Safe Tuning
	8.3.1Overtravel Settings8-88.3.2Torque Limit Settings8-88.3.3Setting the Position Deviation Overflow Alarm Level8-88.3.4Vibration Detection Level Setting8-108.3.5Setting the Position Deviation Overflow Alarm Level at Servo ON8-10
8.4	Tuning-less Function 8-12
	3.4.1Application Restrictions8-123.4.2Operating Procedure8-133.4.3Troubleshooting Alarms8-143.4.4Parameters Disabled by Tuning-less Function8-153.4.5Automatically Adjusted Function Setting8-153.4.6Related Parameters8-15
8.5	Estimating the Moment of Inertia8-16
	3.5.1       Outline

**Trial Operation and Actual Operation** 

8.6	Autot	uning without Host Reference	8-23
	8.6.1 8.6.2 8.6.3 8.6.4 8.6.5 8.6.6 8.6.7	Outline Restrictions Applicable Tools Operating Procedure Troubleshooting Problems in Autotuning without a Host Reference Automatically Adjusted Function Settings Related Parameters	.8-24 .8-25 .8-25 .8-29 .8-31 .8-33
8.7	Autot	uning with a Host Reference	8-34
	8.7.1 8.7.2 8.7.3 8.7.4 8.7.5 8.7.6 8.7.7	Outline Restrictions Applicable Tools Operating Procedure Troubleshooting Problems in Autotuning with a Host Reference Automatically Adjusted Function Settings Related Parameters	.8-35 .8-35 .8-36 .8-39 .8-39
8.8	Custo	om Tuning	8-41
	8.8.1 8.8.2 8.8.3 8.8.4 8.8.5 8.8.6 8.8.7	Outline . Preparations . Applicable Tools . Operating Procedure . Automatically Adjusted Function Settings . Tuning Example for Tuning Mode 2 or 3 . Related Parameters	.8-41 .8-41 .8-42 .8-42 .8-48 .8-48
8.9	Anti-F	Resonance Control Adjustment 8	8-50
	8.9.1 8.9.2 8.9.3 8.9.4 8.9.5 8.9.6	Outline Preparations Applicable Tools Operating Procedure Related Parameters Suppressing Different Vibration Frequencies with	.8-50 .8-51 .8-51 .8-53
		Anti-resonance Control	
8.10	8.10.1 8.10.2 8.10.3 8.10.4 8.10.5	Outline Preparations Applicable Tools Operating Procedure Setting Combined Functions Related Parameters	.8-55 .8-56 .8-56 .8-56 .8-58
8.11	Speed	d Ripple Compensation	8-59
		Outline	.8-59
8.12	Additi	ional Adjustment Functions	8-65
	8.12.1 8.12.2 8.12.3 8.12.4 8.12.5 8.12.6	Gain Switching	.8-65 .8-68 .8-69 .8-70 .8-70

8.13	Manu	al luning 8-76	j
	8.13.1 8.13.2	Tuning the Servo Gains	
8.14	Diagn	ostic Tools 8-90	)
	8.14.1	Mechanical Analysis	0
	8.14.2	Easy FFT	2
9 M	lonito	ring	
			_
9.1		coring Product Information9-2	
	9.1.1 9.1.2	Items That You Can Monitor       9-         Operating Procedures       9-	
9.2	Monit	oring SERVOPACK Status	3
	9.2.1	Servo Drive Status9-	
	9.2.2 9.2.3	Monitoring Status and Operations	
	-	<u> </u>	
9.3		coring Machine Operation Status and Signal Waveforms 9-6	
	9.3.1 9.3.2	Items That You Can Monitor	
	9.3.3	Using a Measuring Instrument	
9.4	Monit	oring Product Life	3
	9.4.1	Items That You Can Monitor	
	9.4.2 9.4.3	Operating Procedure	
9.5		ı Tracing	
0.0	9.5.1	Data for Which Alarm Tracing Is Performed	
	9.5.2	Applicable Tools	
<b>F</b>	ully-C	losed Loop Control	
10.1	Fully-	Closed System 10-2	2
10.2	SERV	OPACK Commissioning Procedure	3
10.3	Paran	neter and Object Settings for Fully-closed Loop Control 10-	5
	10.3.1	Control Block Diagram for Fully-Closed Loop Control	
	10.3.2		
		Setting the Number of External Encoder Scale Pitches	o
		Signals	
		External Absolute Encoder Data Reception Sequence	
		Alarm Detection Settings	
	10.3.8	Analog Monitor Signal Settings	9
	10.3.9	Setting to Use an External Encoder for Speed Feedback	9

10.4	Monitoring an External Encoder	J-10
	10.4.1 Option Module Required for Monitoring	10-10
	10.4.3 Block Diagrams	10-10
S S	afety Functions	
Ш_		
11.1	Introduction to the Safety Functions	11-2
	11.1.1 Safety Functions	
11.2	Hard Wire Base Block (HWBB and SBB)	
	11.2.1 Risk Assessment	.11-5 .11-6
	11.2.5 Detecting Errors in HWBB Signal	.11-7
	11.2.7 Operation without a Host Controller	.11-8
	11.2.9 /BK (Brake Output) Signal	.11-9
	11.2.10 Stopping Methods	
11.3	EDM1 (External Device Monitor)	
	11.3.1 EDM1 Output Signal Specifications	11-11
11.4		
	11.4.1 Connection Example	11-12
11.5		
11.6	Connecting a Safety Function Device	1-15
12) E	therCAT Communications	_
12.1	EtherCAT Slave Information	12-2
12.2	EtherCAT State Machine	12-3
12.3	EtherCAT (CoE) Communications Settings	12-5
	12.3.1 Normal Device Recognition Process at Startup	.12-5 .12-5
12.4	PDO Mappings	12-6
	12.4.1 Setting Procedure for PDO Mappings	.12-7

12.5	Synchronization with Distributed Clocks 12-8
12.6	Emergency Messages 12-11
13 <sup>C</sup>	iA402 Drive Profile
13.1	Device Control
	13.1.1 State Machine Control Commands13-413.1.2 Bits in Statusword (6041 Hex)13-4
	13.1.3 Related Objects
13.2	Modes of Operation
	13.2.1 Related Objects
13.3	Position Control Modes
	13.3.1 Profile Position Mode13-613.3.2 Interpolated Position Mode13-9
	13.3.3 Cyclic Synchronous Position Mode
13.4	Homing
	13.4.1 Related Objects       13-14         13.4.2 Homing Method (6098 Hex)       13-14
13.5	Velocity Control Modes
	13.5.1 Profile Velocity Mode13-1713.5.2 Cyclic Synchronous Velocity Mode13-18
13.6	Torque Control Modes
	13.6.1 Profile Torque Mode       13-19         13.6.2 Cyclic Sync Torque Mode       13-20
13.7	Torque Limits
13.8	Digital I/O Signals
13.9	Touch Probe
	13.9.1 Related Objects13-2313.9.2 Example of Execution Procedure for a Touch Probe13-24
13.10	·
14 o	bject Dictionary
14.1	Object Dictionary List
14.2	General Objects
14.3	PDO Mapping Objects
14.4	Sync Manager Communications Objects 14-13

14.5	Manufacturer-Specific Objects	14-17
14.6	Device Control	14-21
14.7	Profile Position Mode	14-29
14.8	Homing Mode	14-31
14.9	Position Control Function	14-33
14.10	Interpolated Position Mode	14-35
14.11	Cyclic Synchronous Position Mode	14-41
14.12	Profile Velocity/Cyclic Synchronous Velocity Mode	14-42
14.13	Profile Torque/Cyclic Synchronous Torque Mode	14-43
14.14	Torque Limit Function	14-44
14.15	Touch Probe Function	14-45
14.16	Digital Inputs/Outputs	14-47
14.17	Dual Encoder Feedback	14-49
		14-49
	Dual Encoder Feedback	14-49
15 M	aintenance	. <b>15-2</b> 15-2 15-2
15 M	Inspections and Part Replacement  15.1.1 Inspections	. 15-2 15-2 15-2 15-3
15 <sup>M</sup>	Inspections and Part Replacement  15.1.1 Inspections.  15.1.2 Guidelines for Part Replacement  15.1.3 Replacing the Battery.	. 15-2 15-2 15-3 . 15-5 15-11 15-39 15-40 15-41 15-42
15 <sup>M</sup>	Inspections and Part Replacement  15.1.1 Inspections. 15.1.2 Guidelines for Part Replacement 15.1.3 Replacing the Battery.  Alarm Displays.  15.2.1 List of Alarms. 15.2.2 Troubleshooting Alarms 15.2.3 Resetting Alarms 15.2.4 Displaying the Alarm History. 15.2.5 Clearing the Alarm History 15.2.6 Resetting Alarms Detected in Option Modules.	. 15-2 15-2 15-3 . 15-5 15-11 15-39 15-40 15-41 15-42
15.1 15.2	Inspections and Part Replacement  15.1.1 Inspections. 15.1.2 Guidelines for Part Replacement 15.1.3 Replacing the Battery.  Alarm Displays.  15.2.1 List of Alarms. 15.2.2 Troubleshooting Alarms. 15.2.3 Resetting Alarms. 15.2.4 Displaying the Alarm History. 15.2.5 Clearing the Alarm History. 15.2.6 Resetting Alarms Detected in Option Modules. 15.2.7 Resetting Motor Type Alarms.	. 15-2 15-2 15-3 . 15-5 15-11 15-39 15-40 15-41 15-43 15-43

16 P	arameter and Object Lists
16.1	List of Parameters
16.2	16.1.2 List of Parameters       16-3         Object List       16-30
16.3	SDO Abort Code List
16.4	Parameter Recording Table
17 A	ppendices
17.1	Interpreting Panel Displays 17-2
	17.1.1 Interpreting Status Displays17-217.1.2 Alarm and Warning Displays17-217.1.3 Hard Wire Base Block Active Display17-217.1.4 Overtravel Display17-217.1.5 Forced Stop Display17-217.1.6 EtherCAT Communications Indicators17-3
17.2	Corresponding SERVOPACK and SigmaWin+ Function Names17-5
	17.2.1 Corresponding SERVOPACK Utility Function Names
Inde	x
Revi	sion History

# **Basic Information on SERVOPACKs**

This chapter provides information required to select SERVOPACKs, such as SERVOPACK models and combinations with Servomotors.

1.1	The $\Sigma$	-7 Series
1.2	Introd	luction to EtherCAT
	1.2.1 1.2.2 1.2.3	Introduction to CANopen
	1.2.4 1.2.5 1.2.6	CoE Terminology
1.3	Interp	preting the Nameplate1-6
1.4	Part N	Names1-7
1.5	Mode	l Designations1-9
	1.5.1 1.5.2	Interpreting SERVOPACK Model Numbers 1-9 Interpreting Servomotor Model Numbers 1-10
1.6	Combi	nations of SERVOPACKs and Servomotors 1-11
	1.6.1 1.6.2	Combinations of Rotary Servomotors and SERVOPACKs
1.7	Funct	ions

# 1.1

# The $\Sigma$ -7 Series

The  $\Sigma$ -7-series SERVOPACKs are designed for applications that require frequent high-speed and high-precision positioning. The SERVOPACK will make the most of machine performance in the shortest time possible, thus contributing to improving productivity.

These SERVOPACKs support ZONE outputs.

ZONE outputs are used to output signals during preset ranges of positions. You can use the ZONE outputs as triggers for operations related to positioning.

Refer to the following chapter for details on ZONE outputs.

6.14 ZONE Outputs (FT64 Specification) on page 6-58

# 1.2 Introduction to EtherCAT

The CANopen over EtherCAT (CoE) Communications Reference SERVOPACKs implement the CiA 402 CANopen drive profile for EtherCAT communications (real-time Ethernet communications).

Basic position, speed, and torque control are supported along with synchronous position, speed, and torque control. You can select the type of control to match your system from basic positioning to high-speed, high-precision path control.

You can also use EtherCAT communications to control the high-level servo control performance, advanced turning functions, and many actuators of the  $\Sigma$ -7 Series.


### 1.2.1 Introduction to CANopen

The CiA 402 CANopen profile is based on the IEC 61800-7-1, IEC61800-7-201, and IEC 61800-7-301 standards for international standardization of drive control and operation control.

### 1.2.2 CANopen over EtherCAT OSI Model

The OSI model implemented by the SERVOPACKs consists of three layers: the application layer (CANopen), the data link layer (EtherCAT), and the physical layer (Ethernet). The four layers other than the application layer, data link layer, and physical layer are not used. The data link layer is implemented with EtherCAT communications and the application layer is implemented with the DS402 CANopen drive profile.

This manual describes mainly the specifications of the application layer implemented in the SERVOPACKs. For detailed information on the data link layer (EtherCAT), refer to documentation provided by the EtherCAT Technology Group.



The object dictionary in the application layer includes parameters, application data, and PDO mapping information between the master and slaves.

The process data objects (PDOs) consist of the objects in the object dictionary that can be mapped to PDO mappings. The PDO mappings define the structure and contents of the process data.

1.2.3 Sending and Receiving Data in EtherCAT (CoE) Communications

# 1.2.3 Sending and Receiving Data in EtherCAT (CoE) Communications

Objects are used to send and receive data in EtherCAT (CoE) communications.

Reading and writing object data is performed in process data communications (PDO service), which transfers data cyclically, and in mailbox communications (SDO service), which transfers data non-cyclically.

Process data communications are used to read and write PDOs. Mailbox communications (SDO) are used to read and write object dictionary data entries.

### 1.2.4 CoE Terminology

The EtherCAT and CANopen terms that are used in this manual are described in the following table.

CAN in Automation	CiA	A non-profit organization established in 1992 as a joint venture between companies to provide CAN technical information, product information, and marketing information.
Controller Area Network	CAN	Communications protocol for the physical layer and data link layer established for automotive LANs. It was established as an international standard as ISO 11898.
CANopen	CANopen	An upper-layer protocol based on the international CAN standard (EN 50325-4). It consists of profile specifications for the application layer, communications, applications, devices, and interfaces.
CANopen over EtherCAT	CoE	A network that uses Ethernet for the physical layer, EtherCAT for the data link layer, and CANopen for the application layer in a seven-layer OSI reference model.
Distributed Clocks	DC	A clock distribution mechanism that is used to synchronize the EtherCAT slaves with the EtherCAT master.
Electrically Erasable Programmable Read Only Memory	EEPROM	A ROM that can be electrically overwritten.
EtherCAT Slave Controller	ESC	A hardware chip that processes EtherCAT communications (such as loopbacks) and manages the distributed clock.
EtherCAT State Machine	ESM	A state machine in which the state of EtherCAT (the data link layer) changes according to transition conditions.
EtherCAT Technology Group	ETG	An international organization established in 2003 to provide support for developing EtherCAT technologies and to promote the spread of EtherCAT technologies.
Ethernet for Control Automation Technology	EtherCAT	An open network developed by Beckhoff Automation.
Fieldbus Memory Management Unit	FMMU	A unit that manages fieldbus memory.
INIT	INIT	The Init state in the EtherCAT state machine.
OPERATIONAL	OP	The Operational state in the EtherCAT state machine.
Object Dictionary	OD	A group of objects and structure supported by an EtherCAT SERVOPACK.
Process Data Object	PDO	Objects that are sent and received in cyclic communications.
Process Data Object Mapping	PDO mapping	Definitions of the applications objects that are sent with PDOs.
Service Data Object	SDO	Objects that are sent and received in mailbox communications.
PRE-OPERATIONAL	PREOP	The Pre-operational state in the EtherCAT state machine.
Process data	_	The data contained in application objects that are periodically transferred for measurements or controls.

Continued from previous page.

Term	Abbreviation	Description
SyncManager	-	The ESC unit that coordinates data exchange between the master and slaves.
Receive Process Data Object	RXPDO	The process data received by the ESC.
Transmit Process Data Object	TXPDO	The process data sent by the ESC.

# 1.2.5 Data Types

The following table lists the data types and ranges that are used in this manual.

Code	Data Type	Range
SINT	Signed 8-bit integer	-128 to 127
INT	Signed 16-bit integer	-32,768 to 32,767
DINT	Signed 32-bit integer	-2,147,483,648 to 2,147,483,627
USINT	Unsigned 8-bit integer	0 to 255
UINT	Unsigned 16-bit integer	0 to 65,535
UDINT	Unsigned 32-bit integer	0 to 4,294,967,295
STRING	Character string	-

# 1.2.6 Data Ranges


The following table lists the data units and notations that are used in this manual.

Notation	Description	
Pos. unit	The user-defined position reference unit that is set in <i>position user unit</i> (2701 hex).  1 [Pos. unit] = 2701: 01 hex/2701: 02 hex [inc]	
Vel. unit	The user-defined speed reference unit that is set in <i>velocity user unit</i> (2702 hex). 1 [Vel. unit] = 2702: 01 hex/2702: 02 hex [inc/s]	
Acc. unit	The user-defined acceleration reference unit that is set in <i>acceleration user unit</i> (2703 hex). 1 [Acc. unit] = 2703: 01 hex/2703: 02 hex x 10 <sup>4</sup> [inc/s <sup>2</sup> ]	
Trq. unit	The user-defined torque reference unit that is set in <i>torque user unit</i> (2704 hex). 1 [Trq. unit] = 2704: 01 hex/2704: 02 hex [%]	
inc	This is the encoder pulse unit. For a 24-bit encoder, the resolution is 16,777,216 × Pn210/Pn20E [inc] per rotation.	


# 1.3

# Interpreting the Nameplate

The following basic information is provided on the nameplate.



# 1.4 Part Names



No.	Name	Description	Reference
①	Front Cover	-	_
2	Model	The model of the SERVOPACK.	page 1-9
3	QR Code	The QR code that is used by the MechatroCloud service.	_
4	CHARGE	Lit while the main circuit power is being supplied.  Note: Even if you turn OFF the main circuit power supply, this indicator will be lit as long as the internal capacitor remains charged. Do not touch the main circuit or motor terminals while this indicator is lit. Doing so may result in electric shock.	-
(5)	Main Circuit Terminals	The terminals depend on the main circuit power supply input specifications of the SERVOPACK.	page 4-11
6	DC Power Supply Terminals	-	page 4-11
7	Control Power Supply Terminals	The connection terminals for the control power supply.	page 4-11
8	Servomotor Terminals (U, V, and W) and Ground Terminal (PE)	The connection terminals for the Servomotor Main Circuit Cable (power line).	page 4-19
9	Dynamic Brake Terminals	The connection terminals for a Dynamic Brake Resistor.	page 4-37
100	Ground Terminal ()	The ground terminals to prevent electric shock. Always connect this terminal.	-
11)	EtherCAT Communications Connectors (Input: CN6A, Output: CN6B)	Connect to EtherCAT devices.	page 4-39
12	I/O Signal Connector (CN1)	Connects to sequence I/O signals.	page 4-28
13	Safety Connector (CN8)	Connects to a safety function device.	page 4-35
14)	Encoder Connector (CN2)	<ul> <li>Rotary Servomotor: Connects to the encoder in the Servomotor.</li> <li>Linear Servomotor: Connects to a Serial Converter Unit or linear encoder.</li> </ul>	page 4-19
15	Computer Connector (CN7)	A USB connector to connect a computer.	page 4-41
16	Safety Option Module Connector	Connects to a Safety Option Module.	_
17)	Feedback Option Module Connector	Connects to a Feedback Option Module.	
18	Communications Status Indicators	Indicate the status of EtherCAT communications.	-

Continued from previous page.

No.	Name	Description	Reference
19	Serial Communications Connector (CN3)	Connects to the Digital Operator.	page 4-41
20	Serial Number	-	_
21)	DIP Switch (S3)	Not used.	
22	EtherCAT secondary address (S1 and S2)	Use these switches to set the device ID and address.	
23)	PWR	Lights when the control power is being supplied.	_
24)	CN	Not used.	_
25)	L1 and L2	Not used.	_
26	Analog Monitor Connector (CN5)	You can use a special cable (peripheral device) to monitor the motor speed, torque reference, or other values.	page 4-41
27)	Panel Display	Displays the servo status with a seven-segment display.	_
28	Servomotor Brake Power Supply Terminals (CN117)*	Connect to the power supply for the Servomotor brake.	_


<sup>\*</sup> SERVOPACKs without built-in Servomotor brake control do not have these terminals.

# 1.5 Model Designations

# 1.5.1 Interpreting SERVOPACK Model Numbers



1st+2nd+3rd digits Maximum Applicable Motor Capacity		
Voltage	Code	Specification
	1R9	0.5 kW
	3R5	1.0 kW
	5R4	1.5 kW
	8R4	2.0 kW
Three-	120	3.0 kW
Phase, 400 VAC	170	5.0 kW
	210	6.0 kW
	260	7.5 kW
	280	11.0 kW
	370	15.0 kW



Code	Specification	Applicable Models
000	Without options	All models
026	Built-in Servomotor brake control	All models

11th+	12th+13th digits FT/EX Specification
Code	Specification
F64	ZONE outputs

<sup>\*</sup> The same SERVOPACKs are used for both Rotary Servomotors and Linear Servomotors.

1.5.2 Interpreting Servomotor Model Numbers

### 1.5.2 Interpreting Servomotor Model Numbers

This section outlines the model numbers of  $\Sigma$ -7-series Servomotors. Refer to the relevant manual in the following list for details.

- □ Σ-7-Series Rotary Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 86)
- Σ-7-Series Linear Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 81)

### **Rotary Servomotors**



Series	Σ-7-Series Servomotors
Code	Specifications
SGM7J	Medium inertia, high speed
SGM7A	Low inertia, high speed
SGM7G	Medium inertia, low speed, high torque
SGIVI7G	Medium inertia, high speed, high torque



### **Linear Servomotors**



1st digit Servomotor Type

Code	Specification
F	Models with F-type iron core
Т	Models with T-type iron core

Code	Specification
W	Moving Coil
W2	Moving Coil
М	Magnetic Way
M2	

3rd digit on

The specifications for the 3rd digit on depend on the Servomotor type.

1.6.1 Combinations of Rotary Servomotors and SERVOPACKs

# 1.6 Combinations of SERVOPACKs and Servomotors

# 1.6.1 Combinations of Rotary Servomotors and SERVOPACKs

Dotony Company	tor Madal	Canacity	SERVOPACK Model		
Rotary Servomo	tor Model	Capacity	SGD7S-		
SGM7J Models	SGM7J-02D□F	200 W	1000		
(Medium Inertia,	SGM7J-04D□F	400 W	1R9D		
High Speed), Rated motor speed:	SGM7J-08D□F	750 W	3R5D		
3,000 min <sup>-1</sup>	SGM7J-15D□F	1.5 kW	5R4D		
	SGM7A-02D□F	200 W	1000		
	SGM7A-04D□F	400 W	1R9D		
	SGM7A-08D□F	750 W	3R5D		
SGM7A Models	SGM7A-10D□F	1.0 kW	5R4D		
(Low Inertia,	SGM7A-15D□F	1.5 kW	3N4D		
High Speed),	SGM7A-20D□F	2.0 kW	8R4D		
Rated motor speed:	SGM7A-25D□F	2.5 kW	120D		
3,000 min <sup>-1</sup>	SGM7A-30D□F	3.0 kW	1200		
	SGM7A-40D□F	4.0 kW	170D		
	SGM7A-50D□F	5.0 kW	לטווי		
	SGM7A-70D□F	7.0 kW	260D		
	SGM7G-05D□F	450 W	1R9D		
	SGM7G-09D□F	850 W	3R5D		
SGM7G Models	SGM7G-13D□F	1.3 kW	5R4D		
Standard Models	SGM7G-20D□F	1.8 kW	8R4D		
(Medium Inertia, Low Speed,	SGM7G-30D□F	2.9 kW	120D		
High Torque),	SGM7G-44D□F	4.4 kW	170D		
Rated motor speed:	SGM7G-55D□F	5.5 kW	210D		
1,500 min <sup>-1</sup>	SGM7G-75D□F	7.5 kW	260D		
	SGM7G-1AD□F	11.0 kW	280D		
	SGM7G-1ED□F	15.0 kW	370D		
SGM7G Models	SGM7G-05D□R	450 W	3R5D		
High-speed Models	SGM7G-09D□R	850 W	5R4D		
(Medium Inertia, High	SGM7G-13D□R	1.3 kW	8R4D		
Speed, High Torque)	SGM7G-20D□R	1.8 kW	120D		
Rated motor speed: 1,500 min <sup>-1</sup>	SGM7G-30D□R	2.9 kW	170D		
i ,500 min '	SGM7G-44D□R	4.4 kW	210D		

# 1.6.2 Combinations of Linear Servomotors and SERVOPACKs

Linear Servomotor Model		Rated Torque	Instantaneous	SERVOPACK Model
Linear Serv	omotor Model	[N]	Maximum Torque [N]	SGD7S-
	SGLFW-35D120A	80	220	1R9D
	SGLFW-35D230A	160	440	1R9D
	SGLFW-50D200B	280	600	3R5D
	SGLFW-50D380B	560	1200	5R4D
	SGLFW-1ZD200B	300	1200	3N4D
	SGLFW-1ZD380B	1120	2400	120D
	SGLFW2-30D070A	45	135	1R9D
SGLF (Models with	SGLFW2-30D120A	90	270	1R9D
F-type Iron Cores)	SGLFW2-30D230A	180	540	1R9D
r type non cores,	SGLFW2-45D200A	280	840	3R5D
	SGLFW2-45D380A	560	1680	8R4D
	SGLFW2-90D200A	300	1000	5R4D
	SGLFW2-90D380A	1120	3360	120D
	SGLFW2-90D560A	1680	5040	170D
	SGLFW2-1DD380A	1680	5040	170D
	SGLFW2-1DD560A	2520	7560	260D
	SGLTW-35D170H	300	600	3R5D
	SGLTW-35D320H	600	1200	8R4D
	SGLTW-40D400B	670	2600	120D
SGLT (Madala with	SGLTW-40D600B	1000	4000	170D
(Models with T-type Iron Cores)	SGLTW-50D170H	450	900	3R5D
, po o o o o o	SGLTW-50D320H	900	1800	8R4D
	SGLTW-80D400B	1300	5000	170D
	SGLTW-80D600B	2000	7500	260D

# 1.7 Functions

This section lists the functions provided by SERVOPACKs. Refer to the reference pages for details on the functions.

#### · Functions Related to the Machine

Function	
Power Supply Type Settings for the Main Circuit and Control Circuit	page 5-12
Automatic Detection of Connected Motor	page 5-13
Motor Direction Setting	page 5-14
Linear Encoder Pitch Setting	page 5-15
Writing Linear Servomotor Parameters	page 5-16
Selecting the Phase Sequence for a Linear Servomotor	page 5-20
Polarity Sensor Setting	page 5-22
Polarity Detection	page 5-23
Overtravel Function and Settings	page 5-26
Holding Brake	page 5-32
Motor Stopping Methods for Servo OFF and Alarms	page 5-37
Resetting the Absolute Encoder	page 5-49
Setting the Origin of the Absolute Encoder	page 5-52
Setting the Regenerative Resistor Capacity	page 5-55
Operation for Momentary Power Interruptions	page 6-14
SEMI F47 Function	page 6-15
Setting the Motor Maximum Speed	page 6-17
Software Limits	page 6-25
Multiturn Limit Setting	page 6-36
Adjustment of Motor Current Detection Signal Offset	page 6-50
Forcing the Motor to Stop	page 6-55
Speed Ripple Compensation	page 8-59
Current Control Mode Selection	page 8-69
Current Gain Level Setting	page 8-70
Speed Detection Method Selection	page 8-70
Fully-Closed Loop Control	page 10-1
Safety Functions	page 11-1
Touch Probe	page 13-23

### · Functions Related to the Host Controller

Function	Reference
Electronic Gear Settings	page 5-42
I/O Signal Allocations	page 6-4
Servo Alarm (ALM) Signal	page 6-7
Warning Output (/WARN) Signal	page 6-7
Rotation Detection (/TGON) Signal	page 6-8
Servo Ready (/S-RYD) Signal	page 6-8
Speed Coincidence Detection (/V-CMP) Signal	page 6-9
Positioning Completion (/COIN) Signal	page 6-10
Near (/NEAR) Signal	page 6-11
Speed Limit during Torque Control	page 6-12

### Continued from previous page.

Function	Reference
Speed Limit Detection (/VLT) Signal	page 6-12
Encoder Divided Pulse Output	page 6-18
Selecting Torque Limits	page 6-26
Vibration Detection Level Initialization	page 6-46
Alarm Reset	page 15-39
Replacing the Battery	page 15-3
Setting the Position Deviation Overflow Alarm Level	page 8-8

### • Functions to Achieve Optimum Motions

Function	Reference
Tuning-less Function	page 8-12
Automatic Adjustment without a Host Reference	page 8-23
Automatic Adjustment with a Host Reference	page 8-34
Custom Adjustment	page 8-41
Anti-Resonance Control Adjustment	page 8-50
Vibration Suppression	page 8-55
Gain Selection	page 8-65
Friction Compensation	page 8-68
Backlash Compensation	page 8-71
Model Following Control	page 8-83
Compatible Adjustment Functions	page 8-86
Mechanical Analysis	page 8-90
Easy FFT	page 8-92

### • Functions for Trial Operation during Setup

Function	Reference
Software Reset	page 6-44
Trial Operation of Servomotor without a Load	page 7-7
Program Jogging	page 7-13
Origin Search	page 7-19
Test without a Motor	page 7-21
Monitoring Machine Operation Status and Signal Waveforms	page 9-6

### • Functions for Inspection and Maintenance

Function	Reference
Write Prohibition Setting for Parameters	page 5-7
Initializing Parameter Settings	page 5-10
Automatic Detection of Connected Motor	page 5-13
Monitoring Product Information	page 9-2
Monitoring Product Life	page 9-2
Alarm History Display	page 15-40
Alarm Tracing	page 9-16

# Selecting a SERVOPACK

2

This chapter provides information required to select SERVOPACKs, such as specifications, block diagrams, dimensional drawings, and connection examples.

2.1	Rating	gs and Specifications2-2
	2.1.1 2.1.2 2.1.3	Ratings
2.2	BIOCK	Diagrams 2-8
	2.2.1	SERVOPACKs without Built-in Servomotor Brake Control
2.3	Evtor	nal Dimensions
2.0	LATEIT	lai Dillielisiolis
	2.3.1	Front Cover Dimensions and Connector Specifications
2.4	Evamples (	of Standard Connections between SERVOPACKs and Peripheral Devices2-18
Z. <del>4</del>	LAGITIPIES (	of oldindard dofineducing between our workdows and religheral bevices2-10

### 2.1.1 Ratings

# 2.1

# **Ratings and Specifications**

This section gives the ratings and specifications of SERVOPACKs.

# 2.1.1 Ratings

# Three-Phase, 400 VAC

Model SGD7S-			1R9D	3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Maximum Applicable Motor Capacity [kW]		0.5	1	1.5	2	3	5	6	7.5	11	15	
Continuous (	Output Curre	nt [Arms]	1.9	3.5	5.4	8.4	11.9	16	20.8	25.7	28.1	37.2
Instantaneou rent [Arms]	ıs Maximum	Output Cur-	5.5	8.5	14	21	28	42	55	65	70	85
Main Circuit	Power Supp	oly		Thre	e-phase	e, 380 \		480 VA /60 Hz	AC, -15	% to +	10%,	
	Input Curre	nt [Arms]*	1.4	2.9	4.3	5.8	8.6	14.5	17.4	21.7	31.8	43.4
Control	Power Supp	oly					24 VDC	±15%	)			
Power Sup- ply	Input Curre	nt [Arms]*		1.2					1.4		1.5	
Power Supp	ly Capacity [l	«VA]*	1.1	2.3	3.5	4.5	7.1	11.7	12.4	14.4	21.9	30.6
	Main Circuit Power Loss [W]		19.4	30.3	62.8	90.1	137.7	188.7	188.4	228.5	278.2	389.8
Power Loss*	Control Circu [W]	21				22	28		3	32		
L055.	Built-in Regenerative Resistor Power Loss [W]		14	14	28	28	28	36	(18	0)*	(24	0)*
	Total Power	Loss [W]	54.4	65.3	111.8	139.1	186.7	246.7	216.4	256.5	310.2	389.8
5	Built-In Regenera-	Resistance $[\Omega]$	75	75	75	43	43	27		-	-	
Regenera- tive Resis- tor	tive Resis- tor	Capacity [W]	70	70	140	140	140	180	-			
	Minimum Allowable External Resistance [Ω]		75	75	75	43	43	27	18	18	14.25	14.25
Overvoltage	Category		III									

<sup>\*</sup> This is the net value at the rated load.

### 540 VDC

Model SGD7S-			3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Maximum Applicable Motor Capacity [kW]		0.5	1	1.5	2	3	5	6	7.5	11	15
Continuous	Output Current [Arms]	1.9	3.5	5.4	8.4	11.9	16	20.8	25.7	28.1	37.2
Instantaneou rent [Arms]	us Maximum Output Cur-	5.5	8.5	14	21	28	42	55	65	70	85
Main Cir-	Power Supply		•	513	VDC to	648 VI	DC, -15	% to +	10%	•	
cuit	Input Current [Arms]*	2	3.3	5.5	6.8	11	18	19.6	26.2	38.3	47.6
Control	Power Supply	24 VDC ±15%									
Power Supply	Input Current [Arms]*	1.2 1.4						1.5			
Power Supp	ly Capacity [kVA]*	1.1	2.3	3.5	4.5	7.1	11.7	12.4	14.4	21.9	30.6
Power Loss*	Main Circuit Power Loss [W]	16.4	24.4	48.5	73.7	110.4	144.5	188.4	228.5	278.2	389.8
	Control Circuit Power Loss [W]	21 22 28			8	3	2				
	Total Power Loss [W]	37.4	45.4	69.5	94.7	131.4	166.5	216.4	228.5	310.2	389.8
Overvoltage Category		III									

<sup>\*</sup> This is the net value at the rated load.


### 2.1.2 SERVOPACK Overload Protection Characteristics

The overload detection level is set for hot start conditions with a SERVOPACK surrounding air temperature of 55°C.

An overload alarm (A.710 or A.720) will occur if overload operation that exceeds the overload protection characteristics shown in the following diagram (i.e., operation on the right side of the applicable line) is performed.

The actual overload detection level will be the detection level of the connected SERVOPACK or Servomotor that has the lower overload protection characteristics.

In most cases, that will be the overload protection characteristics of the Servomotor.



Note: The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher.

For a Yaskawa-specified combination of SERVOPACK and Servomotor, maintain the effective torque within the continuous duty zone of the torque-motor speed characteristic of the Servomotor.

# 2.1.3 Specifications

Item		Specification					
Control Meth	nod	IGBT-based PWM control, sine wave current drive					
	With Rotary Servomotor	Serial encoder: 24 bits (incremental encoder/absolute encoder)					
Feedback	With Linear Servomotor	<ul> <li>Absolute linear encoder (The signal resolution depends on the absolute linear encoder.)</li> <li>Incremental linear encoder (The signal resolution depends on the incremental linear encoder or Serial Converter Unit.)</li> </ul>					
	Surrounding Air Temperature*1	-5°C to 55°C However, the range for the SGD7S-370D is -5°C to 40°C.					
	Storage Temperature	-20°C to 85°C					
	Surrounding Air Humidity	95% relative humidity max. (with no freezing or condensation)					
	Storage Humidity	95% relative humidity max. (with no freezing or condensation)					
	Vibration Resistance	$4.9 \text{ m/s}^2$					
Environmen	Shock Resistance	19.6 m/s <sup>2</sup>					
tal Condi- tions	Degree of Protection	IP10					
lions	Pollution Degree	<ul> <li>Must be no corrosive or flammable gases.</li> <li>Must be no exposure to water, oil, or chemicals.</li> <li>Must be no dust, salts, or iron dust.</li> </ul>					
	Altitude	1,000 m or less.					
	Others	Do not use the SERVOPACK in the following locations: Locations subject to static electricity noise, strong electromagnetic/magnetic fields, or radioactivity					
Applicable S	tandards	Refer to the following section for details.  © Compliance with UL Standards, EU Directives, and Other Safety Standards on page xxii					
Mounting		Base-mounted					
	Speed Control Range	1:5000 (At the rated torque, the lower limit of the speed control range must not cause the Servomotor to stop.)					
		±0.01% of rated speed max. (for a load fluctuation of 0% to 100%)					
	Coefficient of Speed	0% of rated speed max. (for a voltage fluctuation of ±10%)					
Perfor- mance	Fluctuation*2	±0.1% of rated speed max. (for a temperature fluctuation of 25°C ±25°C)					
	Torque Control Precision (Repeatability)	±1%					
	Soft Start Time Setting	0 s to 10 s (Can be set separately for acceleration and deceleration.					

Continued from previous page.

Item			Specification Specification				
	Encoder Divided Pulse Output		Phase A, phase B, phase C: Line-driver output Number of divided output pulses: Any setting is allowed.				
	Linear Servomotor Overheat Protection Signal Input		Number of input points: 1 Input voltage range: 0 V to +5 V				
			Allowable voltage range: 24 VDC ±20%  Number of input points: 7				
	Sequence Input Signals	Input Signals That Can Be Allo- cated	Input method: Sink inputs or source inputs Input Signals  • P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) signals  • /Probe1 (Probe 1 Latch Input) signal  • /Probe2 (Probe 2 Latch Input) signal  • /Home (Home Switch Input) signal  • /P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals  • /SI0 and /SI3 (General-Purpose Input) signals  A signal can be allocated and the positive and negative logic can be changed.				
I/O Signals		Fixed Output	Allowable voltage range: 5 VDC to 30 VDC  Number of output points: 1  Output signal: ALM (Servo Alarm) signal				
	Sequence Output Signals	Output Signals That Can Be Allo- cated	Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5 (A photocoupler output (isolated) is used.)  Output Signals  • /COIN (Positioning Completion) signal  • /V-CMP (Speed Coincidence Detection) signal  • /TGON (Rotation Detection) signal  • /S-RDY (Servo Ready) signal  • /CLT (Torque Limit Detection) signal  • /VLT (Speed Limit Detection) signal  • /WLT (Speed Limit Detection) signal  • /WARN (Warning) signal  • /WARN (Warning) signal  • /ZONEO (ZONE Signal 1 Output) signal  • /ZONE1 (ZONE Signal 2 Output) signal  • /ZONE2 (ZONE Signal 3 Output) signal  • /ZONE3 (ZONE Signal 4 Output) signal  • /ZONE3 (ZONE Output) signal  • /nZONE (nZONE Output) signal  A signal can be allocated and the positive and negative logic can be changed.				
	RS-422A Communi- cations (CN502)	Inter- faces	Digital Operator (JUSP-OP05A-1-E).				
		1:N Commu- nications	Up to N = 15 stations possible for RS-422A port				
Communi- cations		Axis Address Setting	Set with parameters.				
	USB Com-	Interface	Personal computer (with SigmaWin+) The software version of the SigmaWin+ must be version 7.11 or higher.				
	munica- tions (CN7)	Communications Standard	Conforms to USB2.0 standard (12 Mbps).				

### 2.1.3 Specifications

Continued from previous page.

		Continued from previous page.					
Item		Specification					
Displays/Inc		CHARGE, PWR, RUN, ERR, and L/A (A and B) indicators, and one-digit seven-segment display					
EtherCAT Communications Setting Switches		EtherCAT secondary address (S1 and S2), 16 positions					
	Applicable Communications Standards	IEC 61158 Type 12, IEC 61800-7 CiA402 Drive Profile					
	Physical Layer	100BASE-TX (IEEE 802.3)					
	Communications Connectors	CN6A (RJ45): EtherCAT signal input connector CN6B (RJ45): EtherCAT signal output connector					
	Cable	Category 5, 4 shielded twisted pairs					
	Cabic	* The cable is automatically detected with AUTO MDIX.					
	Sync Manager	SM0: Mailbox output, SM1: Mailbox input, SM2: Process data output and SM3: Process data input					
EtherCAT	FMMU	FMMU 0: Mapped in process data output (RxPDO) area. FMMU 1: Mapped in process data input (TxPDO) area. FMMU 2: Mapped to mailbox status.					
Communi- cations	EtherCAT Commands (Data Link Layer)	APRD, FPRD, BRD, LRD, APWR, FPWR, BWR, LWR, ARMW, and FRMW (APRW, FPRW, BRW, and LRW commands are not supported.)					
	Process Data	Assignments can be changed with PDO mapping.					
	Mailbox (CoE)	Emergency messages, SDO requests, SDO responses, and SDO information (TxPDO/RxPDO and remote TxPDO/RxPDO are not supported.)					
	Distributed Clocks	Free-Run Mode and DC Mode (Can be switched.) Applicable DC cycles: 125 µs to 4 ms in 125-µs increments					
	Slave Information Interface	256 bytes (read-only)					
	Indicators	EtherCAT communications in progress: Link/Activity x 2 EtherCAT communications status: RUN x 1 EtherCAT error status: ERR x 1					
CiA402 Drive Profile		Homing Mode Profile Position Mode Interpolated Position Mode Profile Velocity Mode Profile Torque Mode Cyclic Synchronous Position Mode Cyclic Synchronous Velocity Mode Cyclic Synchronous Torque Mode Touch Probe Function Torque Limit Function					
Analog Monitor (CN5)		Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ)					
Dynamic Brake (DB)*3		Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.					
Regenerative Processing		Built-in Refer to the catalog for details.					
Overtravel (OT) Prevention		Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal					
Protective Functions		Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.					
Utility Functions		Gain adjustment, alarm history, jogging, origin search, etc.					
		Continued on next nage					

#### 2.1.3 Specifications

#### Continued from previous page.

Item		Specification				
Safety Functions	Inputs	/HWBB1 and /HWBB2: Base block signals for Power Modules				
	Output	EDM1: Monitors the status of built-in safety circuit (fixed output).				
	Applicable Standards*4	ISO13849-1 PLe (category 3), IEC61508 SIL3				
Applicable Option Modules		Fully-closed Modules				

<sup>\*1.</sup> If you combine a Σ-7-Series SERVOPACK with a Σ-V-Series Option Module, the surrounding air temperature specification of the Σ-V-Series SERVOPACKs must be used, i.e., 0°C to 55°C. Also, the applicable surrounding range cannot be increased by derating.

\*2. The coefficient of speed fluctuation for load fluctuation is defined as follows:

Coefficient of speed fluctuation =  $\frac{\text{No-load motor speed - Total-load motor speed}}{\text{Rated motor speed}} \times 100\%$ 


- \*3. The SGD7S-210D, -260D, -280D, and -370D do not have a dynamic brake (DB). If a dynamic brake is necessary, create an external dynamic brake circuit.
- \*4. Always perform risk assessment for the system and confirm that the safety requirements are met.

# 2.2 Block Diagrams

This section provides a block diagram of the interior of the SERVOPACKs.


# 2.2.1 SERVOPACKs without Built-in Servomotor Brake Control

SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D



<sup>\*</sup> If using these terminals, contact your YASKAWA representative.


### SGD7S-210D and -260D



<sup>\*</sup> If using these terminals, contact your YASKAWA representative.

### 2.2.1 SERVOPACKs without Built-in Servomotor Brake Control


### SGD7S-280D and -370D



<sup>\*</sup> If using these terminals, contact your YASKAWA representative.

# 2.2.2 SERVOPACKs with Built-in Servomotor Brake Control


### SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D



<sup>\*</sup> If using these terminals, contact your YASKAWA representative.


### 2.2.2 SERVOPACKs with Built-in Servomotor Brake Control

### SGD7S-210D and -260D



<sup>\*</sup> If using these terminals, contact your YASKAWA representative.

### SGD7S-280D and -370D




 $<sup>\</sup>boldsymbol{*}$  If using these terminals, contact your YASKAWA representative.

# 2.3 External Dimensions


# 2.3.1 Front Cover Dimensions and Connector Specifications

The front cover dimensions and panel connector section are the same for all models. Refer to the following figures and table.

#### · Front Cover Dimensions and Connectors



Unit: mm



### • Connector Specifications

Connector No.	Connector Model	Number of Pins	Manufacturer	SERVOPACK Model
CN1	DMC 1.5/15-G1F-3.5-LR-BK	30	Phoenix Contact	All models
CN2	3E106-0220KV	6	3M Japan Limited	All models
CN3	HDR-EC14LFDTN-SLD+	14	Honda Tsushin Kogyo Co., Ltd.	All models
CN6A/B	1-1734579-4	8	Tyco Electronics Japan G.K.	All models
CN7	2172034-1	5	Tyco Electronics Japan G.K.	All models
CN8	1903815-1	8	Tyco Electronics Japan G.K.	All models

### 2.3.1 Front Cover Dimensions and Connector Specifications

Continued from previous page.

Connector No.	Connector Model	Number of Pins	Manufacturer	SERVOPACK Model
CN101	BLZ 7.62HP/08/180LR SN BK BX PRT	8	Weidmüller Interface	SGD7S-1R9D to -170D
CIVIOI	BUZ 10.16HP/07/180F AG BK BX LPR	O	GmbH & Co. KG	SGD7S-210D to -370D
CN102	BLZ 7.62IT/04/180MF4 SN BK BX PRT	4	Weidmüller Interface	SGD7S-1R9D to -170D
CIN 102	BUZ 10.16IT/04/180MF4 AG BK BX LPR	4	GmbH & Co. KG	SGD7S-210D to -370D
CN103*	BVZ 7.62IT/04/180MF3 SN BK BX PRT	4	Weidmüller Interface	SGD7S-1R9D to -170D
	BUZ 10.16IT/04/180MF3 AG BK BX LPR	4	GmbH & Co. KG	SGD7S-210D to -370D
CN115	BLZ 7.62IT/03/180MF2 SN BK BX PRT	3	Weidmüller Interface GmbH & Co. KG	SGD7S-1R9D to -170D
	None	-	_	SGD7S-210D to -370D
CN201	BLF 5.08HC/04/180LR SN OR BX SO	4	Weidmüller Interface GmbH & Co. KG	All models


<sup>\*</sup> If using these terminals, contact your YASKAWA representative.

Note: The above connectors or their equivalents are used for the SERVOPACKs.

### 2.3.2 SERVOPACK External Dimensions


### **Base-mounted SERVOPACKs**

• Three-Phase, 400 VAC: SGD7S-1R9D, -3R5D, -5R4D, -8R4D, and -120D





Approx. mass: SGD7S-1R9D, -3R5D, or -5R4D: 3.4 kg SGD7S-8R4D or -120D: 3.7 kg Unit: mm

• Three-Phase, 400 VAC: SGD7S-170D




### • Three-Phase, 400 VAC: SGD7S-210D and -260D







Approx. mass: 7.0 kg Unit: mm

### • Three-Phase, 400 VAC: SGD7S-280D and -370D








Approx. mass: 13.5 kg Unit: mm

# Examples of Standard Connections between SERVOPACKs and Peripheral Devices

#### Rotary Servomotors




<sup>\*</sup> The power supply for the holding brake is not provided by Yaskawa. Select a power supply based on the holding brake specifications.

If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector.

If the power supply is shared, the I/O signals may malfunction.

#### · Linear Servomotors



# SERVOPACK Installation

3

This chapter provides information on installing SERVO-PACKs in the required locations.

3.1	Installation Precautions							
3.2	Mounting Types and Orientation 3-3							
3.3	Mounting Hole Dimensions3-4							
3.4	Mounting Interval3-5							
	3.4.1 Installing One SERVOPACK in a Control Panel 3-5 3.4.2 Installing More Than One SERVOPACK in a Control Panel							
3.5	Monitoring the Installation Environment3-6							
3.5	Worldoning the installation Environment 3-0							
3.6	EMC Installation Conditions3-7							

# 3.1

# **Installation Precautions**

Refer to the following section for the ambient installation conditions. *2.1.3 Specifications* on page 2-4

#### ■ Installation Near Sources of Heat

Implement measures to prevent temperature increases caused by radiant or convection heat from heat sources so that the ambient temperature of the SERVOPACK meets the ambient conditions.

#### ■ Installation Near Sources of Vibration

Install a vibration absorber on the installation surface of the SERVOPACK so that the SERVOPACK will not be subjected to vibration.

### ■ Other Precautions


Do not install the SERVOPACK in a location subject to high temperatures, high humidity, water drops, cutting oil, excessive dust, excessive dirt, excessive iron powder, corrosive gasses, or radioactivity.

# 3.2 Mounting Types and Orientation

The SERVOPACKs are based mounted. Mount the SERVOPACK vertically, as shown in the following figures.

Also, mount the SERVOPACK so that the front panel is facing toward the operator.

Note: Prepare four mounting holes for the SERVOPACK and mount it securely in the mounting holes. (The number of mounting holes depends on the capacity of the SERVOPACK.)




# 3.3

# **Mounting Hole Dimensions**

Use mounting holes to securely mount the SERVOPACK to the mounting surface.

Note: To mount the SERVOPACK, you will need to prepare a screwdriver that is longer than the depth of the SER-VOPACK.




### ♦ Mounting Hole Dimensions

SERVOPACK Model		Dimensions (mm)							Screw	Number	
		Α	В	С	D	Е	F	G	Н	Size	of Screws
SGD7S-	1R9D, 3R5D, 5R4D, 8R4D, 120D	330	7.5	315 ±0.5	80	10	60 ±0.5	10	60 ±0.5	M5	4
	170D	330	7.5	315 ±0.5	100	10	80 ±0.5	10	80 ±0.5	M5	4
	210D, 260D	380	7.5	365±0.5	100	10	80±0.5	10	80±0.5	M5	4
	280D, 370D	380	6.5	367±0.5	180	12.5	155±0.5	12.5	155±0.5	M6	4

# 3.4 Mounting Interval

# 3.4.1 Installing One SERVOPACK in a Control Panel

Provide the following spaces around the SERVOPACK.




<sup>\*</sup> For this dimension, ignore items protruding from the main body of the SERVOPACK.

# 3.4.2 Installing More Than One SERVOPACK in a Control Panel

Provide the following spaces around the SERVOPACK, and install a cooling fan in the control panel.



Install cooling fans above the SERVOPACKs so that hot spots do not occur around the SERVOPACKs.



SERVOPACK model		Cooling Fan Installation Conditions
		10 mm above SERVOPACK's Top Surface
SGD7S-	1R9D, 3R5D, 5R4D, 8R4D, 120D, 170D, 210D, 260D, 280D, 370D	Air speed: 1.0 m/s min.

# 3.5

# Monitoring the Installation Environment

You can use the SERVOPACK Installation Environment Monitor parameter to check the operating conditions of the SERVOPACK in the installation environment.

You can check the SERVOPACK installation environment monitor with either of the following methods.

- Using the SigmaWin+: Life Monitor Installation Environment Monitor SERVOPACK
- Digital Operator: Un025 (Installation Environment Monitor [%])

Implement one or more of the following actions if the monitor value exceeds 100%.

- Lower the surrounding temperature.
- · Decrease the load.

Information

The value of the SERVOPACK Installation Environment Monitor parameter will increase by about 10% for each 10°C increase in the ambient temperature.



Always observe the surrounding air temperature given in the SERVOPACK environment conditions. Even if the monitor value is 100% or lower, you cannot use a SERVOPACK in a location that exceeds the specified surrounding air temperature.


# **EMC Installation Conditions**

This section gives the installation conditions that were used for EMC certification testing.

The EMC installation conditions that are given here are the conditions that were used to pass testing criteria at Yaskawa. The EMC level may change under other conditions, such as the actual installation structure and wiring conditions. These Yaskawa products are designed to be built into equipment. Therefore, you must implement EMC measures and confirm compliance for the final equipment.

The applicable standards are EN 55011 group 1 class A, EN 61000-6-2, EN 61000-6-4, and EN 61800-3 (category C2, second environment).

• Three-Phase, 400 VAC



Symbol	Cable Name	Specification
1	I/O Signal Cable	Shielded cable
2	Safety Function Device Cable	Shielded cable
3	Servomotor Main Circuit Cable	Shielded cable
4	Encoder Cable	Shielded cable
(5)	Main Circuit Power Supply Cable	Shielded cable
6	EtherCAT Communications Cable	Shielded cable

# Wiring and Connecting SERVOPACKs

4

This chapter provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.

4.1	Wiring	g and Connecting SERVOPACKs4-3
	4.1.1 4.1.2 4.1.3	General Precautions4-3Countermeasures against Noise4-5Grounding4-8
4.2	Basic	Wiring Diagrams4-9
4.3	Wiring	the Power Supply to the SERVOPACK 4-11
	4.3.1 4.3.2 4.3.3 4.3.4 4.3.5 4.3.6	Terminal Symbols and Terminal Names
4.4	Wiring	g Servomotors 4-19
	4.4.1 4.4.2 4.4.3 4.4.4	Terminal Symbols and Terminal Names 4-19 Pin Arrangement of Encoder Connector (CN2) . 4-19 Wiring the SERVOPACK to the Encoder 4-20 Wiring the SERVOPACK to the Holding Brake 4-25
4.5	Conne	ecting I/O Signals4-28
	4.5.1 4.5.2 4.5.3 4.5.4	I/O Signal Connector (CN1) Names and Functions

4.6	Connecting Safety Function Signals 4-35		
	4.6.1 4.6.2	Pin Arrangement of Safety Function Signals (CN8) 4-35 I/O Circuits	
4.7	Conne	ecting Dynamic Brake Resistors 4-37	
	4.7.1 4.7.2	Terminal Symbols and Terminal Names	
4.8	Conne	ecting EtherCAT Communications Cables 4-39	
	4.8.1 4.8.2	EtherCAT Connectors (RJ45)	
4.9	Conn	ecting the Other Connectors 4-41	
	4.9.1 4.9.2 4.9.3	Serial Communications Connector (CN3) 4-41 Computer Connector (CN7)	

# Wiring and Connecting SERVOPACKs

### 4.1.1 General Precautions

### A DANGER

Do not change any wiring while power is being supplied.
 There is a risk of electric shock or injury.

# **WARNING**

- Wiring and inspections must be performed only by qualified engineers.
   There is a risk of electric shock or product failure.
- Check all wiring and power supplies carefully.
   Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.
- Connect the AC and DC power supplies to the specified SERVOPACK terminals.
- Connect an AC power supply to the L1, L2, and L3 terminals on the SERVOPACK.
- Connect a DC power supply to the B1 and ⊝2 terminals and the 24 V and 0 V terminals on the SERVOPACK.

There is a risk of failure or fire.

# **A** CAUTION

- Wait for six minutes after turning OFF the power supply and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK.
   There is a risk of electric shock.
- Observe the precautions and instructions for wiring and trial operation precisely as described in this document.
  - Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the equipment, or cause an accident resulting in death or injury.
- Check the wiring to be sure it has been performed correctly.
   Connectors and pin layouts are sometimes different for different models. Always confirm the pin layouts in technical documents for your model before operation.
   There is a risk of failure or malfunction.
- Connect wires to power supply terminals and motor connection terminals securely with the specified methods and tightening torque.
   Insufficient tightening may cause wires and terminal blocks to generate heat due to faulty contact, possibly resulting in fire.
- Use shielded twisted-pair cables or screened unshielded multi-twisted-pair cables for I/O Signal Cables and Encoder Cables.
- Observe the following precautions when wiring the SERVOPACK's main circuit terminals.
  - Turn ON the power supply to the SERVOPACK only after all wiring, including the main circuit terminals, has been completed.
  - If a connector is used for the main circuit terminals, remove the main circuit connector from the SERVOPACK before you wire it.
  - Insert only one wire per insertion hole in the main circuit terminals.
  - When you insert a wire, make sure that the conductor wire (e.g., whiskers) does not come into contact with adjacent wires.
- Install molded-case circuit breakers and other safety measures to provide protection against short circuits in external wiring.

There is a risk of fire or failure.

#### 4.1.1 General Precautions

### NOTICE

- Whenever possible, use the Cables specified by Yaskawa.
   If you use any other cables, confirm the rated current and application environment of your model and use the wiring materials specified by Yaskawa or equivalent materials.
- Securely tighten cable connector screws and lock mechanisms.
   Insufficient tightening may result in cable connectors falling off during operation.
- Do not bundle power lines (e.g., the Main Circuit Cable) and low-current lines (e.g., the I/O Signal Cables or Encoder Cables) together or run them through the same duct. If you do not place power lines and low-current lines in separate ducts, separate them by at least 30 cm. If the cables are too close to each other, malfunctions may occur due to noise affecting the lowcurrent lines.
- Install a battery at either the host controller or on the Encoder Cable. If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.
- When connecting a battery, connect the polarity correctly.
   There is a risk of battery rupture or encoder failure.
- If you use an External Regenerative Resistor or External Dynamic Brake Resistor, use cable
  ties, clamps, or other means to secure the resistor so that the connectors or terminal blocks
  inside the SERVOPACK will not be affected even if the resistor is subjected to vibration or
  shock.

There is a risk of SERVOPACK damage.



- Use a molded-case circuit breaker (1QF) or fuse to protect the main circuit. The SERVOPACK
  connects directly to a commercial power supply; it is not isolated through a transformer or
  other device. Always use a molded-case circuit breaker (1QF) or fuse to protect the Servo System from accidents involving different power system voltages or other accidents.
- Install an earth leakage breaker. The SERVOPACK does not have a built-in ground fault protective circuit. To configure a safer system, install a ground fault detector against overloads and short-circuiting, or install a ground fault detector combined with a molded-case circuit breaker.
- Do not turn the power supply ON and OFF more than necessary.
  - Do not use the SERVOPACK for applications that require the power supply to turn ON and OFF frequently. Such applications will cause elements in the SERVOPACK to deteriorate.
  - After you have started actual operation, allow at least one hour between turning the power supply ON and OFF (as a guideline).

To ensure safe, stable application of the Servo System, observe the following precautions when wiring.

- Use the Cables specified by Yaskawa. Design and arrange the system so that each cable is as short as possible.
  - Refer to the catalog for information on the specified cables.
- The signal cable conductors are as thin as 0.2 mm<sup>2</sup> or 0.3 mm<sup>2</sup>. Do not subject them to excessive bending stress or tension.

### 4.1.2 Countermeasures against Noise



The SERVOPACK is designed as an industrial device. It therefore provides no measures to prevent radio interference. The SERVOPACK uses high-speed switching elements in the main circuit. Therefore peripheral devices may be affected by switching noise.

If the equipment is to be used near private houses or if radio interference is a problem, take countermeasures against noise.

The SERVOPACK uses microprocessors. Therefore, it may be affected by switching noise from peripheral devices.


To prevent the noise from the SERVOPACK or the peripheral devices from causing malfunctions of any devices, take the following countermeasures against noise as required.

- Install the input reference device and Noise Filter as close to the SERVOPACK as possible.
- Always install a Surge Absorber for relays, solenoids, and Magnetic Contactor coils.
- Do not place the following cables in the same duct or bundle them together. Also, separate the cables from each other by at least 30 cm.
  - •Main Circuit Cables and I/O Signal Cables
  - •Main Circuit Cables and Encoder Cables
- Do not share the power supply with an electric welder or electrical discharge machine. If the SERVOPACK is placed near a high-frequency generator, install Noise Filters on the input side on the Main Circuit Power Supply Cable and Control Power Supply Cable even if the same power supply is not shared with the high-frequency generator. Refer to the following section for information on connecting Noise Filters.
  - Noise Filters on page 4-6
- Implement suitable grounding measures. Refer to the following section for information on grounding measures.
  - 4.1.3 Grounding on page 4-8

### 4.1.2 Countermeasures against Noise

### **Noise Filters**

You must attach Noise Filters in appropriate places to protect the SERVOPACK from the adverse effects of noise. The following is an example of wiring for countermeasures against noise.



- \*1. For the ground wire, use a wire with a thickness of at least 2.0 mm<sup>2</sup> (preferably, flat braided copper wire).
- \*2. Whenever possible, use twisted-pair wires to wire all connections marked with  $\angle$ .
- \*3. Refer to the following section for precautions when using Noise Filters.

  \*\*Refer to the following section for precautions when using Noise Filters.

  \*\*The process of the following section for precautions when using Noise Filters.

  \*\*The process of the following section for precautions when using Noise Filters.

  \*\*The process of the following section for precautions when using Noise Filters.

  \*\*The process of the following section for precautions when using Noise Filters.


  \*\*The process of the following section for precautions when using Noise Filters.

  \*\*The process of the proces


### **Noise Filter Wiring and Connection Precautions**

Always observe the following precautions when wiring or connecting Noise Filters.


• Separate input lines from output lines. Do not place input lines and output lines in the same duct or bundle them together.



• Separate the Noise Filter ground wire from the output lines. Do not place the Noise Filter ground wire, output lines, and other signal lines in the same duct or bundle them together.




• Connect the Noise Filter ground wire directly to the grounding plate. Do not connect the Noise Filter ground wire to other ground wires.



### 4.1.3 Grounding

• If a Noise Filter is located inside a control panel, first connect the Noise Filter ground wire and the ground wires from other devices inside the control panel to the grounding plate for the control panel, then ground the plate.



### 4.1.3 Grounding

Implement grounding measures as described in this section. Implementing suitable grounding measures will also help prevent malfunctions, which can be caused by noise.

Observe the following precautions when wiring the ground cable.

- Ground the SERVOPACK to a resistance of 10  $\Omega$  or less.
- Be sure to ground at one point only.
- Ground the Servomotor directly if the Servomotor is insulated from the machine.

### **Motor Frame Ground or Motor Ground**


If you ground the Servomotor through the machine, switching noise current can flow from the main circuit of the SERVOPACK through the stray capacitance of the Servomotor. To prevent this, always connect the motor frame terminal (FG) or ground terminal (FG) of the Servomotor to the ground terminal  $\oplus$  on the SERVOPACK. Also be sure to ground the ground terminal  $\oplus$ . Ground both the Moving Coil and Magnetic Way of a Linear Servomotor.

### Noise on I/O Signal Cables

If noise enters the I/O Signal Cable, ground the shield of the I/O Signal Cable using a clamp or other means. If the Servomotor Main Circuit Cable is placed in a metal conduit, ground the conduit and its junction box. For all grounding, ground at one point only.

# 4.2 Basic Wiring Diagrams

This section provide the basic wiring diagrams. Refer to the reference sections given in the diagrams for details.



- \*1. represents twisted-pair wires.
- \*2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- \*3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- \*4. Refer to the following chapter if you use a safety function device.

#### Chapter 11 Safety Functions

If you do not use the safety function, insert the Safety Jumper Connector (provided as an accessory) into CN8 when you use the SERVOPACK.

- \*5. Always use line receivers to receive the output signals.
- \*6. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.
- \*7. The CN117 connector is used for SERVOPACKs with built-in Servomotor brake control. SERVOPACKs without built-in Servomotor brake control do not have the CN117 connector.
- \*8. If using these terminals, contact your YASKAWA representative.
- Note: 1. You can use parameters to change the functions allocated to the /SI0, /SI3, P-OT, N-OT, /Probe1, /Probe2, and /Home input signals and the /SO1, /SO2, /SO3, /SO4, and /SO5 output signals. Refer to the following section for details.

#### 6.1 I/O Signal Allocations on page 6-4

- 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.
- 3. Default settings are given in parentheses.

# Wiring the Power Supply to the SERVOPACK

### 4.3.1 Terminal Symbols and Terminal Names

Use the main circuit connector on the SERVOPACK to wire the main circuit power supply and control circuit power supply to the SERVOPACK.

# **⚠** CAUTION

Wire all connections correctly according to the following table and specified reference information. There is a risk of SERVOPACK failure or fire if incorrect wiring is performed.

The SERVOPACKs have the following two types of main circuit power supply input specifications.

Three-Phase, 400-VAC Power Supply Input

Terminal Symbols	Terminal Name	Specifications and Reference
L1, L2, L3	Main circuit power supply input terminals for AC power supply input	Three-phase, 380 VAC to 480 VAC, -15% to +10%, 50 Hz/60 Hz
24 V	Control power supply termi-	24 VDC, -15% to +15%
0 V	nals*1	0 VDC
B1, B2, B3*2	Regenerative Resistor terminal	If the internal regenerative Resistors on page 4-18  If the internal regenerative resistor is insufficient, remove the lead or short bar between B2 and B3 and connect an External Regenerative Resistor between B1 and B2.  The External Regenerative Resistor is not included. Obtain it separately.
	DC Reactor terminals for	4.3.6 Wiring DC Reactors on page 4-18
⊖1, ⊖2	power supply harmonic suppression	These terminals are used to connect a DC Reactor for power supply harmonic suppression or power factor improvement.
⊖, ⊕	-	None. (Do not connect anything to this terminal.)
U, V, W, PE	Servomotor terminals	These are the Σ-7S connection terminals for the Servomotor Main Circuit Cable (power line).  Note: Do not connect the PE terminal to anything other than a ground terminal.
D1, D2, D3*3	Dynamic Brake Resistor terminals	<ul> <li>In the following cases, remove the lead or short bar between D2 and D3 and connect a Dynamic Brake Resistor between D1 and D2.</li> <li>To specify the brake torque when stopping with the dynamic brake</li> <li>To use a larger load moment of inertia than in the standard specifications</li> <li>The Dynamic Brake Resistor is not included. Obtain it separately.</li> </ul>
DC+*5	Servomotor brake power	24 VDC
DC-*5	supply terminals*4	0 VDC
BK+, BK-*5	Servomotor brake terminals	Connect these terminals to the Servomotor's holding brake terminals. The holding brake terminals on the Servomotor do not have any polarity.
	Ground terminal	The ground terminals to prevent electric shock. Always connect this terminal.

<sup>\*1.</sup> Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.

<sup>\*2.</sup> With the SGD7S-210D, -260D, -280D, or -370D, connect a Regenerative Resistor Unit between B1 and B2.

<sup>\*3.</sup> The SGD7S-210D, -260D, -280D, and -370D do not have the D1, D2, and D3 terminals.

<sup>\*4.</sup> Make sure you check the brake specifications of the Servomotor for the 24-VDC power supply input to the Servomotor brake power supply terminals.

<sup>\*5.</sup> SERVOPACKs without built-in Servomotor brake control do not have these terminals.

#### 4.3.1 Terminal Symbols and Terminal Names

### • DC Power Supply Input

Terminal Symbols	Terminal Name	Specifications and Reference
24 V	Control power supply termi-	24 VDC, -15% to +15%
0 V	nals*1	0 VDC
B1*2	Main circuit power supply	513 VDC to 648 VDC, -15% to +10%
⊖2*2	input terminals for DC power supply input	0 VDC
L1, L2, L3, B2, B3, ⊖1, ⊖, ⊕	_	None. (Do not connect anything to these terminals.)
U, V, W, PE	Servomotor terminals	These are the Σ-7S connection terminals for the Servomotor Main Circuit Cable (power line).  Note: Do not connect the PE terminal to anything other than a ground terminal.
D1, D2, D3*3	Dynamic Brake Resistor terminals	<ul> <li>In the following cases, remove the lead or short bar between D2 and D3 and connect a Dynamic Brake Resistor between D1 and D2.</li> <li>To specify the brake torque when stopping with the dynamic brake</li> <li>To use a larger load moment of inertia than in the standard specifications</li> <li>The Dynamic Brake Resistor is not included. Obtain it separately.</li> </ul>
DC+*5	Servomotor brake power	24 VDC
DC-*5	supply terminals*4	0 VDC
BK+, BK-*5	Servomotor brake terminals	Connect these terminals to the Servomotor's holding brake terminals. The holding brake terminals on the Servomotor do not have any polarity.
	Ground terminal	This is the ground terminal to prevent electric shock. Always connect this terminal.

<sup>\*1.</sup> Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.

If you use a DC power supply input to the SERVOPACK, make sure to set parameter Pn001 to n. \$\simeq 1 \subseteq 0\$ (DC power supply input supported) before inputting the power supply. Refer to the following section for details.

5.2 Power Supply Type Settings for the Main Circuit on page 5-12

<sup>\*2.</sup> If using these terminals, contact your YASKAWA representative.

<sup>\*3.</sup> The SGD7S-210D, -260D, -280D, and -370D do not have the D1, D2, and D3 terminals.

<sup>\*4.</sup> Make sure you check the brake specifications of the Servomotor for the 24-VDC power supply input to the Servomotor brake power supply terminals.

<sup>\*5.</sup> SERVOPACKs without built-in Servomotor brake control do not have these terminals.

# 4.3.2 Connector Wiring Procedure

· Required Items: Phillips or flat-blade screwdriver

SERVOPACK model SGD7S-	Terminal Symbols	Screwdriver Type	Screwdriver End Dimensions Thickness × Width [mm]	Wire Stripping Length [mm]
	L1, L2, L3, B1, B2, B3, -1, -2	Flat-blade		7
1R9D, 3R5D, 5R4D, 8R4D, 120D, 170D	U, V, W, PE	Phillips or flat-blade	0.6 × 3.5	7
	24 V, 0 V	Flat-blade		10
0400 0000 0000	L1, L2, L3, B1, B2, B3, -1, -2	Phillips or flat-blade		12
210D, 260D, 280D, 370D	U, V, W, PE	Phillips or flat-blade	1.0 × 5.5	12
	24 V, 0 V	Flat-blade		10


- 1. Prepare the connector that was provided with the SERVOPACK.
- 2. Remove the sheath from the wire to connect.



3. Open the wire insertion hole on the terminal connector with the screwdriver.

Main Circuit Terminals and Motor Terminals	Control Power Supply Terminals
Insert the conductor of the wire into the wire insertion hole, insert the screwdriver into the screwdriver insertion hole, and tighten the screw.	Press the lever with a screwdriver or your fingertip and insert the conductor of the wire into the wire insertion hole.  After you insert conductor, release the screwdriver or your fingertip.
Wire	Wire


- 4. Make all other connections in the same way.
- **5.** When you have completed wiring, attach the connector to the SERVOPACK.
- 6. Press the connector all the way to the back and lock it with the lock lever.



### 4.3.3 Power ON Sequence

Consider the following points when you design the power ON sequence.

The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply
is turned ON. Take this into consideration when you design the power ON sequence, and
turn ON the main circuit power supply to the SERVOPACK when the ALM signal is OFF (alarm
cleared).



- Design the power ON sequence so that main circuit power supply is turned OFF when an ALM (Servo Alarm) signal is output.
- Make sure that the power supply specifications of all parts are suitable for the input power supply.
- Allow at least 1 s after the power supply is turned OFF before you turn it ON again.



Turn ON the control power supply and the main circuit power supply at the same time or turn ON the control power supply before the main circuit power supply.

Turn OFF the main circuit power supply first, and then turn OFF the control power supply.


### **⚠** WARNING

 Even after you turn OFF the power supply, a high residual voltage may still remain in the SERVOPACK. To prevent electric shock, do not touch the power supply terminals after you turn OFF the power. When the voltage is discharged, the CHARGE indicator will turn OFF.
 Make sure the CHARGE indicator is OFF before you start wiring or inspection work.


### 4.3.4 Power Supply Wiring Diagrams

### Using Only One SERVOPACK

• Wiring Example for Three-Phase, 400-VAC Power Supply Input: SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D




• Wiring Example for Three-Phase, 400-VAC Power Supply Input: SGD7S-210D, -260D, -280D, and -370D




#### 4.3.4 Power Supply Wiring Diagrams

Wiring Example for DC Power Supply Input: SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D



• Wiring Example for DC Power Supply Input: SGD7S-210D, -260D, -280D, and -370D




### Using More Than One SERVOPACK

Connect the ALM (Servo Alarm) output for these SERVOPACKs in series to operate the alarm detection relay (1RY).

When a SERVOPACK alarm is activated, the ALM output signal transistor turns OFF.

The following diagram shows the wiring to stop all of the Servomotors when there is an alarm for any one SERVOPACK.

More than one SERVOPACK can share a single Noise Filter. However, always select a Noise Filter that has a large enough capacity to handle the total power supply capacity of all the SERVOPACKs. Be sure to consider the load conditions.



To comply with UL/cUL standards, you must install a branch circuit protective device at the power supply input section to each SERVOPACK. Refer to the following document for details. Σ-7-Series Σ-7S SERVOPACK with 400 V-Input Power Safety Precautions (Manual No.: TOMP C710828 02)

# 4.3.5 Wiring Regenerative Resistors


This section describes how to connect External Regenerative Resistors. Refer to the catalog to select External Regenerative Resistors.

### **WARNING**


Be sure to wire Regenerative Resistors correctly. Do not connect B1/⊕ and B2.
 Doing so may result in fire or damage to the Regenerative Resistor or SERVOPACK.

### **Connecting Regenerative Resistors**

1. Remove the wire connected between the B2 and B3 terminals.



2. Connect the External Regenerative Resistor between the B1 and B2 terminals on the SERVOPACK.




3. Set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistor Resistance). Refer to the following section for details on the settings.

5.17 Setting the Regenerative Resistor Capacity on page 5-55

### 4.3.6 Wiring DC Reactors

You can connect a DC Reactor to the SERVOPACK when power supply harmonic suppression is required. Connection terminals  $\ominus 1$  and  $\ominus 2$  for a DC Reactor are connected when the SERVOPACK is shipped. Remove the lead wire and connect a DC Reactor as shown in the following diagram.



# 4.4 Wiring Servomotors

# 4.4.1 Terminal Symbols and Terminal Names

The SERVOPACK terminals or connectors that are required to connect the SERVOPACK to a Servomotor are given below.

Terminal/Connector Symbols	Terminal/Connector Name	Remarks
U, V, and W	Servomotor terminals	Refer to the following section for the wiring procedure.  3 4.3.2 Connector Wiring Procedure on page 4-13
PE	Ground terminal	_
CN2	Encoder connector	-

# 4.4.2 Pin Arrangement of Encoder Connector (CN2)

### · When Using a Rotary Servomotor

Pin No.	Signal	Function
1	PG5V	Encoder power supply +5 V
2	PG0V	Encoder power supply 0 V
3	BAT (+)*	Battery for absolute encoder (+)
4	BAT (-)*	Battery for absolute encoder (-)
5	PS	Serial data (+)
6	/PS	Serial data (-)
Shell	Shield	_

<sup>\*</sup> You do not need to wire these pins for an incremental encoder.

### When Using a Linear Servomotor

Pin No.	Signal	Function
1	PG5V	Linear encoder power supply +5 V
2	PG0V	Linear encoder power supply 0 V
3	_	- (Do not use.)
4	_	- (Do not use.)
5	PS	Serial data (+)
6	/PS	Serial data (-)
Shell	Shield	_

# 4.4.3 Wiring the SERVOPACK to the Encoder


### When Using an Absolute Encoder

If you use an absolute encoder, use an Encoder Cable with a JUSP-BA01-E Battery Case or install a battery on the host controller.

Refer to the following section for the battery replacement procedure.

15.1.3 Replacing the Battery on page 15-3


· Wiring Example When Installing a Battery on the Host Controller



\*1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.

\*2. represents a shielded twisted-pair cable.

· Wiring Example When Using an Encoder Cable with a Battery Case



\*1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.

\*2. represents a shielded twisted-pair cable.



- When Installing a Battery on the Encoder Cable
   Use the Encoder Cable with a Battery Case that is specified by Yaskawa.
   Refer to the catalog for details.
- When Installing a Battery on the Host Controller Insert a diode near the battery to prevent reverse current flow.

# Circuit Example


Required Component Specifications

• Schottky Diode

Reverse Voltage: Vr > 40 V

Reverse Voltage:  $Vr \ge 40 \text{ V}$ Forward Voltage:  $Vf \le 0.37 \text{ V}$ Reverse current:  $Ir \le 5 \mu\text{A}$ Junction temperature:  $Tj \ge 125 ^{\circ}\text{C}$  Resistor Resistance:  $22~\Omega$  Tolerance:  $\pm 5\%$  max. Rated power: 0.25~W min.

# When Using an Incremental Encoder




- \*1. The incremental encoder pin numbers for wiring the connector depend on the Servomotor that you use.
- \*2. represents a shielded twisted-pair cable.

4.4.3 Wiring the SERVOPACK to the Encoder

### When Using an Absolute Linear Encoder


The wiring depends on the manufacturer of the linear encoder.

Connections to Linear Encoder from Mitutoyo Corporation




\* represents a shielded twisted-pair cable.

◆ Connections to Absolute Linear Encoder from Renishaw PLC



- \* represents a shielded twisted-pair cable.
- ◆ Connections to Absolute Linear Encoder from Magnescale Co., Ltd.
- SR77, SR87, SQ47, and SQ57




\* represents a shielded twisted-pair cable.

### When Using an Incremental Linear Encoder


The wiring depends on the manufacturer of the linear encoder.

### ◆ Connections to Linear Encoder from Heidenhain Corporation



\* represents a shielded twisted-pair cable.

### ◆ Connections to Linear Encoder from Renishaw PLC




\* represents a shielded twisted-pair cable.

### 4.4.3 Wiring the SERVOPACK to the Encoder

### ◆ Connections to Linear Encoder from Magnescale Co., Ltd.

If you use a linear encoder from Magnescale Co., Ltd., the wiring will depend on the model of the linear encoder.

#### ■ SR75 and SR85




\* represents a shielded twisted-pair cable.

#### ■ SL700, SL710, SL720, SL730, and SQ10

PL101-RY, MQ10-FLA, or MQ10-GLA Interpolator
 The following table gives the Linear Encoder and Interpolator combinations.

Linear Encoder Model	Interpolator Model
SL700, SL710, SL720, and SL730	PL101-RY*1
SQ10	MQ10-FLA*2
	MQ10-GLA*2


- \*1. This is the model of the Head with Interpolator.
- \*2. This is the model of the Interpolator.



\* represents a shielded twisted-pair cable.

#### ■ SL700, SL710, SL720, and SL730

• MJ620-T13 Interpolator




represents a shielded twisted-pair cable.

# 4.4.4 Wiring the SERVOPACK to the Holding Brake



- If you use a Rotary Servomotor, select a Surge Absorber according to the brake current and brake power supply. Refer to the catalog for details.
- After the Surge Absorber is connected, check the time required to brake in your application.
   The Surge Absorber may affect the time required to brake.
   Configure the relay circuit to activate the holding brake for an emergency stop.




- You can change the output signal allocation of the /BK signal. Refer to the following section for details.
  - Allocating the /BK (Brake) Signal on page 5-34
- If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

4.4.4 Wiring the SERVOPACK to the Holding Brake

### SERVOPACKs without Built-in Servomotor Brake Control

A wiring example for SERVOPACKs without built-in Servomotor brake control is provided below.




\* Install the Surge Absorber near the brake terminals on the Servomotor.

### SERVOPACKs with Built-in Servomotor Brake Control

SERVOPACKs with built-in brake control contain a brake relay.

The wiring is different because of the built-in brake relays. The following figure shows a wiring example.



### · Connector Specifications

Connector No.	Model	Number of Pins	Manufacturer	
CN117	BLF 5.08HC/04/180LR SN BK BX SO	4	Weidmüller Interface GmbH & Co. KG	

### ◆ Built-in Brake Relay Specifications

The specifications of the built-in brake relay are as follows:

- Service life (number of operations): 30,000 operations
- Allowable number of operations: 30 operations per minute max.

# 4.5

# Connecting I/O Signals

# 4.5.1 I/O Signal Connector (CN1) Names and Functions

The following table gives the pin numbers, names, and functions the I/O signal pins for the default settings.

### Input Signals

Default settings are given in parentheses.

Signal	Pin No.	Name	Function	Reference
/SI1* (P-OT)	7	General-purpose Sequence Input 1 (Forward Drive Prohibit Input)	You can allocate the input signal to use with a parameter. (Stops Servomotor drive (to prevent over-	
/SI2* (N-OT)	8	General-purpose Sequence Input 2 (Reverse Drive Prohibit Input)	travel) when the moving part of the machine exceeds the range of movement.)	page 5-26
/SI3*	9	General-purpose Sequence Input 3	You can allocate the input signal to use with parameters. (Used for general-purpose input.)	_
/SI4* (/Probe1)	10	General-purpose Sequence Input 4 (Probe 1 Latch Input)	You can allocate the input signals to use with parameters.	
/SI5* (/Probe2)	11	General-purpose Sequence Input 5 (Probe 2 Latch Input)	(Connect the external signals that latch the current feedback pulse counter.)	_
/SI6* (/Home)	12	General-purpose Sequence Input 6 (Home Switch Input)	You can allocate the input signal to use with parameters. (Connect the switch that starts homing.)	
/SI0*	13	General-purpose Sequence Input 0	You can allocate the input signal to use with a parameter. (Used for general-purpose input.)	_
+24VIN	6	Sequence Input Signal Power Supply Input	Inputs the sequence input signal power supply. Allowable voltage range: 24 VDC ±20% The 24-VDC power supply is not provided by Yaskawa.	_
BAT+	14	Battery for Absolute Encoder (+)	These are the pins to connect the absolute encoder backup battery.	
BAT-	15	Battery for Absolute Encoder (-)	Do not connect these pins if you use the Encoder Cable with a Battery Case.	
TH	5	Linear Servomotor Overheat Protection Input	Inputs the overheat protection signal from a Linear Servomotor.	_

<sup>\*</sup> You can change the allocations. Refer to the following section for details. 
© 6.1.1 Input Signal Allocations on page 6-4

Note: If forward drive prohibition or reverse drive prohibition is used, the SERVOPACK is stopped by software controls. If the application does not satisfy the safety requirements, add external safety circuits as required.

# **Output Signals**

Default settings are given in parentheses.


Signal	Pin No.	Name	Function	Reference	
ALM+	3	Servo Alarm Output	Turns OFF (opens) when an error is detected.	2000 6 7	
ALM-	4	- Servo Alarm Output	Turns Of F (opens) when an error is detected.	page 6-7	
/SO1+* (/BK+)	1	General-purpose Sequence Output 1	You can allocate the output signal to use with a parameter.	page 5-32	
/SO1-* (/BK-)	2	(Brake Output)	(Controls the brake. The brake is released when the signal turns ON (closes).)	page 5-32	
/SO2+*	23	General-purpose		page 14-47	
/SO2-*	24	Sequence Output 2			
/SO3+*	25	General-purpose			
/SO3-*	26	Sequence Output 3	Used for general-purpose outputs.		
/SO4+*	27	General-purpose	Set the parameters to allocate functions.		
/SO4-*	28	Sequence Output 4			
/SO5+*	29	General-purpose			
/SO5-*	30	Sequence Output 5			
PAO	17	Encoder Divided Pulse		page 6-31	
/PAO	18	Output, Phase A	Output the encoder divided pulse output sig-		
PBO	19	Encoder Divided Pulse	nals with a 90° phase differential.		
/PBO	20	Output, Phase B	hase B		
PCO	21	Encoder Divided Pulse	er Divided Pulse Outputs the origin signal once every encoder		
/PCO	22	Output, Phase C	rotation.		
SG	16	Signal ground	This is the 0-V signal for the control circuits.	_	

<sup>\*</sup> You can change the allocations. Refer to the following section for details.

<sup>6.1.2</sup> Output Signal Allocations on page 6-5

#### I/O Signal Connector (CN1) Pin Arrangement 4.5.2

The following figure gives the pin arrangement of the of the I/O signal connector (CN1) for the default settings.






Side View of I/O Signal Connector

encoder (-)  14 PG BAT+ Battery for absolute encoder (+)  13 /SIO General-purpose sequence input 0  14 /SIE General-purpose sequence input 0  15 /SIE General-purpose sequence input 6  16 /SIE General-purpose sequence input 5  17 /SIE General-purpose sequence input 5  18 /SIE General-purpose sequence input 5  19 /SIE General-purpose sequence input 4  10 /SIE General-purpose sequence input 4  11 /SIE General-purpose sequence input 5  12 /SOE General-purpose sequence output 5  13 /SIE General-purpose sequence input 4  14 /SOE General-purpose sequence output 5  15 /SOE General-purpose sequence input 2  16 /SOE General-purpose sequence input 2  17 /SIE General-purpose sequence input 2  18 /SIE General-purpose sequence input 2  19 /SIE General-purpose sequence input 2  20 /PCO Encoder divided output, phase C  21 /PCO Encoder divided output, phase C  22 /PCO Encoder divided output, phase C  23 /PEO Encoder divided output, phase C  24 /PEO Encoder divided output, phase C	No	Signal	nal Specification	No	Signal	Specification
13 /SIO General-purpose sequence input 0  12 /SI6 General-purpose sequence input 6  13 /SI5 General-purpose sequence input 6  14 /SI5 General-purpose sequence input 5  15 /SI4 General-purpose sequence input 4  16 /SI3 General-purpose sequence input 4  17 /SI3 General-purpose sequence input 4  18 /SI2 General-purpose sequence input 3  19 /SI2 General-purpose sequence input 3  10 /SI4 General-purpose sequence input 4  11 /SO2- General-purpose sequence outpur 3  12 /SO3- General-purpose sequence outpur 4  23 /SO3- General-purpose sequence outpur 5  24 /SO2- General-purpose sequence outpur 6  25 /SO3+ General-purpose sequence outpur 7  26 /SO3- General-purpose sequence outpur 9  27 /SO3+ General-purpose sequence outpur 9  28 /SO3- General-purpose sequence outpur 9  29 /SO3- General-purpose sequence outpur 9  20 /SO2- General-purpose sequence outpur 9  21 /SO2- General-purpose sequence outpur 9  22 /PCO Encoder divided output, phase C  23 /SO2+ General-purpose Sequence outpur 9  24 /SO3- General-purpose Sequence outpur 9  25 /SO3- General-purpose Sequence outpur 9  26 /SO3- General-purpose Sequence outpur 9  27 /SO3- General-purpose Sequence outpur 9  28 /SO3- General-purpose Sequence outpur 9  29 /SO3- General-purpose Sequence outpur 9  20 /PCO Encoder divided output, phase C  20 /PBO Encoder divided output, phase B  20 /PBO Encoder divided output, phase B	15	PG BAT-		30	/SO5-	General-purpose sequence output 5
sequence input 0    12   /SI6   General-purpose sequence input 6   27   /SO4+   General-purpose sequence output 6   27   /SO4+   General-purpose sequence output 6   27   /SO4+   General-purpose sequence output 6   26   /SO3-   General-purpose sequence input 5   26   /SO3-   General-purpose sequence input 5   26   /SO3-   General-purpose sequence output 6   27   /SO3-   General-purpose sequence input 5   27   /SO3-   General-purpose sequence input 4   25   /SO3-   General-purpose sequence input 3   24   /SO2-   General-purpose sequence input 3   27   /SO2-   General-purpose sequence input 2   28   /SO2-   General-purpose sequence input 2   28   /SO2-   General-purpose sequence input 6   27   /SO3-   General-purpose sequence output 7   /SI1   General-purpose sequence input 2   27   /SO2-   General-purpose sequence input 2   28   /SO2-   General-purpose sequence output 6   29   /PCO   Encoder divided output, phase C   29   /PCO   Encoder divided output, phase C   20   /PBO   Encoder divided output, phase B   20   /PBO   Encoder divided output phase B   20   /PBO   Encoder divided output phase B   20   /PBO   Enc	14	PG BAT+		29	/SO5+	General-purpose sequence output 5
// (/Home) sequence input 6  // (/Home) sequence input 6  // (/Probe2) sequence input 5  // (/Probe1) sequence input 4  // (/Probe1) sequence input 3  // (/Probe1) Sequence input 2  // (/Probe1) Sequence input 2  // (/Probe1) Sequence input 3  // (/Probe1) Sequence input 1  // (/Probe1) Sequence input 1  // (/Probe1) Sequence input 3  // (/Probe1) Sequence input 1  // (/Probe1) Sequence input 3  // (/Probe1) Sequence input 1  // (/Probe1) Sequence input 2  // (/Probe1) Sequence output 3  // (/Probe1) Sequence input 3  // (/Probe1) Sequence input 2  // (/Probe1) Sequence output 3  // (/Probe1) Sequence input 3  //	13	/SI0		28	/SO4-	General-purpose sequence output 4
10    (/Probe2)   sequence input 5	12			27	/SO4+	General-purpose sequence output 4
9 /SI3 General-purpose sequence input 3 24 /SO2- General-purpose sequence input 3 24 /SO2- General-purpose sequence input 3 25 /SO2- General-purpose sequence output 3 26 /SO2- General-purpose sequence input 2 27 /SO2- General-purpose sequence input 2 28 /SO2- General-purpose sequence output 3 29 /PCO Encoder divided output, phase C 29 /PCO Encoder divided output, phase B 20 /PCO /PCO Encoder divided output, phase B 20 /PCO /PCO /PCO /PCO /PCO /PCO /PCO /PCO	11			26	/SO3-	General-purpose sequence output 3
sequence input 3    Solution   So	10			25	/SO3+	General-purpose sequence output 3
8 (N-OT) sequence input 2  7 /SI1 General-purpose sequence input 1  22 /PCO Encoder divided output, phase C  6 +24VIN Sequence input signal power supply input  5 TH Linear Servomotor overheat protection input  10 PBO Encoder divided output, phase B  4 ALM- Servo alarm output  10 PBO Encoder divided	9	/SI3		24	/SO2-	General-purpose sequence output 2
(P-OT) sequence input 1  6 +24VIN Sequence input signal power supply input  21 PCO Encoder divided output, phase C  5 TH Linear Servomotor overheat protection input  20 /PBO Encoder divided output, phase B  4 ALM- Servo alarm output  10 PBO Encoder divided	8			23	/SO2+	General-purpose sequence output 2
5 TH Linear Servomotor overheat protection input  21 PCO output, phase C  5 TH Linear Servomotor overheat protection input  20 /PBO Encoder divided output, phase B  4 ALM- Servo alarm output  10 PBO Encoder divided	7	,		22	/PCO	Encoder divided pulse output, phase C
heat protection input 20 /PBO output, phase B	6	+24VIN		21	PCO	Encoder divided pulse output, phase C
	5	TH		20	/PBO	Encoder divided pulse output, phase B
	4	ALM-	- Servo alarm output	19	РВО	Encoder divided pulse output, phase B
3 ALM+ Servo alarm output 18 /PAO Encoder divided output, phase A	3	ALM+	+ Servo alarm output	18	/PAO	Encoder divided pulse output, phase A
2 /SO1- General-purpose sequence output 1 17 PAO Encoder divided output, phase A	2			17	PAO	Encoder divided pulse output, phase A
1 /SO1+ General-purpose sequence output 1 16 SG Signal ground	1			16	sg	Signal ground


# 4.5.3 I/O Signal Wiring Examples

### **Using a Rotary Servomotor**



- \*1. represents twisted-pair wires.
- \*2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- \*3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- \*4. Always use line receivers to receive the output signals.
- Note: 1. You can use parameters to change the functions allocated to the /SI0, /SI3, P-OT, N-OT, /Probe1, /Probe2, and /Home input signals and the /SO1, /SO2, /SO3, /SO4, and /SO5 output signals.
  - 6.1 I/O Signal Allocations on page 6-4
  - 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

### Using a Linear Servomotor




- \*1. represents twisted-pair wires.
- \*2. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- \*3. Always use line receivers to receive the output signals.
- Note: 1. You can use parameters to change the functions allocated to the /SI0, /SI3, P-OT, N-OT, /Probe1, /Probe2, and /Home input signals and the /SO1, /SO2, /SO3, /SO4, and /SO5 output signals.
  - 6.1 I/O Signal Allocations on page 6-4
  - 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

### 4.5.4 I/O Circuits

### **Sequence Input Circuits**

### ◆ Photocoupler Input Circuits


This section describes CN1 connector terminals 6 to 13.



Note: The 24-VDC external power supply capacity must be 50 mA minimum.

The SERVOPACK input circuits use bidirectional photocouplers. Select either a sink circuit or source circuit according to the specifications required by the machine.

Note: The connection examples in 4.5.3 I/O Signal Wiring Examples on page 4-31 are for sink circuit connections.



#### 4.5.4 I/O Circuits

# **Sequence Output Circuits**




Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures.

If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.

## ◆ Photocoupler Output Circuits

Photocoupler output circuits are used for the ALM (Servo Alarm), /S-RDY (Servo Ready), and other sequence output signals. Connect a photocoupler output circuit to a relay or line-receiver circuit.




Note: The maximum allowable voltage and current range for photocoupler output circuits are as follows:

- Maximum allowable voltage: 30 VDC
  Current range: 5 mA to 50 mA DC

## ◆ Line-Driver Output Circuits

This section describes CN1 connector terminals 17-18 (Phase-A Signal), 19-20 (Phase-B Signal), and 21-22 (Phase-C Signal).

The serial data from the encoder is converted to two-phase (phases A and B) pulses. The resulting output signals (PAO, /PAO and PBO, /PBO) and origin pulse signal (PCO and /PCO) are output with line-driver output circuits. Connect the line-driver output circuits to line-receiver circuits at the host controller.



4.6.1 Pin Arrangement of Safety Function Signals (CN8)

# 4.6 Connecting Safety Function Signals

This section describes the wiring required to use a safety function.

Refer to the following chapter for details on the safety function.

Chapter 11 Safety Functions

# 4.6.1 Pin Arrangement of Safety Function Signals (CN8)

Pin No.	Signal	Name	Function	
1	_	- (Do not use those pine because they s	are connected to internal circuits.)	
2	_	- (Do not use these pins because they a		
3	/HWBB1-	Hard Wire Base Block Input 1	For a hard wire base block input. The base block (motor power turned OFF) is in effect when the signal is OFF.	
4	/HWBB1+	That wife base block input i		
5	/HWBB2-	Hard Wire Base Block Input 2		
6	/HWBB2+	Traid Wife base block input 2		
7	EDM1-	External Device Monitor Output	Turns ON when the /HWBB1 and the / HWBB2 signals are input and the SER- VOPACK enters a base block state.	
8	EDM1+	External Device Monitor Output		

# 4.6.2 I/O Circuits



For safety function signal connections, the input signal is the 0-V common and the output signal is a source output. This is opposite to other signals described in this manual.


To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

# **Safety Input Circuits**

Use a 0-V common to connect the safety function signals. You must connect redundant input signals.



# ◆ Input (HWBB) Signal Specifications


Туре	Signal	Connector Pin No.	Status	Meaning
Inputs	/HWBB1	CN8-4 CN8-3	ON (closed)	Does not activate the HWBB (normal operation).
			OFF (open)	Activates the HWBB (motor current shut-OFF request).
	/HWBB2	CN8-6 CN8-5	ON (closed)	Does not activate the HWBB (normal operation).
			OFF (open)	Activates the HWBB (motor current shut-OFF request).

The input (HWBB) signals have the following electrical characteristics.

Item	Characteristics	Remarks
Internal Imped- ance	4.7 kΩ	_
Operating Voltage Range	+24 V ±20%	_
Maximum Delay Time	8 ms	Time from /HWBB1 and /HWBB2 signals turning OFF until HWBB is activated

# **Diagnostic Output Circuits**

The EDM1 output signal uses a source circuit. The following figure shows a connection example.



# ◆ EDM1 Output Signal Specifications

Type	Signal	Pin No.	Output Sta- tus	Meaning
Output	EDM1	CN8-8 CN8-7	ON	Both the /HWBB1 and /HWBB2 signals are operating normally.
			OFF	The /HWBB1 signal, the /HWBB2 signal, or both are not operating.

The electrical characteristics of the EDM1 signal are as follows:

Item	Character- istics	Remarks
Maximum Allow- able Voltage	30 VDC	_
Maximum Allow- able Current	50 mA DC	-
Maximum ON Voltage Drop	1.0 V	Voltage between EDM1+ and EDM1- when current is 50 mA
Maximum Delay Time	8 ms	Time from a change in /HWBB1 or /HWBB2 until a change in EDM1

# 4.7 Connecting Dynamic Brake Resistors

A connector or terminal block is used to wire a Dynamic Brake Resistor.

# 4.7.1 Terminal Symbols and Terminal Names

# **CAUTION**

• Wire all connections correctly according to the following table.

There is a risk of SERVOPACK failure or fire if incorrect wiring is performed.

SERVOPACK Model	Terminal Symbols	Terminal Name	Specification
SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, -170D	D1, D2	Dynamic Brake Resistor terminals	These terminals are connected to an External Dynamic Brake Resistor.

# 4.7.2 Connecting a Dynamic Brake Resistor

# **MARNING**

 Wire the Dynamic Brake Resistor correctly. Do not connect the following terminals directly to each other: D1 and D2.

There is a risk of burning in the SERVOPACK or Servomotor, damage to the machine, or injury.

# **M** CAUTION


 Mount Dynamic Brake Resistors only on nonflammable materials. Do not mount them on or near any flammable material.

There is a risk of fire.

#### · Required Items


Required Item	Remarks
Phillips or flat-blade	Commercially available screwdriver with a tip thickness of 0.6 mm and tip width of
screwdriver	3.5 mm

- 1. Prepare the connector that is provided with the SERVOPACK.
- 2. Remove the lead wire from between D2 and D3.




#### 4.7.2 Connecting a Dynamic Brake Resistor

3. Remove the sheath from the wire to connect.




- 4. Open the wire insertion hole on the terminal connector with the screwdriver.
- **5.** Insert the conductor of the wire into the wire insertion hole. After you insert the conductor, remove the screwdriver.



**6.** Connect the Dynamic Brake Resistor to the D1 and D2 terminals on the SERVOPACK.

Note: 1. The D1 and D2 are in the locations shown in the following figure. Do not connect anything to the D3 terminal.

2. Terminal labels (D1 and D2) are provided on the Dynamic Brake Resistor connector.




7. Set Pn601 (Dynamic Brake Resistor Allowable Energy Consumption) and Pn604 (Dynamic Brake Resistance).

Refer to the following section for details on the settings.

3.18 Setting the Energy Consumption and Resistance of the Dynamic Brake Resistor on page 5-56

# 4.8 Connecting EtherCAT Communications Cables

Connect the EtherCAT Communications Cables to the CN6A and CN6B connectors.



Note: The length of the cable between stations (L1, L2, ... Ln) must be 50 m or less.

# 4.8.1 EtherCAT Connectors (RJ45)

Connector	Description
CN6A	EtherCAT input signals
CN6B	EtherCAT output signals

### ■ Connector Pin Assignments

Pin	Signal	Remarks
1	TD+	Send data
2	TD-	Genu data
3	RD+	Receive data
4	-	N.C.*
5	-	N.C.*
6	RD-	Receive data
7	-	N.C.*
8	-	N.C.*

<sup>\*</sup> These pins are not connected to any signals.

## 4.8.2 Ethernet Communications Cables

## 4.8.2 Ethernet Communications Cables

Use category 5e Ethernet communications cables to make the connections.

Use cables with the following specifications.

Shielded: S/STP or S/UTP

Length: 50 m max. (between nodes)
The following cable is recommended.

Manufacturer	Model
Beckhoff	ZB9020

# 4.9 Connecting the Other Connectors

# 4.9.1 Serial Communications Connector (CN3)

To use a Digital Operator or to connect a computer with an RS-422 cable, connect CN3 on the SERVOPACK.

Refer to the following manual for the operating procedures for the Digital Operator.

Σ-7-Series Servo Drive Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

# 4.9.2 Computer Connector (CN7)

To use the SigmaWin+ Engineering Tool, connect the computer on which the SigmaWin+ is installed to CN7 on the SERVOPACK.

Refer to the following manual for the operating procedures for the SigmaWin+. AC Servo Drive Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)




Use the Cable specified by Yaskawa for the Computer Cable. Operation may not be dependable with any other cable.

Refer to the catalog for details on the Computer Cable.

# 4.9.3 Analog Monitor Connector (CN5)

To use an analog monitor, connect CN5 on the SERVOPACK.

Wiring Example



<sup>\*</sup> The measuring instrument is not provided by Yaskawa.

Refer to the following section for information on the monitoring methods for an analog monitor.

9.3 Monitoring Machine Operation Status and Signal Waveforms on page 9-6

# Basic Functions That Require Setting before Operation

5

This chapter describes the basic functions that must be set before you start Servo System operation. It also describes the setting methods.

5.1	Manipulating SERVOPACK Parameters (Pn $\square\square$ ) 5-3
	<ul> <li>5.1.1 Classifications of SERVOPACK Parameters 5-3</li> <li>5.1.2 Notation for SERVOPACK Parameters 5-4</li> <li>5.1.3 Setting Methods for SERVOPACK Parameters 5-5</li> <li>5.1.4 Write Prohibition Setting for SERVOPACK Parameters</li></ul>
5.2	Power Supply Type Settings for the Main Circuit5-12
F 2	Automotic Detection of Compacted Mater 5 12
5.3	Automatic Detection of Connected Motor 5-13
5.4	Motor Direction Setting 5-14
5.5	Setting the Linear Encoder Pitch5-15
5.6	Writing Linear Servomotor Parameters 5-16
5.7	Selecting the Phase Sequence for a Linear Servomotor 5-20
5.8	Polarity Sensor Setting5-22
5.9	Polarity Detection5-23
	5.9.1 Restrictions

5.10	Overt	ravel and Related Settings5-26
	5.10.1 5.10.2 5.10.3 5.10.4 5.10.5 5.10.6 5.10.7	Overtravel Signals.5-26Setting to Enable/Disable Overtravel.5-27Motor Stopping Method for Overtravel.5-27Overtravel Warnings.5-29Overtravel Release Method Selection.5-30Overtravel Status.5-31Overtravel Operation by Mode.5-31
5.11	Holdii	ng Brake5-32
	5.11.1 5.11.2 5.11.3	Brake Operating Sequence
	5.11.4	Servomotor Is Stopped5-34 Output Timing of /BK (Brake) Signal When the
	5.11.5	Servomotor Is Operating
5.12	Motor	Stopping Methods for Servo OFF and Alarms5-37
	5.12.1	Stopping Method for Servo OFF5-38
	5.12.2	Servomotor Stopping Method for Alarms 5-38
5.13	Motor	r Overload Detection Level5-40
	5.13.1	Detection Timing for Overload Warnings (A.910)
	5.13.2	Detection Timing for Overload Alarms (A.720)5-41
5.14	Settin	g Unit Systems5-42
	5.14.1	Setting the Position Reference Unit5-42
	5.14.2	Setting the Speed Reference Unit5-47
	5.14.3	Setting the Acceleration Reference Unit 5-48
	5.14.4	Setting the Torque Reference Unit5-48
5.15	Reset	ting the Absolute Encoder5-49
	5.15.1	Precautions on Resetting
	5.15.2	Applicable Tools
	5.15.3	Operating Procedure5-50
5.16		g the Origin of the Absolute Encoder 5-52
	5.16.1 5.16.2	Absolute Encoder Origin Offset
5.17	Setting	g the Regenerative Resistor Capacity 5-55
5.18	Setting the	e Energy Consumption and Resistance of the Dynamic Brake Resistor 5-56

# 5.1 Manipulating SERVOPACK Parameters (Pn□□□)

This section describes the classifications, notation, and setting methods for the SERVOPACK parameters given in this manual.

## 5.1.1 Classifications of SERVOPACK Parameters

There are the following two types of SERVOPACK parameters.

Classification	Meaning
Setup Parameters	Parameters for the basic settings that are required for operation.
Tuning Parameters	Parameters that are used to adjust servo performance.

Information

The tuning parameters are not displayed by default when you use the Digital Operator. To display and set the tuning parameters, set Pn00B to n. \(\sigma \square\$ \square\$ (Display all parameters).

Parameter		Meaning	When Enabled	Classification	
Pn00B	n.□□□0 (default setting)	Display only setup parameters.	After restart	Setup	
	n.□□□1	Display all parameters.			


The setting method for each type of parameter is described below.

## **Setup Parameters**

You can use the Digital Operator, or SigmaWin+ to set the setup parameters individually.

Information

We recommend that you use the Setup Wizard of the SigmaWin+ to easily set the required setup parameters by setting the operating methods, machine specifications, and I/O signals according to on-screen Wizard instructions.



#### 5.1.2 Notation for SERVOPACK Parameters

## **Tuning Parameters**

Normally the user does not need to set the tuning parameters individually.

Use the various SigmaWin+ tuning functions to set the related tuning parameters to increase the response even further for the conditions of your machine. Refer to the following sections for details.

- 8.6 Autotuning without Host Reference on page 8-23
- 8.7 Autotuning with a Host Reference on page 8-34
- 8.8 Custom Tuning on page 8-41


You can also set the tuning parameters individually to make adjustments. Refer to the following section for details.

8.13 Manual Tuning on page 8-76

## 5.1.2 Notation for SERVOPACK Parameters

There are two types of notation used for SERVOPACK parameters that depend on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting a function).

· Parameters for Numeric Settings



# Setting Methods for SERVOPACK Parameters


You can use the SigmaWin+ or a Digital Operator to set the SERVOPACK parameters. A sample operating procedure is given below.

# Setting SERVOPACK Parameters with the SigmaWin+

- 1. Click the 🔑 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Edit Parameters in the Menu Dialog Box. The Parameter Editing Dialog Box will be displayed.
- 3. Click the cell of the parameter to edit.

5.1.3

If the parameter to edit is not displayed in the Parameter Editing Dialog Box, click the <a> or <a> Button</a> to display the parameter to edit.



4. Change the setting of the parameter.




- 1. For a parameter for a numeric setting, input the numeric setting.
- 2. If the parameter requires selection of a function, select the function from the list of selections.
- **5.** Press the **Enter** Key.

The background of the edited parameter cell will change to green.


#### 5.1.3 Setting Methods for SERVOPACK Parameters

6. Select Edited Parameters in the Write to Servo Group.



The edited parameters are written to the SERVOPACK and the backgrounds of the cells change to white.

#### 7. Click the OK Button.



**8.** To enable changes to the settings, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to set the parameters.

# Setting SERVOPACK Parameters with a Digital Operator

Refer to the following manual for information on setting the SERVOPACK parameters with a Digital Operator.

Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

# Setting SERVOPACK Parameters with EtherCAT (CoE) Communications

You can set objects 2000 hex to 26FF hex with EtherCAT(CoE) communications to set the SERVOPACK parameters (Pn000 to Pn6FF).

Object index 2000 hex corresponds to SERVOPACK parameter number Pn000.

Example Index 2100 hex is the same as parameter number Pn100 (2100 hex = Pn100).

When you use EtherCAT (CoE) communications objects, you must write the SERVOPACK parameters to non-volatile memory.

To write the SERVOPACK parameters to non-volatile memory, set the Store parameters field (1010 hex) object.

Refer to the following section for information on *Store parameters field* (1010 hex). 

\*\*Table 14.2 General Objects on page 14-5\*\*

# 5.1.4 Write Prohibition Setting for SERVOPACK Parameters

You can prohibit writing SERVOPACK parameters from a Digital Operator. Even if you do, you will still be able to change SERVOPACK parameter settings from the SigmaWin+ or with Ether-CAT (CoE) communications.

# **Preparations**

No preparations are required.

# **Applicable Tools**

The following table lists the tools that you can use to change the write prohibition setting for SERVOPACK parameters and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn010	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Write Prohibited Setting	© Operating Procedure on page 5-7

# **Operating Procedure**

Use the following procedure to prohibit or permit writing parameters.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Write Prohibition Setting in the Menu Dialog Box. The Write Prohibition Setting Dialog Box will be displayed.
- 3. Press the ▼ or ▲ for the rightmost digit and set one of the following. 0000: Writing is permitted (default setting). 0001: Writing is prohibited.




4. Click the Setting Button.



## 5.1.4 Write Prohibition Setting for SERVOPACK Parameters

**5.** Click the **OK** Button. The setting will be written to the SERVOPACK.



6. To enable the new setting, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to prohibit or permit writing parameter settings.

## 5.1.4 Write Prohibition Setting for SERVOPACK Parameters

# Restrictions

If you prohibit writing parameter settings, you will no longer be able to execute some functions. Refer to the following table.

	SigmaWin+	Digital Operator		When Writ-		
Button in Menu Dialog Box	SigmaWin+ Function Name	Fn No.	Utility Function Name	ing Is Pro- hibited	Reference	
	Origin Search	Fn003	Origin Search	Cannot be executed.	page 7-19	
	Absolute Encoder Reset	Fn008	Reset Absolute Encoder	Cannot be executed.	page 5-50	
	Adjusting the Analog Moni-	Fn00C	Adjust Analog Monitor Output Offset	Cannot be executed.	page 9-9	
	tor Output	Fn00D	Adjust Analog Monitor Output Gain	Cannot be executed.	page 9-9	
	Motor Current Detection	Fn00E	Autotune Motor Current Detection Signal Offset	Cannot be executed.	200 6 50	
	Offset Adjustment	Fn00F	Manually Adjust Motor Current Detection Signal Offset	Cannot be executed.	page 6-50	
	Multiturn Limit Setting	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm	Cannot be executed.	page 6-37	
Setup	Reset Configuration Error of Option Module	Fn014	Reset Option Module Configuration Error	Cannot be executed.	page 15-42	
	Vibration Detection Level Initialization	Fn01B	Initialize Vibration Detection Level	Cannot be executed.	page 6-46	
	Set Origin	Fn020	Set Absolute Linear Encoder Origin	Cannot be executed.	page 5-52	
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm	Cannot be executed.	page 5-13	
	Software Reset	Fn030	Software Reset	Can be executed.	page 6-44	
	Polarity Detection	Fn080	Polarity Detection	Cannot be executed.	page 5-25	
	Tuning-less Level Setting	Fn200	Tuning-less Level Setting	Cannot be executed.	page 8-16	
	EasyFFT	Fn206	Easy FFT	Cannot be executed.	page 8-92	
Parameters	Initialize*	Fn005	Initialize Parameters	Cannot be executed.	page 5-10	
	Autotuning without Reference Input	Fn201	Advanced Autotuning with- out Reference	Cannot be executed.	page 8-23	
	Autotuning with Reference Input	Fn202	Advanced Autotuning with Reference	Cannot be executed.	page 8-34	
Tuning	Custom Tuning	Fn203	One-Parameter Tuning	Cannot be executed.	page 8-41	
	Anti-Resonance Control Adjustment	Fn204	Adjust Anti-resonance Control	Cannot be executed.	page 8-50	
	Vibration Suppression	Fn205	Vibration Suppression	Cannot be executed.	page 8-55	

Continued on next page.

#### 5.1.5 Initializing SERVOPACK Parameter Settings

Continued from previous page.

	SigmaWin+  Button in Menu Dialog Box  SigmaWin+ Function Name		Digital Operator	When Writ-		
Menu			Utility Function Name	ing Is Pro-	Reference	
		Fn011	Display Servomotor Model	Can be executed.		
Monitor	Product Information	Fn012	Display Software Version	Can be executed.		
MOTITO	Froduct information	Fn01E	Display SERVOPACK and Servomotor IDs	Can be executed.	page 9-2	
		Fn01F	Display Servomotor ID from Feedback Option Module	Can be executed.		
Test Opera-	Jogging	Fn002	Jog	Cannot be executed.	page 7-7	
tion	Program Jogging	Fn004	Jog Program	Cannot be executed.	page 7-13	
Alarm	Display Alarm	Fn000	Display Alarm History	Can be executed.	page 15-40	
	ыэріау Аіапп	Fn006	Clear Alarm History	Cannot be executed.	page 15-41	

<sup>\*</sup> An Initialize Button is displayed in the Parameter Editing Dialog Box.

# 5.1.5 Initializing SERVOPACK Parameter Settings

You can return the SERVOPACK parameters to their default settings.

This function will not initialize the settings of the parameters that are adjusted for the Fn00C, Fn00D, Fn00E, and Fn00F utility functions.



To enable the new settings, turn the power supply to the SERVOPACK OFF and ON again after you complete the operation.

# **Preparations**

Check the following settings before you initialize the SERVOPACK parameter settings.

- The SERVOPACK parameters must not be write prohibited.
- The servo must be OFF.

# **Applicable Tools**


The following table lists the tools that you can use to initialize the SERVOPACK parameter settings and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn005	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Parameters - Edit Parameters	© Operating Procedure on page 5-11
EtherCAT Communications	Restore Default Parameters (1011 Hex)	Restore Default Parameters (1011 Hex) on page 14-7


## **Operating Procedure**

Use the following procedure to initialize the parameter settings.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Edit Parameters in the Menu Dialog Box. The Parameter Editing Dialog Box will be displayed.
- 3. Select any parameter of the axis to initialize.
- 4. Click the Initialize Button.



5. Click the OK Button.



Click the Cancel Button to cancel initialization. The Parameter Editing Dialog Box will return.

6. Click the OK Button.



7. Turn the power supply to the SERVOPACK OFF and ON again after the parameter settings have been initialized.

This concludes the procedure to initialize the parameter settings.

# 5.2

# Power Supply Type Settings for the Main Circuit

A SERVOPACK can operate on either an AC power supply input or DC power supply input to the main circuits. This section describes the settings related to the power supply.

Set Pn001 = n. \(\Pi\X\) \(\Pi\) (Main Circuit Power Supply AC/DC Input Selection) to specify whether to use an AC or DC power supply input for the main circuit power supply to the SERVOPACK.

If the setting of Pn001 =  $n.\Box X\Box\Box$  does not agree with the actual power supply input, an A.330 alarm (Main Circuit Power Supply Wiring Error) will occur.

Example

Examples of When an A.330 Alarm (Main Circuit Power Supply Wiring Error) Occurs

- A DC power supply is connected between the B1 and ⊕2 terminals, but an AC power supply input is specified (Pn001 = n.□0□□).
- An AC power supply is input to the L1, L2, and L3 terminals, but a DC power supply is specified (Pn001 = n.□1□□).

Para	ameter	Meaning	When Enabled	Classification
Pn001 (2001 hex)	n.□0□□ (default set- ting)	Use an AC power supply input.	After restart	Setup
	n.🗆1🗆 🗆	Use a DC power supply input.		

# **MARNING**

- Connect the AC or DC power supplies to the specified SERVOPACK terminals.
  - Connect an AC power supply to the L1, L2, and L3 terminals on the SERVOPACK.

There is a risk of failure or fire.

- Always specify a DC power supply input (Pn001 = n.□1□□) before you input DC power for the main circuit power supply.
  - If you input DC power without specifying a DC power supply input (i.e., without setting Pn001 to  $n.\Box 1\Box\Box$ ), the SERVOPACK's internal elements may burn and may cause fire or damage to the equipment.
- With a DC power supply input, time is required to discharge electricity after the main power supply is turned OFF. A high residual voltage may remain in the SERVOPACK after the power supply is turned OFF. Be careful not to get an electric shock.
- Install fuses on the power supply line if you use DC power.
- The Servomotor returns regenerative energy to the power supply. If you use a SERVOPACK
  with a DC power supply input, regenerative energy is not processed. Process the regenerative energy at the power supply.

Refer to the following section for information on wiring the SERVOPACK.

4.3.4 Power Supply Wiring Diagrams on page 4-15

# 5.3 Automatic Detection of Connected Motor

You can use a SERVOPACK to operate either a Rotary Servomotor or a Linear Servomotor. If you connect the Servomotor encoder to the CN2 connector on the SERVOPACK, the SERVOPACK will automatically determine which type of Servomotor is connected. Therefore, you normally do not need to specify the motor type.

Information

If an encoder is not connected, e.g., for a test without a motor, you can specify a Rotary Servomotor or a Linear Servomotor in  $Pn000 = n.X \square \square \square$  (Rotary/Linear Startup Selection When Encoder Is Not Connected). If you specify either a Rotary or Linear Servomotor, only the parameters, monitors, alarms, and functions for the specified motor type will be enabled.

Parameter		Meaning	When Enabled	Classification
n.0□□□ Pn000 (default setting)		When an encoder is not connected, start as SERVOPACK for Rotary Servomotor.	After restart	Catura
(2000 hex)	n.1□□□	When an encoder is not connected, start as SERVOPACK for Linear Servomotor.	Alter restait	Setup

# 5.4

# **Motor Direction Setting**

You can reverse the direction of Servomotor rotation by changing the setting of  $Pn000 = n.\Box\Box\BoxX$  (Direction Selection) without changing the polarity of the speed or position reference. This causes the rotation direction of the motor to change, but the polarity of the signals, such as encoder output pulses, output from the SERVOPACK do not change. Set the appropriate direction for your system.

Refer to the following section for details on the encoder divided pulse output. 6.5 Encoder Divided Pulse Output on page 6-18

#### Rotary Servomotors

The default setting for forward rotation is counterclockwise (CCW) as viewed from the load end of the Servomotor.

I	Parameter Forward/Reverse Reference Motor Direction and Encoder Divided Pulse Outputs			Applicable Overtravel Signal (OT)
	n.□□□0 Use CCW as the forward direction. (default setting)	Forward reference	Torque reference Encoder Divided Pulse Outputs  PAO Phase-B lead	P-OT (For- ward Drive Prohibit) sig- nal
Pn000 (2000		Reverse reference	Torque reference Encoder Divided Pulse Outputs PAO TIME PAO Phase-A lead CW Motor speed PBO PBO	N-OT (Reverse Drive Pro- hibit) signal
hex)	n.□□□1 Use CW as the forward direction. (Reverse Rotation Mode)	Forward reference	Time PAO Phase-B lead	P-OT (Forward Drive Prohibit) signal
		Reverse reference	Torque reference Encoder Divided Pulse Outputs PAO The Phase-A lead Motor speed PBO PBO	N-OT (Reverse Drive Pro- hibit) signal

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the torque reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

#### Linear Servomotors

Before you set this parameter, make sure that Pn080 = n. \$\square\$ (Motor Phase Sequence Selection) is set correctly.

Parameter			Forward/Reverse Reference	•	Motor Moving Direction and Encoder Divided Pulse Outputs		
		n.□□□0 Use the direction in which the linear encoder counts up as the forward direction. (default setting)	Forward reference	Moves in the count-up direction.	Encoder Divided Pulse Outputs PAO TOTAL PBO Phase-B lead	P-OT (For- ward Drive Prohibit) signal	
	Pn000		Reverse reference	Moves in the count-down direction.  Force reference Time Motor speed	Encoder Divided Pulse Outputs PAO Phase-A lead PBO PBO	N-OT (Reverse Drive Prohibit) signal	
	(2000 hex)	n.□□□1 Use the direction in which the linear encoder counts down as the forward direction.	Forward reference	Moves in the count-down direction.  Force reference  Time  Motor speed	Encoder Divided Pulse Outputs PAOPBOPhase-B lead	P-OT (For- ward Drive Prohibit) signal	
			Reverse reference	Moves in the count-up direction.	Encoder Divided Pulse Outputs PAO Phase-A lead	N-OT (Reverse Drive Prohibit) signal	

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the force reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

# 5.5 Setting the Linear Encoder Pitch

If you connect a linear encoder to the SERVOPACK through a Serial Converter Unit, you must set the scale pitch of the linear encoder in Pn282.

If a Serial Converter Unit is not connected, you do not need to set Pn282.



#### Serial Converter Unit

The Serial Converter Unit converts the signal from the linear encoder into a form that can be read by the SERVOPACK.

Term

#### Scale Pitch

A linear encoder has a scale for measuring lengths (positions). The length of one division on this scale is the scale pitch.

Pn282	Linear Encoder Pit	ch	Speed Po	osition Force	
(2282	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 6,553,600	0.01 μm	0	After restart	Setup

You will not be able to control the Linear Servomotor if Pn282 is not set correctly. Check the above table and always set the correct value before you operate the Linear Servomotor.

Type of Linear Encoder	Manufacturer	Model	Serial Converter Unit Model	Linear Encoder Pitch [μm]
	Heidenhain Corporation	LIDA48□	JZDP-H003-□□□-E	20
			JZDP-J003-□□□-E	20
Ingramantal		LIF48□	JZDP-H003-□□□-E	4
Incremental			JZDP-J003-□□□-E	4
	Ponjohow DLC	DCHOOD	JZDP-H005-□□□-E	20
	Renishaw PLC	RGH22B	JZDP-J005-□□□-E	20

The first time you supply power to the SERVOPACK, the panel display on the front of the Servomotor will display an A.080 alarm (Linear Encoder Pitch Setting Error). The A.080 alarm is displayed because the setting of Pn282 has not been changed. The A.080 alarm will be cleared when you change the setting of Pn282 and then turn the power supply OFF and ON again.



#### Linear Encoder Pitch

If you do not use a Serial Converter Unit, the linear encoder pitch is automatically set. It is not necessary to set Pn282. You can use the SigmaWin+ to check the linear encoder pitch that was automatically set. Refer to the following section for details.

9.1 Monitoring Product Information on page 9-2


# 5.6

# **Writing Linear Servomotor Parameters**

If you connect a linear encoder to the SERVOPACK without going through a Serial Converter Unit, you must use the SigmaWin+ to write the motor parameters to the linear encoder. The motor parameters contain the information that is required by the SERVOPACK to operate the Linear Servomotor.

# **MARNING**

• Check the motor and linear encoder information before you write the motor parameters. If you do not write the correct motor parameters, the motor may run out of control or burning may occur, possibly resulting in equipment damage or fire.





## **Precautions**

- If the encoder parameters are not written to the linear encoder, an A.CAO alarm (Encoder Parameter Error) will occur. Consult the manufacturer of the linear encoder.
- If the motor parameters are not written to the linear encoder, an A.CAO alarm (Encoder Parameter Error) will not occur, but the following alarms will occur.
  - A.040 (Parameter Setting Error), A.041 (Encoder Output Pulse Setting Error),
  - A.050 (Combination Error), A.051 (Unsupported Device Alarm),
  - A.550 (Maximum Speed Setting Error), A.710 (Instantaneous Overload),
  - A.720 (Continuous Overload), and A.C90 (Encoder Communications Error)

# **Applicable Tools**


The following table lists the tools that you can use to write the parameters to the Linear Servomotor and the applicable tool functions.

Tool	Function	Reference	
Digital Operator	You cannot write Linear Servomotor parameters from the Digital Operator.		
SigmaWin+	Setup - Motor Parameters	© Operating Procedure on page 5-17	

## **Operating Procedure**

Use the following procedure to write the motor parameters to the linear encoder.


- 1. Prepare the motor parameter file to write to the linear encoder.
- 2. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Motor Parameter Scale Write in the Menu Dialog Box. The Motor Parameter Scale Write Dialog Box will be displayed.
- 4. Click the OK Button.




Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

If the write is completed normally, the Motor Parameter Scale Write - File Select Dialog Box will be displayed.


5. Click the Ref. Button.



6. Select the motor parameter file that you prepared and click the Open Button.




7. Confirm that the motor parameter file information that is displayed is suitable for your motor, and then click the **Next** Button.




Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

8. Click the Write Button.




#### 9. Click the Yes Button.




Click the **No** Button to cancel writing the motor parameters to the linear encoder.

If you click the Yes Button, writing the motor parameter scale will start.

#### 10. Click the Complete Button.



## 11. Click the OK Button.



12. Turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to write the motor parameters.

# Confirming If the Motor Parameters Have Been Written

After you write the motor parameters, you can use a monitor function to confirm that the motor parameters are in the encoder.

If the motor parameters have not been written, no information on the Servomotor will be displayed.

9.1 Monitoring Product Information on page 9-2

# 5.7

# Selecting the Phase Sequence for a Linear Servomotor

You must select the phase sequence of the Linear Servomotor so that the forward direction of the Linear Servomotor is the same as the encoder's count-up direction.

Before you set the Linear Servomotor phase sequence ( $Pn080 = n.\square\square X\square$ ), check the following items.

- Confirm that the signal from the linear encoder is being received normally.
- Make sure that the forward direction of the Linear Servomotor and the count-up direction of the linear encoder are in the same direction.



If you do not confirm the above items before you attempt to operate the motor, the motor may not operate or it may run out of control. Always confirm these items before you operate the motor.

#### · Related Parameters

Parameter Meaning		When Enabled	Classification	
Pn080 (2080	n.□□0□ (default setting)	Set a phase-A lead as a phase sequence of U, V, and W.	After restart	Setup
hex)	n.□□1□	Set a phase-B lead as a phase sequence of U, V, and W.		

#### Setting Procedure

- 1. Set Pn000 to n.□□□0 (Set a phase-A lead as a phase sequence of U, V, and W). This setting is to make following confirmation work easier to understand.
- 2. Select Monitor in the Menu Dialog Box.


The Operation Pane will be displayed so that you can check the feedback pulse counter. To check the feedback pulse counter with the Digital Operator, use Un00D (Feedback Pulse Counter).

**3.** Manually move the Moving Coil from one end to the other of the stroke and confirm that only the correct number of feedback pulses is returned.

If the correct number and only the correct number of pulses is returned, the signal is being received correctly from the linear encoder.

Example

In this example, assume that a linear encoder with a scale pitch of 20  $\mu m$  and a resolution of 256 is used. If you manually move the Moving Coil 1 cm in the count-up direction of the linear encoder, the number of feedback pulses would be as follows: 1 cm/(20  $\mu m/256)$  = 128,000 pulses




If there are 128,000 pulses on the feedback pulse counter after you manually move the Moving Coil in the direction of the cable, you have completed the confirmation.

Note: The actual monitor display will be offset by the error in the travel distance. There is no problem as long as the above value is close to the calculated value.

#### Information

If the correct value is not displayed for the feedback pulse counter, the following conditions may exist. Check the situation and correct any problems.

- The linear encoder pitch is not correct.
   If the scale pitch that is set in Pn282 does not agree with the actual scale pitch, the expected number of feedback pulses will not be returned. Check the specifications of the linear encoder.
- The linear encoder is not adjusted properly.
   If the linear encoder is not adjusted properly, the output signal level from the linear encoder will drop and the correct number of pulses will not be counted. Check the adjustment of the linear encoder. Contact the manufacturer of the linear encoder for details.
- There is a mistake in the wiring between the linear encoder and the Serial Converter Unit.
  - If the wiring is not correct, the correct number of pulses will not be counted. Correct the wiring.
- 4. Manually move the Moving Coil in the direction of the cable and check the value of the feedback pulse counter in the Operation Pane to confirm that it is counting up. If the pulses are counted up, the forward direction of the Linear Servomotor is the same as the count-up direction of the linear encoder.



- 5. If the feedback pulse counter counts down, set a phase-B lead as a phase sequence of U, V, and W (Pn080 = n.□□1□) and turn the power supply OFF and ON again.
- **6.** If necessary, return  $Pn000 = n.\Box\Box\Box X$  (Direction Selection) to its original setting.

This concludes the procedure to set the phase sequence of the Linear Servomotor.

# 5.8

# **Polarity Sensor Setting**

The polarity sensor detects the polarity of the Servomotor. You must set a parameter to specify whether the Linear Servomotor that is connected to the SERVOPACK has a polarity sensor. Specify whether there is a polarity sensor in  $Pn080 = n.\square\square\square\square X$  (Polarity Sensor Selection).

If the Linear Servomotor has a polarity sensor, set Pn080 to n. \$\square\$ (Use polarity sensor) (default setting).

If the Linear Servomotor does not have a polarity sensor, set Pn080 to n. \$\square\$ 1 (Do not use polarity sensor). Turn the power supply OFF and ON again to enable the new setting.

Parameter		Meaning	When Enabled	Classification
Pn080 (2080	Use polarity sensor.		After restart	Setup
hex)	n.□□□1	Do not use polarity sensor.		

Information

If you set Pn080 to n. \$\square\$ old (Use polarity sensor) and the Linear Servomotor that is connected to the SERVOPACK does not have a polarity sensor, an A.C21 alarm (Polarity Sensor Error) will occur when you turn the power supply OFF and ON again.

# 5.9 Polarity Detection

If you use a Linear Servomotor that does not have a polarity sensor, then you must detect the polarity.

Detecting the polarity means that the position of the electrical phase angle on the electrical angle coordinates of the Servomotor is detected. The SERVOPACK cannot control the Servomotor correctly unless it accurately knows the position of the electrical angle coordinate of the Servomotor.

The execution timing and execution method for polarity detection depend on the encoder specification as described in the following table.

Encoder Specification	Polarity Detection Execution Timing	Polarity Detection Execution Method
Incremental encoder	Each time the control power supply to the SERVOPACK is turned ON (Even after you execute polarity detec- tion, the position of the polarity will be lost the next time the control power supply to the SERVOPACK is turned OFF.)	<ul> <li>Use the Servo ON command (Enable Operation command).</li> <li>Use the polarity detection function of the SigmaWin+.</li> <li>Execute the Fn080 (Polarity Detection) utility function from the Digital Operator.</li> </ul>
Absolute encoder	Only for initial setup, or after the SER-VOPACK, linear encoder, or motor has been replaced (The results of polarity detection is stored in the absolute encoder, so the polarity position is not lost when the control power supply is turned OFF.)	<ul> <li>Use the polarity detection function of the SigmaWin+.</li> <li>Execute the Fn080 (Polarity Detection) utility function from the Digital Opera- tor.</li> </ul>

Information

If you use a Linear Servomotor that does not have a polarity sensor, you will not be able to turn ON the servo until polarity detection has been completed.

# 5.9.1 Restrictions

## **Assumed Conditions**

The Servomotor will move when you execute polarity detection. The following conditions must be met before you start.

- It must be OK to move the Moving Coil about 10 mm.
   (If polarity detection fails, the Moving Coil may move approximately 5 cm. The amount of movement depends on conditions.)
- The linear encoder pitch must be 100  $\mu m$  or less. (We recommend a pitch of 40  $\mu m$  or less for an incremental encoder.)
- As much as possible, the motor must not be subjected to an imbalanced external force. (We recommend 5% or less of the rated force.)
- The mass ratio must be 50x or less.
- The axis must be horizontal.
- There must be friction equivalent to a few percent of the rated force applied to the guides. (Air sliders cannot be used.)

# **Preparations**

Check the following settings before you execute polarity detection.

- Not using a polarity sensor must be specified (Pn080 = n.□□□1).
- The servo must be OFF.
- The main circuit power supply must be ON.
- There must be no hard wire base block (HWBB).
- There must be no alarms except for an A.C22 alarm (Phase Information Disagreement).

#### 5.9.2 Using the Servo ON Command (Enable Operation Command) to Perform Polarity Detection

- The parameters must not be write prohibited. (This item applies only when using the SigmaWin+ or Digital Operator.)
- The test without a motor function must be disabled (Pn00C = n.□□□0).
- There must be no overtravel.
- If the motor parameters have been written or the origin of the absolute linear encoder has been set, the power supply to the SERVOPACK must be turned OFF and ON again after completion of the writing or setting operation.




 Power is supplied to the Servomotor during polarity detection. Be careful not to get an electric shock. Also, the Moving Coil of the Linear Servomotor may greatly move during detection. Do not approach the moving parts of the Servomotor.

Polarity detection is affected by many factors.For example, polarity detection may fail if the mass ratio or friction is too large or the cable tension is too strong.

# 5.9.2 Using the Servo ON Command (Enable Operation Command) to Perform Polarity Detection

You can use the Servo ON command (Enable Operation command) to perform polarity detection only with an incremental linear encoder.

Polarity detection will start simultaneously with execution of the Servo ON command (Enable Operation command). As soon as polarity detection is completed, the /S-RDY will turn ON and the servo will change to ON status (statusword = operation enabled).



# 5.9.3 Using a Tool Function to Perform Polarity Detection

## **Applicable Tools**


The following table lists the tools that you can use to perform polarity detection and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn080	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Polarity Detection	© Operating Procedure on page 5-25

# **Operating Procedure**

Use the following procedure to perform polarity detection.

- 1. Click the P Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Polarity Detection in the Menu Dialog Box. The Polarity Detection Dialog Box will be displayed.
- 3. Click the Continue Button.



Click the Cancel Button to cancel polarity detection. The Main Window will return.

4. Click the Start Button.

Polarity detection will be executed.



This concludes the polarity detection procedure.

5.10.1 Overtravel Signals

# 5.10


# **Overtravel and Related Settings**

Overtravel is a function of the SERVOPACK that forces the Servomotor to stop in response to a signal input from a limit switch that is activated when a moving part of the machine exceeds the safe range of movement.

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.

You use the P-OT and N-OT signals to stop the machine by installing limit switches at the positions where you want to stop the machine that is operated by the Servomotor.

A SERVOPACK wiring example is provided below.



Using the overtravel function is not necessary for rotating applications such as rotary tables and conveyors. No wiring for overtravel input signals is required.

This section describes the parameters settings related to overtravel.

# **A** CAUTION

- To prevent accidents that may result from contact faults or disconnections, use normally closed limit switches.
  - Do not change the default settings of the polarity of the overtravel signals (P-OT and N-OT).
- If you use a Servomotor for a vertical axis, the /BK (Brake) signal will remain ON (i.e., the brake will be released) when overtravel occurs. This may result in the workpiece falling when overtravel occurs. To prevent the workpiece from falling, set Pn001 to n.□□1□ to place the Servomotor in a zero-clamped state when it stops.
- A base block state is entered after stopping for overtravel. This may cause the Servomotor to be pushed back by an external force on the load shaft. To prevent the Servomotor from being pushed back, set Pn001 to n.□□1□ to place the Servomotor in a zero-clamped state when it stops.

# 5.10.1 Overtravel Signals

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Input P-OT N-OT		CN1-7	ON	Forward drive is enabled (actual operation).
	P-OT		OFF	Forward drive is prohibited (forward overtravel).
	N-OT (	CN1-8	ON	Reverse drive is enabled (actual operation).
			OFF	Reverse drive is prohibited (reverse overtravel).

You can operate the Servomotor in the opposite direction during overtravel by inputting a reference.

# 5.10.2 Setting to Enable/Disable Overtravel

You can use  $Pn50A = n.X \square \square \square$  (P-OT (Forward Drive Prohibit) Signal Allocation) and  $Pn50B = n.\square \square \square \square X$  (N-OT (Reverse Drive Prohibit) Signal Allocation) to enable and disable the overtravel function.

You do not need to wire the overtravel input signals if you are not going to use the overtravel function.

F	arameter	Meaning	When Enabled	Classification	
Pn50A (250A hex)	n.1□□□ (default setting)	The forward overtravel function is enabled and the P-OT (Forward Drive Prohibit) signal is input from CN1-7.			
	n.8□□□	The reverse overtravel function is disabled. Forward drive is always enabled.	After restart	Catus	
Pn50B (250B hex)	n.□□□2 (default setting)	The reverse overtravel function is enabled and the N-OT (Reverse Drive Prohibit) signal is input from CN1-8.	Aller restart	Setup	
	n.□□□8	The reverse overtravel function is disabled. Reverse drive is always enabled.			

You can allocate the P-OT and N-OT signals to other connector pins. Refer to the following section for details.

6.1.1 Input Signal Allocations on page 6-4

# 5.10.3 Motor Stopping Method for Overtravel

You can set the stopping method of the Servomotor when overtravel occurs in Pn001 = n.□□XX (Servo OFF or Alarm Group 1 Stopping Method and Overtravel Stopping Method).

ı	Parameter	Motor Stopping Method*	Status after Stopping	When Enabled	Classification
Pn001 (2001 hex)	n.□□00 (default setting)	Dynamic brake	Coasting		Setup
	n.□□01			After restart	
	n.□□02	Coasting			
	n.□□1□	Deceleration according to setting of Pn406 (2406 hex)	Zero clamp		
	n.□□2□		Coasting		
	n.□□3□	Deceleration	Zero clamp		
	n.□□4□	according to setting of Pn30A (230A hex)	Coasting		

<sup>\*</sup> You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop (according to the setting of Pn001 = n.□□□X (Servo OFF or Alarm Group 1 Stopping Method)), and then the Servomotor will enter a coasting state.

Refer to the following section for information on stopping methods other than those for overtravel.

5.12.1 Stopping Method for Servo OFF on page 5-38

5.10.3 Motor Stopping Method for Overtravel

# Stopping the Servomotor by Setting Emergency Stop Torque

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If  $Pn001 = n.\Box\Box X\Box$  is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

Pn406	Emergency Stop Torque			Speed Positio	n
(2406	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	800	Immediately	Setup

<sup>\*</sup> Set a percentage of the motor rated torque.


# Stopping the Servomotor by Setting the Deceleration Time

To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

Pn30A	Deceleration Time for	or Servo OFF and Fo	Speed Position	า	
(230A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 ms	0	Immediately	Setup

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the motor from the maximum motor speed.



## 5.10.4 Overtravel Warnings

You can set the system to detect an A.9A0 warning (Overtravel) if overtravel occurs while the servo is ON. This allows the SERVOPACK to notify the host controller with a warning even when the overtravel signal is input only momentarily. An alarm occurs only if overtravel occurs while the servo is ON. An overtravel warning will not be detected when the servo is OFF, even if overtravel occurs.




- 1. The occurrence of an A.9A0 warning will not stop the motor or have any effect on host controller motion operations. The next step (e.g., the next motion or command) can be executed even if an overtravel warning exists.
- However, depending on the processing specifications and programming for warnings in the host controller, operation may be affected when an overtravel warning occurs (e.g., motion may stop or not stop). Confirm the specifications and programming in the host controller.
- 2. When overtravel occurs, the SERVOPACK will perform stop processing for overtravel. Therefore, when an A.9A0 warning occurs, the Servomotor may not reach the target position specified by the host controller. Check the feedback position to make sure that the axis is stopped at a safe position.

The following parameter is set for this function.

Parameter		Meaning	When Enabled	Classification
Pn00D (200D	n.0□□□ (default setting)	Do not detect overtravel warnings.	Immediately	Setup
hex)	n.1□□□	Detect overtravel warnings.		

A timing chart for warning detection is provided below.



### Information

- 1. Warnings are detected for overtravel in the same direction as the reference.
- Warnings are not detected for overtravel in the opposite direction from the reference. Example: A warning will not be output for a forward reference even if the N-OT signal turns ON.
- A warning can be detected in either the forward or reverse direction if there is no reference.
- A warning will not be detected when the servo is turned ON even if overtravel status exists.
- 5. You can use the ALM\_CLR (Clear Alarms and Warnings) command to clear the warning regardless of the servo ON/OFF status and overtravel signal status.
- 6. If you clear the warning with the Fault Reset command during overtravel status, a warning will not be detected again until the overtravel status is left.
- 7. An overtravel warning will be detected even when the software limit has been detected.


### 5.10.5 Overtravel Release Method Selection

You can set Pn022 = n. \(\subseteq \subseteq \text{X}\) (Overtravel Release Method Selection) to release overtravel. Internal limit active (bit 11) in statusword changes to 1 during overtravel. The motor will not be driven if there is overtravel in the same direction as the reference.


Parameter Mean		Meaning	When Enabled	Classification
Pn022	n.□□□0 (default setting)	Overtravel exists while the P-OT or N-OT signal is being input.		
(2022 hex)	n.□□□1	Overtravel exists while the P-OT or N-OT signal is input and the current position of the workpiece is separated* from the P-OT signal or N-OT signal.	After restart	Setup

<sup>\*</sup> Here, "separated" means a position that is further in the positive direction than the P-OT signal or a position that is further in the negative direction than the N-OT signal.

### When Pn022 Is Set to n.□□□0



### When Pn022 Is Set to n.□□□1



## 5.10.6 Overtravel Status

If an overtravel signal is input, the following SERVOPACK status will change to 1 and the Servomotor will be stopped according to the overtravel stopping method set in Pn001. When the overtravel signal is reset, the status changes to 0.

Internal limit active (bit 11) in statusword (6041 hex)

Negative limit switch (bit 0) or positive limit switch (bit 1) in digital inputs (60FD hex)

## 5.10.7 Overtravel Operation by Mode


Operation Mode	Operation
Profile position mode	<ul> <li>If an overtravel signal is input, the positioning operation to the current target position will be canceled and, after the motor stops, target reached in statusword will be reset.</li> <li>A positioning operation (return operation) is started only when a movement reference to a target position in the opposite direction from the overtravel signal is specified in the current Position Actual Value (e.g., a negative movement reference if the P-OT signal is input).</li> </ul>
Homing mode	<ul> <li>For Homing Method 1, 11, 12, 13, 14, 28, or 34: If the P-OT signal is input, homing error (bit 13) in statusword (6041 hex) changes to 1 and the homing operation is canceled.</li> <li>For Homing Method 2, 7, 8, 9, 10, 24, or 33: If the N-OT signal is input, homing error (bit 13) in statusword (6041 hex) changes to 1 and the homing operation is canceled.</li> </ul>
Interpolated position mode, Cyclic synchronous posi- tion mode	<ul> <li>If an overtravel signal is input, the positioning operation to the current target position will be canceled and, after the motor stops, target reached in statusword will be reset.</li> <li>A positioning operation (return operation) is started only when a movement reference to a target position in the opposite direction from the overtravel signal is specified in the current position actual value (e.g., a negative movement references if the P-OT signal is input).</li> </ul>
Profile velocity mode, Cyclic synchronous velocity mode	During overtravel, the motor is operated only when a speed in the direction opposite from the overtravel signal is specified (e.g., a negative target speed when the P-OT signal is input).
Profile torque mode, Cyclic synchronous torque mode	During overtravel, torque is applied only when a torque in the direction opposite from the overtravel signal is specified (e.g., a negative torque when the P-OT signal is input).

### 5.11.1 Brake Operating Sequence

## 5.11 Holding Brake

A holding brake is used to hold the position of the moving part of the machine when the SER-VOPACK is turned OFF so that moving part does not move due to gravity or an external force. You can use the brake that is built into a Servomotor with a Brake, or you can provide one on the machine.

The holding brake is used in the following cases.





The brake built into a Servomotor with a Brake is a de-energization brake. It is used only to hold the Servomotor and cannot be used for braking. Use the holding brake only to hold a Servomotor that is already stopped.

## 5.11.1 Brake Operating Sequence

You must consider the time required to release the brake and the time required to brake to determine the brake operation timing, as described below.




#### Time Required to Release Brake

The time from when the /BK (Brake) signal is turned ON until the brake is actually released.

### Time Required to Brake

The time from when the /BK (Brake) signal is turned OFF until the brake actually operates.



\*1. Rotary Servomotors: The brake delay times for Servomotors with Holding Brakes are given in the following table. The operation delay times in the following table are examples for when the power supply is switched on the DC side. You must evaluate the actual brake delay times on the actual equipment before using the application

Model	Voltage	Time Required to Release Brake [ms]	Time Required to Brake [ms]
SGM7J-02, -04		60	
SGM7J-08, -15		80	100
SGM7A-02, -04		60	100
SGM7A-08, -10		80	
SGM7A-15 to -25		170	
SGM7A-30 to -50		100	80
SGM7G-05 to -20		100	
SGM7G-30, -44		170	100

Linear Servomotors: The brake delay times depend on the brake that you use. Set the parameters related to /BK signal output timing according to the delay times for the brake that you will actually use.

- \*2. Before you output a reference from the host controller to the SERVOPACK, wait for at least 50 ms plus the time required to release the brake after you send the Servo ON command (Enable Operation command).
- \*3. Use the following parameters to set the timing of when the brake will operate and when the servo will be turned
  - Rotary Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn507 (Brake Reference Output
  - Speed Level), and Pn508 (Servo OFF-Brake Reference Waiting Time)

    Linear Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn508 (Servo OFF-Brake Reference Waiting Time), and Pn583 (Brake Reference Output Speed Level)

Note: The brake operation delay time on SERVOPACKs with built-in Servomotor brake control is somewhat longer than the time required on SERVOPACKs without built-in Servomotor brake control. Consider the brake operation delay time when you design the system.

## **Connection Examples**

Refer to the following section for information on brake wiring. 4.4.4 Wiring the SERVOPACK to the Holding Brake on page 4-25

#### 5.11.2 /BK (Brake) Signal

The following settings are for the output signal that controls the brake. You can change the connector pin that is allocated. For details, refer to Allocating the /BK (Brake) Signal. The /BK signal is turned OFF (to operate the brake) when the servo is turned OFF or when an alarm is detected. You can adjust the timing of brake operation (i.e., the timing of turning OFF the /BK signal) with the servo OFF delay time (Pn506).

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output /BK	/BK	CNI4 4 CNI4 0	ON (closed)	Releases the brake.
Output	ut /BK CN1-1, CN1-2	OFF (open)	Activates the brake.	

Information The /BK signal will remain ON during overtravel. The brake will not be applied.

5.11.3 Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped

### Allocating the /BK (Brake) Signal

Set the allocation for the /BK signal in Pn50F =  $n.\Box X\Box\Box$  (/BK (Brake Output) Signal Allocation).

Parameter		Connector Pin No.		Meaning	When	Classification
		+ Pin	- Pin	Wearing	Enabled	Classification
	n.□0□□	-	-	The /BK signal is not used.		
Pn50F (250F	n.□1□□ (default set- ting)	CN1-1	CN1-2	The /BK signal is output from CN1-1 and CN1-2.	After restart	Setup
hex)	n.□2□□	CN1-23	CN1-24	The /BK signal is output from CN1-23 and CN1-24.	Alterrestart	Getup
	n.□3□□	CN1-25	CN1-26	The /BK signal is output from CN1-25 and CN1-26.		



If you allocate more than one signal to the same output connector pin, a logical OR of the signals is output. Allocate the /BK signal to its own output connector pin, i.e., do not use the same output terminal for another signal.


For example, never allocate the /TGON (Rotation Detection) signal and /BK signal to the same output connector pin. If you did so, the /TGON signal would be turned ON by the falling speed on a vertical axis, and the brake would not operate.

## 5.11.3 Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped

When the Servomotor is stopped, the /BK signal turns OFF as soon as the Servo OFF command (Disable Operation command) is received. Use the servo OFF delay time (Pn506) to change the timing to turn OFF power supply to the motor after the Servo OFF command (Disable Operation command) is input.

Pn506	Brake Reference-Servo OFF Delay Time			Speed Position	on Torque
(2506	Setting Range	Setting Unit	Default Setting	When Enabled Classification	
hex)	0 to 50	10 ms	0*	Immediately	Setup

- \* The default setting is 32 for a SERVOPACK with built-in Servomotor brake control.
- When the Servomotor is used to control a vertical axis, the machine moving part may move slightly due to gravity or an external force. You can eliminate this slight motion by setting the servo OFF delay time (Pn506) so that power supply to the motor is stopped after the brake is applied.
- This parameter sets the timing of stopping power supply to the Servomotor while the Servomotor is stopped.





Power supply to the Servomotor will be stopped immediately when an alarm occurs, regardless of the setting of this parameter. The machine moving part may move due to gravity or an external force before the brake is applied.

## 5.11.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

If an alarm occurs while the Servomotor is operating, the Servomotor will start stopping and the /BK signal will be turned OFF. You can adjust the timing of /BK signal output by setting the brake reference output speed level (Rotary Servomotors: Pn507, Linear Servomotors: Pn583) and the servo OFF-brake reference waiting time (Pn508).

Note: If zero-speed stopping is set as the stopping method for alarms, the setting of Pn506 (Brake Reference-Servo OFF Delay Time) is used after the motor stops.

Rotary Servomotors


Pn507	Brake Reference O	utput Speed Level		Speed Positi	on Torque
(2507	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 min <sup>-1</sup>	100	Immediately	Setup
Pn508	Servo OFF-Brake Reference Waiting Time Speed Position				on Torque
(2508	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	10 to 100	10 ms	50	Immediately	Setup

Linear Servomotors

Pn583	Brake Reference O	utput Speed Level	Speed Positi	on Force	
(2583	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 mm/s	10	Immediately	Setup
Pn508	Servo OFF-Brake Reference Waiting Time Speed Position Force			on Force	
(2508	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	10 to 100	10 ms	50	Immediately	Setup


The brake operates when either of the following conditions is satisfied:

 When the Motor Speed Goes below the Level Set in Pn507 for a Rotary Servomotor or in Pn583 for a Linear Servomotor after the Power Supply to the Motor Is Stopped



### 5.11.5 Built-in Brake Relay Usage Selection

• When the Time Set In Pn508 Elapses after the Power Supply to the Motor Is Stopped





The Servomotor will be limited to its maximum speed even if the brake reference output speed level (Rotary Servomotor: Pn507, Linear Servomotor: Pn583) is higher than the maximum speed.

## 5.11.5 Built-in Brake Relay Usage Selection

SERVOPACKs with built-in brake control contain a brake relay.

Set Pn023 = n.□□□X (Built-in Brake Relay Usage Selection) to specify whether to use the built-in brake relays.

Para	ameter	Description	When Enabled	Classification
Pn023 (2023 hex)	n.□□□0 (default setting)	Use the built-in brake relays.	After restart	Setup
(2023 HeX)	n.□□□1	Do not use the built-in brake relays.		

## 5.12

## Motor Stopping Methods for Servo OFF and Alarms

You can use the following methods to stop the Servomotor when the servo is turned OFF or an alarm occurs.

There are the following four stopping methods.

Motor Stopping Method	Meaning
Stopping by Applying the Dynamic Brake	The electric circuits are internally connected to stop the Servomotor quickly.
Coasting to a Stop	The motor stops naturally due to friction during operation.
Zero Clamping	The speed reference is set to 0 to stop the Servomotor quickly.
Decelerating to a Stop	Emergency stop torque is used to decelerate the motor to a stop.

There are the following three conditions after stopping.

Status after Stopping	Meaning
Dynamic Brake Applied	The electric circuits are internally connected to hold the Servomotor.
Coasting	The SERVOPACK does not control the Servomotor. (The machine will move in response to a force from the load.)
Zero Clamping	A position loop is created and the Servomotor remains stopped at a position reference of 0. (The current stop position is held.)



- The dynamic brake is used for emergency stops. The dynamic brake circuit will operate frequently if the power supply is turned ON and OFF or the servo is turned ON and OFF while a reference input is applied to start and stop the Servomotor. This may result in deterioration of the internal elements in the SERVOPACK. Use speed input references or position references to start and stop the Servomotor.
- If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor stopping method depends on the SERVOPACK model as shown in the following table.

	Servomotor Stopping Method				
Condition	SGD7S-1R9D, -3R5D, -5R4	ID, -8R4D, -120D, or -170D			
Condition	Built-in or External Dy	namic Brake Resistor			
	Not connected	Connected			
Main circuit power supply turned OFF before turning OFF the servo	Consting to a stop	Stopping with the dynamic broke			
Control power supply turned OFF before turning OFF the servo	Coasting to a stop	Stopping with the dynamic brake			

Note: The SGD7S-210D, -260D, -280D, and -370D do not have a built-in dynamic brake. They will always coast to a stop.

 To minimize the coasting distance of the Servomotor to come to a stop when an alarm occurs, zero-speed stopping is the default method for alarms to which it is applicable. However, depending on the application, stopping with the dynamic brake may be more suitable than zero-speed stopping.

For example, when coupling two shafts (twin-drive operation), machine damage may occur if a zero-speed stopping alarm occurs for one of the coupled shafts and the other shaft stops with a dynamic brake. In such cases, change the stopping method to the dynamic brake.

### 5.12.1 Stopping Method for Servo OFF

Set the stopping method for when the servo is turned OFF in Pn001 =  $n.\square\square\square\square X$  (Servo OFF or Alarm Group 1 Stopping Method).

To use the dynamic brake to stop the motor, set Pn001 to n. \(\sigma\) or n. \(\sigma\) \(\sigma\).

If you do not connect an external dynamic brake, set Pn001 to n. \(\sigma \sigma \sigma \) (Coast the motor to a stop without the dynamic brake).

Parameter		Servomotor Stop- ping Method	Status after Servo- motor Stops	When Enabled	Classifi- cation
Pn001	n.□□□0 (default setting)	Dynamic brake *	Dynamic brake *	A ft t t	0 - 1
(2001 hex)	n.□□□1		Coasting	After restart	Setup
	n.□□□2	Coasting	Coasting		

<sup>\*</sup> If the built-in or an External Dynamic Brake Resistor is not connected, the Servomotor will coast to a stop.

Note: If Pn001 is set to n. \(\sigma\) \(\sigma\) (Stop the motor by applying the dynamic brake) and the Servomotor is stopped or operates at a low speed, braking force may not be generated, just like it is not generated for coasting to a stop.

## 5.12.2 Servomotor Stopping Method for Alarms

There are two types of alarms, group 1 (Gr. 1) alarms and group 2 (Gr. 2) alarms. A different parameter is used to set the stopping method for alarms for each alarm type.

Refer to the following section to see which alarms are in group 1 and which are in group 2. 
15.2.1 List of Alarms on page 15-5

### Motor Stopping Method for Group 1 Alarms

When a group 1 alarm occurs, the Servomotor will stop according to the setting of Pn001 =  $n.\Box\Box\Box$ X. The default setting is to stop by applying the dynamic brake.

Refer to the following section for details.

5.12.1 Stopping Method for Servo OFF on page 5-38

## Motor Stopping Method for Group 2 Alarms

When a group 2 alarm occurs, the Servomotor will stop according to the settings of the following three parameters. The default setting is for zero clamping.

- Pn001 = n.□□□X (Servo OFF or Alarm Group 1 Stopping Method)
- Pn00A = n. □□□X (Motor Stopping Method for Group 2 Alarms)
- Pn00B = n.□□X□ (Motor Stopping Method for Group 2 Alarms)

However, during torque control, the group 1 stopping method is always used.

If you set Pn00B to n. \$\square\$ (Apply dynamic brake or coast Servomotor to a stop), you can use the same stopping method as group 1. If you are coordinating a number of Servomotors, you can use this stopping method to prevent machine damage that may result because of differences in the stopping method.

The following table shows the combinations of the parameter settings and the resulting stopping methods.

	Paramete	er	Servomotor	Status after	When	
Pn00B (200B hex)	Pn00A (200A hex)	Pn001 (2001 hex)	Stopping Method	Servomotor Stops	Enabled	Classification
n.□□0□		n.□□□0 (default setting)	Zero-speed stop-	Dynamic brake		
(default setting)	_	n.□□□1	ping	Coasting		
		n.□□□2				
n.0010	_	n.□□□0 (default setting)	Dynamic brake	Dynamic brake		
11.0010	_	n.□□□1		Coasting		
		n.□□□2	Coasting	o o		
	n.□□□0 (default setting)	n.□□□0 (default setting)	Dynamic brake	Dynamic brake		Setup
		n.□□□1		Coacting	After restart	
		n.□□□2	Coasting	Coasting		
	n.□□□1	n.□□□0 (default setting)		Dynamic brake		
		n.□□□1	Motor is deceler- ated using the	Coasting		
		n.□□□2	torque set in			
n.□□2□	n.□□□2	n.□□□0 (default setting) n.□□□1	Pn406 (2406 hex) as the maximum torque.			
		n.□□□2				
		n.□□□0 (default setting)		Dynamic brake		
	n.□□□3	n.□□□1	Motor is deceler-	Capatina		
		n.□□□2	ated according to	Coasting		
	- 0004	n.□□□0 (default setting)	setting of Pn30A (230A hex).	Constinu		
	n.□□□4	n.□□□1		Coasting		
		n.□□□2				

Note: 1. The setting of Pn00A is ignored if Pn001 is set to n.  $\square$   $\square$  0 or n.  $\square$   $\square$  1  $\square$ .

<sup>2.</sup> The setting of Pn00A = n. \(\sigma \square\) is enabled for position control and speed control. During torque control, the setting of Pn00A = n. \(\subset\) \(\supset \text{X}\) will be ignored and only the setting of Pn001 = n. \(\supset\) \(\supset \text{X}\) will be used.

<sup>3.</sup> Refer to the following section for details on Pn406 (Emergency Stop Torque).

Stopping the Servomotor by Setting Emergency Stop Torque on page 5-28

<sup>4.</sup> Refer to the following section for details on Pn30A (Deceleration Time for Servo OFF and Forced Stops).

Stopping the Servomotor by Setting the Deceleration Time on page 5-28

5.13.1 Detection Timing for Overload Warnings (A.910)

## 5.13

## **Motor Overload Detection Level**

The motor overload detection level is the threshold used to detect overload alarms and overload warnings when the Servomotor is subjected to a continuous load that exceeds the Servomotor ratings.


It is designed to prevent Servomotor overheating.

You can change the detection timing for A.910 warnings (Overload) and A.720 alarms (Continuous Overload). You cannot change the detection level for A.710 alarms (Instantaneous Overload).

## 5.13.1 Detection Timing for Overload Warnings (A.910)

With the default setting for overload warnings, an overload warning is detected in 20% of the time required to detect an overload alarm. You can change the time required to detect an overload warning by changing the setting of the overload warning level (Pn52B). You can increase safety by using overload warning detection as an overload protection function matched to the system.

The following graph shows an example of the detection of overload warnings when the overload warning level (Pn52B) is changed from 20% to 50%. An overload warning is detected in half of the time required to detect an overload alarm.



Pn52B	Overload Warning L	evel	Speed Position	Torque	
(252B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 100	1%	20	Immediately	Setup

## 5.13.2 Detection Timing for Overload Alarms (A.720)


If Servomotor heat dissipation is insufficient (e.g., if the heat sink is too small), you can lower the overload alarm detection level to help prevent overheating.

To reduce the overload alarm detection level, change the setting of Pn52C (Base Current Derating at Motor Overload Detection).

Pn52C	Base Current Derati	ng at Motor Overloa	Speed Position	Torque	
(252C	Setting Range	Setting Unit	When Enabled	Classification	
hex)	10 to 100	1%	100	After restart	Setup

An A.720 alarm (Continuous Overload) can be detected earlier to protect the Servomotor from overloading.

Overload detection time



Note: The gray areas in the above graph show where A.710 and A.720 alarms occur.

Refer to the relevant manual given below for a diagram that shows the relationships between the motor heat dissipation conditions (heat sink size, surrounding air temperature, and derating). You can protect the motor from overloads more effectively by setting this derating value in Pn52C.

- Ω-7-Series Rotary Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 86)
- Σ-7-Series Linear Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 81)

## 5.14

## **Setting Unit Systems**

You can set the SERVOPACK reference units with EtherCAT (CoE) communications. You can set the following four reference units with EtherCAT communications.

- · Position reference unit
- Speed reference unit
- · Acceleration reference unit
- Torque reference unit

The setting procedures are given below.

## 5.14.1 Setting the Position Reference Unit

Set the position reference unit in *position user unit* (2701 hex). The position reference unit setting will be used for the electronic gear ratio setting.



- For a Rotary Servomotor with an encoder resolution of 24 bits (16,777,216), Pn20E (Electronic Gear Ratio (Numerator)) is automatically set to 16 and Pn210 (Electronic Gear Ratio (Denominator)) is automatically set to 1. Therefore, the encoder resolution will be equivalent to 20 bits (1,048,576). Consider this when you set the position reference unit in *position user unit* (2701 hex).
- Set the position reference unit within the following range.
   1/4,096 < Numerator/Denominator < 65,536</li>
   If the setting range is exceeded, an A.A20 alarm (Parameter Setting Error) will occur.

Index	Subin- dex	Name	Data Type	Access	PDO Mappings	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
2701 hex	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
110%	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes

Note: Refer to the following section for information on *position user unit* (2701 hex).

Position User Unit (2701 Hex) on page 14-17

The minimum unit of the position data that is used to move a load is called the reference unit. The reference unit is used to give travel amounts, not in pulses, but rather in distances or other physical units (such as  $\mu m$  or °) that are easier to understand.


The electronic gear is used to convert the travel distances that are specified in reference units to pulses, which are required for actual movements.

With the electronic gear, one reference unit is equal to the workpiece travel distance per reference pulse input to the SERVOPACK. In other words, if you use the SERVOPACK's electronic gear, pulses can be read as reference units.

The difference between using and not using the electronic gear is shown below.

#### · Rotary Servomotors

In this example, the following machine configuration is used to move the workpiece 10 mm.



#### When the Electronic Gear Is Not Used

To move a workpiece 10 mm:

①Calculate the number of revolutions.

The motor will move 6 mm for each revolution. so 10/6 revolutions are required to move 10 mm.

<sup>2</sup>Calculate the required number of reference pulses.

One revolution is 1,048,576 pulses, therefore  $10/6 \times 1,048,576 = 1,747,626.66$  pulses.

3 Input 1,747,627 pulses as the reference.

Calculating the number of reference pulses for each reference is troublesome.



When the Electronic Gear Is Used

5.14.1 Setting the Position Reference Unit


If you use reference units to move the workpiece when one reference unit is set to 1 μm, the travel distance is 1 µm per pulse.

To move the workpiece 10 mm  $(10,000 \mu m), 10,000 \div 1 =$ 10,000 pulses, so 10,000 pulses would be input.

Calculating the number of reference pulses for each reference is not necessary.

#### Linear Servomotors

In this example, the following machine configuration is used to move the load 10 mm. We'll assume that the resolution of the Serial Converter Unit is 256 and that the linear encoder pitch is 20 µm.



#### When the Electronic Gear Is Not Used

To move the load 10 mm:  $10 \times 1000 \div 20 \times 256 = 128,000$ pulses, so 128,000 pulses are input as the reference.

Calculating the number of reference pulses for each reference is troublesome.



When the Electronic Gear Is Used

To use reference units to move the load 10 mm: If we set the reference unit to 1 µm, the travel distance is 1 µm per pulse. To move the load 10 mm  $(10,000 \mu m)$ , 10,000/1 = 10,000 pulses, so 10,000 pulses would be input as the reference.

Calculating the number of reference pulses for each reference is not necessary.

## Calculating the Settings for the Electronic Gear Ratio

### Rotary Servomotors

If the gear ratio between the Servomotor shaft and the load is given as n/m, where n is the number of load rotations for m Servomotor shaft rotations, the settings for the electronic gear ratio can be calculated as follows:

Electronic gear ratio 
$$\frac{B}{A} = \frac{Numerator}{Denominator} = \frac{Encoder resolution}{Travel distance per load shaft revolution (reference units)} \times \frac{m}{n}$$

Information

For a Rotary Servomotor with an encoder resolution of 24 bits (16,777,216), Pn20E (Electronic Gear Ratio (Numerator)) is automatically set to 16 and Pn210 (Electronic Gear Ratio (Denominator)) is automatically set to 1. Therefore, the encoder resolution will be equivalent to 20 bits (1,048,576). Consider this when you set the position reference unit in position user unit (2701 hex).

#### ■ Encoder Resolution

You can check the encoder resolution in the Servomotor model number.



### ◆ Linear Servomotors

You can calculate the settings for the electronic gear ratio with the following equation:

When Not Using a Serial Converter Unit

Use the following formula if the linear encoder and SERVOPACK are connected directly or if a linear encoder that does not require a Serial Converter Unit is used.

Electronic gear ratio 
$$\frac{B}{A} = \frac{Numerator}{Denominator} = \frac{Travel \ distance \ per \ reference \ unit \ (reference \ units) \times Linear \ encoder \ resolution}{Linear \ encoder \ pitch \ (the \ value \ from \ the \ following \ table)}$$

When Using a Serial Converter Unit

Electronic gear ratio 
$$\frac{B}{A} = \frac{Numerator}{Denominator} = \frac{Travel distance per reference unit (reference units) × Resolution of the Serial Converter Unit Linear encoder pitch (setting of Pn282)$$

### ■ Feedback Resolution of Linear Encoder

The linear encoder pitches and resolutions are given in the following table.

Calculate the electronic gear ratio using the values in the following table.

Type of Linear Encoder	Manufac- turer	Linear Encoder Model	Linear Encoder Pitch [µm]*1	Model of Serial Con- verter Unit or Model of Interpolator	Resolution	Resolution
		LIDA48□	20	JZDP-H003-□□□-E*2	256	0.078 μm
	Heidenhain	LIDA40LI	20	JZDP-J003-□□□-E*2	4,096	0.0049 μm
	Corporation	LIF48□	4	JZDP-H003-□□□-E*2	256	0.016 μm
		LII 40LI	4	JZDP-J003-□□□-E*2	4,096	0.00098 μm
R	Renishaw	RGH22B	20	JZDP-H005- <b></b> E*2	256	0.078 μm
	PLC	NGH22B		JZDP-J005-□□□-E*2	4,096	0.0049 μm
Incre-		SR75-0000LF*5	80	_	8,192	0.0098 μm
mental		SR75-□□□□□MF		_	1,024	0.078 μm
		SR85-0000LF*5	80	_	8,192	0.0098 μm
	Magnes-	SR85-000MF	80	_	1,024	0.078 μm
	cale Co., Ltd.	SL700*5, SL710*5,	800	PL101-RY*3	8,192	0.0977 μm
		SL720*5, SL730*5	000	MJ620-T13*4	0,132	0.0311 μιπ
		SQ10	400	MQ10-FLA*4	8,192	0.0488.um
		JQTU	400	MQ10-GLA*4	0,192	0.0488 μm

Continued on next page.

Continued from previous page.

			evious page.			
Type of Linear Encoder	Manufac- turer	Linear Encoder Model	Linear Encoder Pitch [µm]*1	Model of Serial Con- verter Unit or Model of Interpolator	Resolution	Resolution
		LIC4100 Series	20.48	EIB3391Y*4	4,096	0.005 μm
		LIC2100 Series	204.8	EIB3391Y*4	4096	0.05 μm
	Heidenhain Corporation	LICZ TOO Series	409.6	EIB3391Y*4	4096	0.1 μm
	Corporation	LC115	40.96	EIB3381Y*4	4,096	0.01 μm
		LC415	40.96	EIB3391Y*4	4096	0.01 μm
		ST781A/ST781AL	256	_	512	0.5 μm
		ST782A/ST782AL	256	_	512	0.5 μm
		ST783/ST783AL	51.2	_	512	0.1 μm
	Mitutoyo	ST784/ST784AL	51.2	_	512	0.1 μm
	Corporation	ST788A/ST788AL	51.2	_	512	0.1 μm
		ST789A/ST789AL	25.6	_	512	0.05 μm
		ST1381	5.12	_	512	0.01 μm
		ST1382	0.512	_	512	0.001 μm
Absolute		EL36Y-0050F000	12.8	_	256	0.05 μm
Absolute		EL36Y-00100F000	25.6	_	256	0.1 μm
	Renishaw PLC	EL36Y-00500F000	128	_	256	0.5 μm
	1 20	RL36Y-00500000	12.8	_	256	0.05 μm
		RL36Y-0001000	0.256	_	256	0.001 μm
		SR77-0000LF*5	80	_	8,192	0.0098 μm
		SR77-0000MF	80	_	1,024	0.078 μm
		SR87-0000LF*5	80	_	8,192	0.0098 μm
		SR87-□□□□□MF	80	_	1,024	0.078 μm
	Magnes- cale Co., Ltd.	SQ47/SQ57- □□□□S□F□□□ SQ47/SQ57- □□□□T□F□□□	20.48	_	4096	0.005 μm
		SQ47/SQ57- □□□□A□F□□□ SQ47/SQ57- □□□□F□F□□□	40.96	_	4096	0.01 μm

- \*1. These are reference values for setting SERVOPACK parameters. Contact the manufacturer for actual linear encoder scale pitches.
- \*2. This is the model of the Serial Converter Unit.
- \*3. This is the model of the Head with Interpolator.
- \*4. This is the model of the Interpolator.
- \*5. If you use an encoder pulse output with this linear encoder, the setting range of the encoder output resolution (Pn281) is restricted. Refer to the following section for details on the encoder output resolution (Pn281).

### 6.5.2 Setting for the Encoder Divided Pulse Output on page 6-23

### Information


#### Resolution

You can calculate the resolution that is used inside the SERVOPACK (i.e., the travel distance per feedback pulse) with the following formula.

Resolution (travel distance per feedback pulse) = Linear encoder pitch

Resolution of Serial Converter Unit or linear encoder

The SERVOPACK uses feedback pulses as the unit to control a Servomotor.



Linear encoder pitch

=Distance for one cycle of the analog voltage feedback signal from the linear encoder

## **Electronic Gear Ratio Setting Examples**

Setting examples are provided in this section.

Rotary Servomotors

			Machine Configuration	
		Ball Screw	Rotary Table	Belt and Pulley
Step	Description	Reference unit: 0.001 mm Load shaft Encoder: Ball screw lead: 24 bits 6 mm	Reference unit: 0.01°  Gear ratio: 1/100  Load shaft  Encoder: 24 bits	Reference unit: 0.005 mm Load shaft  Gear ratio: Pulley dia.: 100 mm 1/50 Encoder: 24 bits
1	Machine Specifications	Ball screw lead: 6 mm     Gear ratio: 1/1	Rotation angle per revolution: 360°     Gear ratio: 1/100	• Pulley dia.: 100 mm (Pulley circumference: 314 mm) • Gear ratio: 1/50
2	Encoder Resolution	16,777,216 (24 bits)	16,777,216 (24 bits)	16,777,216 (24 bits)
3	Reference Unit	0.001 mm (1 μm)	0.01°	0.005 mm (5 μm)
4	Travel Distance per Load Shaft Revolution (Reference Units)	6 mm/0.001 mm = 6,000	360°/0.01° = 36,000	314 mm/0.005 mm = 62,800
5	Electronic Gear Ratio*	$\frac{B}{A} = \frac{16,777,216}{6,000} \times \frac{1}{16} \times \frac{1}{1}$	$\frac{B}{A} = \frac{16,777,216}{36,000} \times \frac{1}{16} \times \frac{100}{1}$	$\frac{B}{A} = \frac{16,777,216}{36,000} \times \frac{1}{16} \times \frac{50}{1}$
6	Position User Unit (2701 hex)	Numerator: 1,048,576	Numerator: 104,857,600	Numerator: 52,428,800
	(2701110%)	Denominator: 6,000	Denominator: 36,000	Denominator: 62,800

<sup>\*</sup> For a Rotary Servomotor with an encoder resolution of 24 bits (16,777,216), Pn20E (Electronic Gear Ratio (Numerator)) is automatically set to 16 and Pn210 (Electronic Gear Ratio (Denominator)) is automatically set to 1. Therefore, the encoder resolution will be equivalent to 20 bits (1,048,576). Consider this when you set the position reference unit in *position user unit* (2701 hex).

#### Linear Servomotors

A setting example for a Serial Converter Unit resolution of 256 is given below.

		Machine Configuration
Step	Description	Reference unit: 0.02 mm (20 µm) Forward direction
1	Linear Encoder Pitch	0.02 mm (20 μm)
2	Reference Unit	0.001 mm (1 μm)
3	Electronic Gear Ratio*	$\frac{B}{A} = \frac{1 (\mu m)}{20 (\mu m)} \times \frac{1}{1}$
4	Position User Unit	Numerator: 256
	(2701 hex)	Denominator: 20

<sup>\*</sup> For a Linear Servomotor, both Pn20E (Electronic Gear Ratio (Numerator)) and Pn210 (Electronic Gear Ratio (Denominator)) are automatically set to 1. Consider this when you set the position reference unit in position user unit (2701 hex).

## 5.14.2 Setting the Speed Reference Unit

Set the speed reference unit [Vel Unit] in velocity user unit (2702 hex).



For a Rotary Servomotor with an encoder resolution of 24 bits (16,777,216), Pn20E (Electronic Gear Ratio (Numerator)) is automatically set to 16 and Pn210 (Electronic Gear Ratio (Denominator)) is automatically set to 1. Therefore, the encoder resolution will be equivalent to 20 bits (1,048,576). Consider this when you set the position reference unit in *position user unit* (2701 hex).

Index	Subin- dex	Name	Data Type	Access	PDO Mappings	Value	Saving to EEPROM
2702 hex	0	Number of entries	USINT	RO	No	2	No
	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes

Setting range: 1/128 ≤ Numerator/Denominator ≤ 8,388,608 (Alarm A.A20 will be detected if the setting exceeds the setting range.)

Example

Speed Reference Unit Setting Example (Electronic Gear Ratio Setting Example for a Ball Screw)

Velocity User Unit (2702 Hex)
 Converting one user-defined velocity reference unit [0.1 mm/s] into [inc/s]:

1 [Vel unit]
$$= \frac{16,777,216 \text{ [inc]} \times (1/16)}{6 \text{ [mm]}} \times 0.1 \text{ [mm/s]}$$

$$= \frac{1,048,576}{60} \text{ [inc/s]}$$

Therefore, the objects are set as follows: Object 2702 hex: 01 (Numerator) = 1,048,576 Object 2702 hex: 02 (Denominator) = 60

## 5.14.3 Setting the Acceleration Reference Unit

Set the acceleration reference unit [Acc Unit] in acceleration user unit (2703 hex).



For a Rotary Servomotor with an encoder resolution of 24 bits (16,777,216), Pn20E (Electronic Gear Ratio (Numerator)) is automatically set to 16 and Pn210 (Electronic Gear Ratio (Denominator)) is automatically set to 1. Therefore, the encoder resolution will be equivalent to 20 bits (1,048,576). Consider this when you set the position reference unit in *position user unit* (2701 hex).

Index	Subin- dex	Name	Data Type	Access	PDO Mappings	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
2703 hex	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
110%	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes

Setting range: 1/128 ≤ Numerator/Denominator ≤ 262,144

(Alarm A.A20 will be detected if the setting exceeds the setting range.)

Example

Acceleration Reference Unit Setting Example (Electronic Gear Ratio Setting Example for a Ball Screw)

Acceleration User Unit (2703 hex)
 Converting one user-defined acceleration reference unit [0.1 mm/s<sup>2</sup>] into [10<sup>4</sup> inc/s<sup>2</sup>]:

1 [Acc unit]

$$= \frac{16,777,216 \text{ [inc]} \times (1/16)}{6 \text{ [mm]}} \times 0.1 \text{ [mm/s}^2] \times 10^{-4}$$

$$= \frac{1,048,576}{6 \times 10^5} \text{ [} 10^4 \text{ inc/s}^2\text{]}$$

Therefore, the objects are set as follows: Object 2703 hex: 01 (Numerator) = 1,048,576 Object 2703 hex: 02 (Denominator) = 600,000

## 5.14.4 Setting the Torque Reference Unit

Set the torque reference unit [Torque Unit] in torque user unit (2704 hex).

Index	Subin- dex	Name	Data Type	Access	PDO Mappings	Value	Saving to EEPROM
2704 hex	0	Number of entries	USINT	RO	No	2	No
	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 10)	Yes

Setting range: 1/256 ≤ Numerator/Denominator ≤ 1

(Alarm A.A20 will be detected if the setting exceeds the setting range.)

## 5.15 Resetting the Absolute Encoder

In a system that uses an absolute encoder, the multiturn data must be reset at startup. An alarm related to the absolute encoder (A.810 or A.820) will occur when the absolute encoder must be reset, such as when the power supply is turned ON.

When you reset the absolute encoder, the multiturn data is reset and any alarms related to the absolute encoder are cleared.

Reset the absolute encoder in the following cases.

- · When starting the system for the first time
- When an A.810 alarm (Encoder Backup Alarm) occurs
- When an A.820 alarm (Encoder Checksum Alarm) occurs
- When you want to reset the multiturn data in the absolute encoder

## **A** CAUTION

 The multiturn data will be reset to a value between -2 and +2 rotations when the absolute encoder is reset. The reference position of the machine system will change. Adjust the reference position in the host controller to the position that results from resetting the absolute encoder.

If the machine is started without adjusting the position in the host controller, unexpected operation may cause personal injury or damage to the machine.



When the encoder is set to be used as a single-turn absolute encoder ( $Pn002 = n.\Box 2\Box\Box$ ), the multiturn data will always be zero. It is not necessary to reset the absolute encoder. Also, an alarm related to the absolute encoder (A.810 or A.820) will not occur.

## 5.15.1 Precautions on Resetting

- The parameters must not be write prohibited.
- The servo must be OFF to reset the absolute encoder.
- You cannot use the Alarm/Warning Clear (Fault Reset) command from the SERVOPACK to clear the A.810 alarm (Encoder Backup Alarm) or the A.820 alarm (Encoder Checksum Alarm). Always use the operation to reset the absolute encoder to clear these alarms.
- If an A.8□□ alarm (Internal Encoder Monitoring Alarm) occurs, turn OFF the power supply to reset the alarm.

## 5.15.2 Applicable Tools


The following table lists the tools that you can use to reset the absolute encoder and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn008	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Absolute Encoder Reset	5.15.3 Operating Procedure on page 5-50
EtherCAT (CoE) communications	SERVOPACK Adjusting Command (2710 hex)	SERVOPACK Adjusting Command (2710 Hex) on page 14-19

## 5.15.3 Operating Procedure


Use the following procedure to reset the absolute encoder.

- 1. Confirm that the servo is OFF.
- 2. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Absolute Encoder Reset in the Menu Dialog Box. The Absolute Encoder Reset Dialog Box will be displayed.
- 4. Click the Continue Button.



Click the Cancel Button to cancel resetting the absolute encoder. The Main Window will return.

5. Click the Execute setting Button.



The current alarm code and name will be displayed in the Alarm name Box.

6. Click the Continue Button.




Click the Cancel Button to cancel resetting the absolute encoder. The previous dialog box will return.

#### 7. Click the OK Button.

The absolute encoder will be reset.

### When Resetting Fails

If you attempted to reset the absolute encoder when the servo was ON in the SERVOPACK, the following dialog box will be displayed and processing will be canceled.



Click the **OK** Button. The Main Window will return. Turn OFF the servo and repeat the procedure from step 1.

### When Resetting Is Successful

The following dialog box will be displayed when the absolute encoder has been reset.



The Main Window will return.

**8.** To enable the change to the settings, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to reset the absolute encoder.

5.16.1 Absolute Encoder Origin Offset

## 5.16

## Setting the Origin of the Absolute Encoder

## 5.16.1 Absolute Encoder Origin Offset


The origin offset of the absolute encoder is a correction that is used to set the origin of the machine coordinate system in addition to the origin of the absolute encoder. Set the offset between the absolute encoder origin and the machine coordinate system position in *home offset* (607C hex).

The offset is added to *position actual value* (6064 hex) after the parameters are enabled when the power supply is turned ON or with *user parameter configuration* (2700 hex).

Index	Subindex	Name	Data Type	Access	Data Ranges	Default Value	Saving to EEPROM
607C hex	0	Home offset	DINT	RW	-536,870,912 to 536,870,911	0	Yes

Example

If the encoder position (X) is at the origin (0), then *home offset* (607C hex) would be set to the value of -X.



## 5.16.2 Setting the Origin of the Absolute Linear Encoder

You can set any position as the origin in the following linear encoders.

 From Mitutoyo Corporation ABS ST780A Series or ST1300 Series

Models: ABS ST78□A/ST78□AL/ST13□□

• Renishaw PLC EVOLUTE Series

Models: EL36Y-DDDDDDDD

 Renishaw PLC RESOLUTE Series

Models: RL36Y-



- 1. After you set the origin, the /S-RDY (Servo Ready) signal will become inactive because the system position data was changed. Always turn the SERVOPACK power supply OFF and ON again.
- 2. After you set the origin, the Servomotor phase data in the SERVOPACK will be discarded. If you are using a Linear Servomotor without a Polarity Sensor, execute polarity detection again to save the Servomotor phase data in the SERVOPACK.

## **Preparations**

The following conditions must be met to set the origin of the absolute linear encoder.

- The parameters must not be write prohibited.
- The servo must be OFF.

5.16.2 Setting the Origin of the Absolute Linear Encoder

### **Applicable Tools**


The following table lists the tools that you can use to set the origin of the absolute linear encoder and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn020	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Set Origin	© Operating Procedure on page 5-53


### **Operating Procedure**

Use the following procedure to set the origin of an absolute linear encoder.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Set Origin in the Menu Dialog Box. The Set Origin Dialog Box will be displayed.
- 3. Click the Continue Button.



4. Click the Execute Button.




### 5.16.2 Setting the Origin of the Absolute Linear Encoder

5. Click the Continue Button.



Click the **Cancel** Button to cancel setting the origin of the absolute linear encoder. The previous dialog box will return.

6. Click the OK Button.



- 7. Turn the power supply to the SERVOPACK OFF and ON again.
- **8.** If you use a Linear Servomotor that does not have a polarity sensor, perform polarity detection.

Refer to the following section for details on the polarity detection.

5.9 Polarity Detection on page 5-23

This concludes the procedure to set the origin of the absolute linear encoder.

## 5.17

## **Setting the Regenerative Resistor Capacity**

The Regenerative Resistor consumes regenerative energy that is generated by the Servomotor, e.g., when the Servomotor decelerates.

If an External Regenerative Resistor is connected, you must set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistor Resistance).

## **MARNING**

- If you connect an External Regenerative Resistor, set Pn600 and Pn603 to suitable values.
   If a suitable value is not set, A.320 alarms (Regenerative Overload) will not be detected correctly, and the External Regenerative Resistor may be damaged or personal injury or fire may result.
- When you select an External Regenerative Resistor, make sure that it has a suitable capacity.

There is a risk of personal injury or fire.

	Regenerative Resist	or Capacity	Speed Position Torque		
Pn600 (2600 hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to SERVOPACK's maximum applicable motor capacity	10 W	0	Immediately	Setup
Pn603	Regenerative Resist	or Resistance	Speed Pos	Sition Torque	
(2603 hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	10 mΩ	0	Immediately	Setup

Set the Regenerative Resistor capacity to a value that is consistent with the allowable capacity of the External Regenerative Resistor. The setting depends on the cooling conditions of the External Regenerative Resistor.

- For self-cooling (natural convection cooling): Set the parameter to a maximum 20% of the capacity (W) of the actually installed Regenerative Resistor.
- For forced-air cooling: Set the parameter to a maximum 50% of the capacity (W) of the actually installed Regenerative Resistor.

For a self-cooling 100-W External Regenerative Resistor, set Pn600 to 2 (×10 W) (100 W ×

Example 20% = 20 W).

Note: 1. An A.320 alarm will be displayed if the setting is not suitable.

2. The default setting of 0 specifies that the SERVOPACK's built-in regenerative resistor or Yaskawa's Regenerative Resistor Unit is being used.



- 1. When an External Regenerative Resistor is used at the normal rated load ratio, the resistor temperature increases to between 200°C and 300°C. Always apply derating. Consult the manufacturer for the resistor's load characteristics.
- 2. For safety, use an External Regenerative Resistor with a thermoswitch.

## 5.18

## Setting the Energy Consumption and Resistance of the Dynamic Brake Resistor

If an External Dynamic Brake Resistor is connected, you must set Pn601 (Dynamic Brake Resistor Allowable Energy Consumption) and Pn604 (Dynamic Brake Resistance).

## **⚠** WARNING

- If you connect an External Dynamic Brake Resistor, set Pn601 and Pn604 to suitable values. Failure to set these parameters will cause an A.730 alarm (Dynamic Brake Overload) to be detected incorrectly and can destroy the External Dynamic Brake Resistor, cause unintended operation during an emergency stop, cause damage to the machine, and cause burning or injury.
- When you select an External Dynamic Brake Resistor, make sure that it has a suitable energy consumption and resistance.
   There is a risk of personal injury or fire.

## **⚠** CAUTION

 Mount Dynamic Brake Resistors only on nonflammable materials. Do not mount them on or near any flammable material.
 There is a risk of fire.

Pn601	Dynamic Brake Res	sistor Allowable Ene	Speed Position Torque		
(2601	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 65,535	10 J	0	After restart	Setup
Pn604					
Pn604	Dynamic Brake Res	sistance		Speed	osition Torque
Pn604 (2604 hex)	Dynamic Brake Res Setting Range	Setting Unit	Default Setting	Speed Po	Classification

Set Pn601 to the capacity of the Dynamic Brake Resistor that you calculated when selecting the connected External Dynamic Brake Resistor or the capacity of the Resistor as reported by the manufacturer.

Refer to the catalog for details on the energy consumption of the Dynamic Brake Resistor.

# **Application Functions**

This chapter describes the application functions that you can set before you start Servo System operation. It also describes the setting methods.

6.1	I/O Signal Allocations6-4
	6.1.1       Input Signal Allocations       6-4         6.1.2       Output Signal Allocations       6-5         6.1.3       ALM (Servo Alarm) Signal       6-7         6.1.4       /WARN (Warning) Signal       6-7         6.1.5       /TGON (Rotation Detection) Signal       6-8         6.1.6       /S-RDY (Servo Ready) Signal       6-8         6.1.7       /V-CMP (Speed Coincidence Detection) Signal       6-9         6.1.8       /COIN (Positioning Completion) Signal       6-10         6.1.9       /NEAR (Near) Signal       6-11         6.1.10       Speed Limit during Torque Control       6-12
6.2	Operation for Momentary Power Interruptions 6-14
6.3	<b>SEMI F47 Function</b>
6.4	Setting the Motor Maximum Speed6-17
6.5	Encoder Divided Pulse Output6-18
	<ul><li>6.5.1 Encoder Divided Pulse Output Signals 6-18</li><li>6.5.2 Setting for the Encoder Divided Pulse Output 6-23</li></ul>
6.6	Software Limits6-25
6.7	Selecting Torque Limits 6-26
	6.7.1 Internal Torque Limits

6.8	Absol	ute Encoders6-31
	6.8.1 6.8.2	Connecting an Absolute Encoder
	6.8.3	Output Ports for the Position Data from the Absolute Encoder
	6.8.4	Reading the Position Data from the Absolute Encoder
	6.8.5 6.8.6	Transmission Specifications
	6.8.7 6.8.8	Multiturn Limit Setting
6.9	Absol	ute Linear Encoders6-40
	6.9.1 6.9.2	Connecting an Absolute Linear Encoder 6-40 Structure of the Position Data of the Absolute Linear Encoder
	6.9.3	Output Ports for the Position Data from the Absolute Linear Encoder
	6.9.4	Reading the Position Data from the Absolute Linear Encoder
	6.9.5 6.9.6	Transmission Specifications
6.10	Softw	vare Reset6-44
0.10		
	6.10.1 6.10.2 6.10.3	Preparations
6.11	Initial	izing the Vibration Detection Level 6-46
	6.11.1	Preparations
	6.11.2	Applicable Tools
		Operating Procedure
	6.11.4	Related Parameters6-49
6.12	Adjusti	ng the Motor Current Detection Signal Offset6-50
	6.12.1 6.12.2	Automatic Adjustment
6.13	Forcir	ng the Motor to Stop6-55
	6.13.1	FSTP (Forced Stop Input) Signal
	6.13.2 6.13.3	Stopping Method Selection for Forced Stops 6-55 Resetting Method for Forced Stops 6-57
		·

6.14	ZONE	Outputs (FT64 Specification)6-58
	6.14.1	ZONE Table and ZONE Signals 6-58
	6.14.2	ZONE Table Settings 6-59
	6.14.3	ZONE Signals 1 to 4 Outputs
		(/ZONE0 to /ZONE3)6-60
	6.14.4	nZONE Signal Output6-61
	6.14.5	ZONE Output Application Example 6-62

#### 6.1.1 Input Signal Allocations

## 6.1

## I/O Signal Allocations

Functions are allocated to the pins on the I/O signal connector (CN1) in advance. You can change the allocations and the polarity for some of the connector pins. Function allocations and polarity settings are made with parameters.

This section describes the I/O signal allocations.

## 6.1.1 Input Signal Allocations



- If you change the default polarity settings for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal, the overtravel function will not operate if there are signal line disconnections or other problems. If you must change the polarity of one of these signals, verify operation and make sure that no safety problems will exist.
- If you allocate two or more signals to the same input circuit, a logical OR of the inputs will be used and all of the allocated signals will operate accordingly. This may result in unexpected operation.

The input signals that you can allocate to the pins on the I/O signal connector (CN1) and the related parameters are given in the following table.

Input Signal	Input Signal Name	Parameter
P-OT	Forward Drive Prohibit	Pn50A (250A hex) = n.X□□□
N-OT	Reverse Drive Prohibit	Pn50B (250B hex) = n.□□□X
/P-CL	Forward External Torque Limit	Pn50B (250B hex) = n.□X□□
/N-CL	Reverse External Torque Limit	Pn50B (250B hex) = n.X□□□
/Probe1	Probe 1 Latch Input	Pn511 (2511 hex) = n.□□X□
/Probe2	Probe 2 Latch Input	Pn511 (2511 hex) = n.□X□□
/Home	/Home Input	Pn511 (2511 hex) = n.X□□□
FSTP	Forced Stop	Pn516 (2516 hex) = n.□□□X

## Relationship between Parameter Settings, Allocated Pins, and Polarities

The following table shows the relationship between the input signal parameter settings, the pins on the I/O signal connector (CN1), and polarities.

Parameter Setting	Pin No.	Description
0	13	
1	7	+24 V
2	8	
3	9	A reverse signal (a signal with "/" before the signal abbreviation, such as the /
4	10	P-CL signal) is active when the contacts are ON (closed).
5	11	A signal that does not have "/" before the signal abbreviation (such as the P-OT signal) is active when the contacts are OFF (open).
6	12	or digitally to dollar whom the contracto are of the copony.
7	_	The input signal is not allocated to a connector pin and it is always active. If the signal is processed on a signal edge, then it is always inactive.
8	_	The input signal is not allocated to a connector pin and it is always inactive. Set the parameter to 8 if the signal is not used.

Continued on next page.

Continued from previous page.

Parameter Setting	Pin No.	Description
9	13	
Α	7	+24 V
В	8	
С	9	A reverse signal (a signal with "/" before the signal abbreviation, such as the /
D	10	P-CL signal) is active when the contacts are OFF (open).
Е	11	A signal that does not have "/" before the signal abbreviation (such as the P-OT signal) is active when the contacts are ON (closed).
	10	

Note: 1. You can allocate the /Probe1, /Probe2, and /Home input signals only to pins 10 to 12 on the I/O signal connector (CN1).

16.1.2 List of Parameters on page 16-3

### **Example of Changing Input Signal Allocations**

The following example shows reversing the P-OT (Forward Drive Prohibit) signal allocated to CN1-7 and the /DEC (Origin Return Deceleration Switch) signal allocated to CN1-9.

Pn50A = n.1
$$\square$$
1 Pn511 = n. $\square$ 2 Before change   

$$\downarrow \qquad \qquad \downarrow$$
Pn50A = n.3 $\square$ 2 Pn511 = n. $\square$ 2 After change

Refer to the following section for the parameter setting procedure.

5.1.3 Setting Methods for SERVOPACK Parameters on page 5-5

### **Confirming Input Signals**

You can confirm the status of input signals on the I/O signal monitor. Refer to the following section for information on the I/O signal monitor.

9.2.3 I/O Signal Monitor on page 9-5

#### 6.1.2 **Output Signal Allocations**

You can allocate the desired output signals to pins 1, 2, and 23 to 30 on the I/O signal connector (CN1). You set the allocations in the following parameters: Pn50E, Pn50F, Pn510, Pn513, and Pn514.



- The signals that are not detected are considered to be OFF. For example, the /COIN (Positioning Completion) signal is considered to be OFF during speed control.
- Reversing the polarity of the /BK (Brake) signal, i.e., changing it to positive logic, will prevent the holding brake from operating if its signal line is disconnected. If you must change the polarity of this signal, verify operation and make sure that no safety problems will exist.
- · If you allocate more than one signal to the same output circuit, a logical OR of the signals will be output.

Output signals are allocated as shown in the following table.

Refer to Interpreting the Output Signal Allocation Tables and change the allocations accordingly.

<sup>2.</sup> Refer to the following section for details on input signal parameter settings.

### 6.1.2 Output Signal Allocations

### Interpreting the Output Signal Allocation Tables

These columns give the parameter settings to use. Signals are allocated to CN1 pins according to the settings.

						$\overline{}$	
Output Signal Name and Parameter	Output Signals	CN1 Pin No.				Disabled	
	Output Signals	1 and 2	23 and 24	25 and 26	27 and 28	29 and 30	(Not Used)
Brake Pn50F (250F hex) = □X□□	/BK	1	2	3	4	5	0

0 1 10: 11		CN1 Pin No.					Disabled
Output Signal Name and Parameter	Output Signals	1 and 2	23 and 24	25 and 26	27 and 28	29 and 30	Disabled (Not Used)
Positioning Completion Pn50E (250E hex) = n.□□□X	/COIN	1	2	3	4	5	0 (default setting)
Speed Coincidence Detection Pn50E (250E hex) = n.□□X□	/V-CMP	1	2	3	4	5	0 (default setting)
Rotation Detection Pn50E (250E hex) = n.□X□□	/TGON	1	2	3	4	5	0 (default setting)
Servo Ready Pn50E (250E hex) = n.X□□□	/S-RDY	1	2	3	4	5	0 (default setting)
Torque Limit Detection Pn50F (250F hex) = n.□□□X	/CLT	1	2	3	4	5	0 (default setting)
Speed Limit Detection Pn50F (250F hex) = n.□□X□	/VLT	1	2	3	4	5	0 (default setting)
Brake Pn50F (250F hex) = n.□X□□	/BK	1 (default setting)	2	3	4	5	0
Warning Pn50F (250F hex) = n.X□□□	/WARN	1	2	3	4	5	0 (default setting)
Near Pn510 (2510 hex) = n.□□□X	NEAR	1	2	3	4	5	0 (default setting)
Preventative Maintenance Pn514 (2514 hex) = n.□X□□	/PM	1	2	3	4	5	0 (default setting)
ZONE Signal 1 Output PnBA0 (2752 hex) = n.□□□X	/ZONE0	1	2	3	4	5	0 (default setting)
ZONE Signal 2 Output PnBA0 (2752 hex) = n.□□X□	/ZONE1	1	2	3	4	5	0 (default setting)
ZONE Signal 3 Output PnBA0 (2752 hex) = n.□X□□	/ZONE2	1	2	3	4	5	0 (default setting)
ZONE Signal 4 Output PnBA0 (2752 hex) = n.X□□□	/ZONE3	1	2	3	4	5	0 (default setting)
nZONE Signal Output PnBA1 (2753 hex) = n.□□□X	/nZONE	1	2	3	4	5	0 (default setting)
Pn512 (2512 hex) = n.□□□1		leverse polarity for CN1-1 and CN1-2					
Pn512 (2512 hex) = n.□□1□		polarity for and CN1-24					0 (default setting)
Pn512 (2512 hex) = n.□1□□	Reverse polarity for CN1-25 and CN1-26				The polarity is not reversed in the default		
Pn512 (2512 hex) = n.1□□□	Reve	Reverse polarity for CN1-27 and CN1-28			-28		settings.
Pn513 (2513 hex) = n.□□□1		Reverse polarity for CN1-29 and CN1-30				<del>-</del>	

### **Example of Changing Output Signal Allocations**

The following example shows disabling the /COIN (Positioning Completion) signal allocated to CN1-25 and CN1-26 and allocating the /SRDY (Servo Ready) signal.

Pn50E = n.0 $\square$ 3 Before change  $\downarrow$ Pn50E = n.3 $\square$ 0 After change

Refer to the following section for the parameter setting procedure.

5.1.3 Setting Methods for SERVOPACK Parameters on page 5-5

### **Checking Output Signal Status**

You can confirm the status of output signals on the I/O signal monitor. Refer to the following section for information on the I/O signal monitor.

9.2.3 I/O Signal Monitor on page 9-5

## 6.1.3 ALM (Servo Alarm) Signal

This signal is output when the SERVOPACK detects an error.



Configure an external circuit so that this alarm output turns OFF the main circuit power supply to the SERVOPACK whenever an error occurs.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Output ALM	CN1-3 and CN1-4	ON (closed)	Normal SERVOPACK status	
		OFF (open)	SERVOPACK alarm	

### Alarm Reset Methods

Refer to the following section for information on the alarm reset methods. *[3]* 15.2.3 Resetting Alarms on page 15-39

## 6.1.4 /WARN (Warning) Signal

Both alarms and warnings are generated by the SERVOPACK. Alarms indicate errors in the SERVOPACK for which operation must be stopped immediately. Warnings indicate situations that may results in alarms but for which stopping operation is not yet necessary.

The /WARN (Warning) signal indicates that a condition exists that may result in an alarm.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output /WAR	/\//\ DNI	Must be allocated.	ON (closed)	Warning
	/ VVAIN	i Must be allocated.	OFF (open)	Normal status

Note: You must allocate the /WARN signal to use it. Use Pn50F = n.XDDD (/WARN (Warning Output) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

## 6.1.5 /TGON (Rotation Detection) Signal

The /TGON signal indicates that the Servomotor is operating.

This signal is output when the shaft of the Servomotor rotates at the setting of Pn502 (Rotation Detection Level) or faster or the setting of Pn581 (Zero Speed Level) or faster.

Type	Signal	Connector Pin No.	Signal Status	Servomotor	Meaning
Output /TGON Must be allow			ON (aloned)	Rotary Servomotors	The Servomotor is operating at the setting of Pn502 or faster.
		ON (closed)	Linear Servomotors	The Servomotor is operating at the setting of Pn581 or faster.	
	/TGON	Must be allocated.	OFF (open)	Rotary Servomotors	The Servomotor is operating at a speed that is slower than the setting of Pn502.
				Linear Servomotors	The Servomotor is operating at a speed that is slower than the setting of Pn581.

Note: You must allocate the /TGON signal to use it. Use Pn50E = n. \(\Delta\text{D}\Delta\) (/TGON (Rotation Detection Output) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

### **Setting the Rotation Detection Level**

Use the following parameter to set the speed detection level at which to output the /TGON signal.

· Rotary Servomotors

Pn502	Rotation Detection I	Level	Speed Position	Torque	
(2502	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 10,000	1 min <sup>-1</sup>	20	Immediately	Setup

Linear Servomotors

Pn581	Zero Speed Level			Speed Position	Force
(2581	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 10,000	1 mm/s	20	Immediately	Setup

## 6.1.6 /S-RDY (Servo Ready) Signal

The /S-RDY (Servo Ready) signal turns ON when the SERVOPACK is ready to accept the Servo ON command (Enable Operation command).

The /S-RDY signal is turned ON under the following conditions.

- Main circuit power supply is ON.
- There is no hard wire base block state.
- · There are no alarms.
- If a Servomotor without a polarity sensor is used, polarity detection has been completed.\*
- \* Do not include this condition if the Servo ON command (Enable Operation command) is input for the first time after the control power supply was turned ON. In that case, when the first Servo ON command (Enable Operation command) is input, polarity detection is started immediately and the /S-RDY signal turns ON at the completion of polarity detection.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Output	Output /S-RDY	Must be allocated.	ON (closed)	Ready to receive Servo ON command (Enable Operation command).
Output /S	/3-ND1		OFF (open)	Not ready to receive Servo ON command (Enable Operation command).

Note: 1. You must allocate the /S-RDY signal to use it. Use Pn50E = n.XDDD (/S-RDY (Servo Ready) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

 $2. \ Refer to the following section for information on the hard wire base block and the {\it /S-RDY signal.}\\$ 

11.2.8 /S-RDY (Servo Ready Output) Signal on page 11-9

### 6.1.7 /V-CMP (Speed Coincidence Detection) Signal

The /V-CMP (Speed Coincidence Detection Output) signal is output when the Servomotor speed is the same as the reference speed. This signal is used, for example, to interlock the SERVOPACK and the host controller. You can use this output signal only during speed control.

The /V-CMP signal is described in the following table.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Output /V-CMP	A/ CMD	-CMP Must be allocated.	ON (closed)	The speed coincides.
	/ V-CIVIP IVIUST I	iviust be allocated.	OFF (open)	The speed does not coincide.

Note: You must allocate the /V-CMP signal to use it. Use Pn50E = n. \$\square\$ (/V-CMP (Speed Coincidence Detection Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following section for details on allocations.

6.1.2 Output Signal Allocations on page 6-5

You can set the speed detection width for the /V-CMP signal in Pn503 (Speed Coincidence Signal Detection Width) for a Rotary Servomotor or in Pn582 (Speed Coincidence Signal Detection Width) for a Linear Servomotor.


Rotary Servomotors

Pn503	Speed Coincidence Signal Detection Width			Speed	
(2503	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 100	1 min <sup>-1</sup>	10	Immediately	Setup

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.

Example

If Pn503 is set to 100 and the speed reference is 2,000 min<sup>-1</sup>, the signal would be output when the motor speed is between 1,900 and 2,100 min<sup>-1</sup>.



#### Linear Servomotors


Pn582	Speed Coincidence	Signal Detection Wi	Speed		
(2582	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 100	1 mm/s	10	Immediately	Setup

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.

#### 6.1.8 /COIN (Positioning Completion) Signal

Example

If Pn582 is set to 100 and the speed reference is 2,000 mm/s the signal would be output when the motor speed is between 1,900 and 2,100 mm/s.



### 6.1.8 /COIN (Positioning Completion) Signal

The /COIN (Positioning Completion) signal indicates that Servomotor positioning has been completed during position control.

The /COIN signal is output when the difference between the reference position output by the host controller and the current position of the Servomotor (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

Use this signal to check the completion of positioning from the host controller.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Output /COIN	/COIN	Must be allocated.	ON (closed)	Positioning has been completed.
	/COIN	OIN Must be allocated.	OFF (open)	Positioning has not been completed.

Note: You must allocate the /COIN signal to use it. Use Pn50E = n. \$\square\$ (/COIN (Positioning Completion Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following section for details on allocations


6.1.2 Output Signal Allocations on page 6-5

### **Setting the Positioning Completed Width**

The /COIN signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

Pn522	Positioning Complet	ted Width	Position		
(2522	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 1,073,741,824	1 reference unit	7	Immediately	Setup

The setting of the positioning completed width has no effect on final positioning accuracy.



Note: If the parameter is set to a value that is too large, the /COIN signal may be output when the position deviation is low during a low-speed operation. If that occurs, reduce the setting until the signal is no longer output.

# Setting the Output Timing of the /COIN (Positioning Completion Output) Signal

You can add a reference input condition to the output conditions for the /COIN signal to change the signal output timing.

If the position deviation is always low and a narrow positioning completed width is used, change the setting of  $Pn207 = n.X \square \square \square \square$  (/COIN (Positioning Completion Output) Signal Output Timing) to change output timing for the /COIN signal.

Parameter		Description	When Enabled	Classification
Pn207	n.0□□□ (default setting)	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width).		Setup
	n. 1000	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width) and the reference after the position reference filter is 0.	After restart	
	n. 2000	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width) and the reference input is 0.		

### 6.1.9 /NEAR (Near) Signal

The /NEAR (Near) signal indicates when positioning completion is being approached.

The host controller receives the NEAR signal before it receives the /COIN (Positioning Completion) signal, it can start preparations for the operating sequence to use after positioning has been completed. This allows you to reduce the time required for operation when positioning is completed.

The NEAR signal is generally used in combination with the /COIN signal.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Output	/NEAR	Must be allocated.	ON (closed)	The Servomotor has reached a point near to positioning completion.
			OFF (open)	The Servomotor has not reached a point near to positioning completion.

Note: You must allocate the /NEAR signal to use it. Use Pn510 = n. \$\square\$ (/NEAR (Near) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.


6.1.2 Output Signal Allocations on page 6-5

6.1.10 Speed Limit during Torque Control

### /NEAR (Near) Signal Setting

You set the condition for outputting the /NEAR (Near) signal (i.e., the near signal width) in Pn524 (Near Signal Width). The /NEAR signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the near signal width (Pn524).

Pn524	Near Signal Width			Position		
(2524	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	1 to 1,073,741,824	1 reference unit	1,073,741,824	Immediately	Setup	




Note: Normally, set Pn524 to a value that is larger than the setting of Pn522 (Positioning Completed Width).

### 6.1.10 Speed Limit during Torque Control

You can limit the speed of the Servomotor to protect the machine.

When you use a Servomotor for torque control, the Servomotor is controlled to output the specified torque, but the motor speed is not controlled. Therefore, if a reference torque is input that is larger than the machine torque, the speed of the Servomotor may increase greatly. If that may occur, use this function to limit the speed.

Note: The actual limit of motor speed depends on the load conditions on the Servomotor.



### /VLT (Speed Limit Detection) Signal

The signal that is output when the motor speed is being limited by the speed limit is described in the following table.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Output	/VLT	Must be allocated.	ON (closed)	The Servomotor speed is being limited.
			OFF (open)	The Servomotor speed is not being limited.

Note: You must allocate the /VLT signal to use it. Use Pn50F = n. \$\square\$ \text{ID} \text{ (/VLT (Speed Limit Detection) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

#### Selecting the Speed Limit

You set the speed limit to use in  $Pn002 = n.\square\square X\square$  (Torque Control Option). If you set Pn.002 to  $n.\square\square 1\square$  (Use V-REF as an external speed limit input), the smaller of the external speed limit and the internal speed limit will be used.

Parameter		Meaning	When Enabled	Classification	
Pn002 (2002	n.□□0□ (default setting)	Ignore the setting of the speed limit for the VLIM (Limit Speed for Torque Control) command and use the speed limit set in Pn407 or Pn480. (Use internal speed limiting.)	After restart	Setup	
hex)	n.□□1□	Use the speed limit from the VLIM (Limit Speed for Torque Control) command as the speed limit. (Use external speed limiting.)			

Note: If you are using a Rotary Servomotor, set Pn407 (Speed Limit during Torque Control). If you are using a Linear Servomotor, set Pn480 (Speed Limit during Force Control).

#### ◆ Internal Speed Limiting

If you select internal speed limiting for the torque control option (Pn002 =  $n.\square\square X\square$ ), set the speed limit for the motor in Pn407 (Speed Limit during Torque Control) or Pn480 (Speed Limit during Force Control). Also set Pn408 =  $n.\square\square X\square$  (Speed Limit Selection) to specify using the maximum motor speed or the overspeed alarm detection speed as the speed limit. Select the overspeed alarm detection speed to limit the speed to the equivalent of the maximum motor speed.

Parameter		Meaning	When Enabled	Classification	
Pn408 (2408 hex)	n.□□0□ (default setting)	Use the smaller of the maximum motor speed and the setting of Pn407 or Pn480 as the speed limit.	After restart	Setup	
	n.□□1□	Use the smaller of the overspeed alarm detection speed and the setting of Pn407 or Pn480 as the speed limit.	Allel Testart	Setup	

Note: If you are using a Rotary Servomotor, set Pn407 (Speed Limit during Torque Control). If you are using a Linear Servomotor, set Pn480 (Speed Limit during Force Control).

#### · Rotary Servomotors

Pn407	Speed Limit during	Speed Limit during Torque Control			
(2407	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 min <sup>-1</sup>	10000	Immediately	Setup

#### · Linear Servomotors

Pn480	Speed Limit during Force Control				Force
(2480	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 mm/s	10000	Immediately	Setup

Note: If the parameter setting exceeds the maximum speed of the Servomotor, the Servomotor's maximum speed or the overspeed alarm detection speed will be used.

### 6.2

# **Operation for Momentary Power Interruptions**


Even if the main power supply to the SERVOPACK is interrupted momentarily, power supply to the motor (servo ON status) will be maintained for the time set in Pn509 (Momentary Power Interruption Hold Time).


Pn509	Momentary Power Interruption Hold Time			Speed Position	Torque
(2509	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	20 to 50,000	1 ms	20	Immediately	Setup

If the momentary power interruption time is equal to or less than the setting of Pn509, power supply to the motor will be continued. If it is longer than the setting, power supply to the motor will be stopped. Power will be supplied to the motor again when the main circuit power supply recovers.

Setting of Pn509 ≥ Momentary power interruption time

Setting of Pn509 < Momentary power interruption time





#### Information

- 1. If the momentary power interruption time exceeds the setting of Pn509, the /S-RDY (Servo Ready) signal will turn OFF.
- 2. If uninterruptible power supplies are used for the control power supply and main circuit power supply, the SERVOPACK can withstand a power interruption that lasts longer than 50,000 ms.
- 3. The holding time of the SERVOPACK control power supply (24 VDC) depends on the specifications of the 24-VDC power supply. Confirm the holding time yourself. If control operations become impossible during a momentary power interruption of the control power supply, the setting of Pn509 will be ignored and the same operation will be performed as for when the power supply is turned OFF normally.



The holding time of the main circuit power supply depends on the output from the SERVOPACK. If the load on the Servomotor is large and an A.410 alarm (Undervoltage) occurs, the setting of Pn509 will be ignored.

## 6.3 SEMI F47 Function

The SEMI F47 function detects an A.971 warning (Undervoltage) and limits the output current if the DC main circuit power supply voltage to the SERVOPACK drops to a specified value or lower because the power was momentarily interrupted or the main circuit power supply voltage was temporarily reduced.

This function complies with the SEMI F47 standards for semiconductor manufacturing equipment.


You can combine this function with the momentary power interruption hold time (Pn509) to allow the Servomotor to continue operating without stopping for an alarm or without recovery work even if the power supply voltage drops.

### **Execution Sequence**

This function can be executed either with the host controller or with the SERVOPACK. Use  $Pn008 = n.\square\square X\square$  (Function Selection for Undervoltage) to specify whether the function is executed by the host controller or by the SERVOPACK.


#### ◆ Execution with the Host Controller (Pn008 = n.□□1□)

The host controller limits the torque in response to an A.971 warning (Undervoltage). The host controller removes the torque limit after the Undervoltage warning is cleared.



### ◆ Execution with the SERVOPACK (Pn008 = n.□□2□)

The torque is limited in the SERVOPACK in response to an Undervoltage warning. The SERVOPACK controls the torque limit for the set time after the Undervoltage warning is cleared.



### Setting for A.971 Warnings (Undervoltage)

You can set whether or not to detect A.971 warnings (Undervoltage).

Р	arameter	Meaning	When Enabled	Classification
	n.□□0□ (default setting)	Do not detect undervoltage warning.		
Pn008	n.□□1□	Detect undervoltage warning and limit torque at host controller.	After restart	
(2008 hex)	n.□□2□	To detect undervoltage warnings, use Pn424 (Torque Limit at Main Circuit Voltage		Setup

#### ◆ Related Parameters

The following parameters are related to the SEMI F47 function.

Pn424	Torque Limit at Mair	n Circuit Voltage Dro	ρ	Speed Position	Torque
(2424	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 100	1%*	50	Immediately	Setup
Pn425	Release Time for To	rque Limit at Main C	Speed Position	Torque	
(2425	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 1,000	1 ms	100	Immediately	Setup
Pn509	Momentary Power I	nterruption Hold Tim	е	Speed Position	Torque
(2509	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	20 to 50,000	1 ms	20	Immediately	Setup

<sup>\*</sup> Set a percentage of the motor rated torque.

Note: If you will use the SEMI F47 function, set the time to 1,000 ms.



- This function handles momentary power interruptions for the voltage and time ranges stipulated in SEMI F47. An uninterruptible power supply (UPS) is required as a backup for momentary power interruptions that exceed these voltage and time ranges.
- Set the host controller or SERVOPACK torque limit so that a torque reference that exceeds the specified acceleration torque will not be output when the power supply for the main circuit is restored.
- For a vertical axis, do not limit the torque to a value that is lower than the holding torque.
- This function limits torque within the range of the SERVOPACK's capability for power interruptions. It is not intended for use under all load and operating conditions. Set the parameters while monitoring operation on the actual machine.
- You can set the momentary power interruption hold time to increase the amount of time from
  when the power supply is turned OFF until power supply to the motor is stopped. To stop the
  power supply to the motor immediately, use the Servo OFF command (Disable Operation command).

# 6.4 Setting the Motor Maximum Speed

You can set the maximum speed of the Servomotor with the following parameter.

Rotary Servomotors

Pn316	Maximum Motor Speed			Speed Positi	on Torque
(2316	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 65,535	1 min <sup>-1</sup>	10,000	After restart	Setup

Linear Servomotors

Pn385	Maximum Motor Speed			Speed Positi	on Force
(2385	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 100	100 mm/s	50	After restart	Setup

You can achieve the following by lowering the maximum speed of the Servomotor.

- If the motor speed exceeds the setting, an A.510 alarm (Overspeed) will occur.
- With a Linear Servomotor, you can increase the upper limit for the setting of Pn281 (Encoder Output Resolution). Refer to the following section for details.

6.5 Encoder Divided Pulse Output on page 6-18

Changing the setting of the parameter is effective in the following cases.

- To protect the machine by stopping machine operation with an alarm when the set speed is reached or exceeded
- To limit the speed so that the load is not driven beyond the allowable moment of inertia Refer to relevant manual from the following list for the relationship between the speed and the allowable moment of inertia.
  - Σ-7-Series Rotary Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 86)
  - □ Σ-7-Series Linear Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 81)
- To increase the encoder output resolution and increase the position resolution managed by the host controller (for a Linear Servomotor)

6.5.1 Encoder Divided Pulse Output Signals

# 6.5 Encoder Divided Pulse Output


The encoder divided pulse output is a signal that is output from the encoder and processed inside the SERVOPACK. It is then output externally in the form of two phase pulse signals (phases A and B) with a 90° phase differential. At the host controller, it is used as the position feedback.

The following table describes the signals and output phase forms.


### 6.5.1 Encoder Divided Pulse Output Signals

Type	Signal	Connector Pin No.	Name	Remarks
	PAO C	CN1-17	Encoder Divided Pulse Output,	Rotary Servomotors     These encoder divided pulse     output pins output the number
/PAO	/PAO	CN1-18	Phase A	of pulses per motor resolution that is set in Pn212 (Number of Encoder Output Pulses). The
	PBO	CN1-19		phase difference between phase A and phase B is an electric angle of 90°.
Output /P	/PBO	CN1-20	Encoder Divided Pulse Output, Phase B	Linear Servomotors     These encoder divided pulse     output pins output pulses at the     resolution that is set in Pn281     (Encoder Output Resolution).     The phase difference between     phase A and phase B is an     electric angle of 90°.
	PCO	CN1-21	Encoder Divided Pulse Output,	These pins output one pulse
	/PCO	CN1-22	Phase C*	every motor rotation.

- Rotary Servomotor



Linear Servomotors



#### **Output Phase Forms**

Forward rotation or movement (phase B leads by 90°)	Reverse rotation or movement (phase A leads by 90°)
Phase A Phase B Phase C	Phase A Phase B Phase C

Note: The pulse width of the origin within one encoder rotation depends on the setting of number of encoder output pulses (Pn212) or the encoder output resolution (Pn281). It is the same as the width of phase A. Even for reverse operation (Pn000 = n.□□□1), the output phase form is the same as shown above.



If you use the SERVOPACK's phase-C pulse output for an origin return, rotate the Servomotor two or more rotations before you start an origin return. If the Servomotor cannot be rotated two or more times, perform an origin return operation at a motor speed of 600 min<sup>-1</sup> or lower. If the motor speed is higher than 600 min<sup>-1</sup>, the phase-C pulse may not be output correctly.

### **Linear Encoder Application Precautions**

The following precautions apply to the encoder output pulses when an external linear encoder is used.


 Relation between Renishaw PLC Incremental Linear Encoders and Encoder Output Pulse Signal from the SERVOPACK When Using a RGS20 Scale and RGH22B Sensor Head

The output position of the origin signal (Ref) will depend on the direction of movement for some models of incremental linear encoders from Renishaw PLC.

In that case, the phase-C pulse of the SERVOPACK is output at two positions.


For detailed specifications on the origin signal, refer to the manual for the Renishaw PLC incremental linear encoder.

 When Passing the First Origin Signal (Ref) in the Forward Direction and Returning after Turning ON the Power Supply



#### 6.5.1 Encoder Divided Pulse Output Signals

## ■ When Passing the First Origin Signal (Ref) in the Reverse Direction and Returning after Turning ON the Power Supply




#### Precautions When Using a Linear Incremental Encoder from Magnescale Co., Ltd.

#### ■ Encoder Divided Phase-C Pulse Output Selection

You can also output the encoder's phase-C pulse for reverse movement. To do so, set Pn081 to n.□□□1.

F	arameter	Meaning	When Enabled	Classification
Pn081 (2081	n.□□□0 (default setting)	Output phase-C pulses only in the forward direction.	After restart	Setup
hex)	n.□□□1	Output phase-C pulses in both the forward and reverse directions.	Alter restait	Setup



Observe the following precaution if you set Pn081 to n. \$\square\$ (Output phase-C pulses only in the forward direction).

When a linear incremental encoder from Magnescale Co., Ltd. is used, the count direction of the encoder determines how the phase-C pulse (CN1-21 and CN1-22) is output.


Note: The count direction (up or down) of the linear encoder determines whether a phase-C pulse is output. The	)
output of the pulse does not depend on the setting of the movement direction (Pn000 = $n.\square\square\square$ 1).	

Encoder Model	Interpolator	Linear Encoder Pitch [μm]
SL710	DI 101 DV	800
SL720	PL101-RY MJ620-T13	800
SL730	10020 110	800
SR75		80
SR85		80
SQ10	MQ10-FLA	400
	MQ10-GLA	400

# ■ When First Passing the Origin Signal in the Forward Direction and Returning after Turning ON the Power Supply

The encoder's phase-C pulse (CN1-21 and CN1-22) is output when the origin detection position is passed for the first time in the forward direction after the power supply is turned ON.


After that, the phase-C pulse is output whenever the origin detection position is passed in the forward or reverse direction.



## ■ When First Passing the Origin Signal in the Reverse Direction and Returning after Turning ON the Power Supply

The encoder's phase-C pulse (CN1-19 and CN1-20) is not output when the origin detection position is passed for the first time in the reverse direction after the power supply is turned ON.


However, after the origin detection position is passed in the forward direction and the encoder's phase-C pulse is output, it will then also be output when the origin detection point is passed in the reverse direction.



#### 6.5.1 Encoder Divided Pulse Output Signals

## ■ When Using a Linear Encoder with Multiple Origins and First Passing the Origin Position in the Forward Direction and Returning after Turning ON the Power Supply


The encoder's phase-C pulse is output when the origin detection position is passed for the first time in the forward direction after the power supply is turned ON. After that, the phase-C pulse is output whenever the origin detection position is passed in the forward or reverse direction.



# When Using a Linear Encoder with Multiple Origins and First Passing the Origin Position in the Reverse Direction after Turning ON the Power Supply

The encoder's phase-C pulse is not output when the origin detection position is passed for the first time in the reverse direction after the power supply is turned ON.

However, after the origin detection position is passed in the forward direction and the encoder's phase-C pulse it output, it will then also be output when the origin detection point is passed in the reverse direction.



### 6.5.2 Setting for the Encoder Divided Pulse Output

This section describes the setting for the encoder divided pulse output for a Rotary Servomotor or Linear Servomotor.

# Encoder Divided Pulse Output When Using a Rotary Servomotor

If you will use a Rotary Servomotor, set the number of encoder output pulses (Pn212).

Pn212	Number of Encoder C	Output Pulses	Speed Position	on Torque	
(2212	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	16 to 1,073,741,824	1 P/Rev	2,048	After restart	Setup

The number of pulses from the encoder per rotation are processed inside the SERVOPACK, divided by the setting of Pn212, and then output.

Set the number of encoder divided output pulses according to the system specifications of the machine or host controller.

The setting of the number of encoder output pulses is limited by the resolution of the encoder.


Setting of the Number of Encoder Output Pulses [P/Rev]	Setting Increment	Encoder Resolution 24 bits (16,777,216 pulses)	Upper Limit of Servomotor Speed for Set Number of Encoder Output Pulses [min <sup>-1</sup> ]
16 to 16,384	1	0	6,000
16,386 to 32,768	2	0	3,000
32,772 to 65,536	4	0	1,500
65,544 to 131,072	8	0	750
131,088 to 262,144	16	0	375
262,176 to 524,288	32	0	187
524,352 to 1,048,576	64	0	93
1,048,704 to 2,097,152	128	0	46
2,097,408 to 4,194,304	256	0	23

Note: 1. The setting range of the number of encoder output pulses (Pn212) depends on the resolution of the Servomotor encoder. An A.041 alarm (Encoder Output Pulse Setting Error) will occur if the above setting conditions are not met.

Correct setting example: Pn212 can be set to 25,000 [P/Rev]. Incorrect setting example: Pn212 cannot be set to 25,001 (P/Rev) because the setting increment in the above table is not used.

2. The upper limit of the pulse frequency is approximately 1.6 Mpps. The Servomotor speed will be limited if the setting of the number of encoder output pulses is too high. An A.511 alarm (Encoder Output Pulse Overspeed) will occur if the upper limit of the motor speed is exceeded.

Output example: An output example is given below for the PAO (Encoder Pulse Output Phase A) signal and the PBO (Encoder Pulse Output Phase B) signal when Pn212 is set to 16 (16 pulses output per revolution).



6.5.2 Setting for the Encoder Divided Pulse Output

# Encoder Divided Pulse Output When Using a Linear Servomotor

If you will use a Linear Servomotor, set the encoder output resolution (Pn281).

Pn281	Encoder Output Re	solution	Speed Posit	ion Force	
(2281	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 4,096	1 edge/pitch	20	After restart	Setup

Note: The maximum setting for the encoder output resolution is 4,096. Pulse output at a linear encoder resolution of 4,096 or higher is not possible.

Set the encoder output resolution for the encoder pulse output signals (PAO, /PAO, PBO, and /PBO) from the SERVOPACK to the host controller.

The number of feedback pulses per linear encoder pitch is divided by the setting of Pn281 (after multiplication by 4) inside the SERVOPACK and then the resulting number of pulses is output. Set the parameter according to the system specifications of the machine or host controller.

The setting range depends on the Servomotor's maximum speed (Pn385) and the linear scale pitch (Pn282).\* You can calculate the upper limit of the setting of Pn281 with the following formula

Upper limit of Pn281 = 
$$\frac{\text{Linear Encoder Pitch*/100}}{\text{Pn385}} \times 72$$

\* The value depends on whether a Serial Converter Unit is used.

Using a Serial Converter Unit	Setting of Pn282
ear encoder and SERVOPACK are connected	The linear encoder pitch is automatically detected by the SERVO-PACK, so the setting of Pn282 is ignored. You can use the monitor functions of the SigmaWin+ to check the linear encoder pitch that was automatically detected.

#### Information

When the linear encoder pitch is 4  $\mu$ m, the maximum motor speed is limited to 1 mm/s because of the maximum response frequency of the Serial Converter Unit.

If the setting is out of range or does not satisfy the setting conditions, an A.041 alarm (Encoder Output Pulse Setting Error) will be output. If the motor speed exceeds the upper limit for the set encoder output resolution, an A.511 alarm (Encoder Output Pulse Overspeed) will be output.

The upper limit of the encoder output resolution is restricted by the dividing specifications of the Serial Converter Unit.

#### Example

#### Setting Example


Correct setting for a linear encoder pitch of 20  $\mu$ m and a maximum motor speed of 5 m/s (Pn385 = 50): Pn281 = 28 (edges/pitch)

Incorrect setting: Pn281 = 29 (edges/pitch) (An A.041 alarm would be output.)

#### Example

#### Pulse Output Example

When Pn281 = 20 (20-edge output (5-pulse output) per linear encoder pitch)



# 6.6 Software Limits

You can set limits in the software for machine movement that do not use the overtravel signals (P-OT and N-OT). If a software limit is exceeded, an emergency stop will be executed in the same way as it is for overtravel.

Refer to the following section for details on this function.

Software Position Limits (607D Hex) on page 14-29

#### 6.7.1 Internal Torque Limits

## 6.7

# **Selecting Torque Limits**

You can limit the torque that is output by the Servomotor.

There are four different ways to limit the torque. These are described in the following table.

Limit Method	Outline	Control Method	Reference
Internal Torque Limits	The torque is always limited with the setting of a parameter.	Speed control, position control, or	6.7.1
External Torque Limits	The torque is limited with an input signal from the host computer.	torque control	6.7.2
Limiting Torque with controlword (6040 hex)	A command from the Controller enables the torque limit that is set in a parameter.		14.6
Limiting Torque with positive torque limit value (60E0 hex) and negative torque limit value (60E1 hex)	Torque is controlled with torque limits from the Controller.	Speed control or position control	13.7

Note: If you set a value that exceeds the maximum torque of the Servomotor, the torque will be limited to the maximum torque of the Servomotor.

### 6.7.1 Internal Torque Limits


If you use internal torque limits, the maximum output torque will always be limited to the specified forward torque limit (Pn402) and reverse torque limit (Pn403).

Rotary Servomotors

Pn402 (2402 hex)	Forward Torque Limit Speed Position Torque				
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup
Pn403	Reverse Torque Limit			Speed Positio	n Torque
(2403	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	800	Immediately	Setup

<sup>\*</sup> Set a percentage of the rated motor torque.

Note: If the setting of Pn402 or Pn403 is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.




#### Linear Servomotors

Pn483	Forward Force Limit Speed Position Force					
(2483	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 800	1%*	30	Immediately	Setup	
Pn484	Reverse Force Limit Speed Position Force					
(2484	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 800	1%*	30	Immediately	Setup	

<sup>\*</sup> Set a percentage of the rated motor force.

Note: If the setting of Pn483 or Pn484 is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.



#### 6.7.2 **External Torque Limits**

You can limit the torque only when required by the operating conditions of the machine by turning a signal ON and OFF.

You can use this for applications such as stopping on physical contact, or holding a workpiece with a robot.

### **External Torque Limit Reference Signals**

The /P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals are used as the external torque limit reference signals. The /P-CL signal is used for the forward torque limit and the /N-CL signal is used for the reverse torque limit.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Input	/P-CL	Must be allocated.	ON (closed)	Applies the forward external torque limit. The torque is limited to the smaller of the settings of Pn402*1 and Pn404.
·			OFF (open)	Cancels the forward external torque limit.  The torque is limited to the setting of Pn402*1.
Input	/N-CL	Must be allocated.	ON (closed)	Applies the reverse external torque limit. The torque is limited to the smaller of the settings of Pn403*2 and Pn404.
			OFF (open)	Cancels the reverse external torque limit.  The torque is limited to the setting of Pn403*2.

<sup>\*1.</sup> Pn483 is used for a Linear Servomotor.

Note: You must allocate the /P-CL and /N-CL signals to use them. You can use the following parameters to allocate the signal to a terminal.

- Pn50B = n. \(\text{DX}\) \(\text{D}\) (/P-CL (Forward External Torque Limit Input) Signal Allocation)
- Pn50B = n.X□□□ (/N-CL (Reverse External Torque Limit Input) Signal Allocation)

Refer to the following section for details.

(3 6.1.1 Input Signal Allocations on page 6-4

<sup>\*2.</sup> Pn484 is used for a Linear Servomotor.

#### 6.7.2 External Torque Limits

### **Setting the Torque Limits**

The parameters that are related to setting the torque limits are given below.

#### Rotary Servomotors

If the setting of Pn402 (Forward Torque Limit), Pn403 (Reverse Torque Limit), Pn404 (Forward External Torque Limit), or Pn405 (Reverse External Torque Limit) is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.

Pn402	Forward Torque Lim	it		Speed Position	Torque
(2402	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	800	Immediately	Setup
Pn403	Reverse Torque Lim	it	Speed Position	on Torque	
(2403	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	800	Immediately	Setup
Pn404	Forward External Torque Limit Speed Position To				on Torque
(2404	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	100	Immediately	Setup
Pn405 (2405	Reverse External To	rque Limit		Speed Position	on Torque
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	100	Immediately	Setup

<sup>\*</sup> Set a percentage of the rated motor torque.

#### · Linear Servomotors

If the setting of Pn483 (Forward Force Limit), Pn484 (Reverse Force Limit), Pn404 (Forward External Force Limit), or Pn405 (Reverse External Force Limit) is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.

Pn483 (2483	Forward Force Limit	t		Speed Position	n Force
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	30	Immediately	Setup
Pn484	Reverse Force Limit	t		Speed Position	n Force
(2484	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	30	Immediately	Setup
Pn404	Forward External Force Limit Speed Position Force				
(2404	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	100	Immediately	Setup
Pn405 (2405	Reverse External Fo	orce Limit		Speed Position	n Force
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%*	100	Immediately	Setup


<sup>\*</sup> Set a percentage of the rated motor force.

### Changes in the Output Torque for External Torque Limits

The following table shows the changes in the output torque when the internal torque limit is set to 800%.


#### · Rotary Servomotors

It is assumed that counterclockwise is set as the forward direction of motor rotation (Pn000 =  $n.\Box\Box\Box$ 0).



#### · Linear Servomotors

It is assumed that the linear encoder count-up direction is set as the forward direction of motor movement ( $Pn000 = n.\square\square\square\square$ 0).



### 6.7.3 /CLT (Torque Limit Detection) Signal

This section describes the /CLT signal, which indicates the status of limiting the motor output torque.

Type	Signal	Connector Pin No.	Signal Status	Meaning
Output /CLT	/CLT	Must be allocated.	ON (closed)	The motor output torque is being limited.
	/CLT		OFF (open)	The motor output torque is not being limited.

Note: You must allocate the /CLT signal to use it. Use Pn50F = n. \(\sigma \square\) \(\text{CLT (Torque Limit Detection)}\) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

## 6.8 Absolute Encoders

The absolute encoder records the current position of the stop position even when the power supply is OFF

With a system that uses an absolute encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are two types of encoders for Rotary Servomotors. The usage of the encoder is specified in  $Pn002 = n.\Box X\Box \Box$ .

Refer to the following section for encoder models.

■ Encoder Resolution on page 5-43

· Parameter Settings When Using an Incremental Encoder

Parameter		Meaning	When Enabled	Classification
n.□0□□ (default setting)		Use the encoder as an incremental encoder. A battery is not required.		
Pn002 (2002 hex)	n.□1□□ Use the encoder as an incremental encoder. A battery is not required.		After restart	Setup
,	n.□2□□	Use the encoder as a single-turn absolute encoder. A battery is not required.		

Parameter Settings When Using a Multiturn Absolute Encoder

Parameter		Meaning	When Enabled	Classification
D 000	n.□0□□ (default setting)	Use the encoder as a multiturn absolute encoder. A battery is required.		
Pn002 (2002 hex)	n.□1□□	Use the encoder as an incremental encoder. A battery is not required.	After restart	Setup
,	n.□2□□	Use the encoder as a single-turn absolute encoder. A battery is not required.		

### NOTICE

• Install a battery at either the host controller or on the Encoder Cable.

If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.

### 6.8.1 Connecting an Absolute Encoder

You can get the position data from the absolute encoder with EtherCAT communications. Therefore, it is not necessary to wire the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

If they need to be wired, refer to the following section.

4.4.3 Wiring the SERVOPACK to the Encoder on page 4-20

(2) 4.5.3 I/O Signal Wiring Examples on page 4-31

6.8.2 Structure of the Position Data of the Absolute Encoder

#### 6.8.2 Structure of the Position Data of the Absolute Encoder

The position data of the absolute encoder is the position coordinate from the origin of the absolute encoder.

The position data from the absolute encoder contains the following two items.

- The number of rotations from the origin of the encoder coordinate system (called the multiturn data)
- The position (number of pulses) within one rotation

The position data of the absolute encoder is as follows:


Position data of absolute encoder = Multiturn data × Number of pulses within one encoder rotation (setting of Pn212) + Position (number of pulses) within one rotation.

For a single-turn absolute encoder, the multiturn data is 0.

# 6.8.3 Output Ports for the Position Data from the Absolute Encoder

You can read the position data of the absolute encoder from the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

The output method and timing for the position data of the absolute encoder are different in each case. A conceptual diagram of the connections of the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals to the host controller is provided below.



Signal	Status	Signal Contents When Using an Absolute Encoder
PAO	First signal	Multiturn data position within one rotation (pulse train)
	During normal operation	Incremental pulses
PBO	First signal	Position within one rotation (pulse train)
1 00	During normal operation	Incremental pulses
PCO	Always	Origin pulse

The PAO (Encoder Divided Pulse Output) signal outputs the position data from the absolute encoder after the control power supply is turned ON.

The position data of the absolute encoder is the current stop position. The absolute encoder outputs the multiturn data with the specified protocol. The absolute encoder outputs the position within one rotation as a pulse train. It then outputs pulses as an incremental encoder (incremental operation status).

The host controller must have a reception circuit (e.g., UART) for the position data from the absolute encoder. The pulse counter at the host controller will not count pulses when the multiturn data (communications message) is input because only phase A is input. Counting starts from the position of the absolute encoder within one rotation.

The output circuits for the PAO, PBO, and PCO signals use line drivers. Refer to the following section for details on line drivers.


(a) 4.5.4 I/O Circuits on page 4-33

### 6.8.4 Reading the Position Data from the Absolute Encoder

The sequence to read the position data from the absolute encoder of a Rotary Servomotor is given below.

The multiturn data is sent according to the transmission specifications.

The position of the absolute encoder within one rotation is output as a pulse train.



\* The pulse output time T for the position of the absolute encoder within one rotation depends on the setting of Pn212 (Number of Encoder Output Pulses). Refer to the following table.

Setting of Pn212	Calculation of the Pulse Output Speed for the Position of the Absolute Encoder within One Rotation	Calculation of the Pulse Output Time T for the Position of the Absolute Encoder within One Rotation
16 to 16,384	680 × Pn212/16,384 [kpps]	25 ms max.
16,386 to 32,768	680 × Pn212/32,768 [kpps]	50 ms max.
32,722 to 65,536	680 × Pn212/65,536 [kpps]	100 ms max.
65,544 to 131,072	680 × Pn212/131,072 [kpps]	200 ms max.
131,088 to 262,144	680 × Pn212/262,144 [kpps]	400 ms max.
262,176 to 524,288	680 × Pn212/524,288 [kpps]	800 ms max.
524,352 to 1,048,576	680 × Pn212/1,048,576 [kpps]	1,600 ms max.
1,048,704 to 2,097,152	680 × Pn212/2,097,152 [kpps]	3,200 ms max.
2,097,408 to 4,194,304	680 × Pn212/4,194,304 [kpps]	6,400 ms max.

### 6.8.5 Transmission Specifications

The position data transmission specifications for the PAO (Encoder Divided Pulse Output) signal are given in the following table.

The PAO signal sends only the multiturn data.


Refer to the following section for the timing of sending the position data from the absolute encoder.

6.8.4 Reading the Position Data from the Absolute Encoder on page 6-33

Item	PAO signal
Synchronization Method	Start-stop synchronization (ASYNC)
Baud Rate	9,600 bps
Start Bits	1 bit
Stop Bits	1 bit
Parity	Even
Character Code	ASCII, 7 bits
Data Format	Refer to Data Format of PAO Signal.
Data Output Period	Only once after the control power supply is turned ON

#### **Data Format of PAO Signal**

As shown below, the message format consists of eight characters: "P," the sign, the 5-digit multiturn data, and "CR" (which indicates the end of the message).




### 6.8.6 Calculating the Current Position in Machine Coordinates

When you reset the absolute encoder, the reset position becomes the reference position.

The host controller reads the coordinate Ps from the origin of the encoder coordinate system. The host controller must record the value of coordinate Ps.

This section describes the reference position in the machine coordinate system.

The method to calculate the coordinate value of the present position from the origin of the machine coordinate system is given below.



The current position  $P_M$  in the machine coordinate system is calculated as follows:

$$P_{M} = P_{E} - P_{S}$$

$$P_{E} = M \times R + P_{O}$$

$$P_{S} = M_{S} \times R + P_{S}'$$

Symbol	Meaning	
PE	Position data for the current position of the absolute encoder	
М	Current position of the multiturn data of the absolute encoder	
Po	Position of the current position within one rotation	
P <sub>S</sub>	Position data of the absolute encoder when absolute encoder was reset	
M <sub>S</sub>	Multiturn data of the absolute encoder when absolute encoder was reset	
P <sub>S</sub> '	Position of the absolute encoder within one rotation when absolute encoder was reset	
P <sub>M</sub>	Current position in machine coordinate system	
R	Pulses output per encoder rotation (value after dividing; setting of Pn212)	

Note: The following formulas apply in Reverse Rotation Mode (Pn000 = n.□□□1).

$$P_{M} = P_{E} - P_{S}$$

$$P_{E} = -M \times R + P_{O}$$

$$P_{S} = M_{S} \times R + P_{S}$$

#### Information


1. If you are using a Rotary Servomotor, you must reset the absolute encoder. Refer to the following section for information on resetting the absolute encoder.

5.15 Resetting the Absolute Encoder on page 5-49

- 2. You can set the origin to a different position from the reset position. Refer to the following section for information on the origin position offset.
  - 5.16 Setting the Origin of the Absolute Encoder on page 5-52

### 6.8.7 Multiturn Limit Setting

The multiturn limit is used in position control for a turntable or other rotating body. For example, consider a machine that moves the turntable shown in the following diagram in only one direction.



Because the turntable moves in only one direction, the upper limit to the number of revolutions that can be counted by an absolute encoder will eventually be exceeded.

The multiturn limit is used in cases like this to prevent fractions from being produced by the integral ratio of the number motor revolutions and the number of turntable revolutions.


For a machine with a gear ratio of n:m, as shown above, the value of m minus 1 will be the setting for the multiturn limit setting (Pn205).

Multiturn limit (Pn205) = m - 1

The relationship between the number of turntable revolutions and the number of motor revolutions is shown in the following graph for when m is 100 and n is 3.

Set Pn205 to 99.

Pn205 = 100 - 1 = 99




Pn205	Multiturn Limit Speed Position				n Torque
(2205	Setting Range Setting Unit Default Setting			When Enabled	Classification
hex)	0 to 65,535	1 Rev	65,535	After restart	Setup

Note: This parameter is enabled when you use an absolute encoder.

The data will change as shown below when this parameter is set to anything other than the default setting.

- If the motor operates in the reverse direction when the multiturn data is 0, the multiturn data will change to the value set in Pn205.
- If the motor operates in the forward direction when the multiturn data is at the value set in Pn205, the multiturn data will change to 0.

Set Pn205 to one less than the desired multiturn data.



Information

When the encoder is set to be used as a single-turn absolute encoder ( $Pn002 = n.\Box 2\Box\Box$ ), the multiturn data will always be zero. It is not necessary to reset the absolute encoder. Also, an alarm related to the absolute encoder (A.810 or A.820) will not occur.

### 6.8.8 Multiturn Limit Disagreement Alarm (A.CC0)

If you change the multiturn limit in Pn205 (Multiturn Limit), an A.CCO alarm (Multiturn Limit Disagreement) will be displayed because the setting disagrees with the value in the encoder.

Display	Name	Meaning
A.CC0	Multiturn Limit Disagreement	Different multiturn limits are set in the encoder and SERVO-PACK.

If this alarm is displayed, use the following procedure to change the multiturn limit in the encoder to the same value as the setting of Pn205.

#### **Applicable Tools**

The following table lists the tools that you can use to set the multiturn limit.


Tool	Function	Operating Procedure Reference
Digital Operator	Fn013	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Multiturn Limit Setting	Operating Procedure on page 6-38
EtherCAT communications	SERVOPACK Adjusting Command (2710 hex)	SERVOPACK Adjusting Command (2710 Hex) on page 14-19

6.8.8 Multiturn Limit Disagreement Alarm (A.CC0)

#### **Operating Procedure**


Use the following procedure to adjust the multiturn limit setting.

- 1. Click the 🔑 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Multiturn Limit Setting in the Menu Dialog Box. The Multiturn Limit Setting Dialog Box will be displayed.
- 3. Click the Continue Button.




Click the **Cancel** Button to cancel setting the multiturn limit. The Main Window will return.

4. Change the setting.




- 5. Click the Writing into the Servopack Button.
- 6. Click the OK Button.




- 7. Turn the power supply to the SERVOPACK OFF and ON again.

  An A.CC0 alarm (Multiturn Limit Disagreement) will occur because setting the multiturn limit in the Servomotor is not yet completed even though the setting has been changed in the SERVOPACK.
- 8. Display the Multiturn Limit Setting in the Menu Dialog Box.
- 9. Click the Continue Button.



10. Click the Writing into the Motor Button.



Click the **Re-change** Button to change the setting.

11. Click the OK Button.



This concludes the procedure to set the multiturn limit.

6.9.1 Connecting an Absolute Linear Encoder

### 6.9

# **Absolute Linear Encoders**

The absolute linear encoder records the current position of the stop position even when the power supply is OFF.

With a system that uses an absolute linear encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are two types of linear encoders for Linear Servomotors. The usage of the linear encoder is specified in  $Pn002 = n.\Box X \Box \Box$ .

Refer to the following section for linear encoder models.

Feedback Resolution of Linear Encoder on page 5-44

· Parameter Settings When Using an Incremental Linear Encoder

Parameter		Meaning	When Enabled	Classification
Pn002 (2002	n.□0□□ (default setting)	Use the encoder as an incremental linear encoder.	After restart	Setup
hex)	n.□1□□	Use the encoder as an incremental linear encoder.		

#### Parameter Settings When Using an Absolute Linear Encoder

Parameter		arameter	Meaning	When Enabled	Classification
	1 11002	n.□0□□ (default setting)	Use the encoder as an absolute linear encoder.	After restart	Setup
	hex)	n.□1□□	Use the encoder as an incremental linear encoder.		

### 6.9.1 Connecting an Absolute Linear Encoder

You can get the position data from the absolute linear encoder with EtherCAT communications. Therefore, it is not necessary to wire the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

If they need to be wired, refer to the following section.


4.4.3 Wiring the SERVOPACK to the Encoder on page 4-20

4.5.3 I/O Signal Wiring Examples on page 4-31

# 6.9.2 Structure of the Position Data of the Absolute Linear Encoder

The position data of the absolute linear encoder is the distance (number of pulses) from the origin of the absolute linear encoder.

The position data is signed 36-bit data.




When the SERVOPACK sends the position data, it sends the upper 16-bit data (with sign) separately from the lower 20-bit data.

# 6.9.3 Output Ports for the Position Data from the Absolute Linear Encoder

You can read the position data of the absolute linear encoder from the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

The output method and timing for the position data of the absolute linear encoder are different in each case.

A conceptual diagram of the connections of the PAO, PBO, and PCO (Encoder Divided Pulse Output) ports to the host controller is provided below.



Signal	Status	Signal Contents	
Signal	Status	When Using an Absolute Linear Encoder	
PAO	First signal	Upper 16-bit data (with sign) Lower 20-bit data (pulse train)	
	During normal operation	Incremental pulses	
PBO	First signal	Lower 20-bit data (pulse train)	
1 00	During normal operation	Incremental pulses	
PCO Always		Origin pulse	

The PAO (Encoder Divided Pulse Output) signal outputs the position data from the absolute linear encoder after the control power supply is turned ON.

The position data of the absolute linear encoder is the current stop position. The absolute linear encoder outputs the upper 16-bit data (with sign) according to the specified protocol. The absolute encoder outputs the lower 20-bit data as a pulse train. It then outputs pulses as an incremental linear encoder (incremental operation status).

The host controller must have a reception circuit (e.g., UART) for the position data from the absolute linear encoder. The pulse counter at the host controller will not count pulses when the upper 16-bit data (with sign) (communications message) is input because only phase A is input.

The output circuits for the PAO, PBO, and PCO signals use line drivers. Refer to the following section for details on line drivers.


(a) 4.5.4 I/O Circuits on page 4-33

# 6.9.4 Reading the Position Data from the Absolute Linear Encoder

The sequence to read the position data from the absolute linear encoder of a Linear Servomotor is given below.

The upper 16-bit position data (with sign) are sent according to the transmission specifications.

The lower 20-bit data is output as a pulse train.



### 6.9.5 Transmission Specifications

The position data transmission specifications for the PAO (Encoder Divided Pulse Output) signal are given in the following table.

The PAO signal sends only the 16-bit data (with sign).


Refer to the following section for the timing of sending the position data from the absolute encoder.

6.9.4 Reading the Position Data from the Absolute Linear Encoder on page 6-42

Item	PAO signal
Synchronization Method	Start-stop synchronization (ASYNC)
Baud Rate	9,600 bps
Start Bits	1 bit
Stop Bits	1 bit
Parity	Even
Character Code	ASCII, 7 bits
Data Format	Refer to Data Format of PAO Signal.
Data Output Period	Only once after the control power supply is turned ON

### **Data Format of PAO Signal**

As shown below, the message format consists of eight characters: "P," the sign, the 5-digit upper 15-bit position data, and "CR" (which indicates the end of the message).



### 6.9.6 Calculating the Current Position in Machine Coordinates

With an absolute linear encoder, you must set the position of the origin (i.e., the origin of the machine coordinate system).


The host controller reads the coordinate from the origin of the encoder coordinate system. The host controller must record the value of this coordinate.

The method to calculate the coordinate value of the present position from the origin of the machine coordinate system is given below.

The position data from the absolute linear encoder is signed 36-bit data, but the upper 16 bits (with sign) and the lower 20 bits are output separately.

For the upper 16-bit data (with sign), the upper bits (16 bits, including the sign) of the current position after dividing by the setting of Pn281 are output with serial communications according to the transmission specifications.

For the lower 20-bit data, the lower bits (20 bits) of the current position after dividing by the setting of Pn281 are output as a pulse train.



The current position P<sub>M</sub> in the machine coordinate system is calculated as follows:

$$P_{M} = P_{E} - P_{S}$$

$$P_{E} = M_{O} \times R + P_{O}$$

$$P_{S} = M_{S} \times R + P_{S}'$$

Symbol	Meaning
PE	Position data for the current position of the absolute linear encoder
M <sub>O</sub>	Upper 16 bits (with sign) of the position data for the current position of the absolute linear encoder
Po	Lower 20 bits of the position data for the current position of the absolute linear encoder
P <sub>S</sub>	Position data of the origin
M <sub>S</sub>	Upper 16 bits (with sign) of the position data of the origin
P <sub>S</sub> '	Lower 20 bits of the position data of the origin
P <sub>M</sub>	Current position in machine coordinate system
R	1048576 (=2 <sup>20</sup> )

Note: The above formulas also apply in reverse movement mode (Pn000 =  $n.\square\square\square1$ ).

Information

If you are using a Linear Servomotor, you do not need to reset the absolute linear encoder to define the origin. (Some absolute linear encoders also allow you to set any position as the origin.)

#### 6.10.1 Preparations

### 6.10

### **Software Reset**

You can reset the SERVOPACK internally with the software. A software reset is used when resetting alarms and changing the settings of parameters that normally require turning the power supply to the SERVOPACK OFF and ON again. This can be used to change those parameters without turning the power supply to the SERVOPACK OFF and ON again.

#### Information

- Always confirm that the servo is OFF and that the motor is stopped before you start a software reset.
- This function resets the SERVOPACK independently of the host controller. The SERVO-PACK carries out the same processing as when the power supply is turned ON and outputs the ALM (Servo Alarm) signal. The status of other output signals may be forcibly changed.
- 3. When you execute a software reset, the SERVOPACK will not respond for approximately five seconds.
  - Before you execute a software reset, check the status of the SERVOPACK and Servomotor and make sure that no problems will occur.

### 6.10.1 Preparations

Confirm that the following conditions are met before you perform a software reset.

- The servo must be OFF.
- The motor must be stopped.

### 6.10.2 Applicable Tools


The following table lists the tools that you can use to perform a software reset.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn030	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Software Reset	6.10.3 Operating Procedure on page 6-45

### 6.10.3 Operating Procedure


Use the following procedure to perform a software reset.

- 1. Click the 🔑 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Software Reset in the Menu Dialog Box. The Software Reset Dialog Box will be displayed.
- 3. Click the Execute Button.



Click the Cancel Button to cancel the software reset. The Main Window will return.

4. Click the Execute Button.



**5.** Click the **OK** Button to end the software reset operation.

All settings including parameters will have been re-calculated. When you finish this operation, disconnect the SigmaWin+ from the SERVOPACK, and then connect it again.



This concludes the procedure to reset the software.

### 6.11.1 Preparations

## 6.11

# Initializing the Vibration Detection Level

You can detect machine vibration during operation to automatically adjust the settings of Pn312 or Pn384 (Vibration Detection Level) to detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration Warning) more precisely.

This function detects specific vibration components in the Servomotor speed.

		Parameter	Meaning	When Enabled	Classification
	Pn310	n.□□□0 (default setting)	Do not detect vibration.	lanca a Ratalia	
	(2310 hex)	n.□□□1	Output a warning (A.911) if vibration is detected.	Immediately	Setup
	ΠΟΧ	n.□□□2	Output an alarm (A.520) if vibration is detected.		

If the vibration exceeds the detection level calculated with the following formula, an alarm or warning occurs according to Pn310 (Vibration Detection Selection).

· Rotary Servomotors

Detection level = Vibration detection level (Pn312 [min-1]) × Vibration detection sensitivity (Pn311 [%])

Linear Servomotors

Detection level = Vibration detection level (Pn384 [mm/s]) × Vibration detection sensitivity (Pn311 [%])

Use this function only if A.520 or A.911 alarms are not output at the correct times when vibration is detected with the default vibration detection level (Pn312 or Pn384).

There will be discrepancies in the detection sensitivity for vibration alarms and warnings depending on the condition of your machine. If there is a discrepancy, use the above formula to adjust Pn311 (Vibration Detection Sensitivity).

D=011	Vibration Detection	Sensitivity		Speed Position Torque		
Pn311 (2311 hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
(2011110)	50 to 500	1%	100	Immediately	Tuning	

### Information

- 1. Vibration may not be detected because of unsuitable servo gains. Also, not all kinds of vibrations can be detected.
- 2. Set a suitable moment of inertia ratio (Pn103). An unsuitable setting may result in falsely detecting or not detecting vibration alarms or vibration warnings.
- 3. To use this function, you must input the actual references that will be used to operate your system.
- 4. Execute this function under the operating conditions for which you want to set the vibration detection level.
- 5. Execute this function while the motor is operating at 10% of its maximum speed or faster.

### 6.11.1 Preparations

Check the following settings before you initialize the vibration detection level.

- The parameters must not be write prohibited.
- The test without a motor function must be disabled (Pn00C = n.□□□0).

### 6.11.2 Applicable Tools


The following table lists the tools that you can use to initialize the vibration detection level and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn01B	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Initialize Vibra- tion Detection Level	6.11.3 Operating Procedure on page 6-47

### 6.11.3 Operating Procedure


Use the following procedure to initialize the vibration detection level.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Initialize Vibration Detection Level in the Menu Dialog Box. The Initialize Vibration Detection Level Dialog Box will be displayed.
- Select Pn311: Vibration Detection Sensitivity and Pn310: Vibration Detection Selections and then click the Detection Start Button.
   A setting execution standby mode will be entered.




### 6.11.3 Operating Procedure

### 4. Click the Execute Button.



The newly set vibration detection level will be displayed and the value will be saved in the SERVO-PACK.



This concludes the procedure to initialize the vibration detection level.

### 6.11.4 Related Parameters

The following three items are given in the following table.

- Parameters Related to this Function

  These are the parameters that are used or referenced when this function is executed.
- Changes during Function Execution
   Not allowed: The parameter cannot be changed using the SigmaWin+ or other tool while this function is being executed.
  - Allowed: The parameter can be changed using the SigmaWin+ or other tool while this function is being executed.
- Automatic Changes after Function Execution
   Yes: The parameter is automatically set or adjusted after execution of this function.
   No: The parameter is not automatically set or adjusted after execution of this function.

Parameter	Name	Setting Changes	Automatic Changes	
Pn311 (2311 hex)	Vibration Detection Sensitivity	Allowed	No	
Pn312 (2312 hex)	Vibration Detection Level	Not allowed	Yes	
Pn384 (2384 hex)	Vibration Detection Level	Not allowed	Yes	

6.12.1 Automatic Adjustment

## 6.12

# Adjusting the Motor Current Detection Signal Offset

The motor current detection signal offset is used to reduce ripple in the torque. You can adjust the motor current detection signal offset either automatically or manually.

### 6.12.1 Automatic Adjustment

Perform this adjustment only if highly accurate adjustment is required to reduce torque ripple. It is normally not necessary to adjust this offset.



Execute the automatic offset adjustment if the torque ripple is too large when compared with other SERVOPACKs.



The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

### **Preparations**

The following conditions must be met to automatically adjust the motor current detection signal offset.

- The parameters must not be write prohibited.
- The servo must be in ready status.
- The servo must be OFF.

### Applicable Tools

The following table lists the tools that you can use to automatically adjust the offset.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn00E	Σ-7-Series Digital Operator Operating Manual (document No. SIEP S800001 33)
SigmaWin+	Setup - Adjust Offset - Adjust the Motor Current Detection Offset	Operating Procedure on page 6-51
EtherCAT communications	SERVOPACK Adjusting Command (2710 hex)	SERVOPACK Adjusting Command (2710 Hex) on page 14-19


### **Operating Procedure**

Use the following procedure to automatically adjust the motor current detection signal offset.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Adjust the Motor Current Detection Signal Offsets in the Menu Dialog Box. The Adjust the Motor Current Detection Signal Offsets Dialog Box will be displayed.
- 3. Click the Continue Button.




**4.** Click the **Automatic Adjustment** Tab in the Adjust the Motor Current Detection Signal Offsets Dialog Box.



### 6.12.1 Automatic Adjustment

**5.** Click the Adjust Button. The values that result from automatic adjustment will be displayed in the **New** Boxes.



This concludes the procedure to automatically adjust the motor current detection signal offset.

### 6.12.2 Manual Adjustment

You can use this function if you automatically adjust the motor current detection signal offset and the torque ripple is still too large.



If the offset is incorrectly adjusted with this function, the Servomotor characteristics may be adversely affected.

Observe the following precautions when you manually adjust the offset.

- Operate the Servomotor at a speed of approximately 100 min<sup>-1</sup>.
- Adjust the offset while monitoring the torque reference with the analog monitor until the ripple is minimized.
- Adjust the offsets for the phase-U current and phase-V current of the Servomotor so that they are balanced. Alternately adjust both offsets several times.



The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

### **Preparations**

The following conditions must be met to manually adjust the motor current detection signal offset.

• The parameters must not be write prohibited.

### **Applicable Tools**


The following table lists the tools that you can use to manually adjust the offset and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn00F	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Adjust Offset - Adjust the Motor Current Detection Offset	Operating Procedure on page 6-53

### **Operating Procedure**


Use the following procedure to manually adjust the motor current detection signal offset.

- 1. Operate the motor at approximately 100 min<sup>-1</sup>.
- 2. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Adjust the Motor Current Detection Signal Offsets in the Menu Dialog Box. The Adjust the Motor Current Detection Signal Offsets Dialog Box will be displayed.
- 4. Click the Continue Button.



### 6.12.2 Manual Adjustment

**5.** Click the **Manual Adjustment** Tab in the Adjust the Motor Current Detection Signal Offsets Dialog Box.



- 6. Set the Channel Box in the Motor Current Detection Offset Area to U-phase.
- 7. Use the +1 and -1 Buttons to adjust the offset for phase U.

  Change the offset by about 10 in the direction that reduces the torque ripple.

  Adjustment range: -512 to +511
- 8. Set the Channel Box in the Motor Current Detection Offset Area to V-phase.
- **9.** Use the +1 and -1 Buttons to adjust the offset for phase V. Change the offset by about 10 in the direction that reduces the torque ripple.
- **10.** Repeat steps 6 to 9 until the torque ripple cannot be improved any further regardless of whether you increase or decrease the offsets.
- 11. Reduce the amount by which you change the offsets each time and repeat steps 6 to 9.

This concludes the procedure to manually adjust the motor current detection signal offset.

# 6.13 Forcing the Motor to Stop

You can force the Servomotor to stop for a signal from the host controller or an external device.

To force the motor to stop, you must allocate the FSTP (Forced Stop Input) signal in Pn516 =  $n.\Box\Box\Box$ X. You can specify one of the following stopping methods: dynamic brake (DB), coasting to a stop, or decelerating to a stop.

Note: Forcing the motor to stop is not designed to comply with any safety standard. In this respect, it is different from the hard wire base block (HWBB).

Information

Panel Operator and Digital Operator Displays

When a forced stop is performed, the panel and the Digital Operator will display FSTP.

## **CAUTION**

• To prevent accidents that may result from contact faults or disconnections, use a normally closed switch for the Forced Stop Input signal.

### 6.13.1 FSTP (Forced Stop Input) Signal

Classifica- tion	Signal	Connector Pin No.	Signal Status	Description
Input	FSTP	Must be allocated.	ON (closed)	Drive is enabled (normal operation).
прис	FSIP		OFF (open)	The motor is stopped.

Note: You must allocate the FSTP signal to use it. Use Pn516 = n.□□□X (FSTP (Forced Stop Input) Signal Allocation) to allocate the FSTP signal to a connector pin. Refer to the following section for details.

6.1.1 Input Signal Allocations on page 6-4

### 6.13.2 Stopping Method Selection for Forced Stops

Use  $Pn00A = n.\square\square X\square$  (Stopping Method for Forced Stops) to set the stopping method for forced stops.

	Par	ameter	Description	When Enabled	Classifi- cation
(2		n.□□0□	Apply the dynamic brake or coast the motor to a stop (use the stopping method set in $Pn001 = n.\square\square\square\square X$ ).		
		n.□□1□ (default set- ting)	Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque. Use the setting of Pn001 = n. \(\sigma\) \(\sigma\) for the status after stopping.		
	Pn00A (200A hex)	n.□□2□	Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque and then let the motor coast.	After restart	Setup
		n.□□3□	Decelerate the motor to a stop using the deceleration time set in Pn30A. Use the setting of Pn001 = n. \(\Pi\)\(\P		
		n.□□4□	Decelerate the motor to a stop using the deceleration time set in Pn30A and then let the motor coast.		

Note: You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop according to the setting of Pn001 = n. \(\sigma \square \text{D} \square X\) (Servo OFF or Alarm Group 1 Stopping Method).

6.13.2 Stopping Method Selection for Forced Stops

# Stopping the Servomotor by Setting Emergency Stop Torque (Pn406)

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If  $Pn001 = n.\square\squareX\square$  is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

Pn406	Emergency Stop To	rque		Speed Position  When Enabled Classification		
(2406	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 800	1%*	800	Immediately	Setup	

<sup>\*</sup> Set a percentage of the motor rated torque.


# Stopping the Servomotor by Setting the Deceleration Time for Servo OFF and Forced Stops (Pn30A)

To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

Pn30A	Deceleration Time for	or Servo OFF and Fo	rced Stops	Speed Position		
(230A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 10,000	1 ms	0	Immediately	Setup	

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the motor from the maximum motor speed.




### 6.13.3 Resetting Method for Forced Stops

This section describes the reset methods that can be used after stopping operation for an FSTP (Forced Stop Input) signal.

If the FSTP (Forced Stop Input) signal is OFF and the Servo ON command (Enable Operation command) is input, the forced stop state will be maintained even after the FSTP signal is turned ON.

Send the Servo OFF command (Disable Operation command) to place the SERVOPACK in the base block (BB) state and then send the Servo ON command (Enable Operation command).



6.14.1 ZONE Table and ZONE Signals

# 6.14

# **ZONE Outputs (FT64 Specification)**

You can use ZONE signals to output a ZONE number to indicate when the current value is within a registered zone.

The ZONE signals (/ZONE0 to /ZONE3) are assigned to output signals (/SO1 to /SO5) on CN1.

### 6.14.1 ZONE Table and ZONE Signals

You can register the desired zones in the ZONE table. The ZONE table consists of settings for the ZONE numbers (ZONE), ZONE N values (ZONE N), and ZONE P values (ZONE P). You can register up to 16 zones.

The ZONE numbers identify the registered zones.

ZONE N is the lower limit of the ZONE and ZONE P is the upper limit of the ZONE. The setting conditions for ZONE N and ZONE P are given in the following table.

Setting Range	Setting Unit	Default Setting	When Enabled
-2,147,483,648 to 2,147,483,647	Pos unit	0	Immediately

The ZONE signals indicate the ZONE number. If the current value is within a zone registered in the ZONE table, the corresponding ZONE number is output on the ZONE signals.

You can use the ZONE signals as required, e.g., to trigger operations related to positioning.

	ZONE Table				Signals	
ZONE Number (ID)	ZONE N [Pos unit]	ZONE P [Pos unit]	/ZONE3	/ZONE2	/ZONE1	/ZONE0
0	±nnnnnnnnnn	±nnnnnnnnnn	0	0	0	0
1	±nnnnnnnnnn	±nnnnnnnnnn	0	0	0	1
2	±nnnnnnnnnn	±nnnnnnnnnn	0	0	1	0
3	±nnnnnnnnnn	±nnnnnnnnnn	0	0	1	1
4	±nnnnnnnnnn	±nnnnnnnnnn	0	1	0	0
5	±nnnnnnnnnn	±nnnnnnnnnn	0	1	0	1
6	±nnnnnnnnnn	±nnnnnnnnnn	0	1	1	0
7	±nnnnnnnnnn	±nnnnnnnnnn	0	1	1	1
8	±nnnnnnnnnn	±nnnnnnnnnn	1	0	0	0
9	±nnnnnnnnnn	±nnnnnnnnnn	1	0	0	1
10	±nnnnnnnnnn	±nnnnnnnnnn	1	0	1	0
11	±nnnnnnnnnn	±nnnnnnnnnn	1	0	1	1
12	±nnnnnnnnnn	±nnnnnnnnnn	1	1	0	0
13	±nnnnnnnnnn	±nnnnnnnnnn	1	1	0	1
14	±nnnnnnnnnn	±nnnnnnnnnn	1	1	1	0
15	±nnnnnnnnnn	±nnnnnnnnnn	1	1	1	1

Note: 1: Signal is ON (active), 0: Signal is OFF (inactive).

### **ZONE Table Settings and ZONE Numbers**

The relationship between the ZONE table settings and the ZONE numbers is shown below.

ZONE N ≤ ZONE P

The ZONE signals for the corresponding ZONE number is output if the current value is between ZONE N and ZONE P, inclusive (the shaded part in the following figure).



ZONE P < ZONE N</li>

The ZONE signals for the corresponding ZONE number is output if the current value is less than or equal to ZONE P or greater than or equal to ZONE N (the shaded parts in the following figure).



- Duplicated Settings in the ZONE Table
   The smaller ZONE number is output.
- ZONE N and ZONE P = 0
  The ZONE number is disabled.
- When the Current Value Is Not In Any ZONE All of the ZONE signals will be OFF (0).

### 6.14.2 ZONE Table Settings

The ZONE table is set by setting the ZONE table positive side boundary position (ZONE P) (2750 hex) and the ZONE table negative side boundary position (ZONE N) (2751 hex).

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type	Parameter No.
	ZONE table F	Positive side bo	oundary pos	sition (ZONE P)			-
	1	ZONE ID 0	RW	No	Pos.unit	DINT	PnA00
	2	ZONE ID 1	RW	No	Pos.unit	DINT	PnA04
	3	ZONE ID 2	RW	No	Pos.unit	DINT	PnA08
	4	ZONE ID 3	RW	No	Pos.unit	DINT	PnA0C
	5	ZONE ID 4	RW	No	Pos.unit	DINT	PnA10
	6	ZONE ID 5	RW	No	Pos.unit	DINT	PnA14
	7	ZONE ID 6	RW	No	Pos.unit	DINT	PnA18
2750 hex	8	ZONE ID 7	RW	No	Pos.unit	DINT	PnA1C
	9	ZONE ID 8	RW	No	Pos.unit	DINT	PnA20
	10	ZONE ID 9	RW	No	Pos.unit	DINT	PnA24
	11	ZONE ID 10	RW	No	Pos.unit	DINT	PnA28
	12	ZONE ID 11	RW	No	Pos.unit	DINT	PnA2C
	13	ZONE ID 12	RW	No	Pos.unit	DINT	PnA30
	14	ZONE ID 13	RW	No	Pos.unit	DINT	PnA34
	15	ZONE ID 14	RW	No	Pos.unit	DINT	PnA38
	16	ZONE ID 15	RW	No	Pos.unit	DINT	PnA3C

Continued on next page.

### 6.14.3 ZONE Signals 1 to 4 Outputs (/ZONE0 to /ZONE3)

Continued from previous page.

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type	Parameter No.
	ZONE table I	Negative side b	oundary po	sition (ZONE N)			
	1	ZONE ID 0	RW	No	Pos.unit	DINT	PnA02
	2	ZONE ID 1	RW	No	Pos.unit	DINT	PnA06
	3	ZONE ID 2	RW	No	Pos.unit	DINT	PnA0A
	4	ZONE ID 3	RW	No	Pos.unit	DINT	PnA0E
	5	ZONE ID 4	RW	No	Pos.unit	DINT	PnA12
	6	ZONE ID 5	RW	No	Pos.unit	DINT	PnA16
	7	ZONE ID 6	RW	No	Pos.unit	DINT	PnA1A
2751 hex	8	ZONE ID 7	RW	No	Pos.unit	DINT	PnA1E
	9	ZONE ID 8	RW	No	Pos.unit	DINT	PnA22
	10	ZONE ID 9	RW	No	Pos.unit	DINT	PnA26
	11	ZONE ID 10	RW	No	Pos.unit	DINT	PnA2A
	12	ZONE ID 11	RW	No	Pos.unit	DINT	PnA2E
	13	ZONE ID 12	RW	No	Pos.unit	DINT	PnA32
	14	ZONE ID 13	RW	No	Pos.unit	DINT	PnA36
	15	ZONE ID 14	RW	No	Pos.unit	DINT	PnA3A
	16	ZONE ID 15	RW	No	Pos.unit	DINT	PnA3E

# 6.14.3 ZONE Signals 1 to 4 Outputs (/ZONE0 to /ZONE3)

The /ZONE0 to /ZONE3 signals indicate when the current value is within a zone registered in the ZONE table.

Type	Signal	Connector Pin No.	Signal Status	Meaning
	(70NF0	Must be allocated.	ON (closed)	The current value is within a zone in the ZONE table and / ZONE0 is active.
	/ZONE0	iviust be allocated.	OFF (open)	The current value is not within a zone in the ZONE table or / ZONE0 is inactive.
	/ZONE1	Must be allocated.	ON (closed)	The current value is within a zone in the ZONE table and / ZONE1 is active.
Outouto		iviust be anocated.	OFF (open)	The current value is not within a zone in the ZONE table or / ZONE1 is inactive.
Outputs	/ZONE2	Must be allocated.	ON (closed)	The current value is within a zone in the ZONE table and / ZONE2 is active.
			OFF (open)	The current value is not within a zone in the ZONE table or / ZONE2 is inactive.
			ON (closed)	The current value is within a zone in the ZONE table and / ZONE3 is active.
	/ZONE3 Must be allocated		OFF (open)	The current value is not within a zone in the ZONE table or / ZONE3 is inactive.

Note: You must allocate the /ZONE0 to /ZONE3 signals to use them. Use PnBA0 (ZONE Output Signal Selection 1) to allocate them to connector pins. Refer to the following sections for details.

6.1.2 Output Signal Allocations on page 6-5

## 6.14.4 nZONE Signal Output

The /nZONE signal indicates when the current value is within a zone registered in the ZONE table.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output	/nZONE	Must be allocated.	ON (closed)	The current value is within a zone registered in the ZONE table.
Output	MIZONE	Must be allocated.	OFF (open)	The current value is not within a zone registered in the ZONE table.

Note: You must allocate the /nZONE signal to use it. Use PnBA1 = n. \(\sigma \sqrt{D} \sqrt{X}\) (/nZONE (nZONE Signal Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following sections for details.

6.1.2 Output Signal Allocations on page 6-5

The relationship between the ZONE table and /nZONE signal is shown in the following table.

ZONE Number (ID)	ZONE N [Reference Units]	ZONE P [Reference Units]	/nZONE
0	±nnnnnnnnn	±nnnnnnnnn	1
1	±nnnnnnnnn	±nnnnnnnnn	1
2	±nnnnnnnnn	±nnnnnnnnn	1
3	±nnnnnnnnn	±nnnnnnnnn	1
4	±nnnnnnnnn	±nnnnnnnnn	1
5	±nnnnnnnnn	±nnnnnnnnn	1
6	±nnnnnnnnn	±nnnnnnnnn	1
7	±nnnnnnnnn	±nnnnnnnnn	1
8	±nnnnnnnnn	±nnnnnnnnn	1
9	±nnnnnnnnn	±nnnnnnnnn	1
10	±nnnnnnnnn	±nnnnnnnnn	1
11	±nnnnnnnnn	±nnnnnnnnn	1
12	±nnnnnnnnn	±nnnnnnnnn	1
13	±nnnnnnnnn	±nnnnnnnnn	1
14	±nnnnnnnnn	±nnnnnnnnn	1
15	±nnnnnnnnn	±nnnnnnnnn	1

Note: The  $\mbox{/nZONE}$  signal will be 0 (OFF) if both ZONE N and ZONE P are zero.

### 6.14.5 ZONE Output Application Example

## Using the ZONE Outputs as Zone Signals

The ZONE signals are output when the current value is within a zone registered in the ZONE table. The relationship between the ZONE table and ZONE signals is shown in the following table.

The ZONE table is given below.


ZONE Number (ID)	ZONE N	ZONE P
0	0	0
1	-1000	+1000
2	+99000	+101000
3	0	0
4	+199000	+201000
5	0	0
6	0	0
7	0	0
8	+299000	+301000
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0

The relationship between the operation pattern and ZONE signals is shown in the following diagrams.




The ZONE outputs operate independently of the Digital outputs (60FE hex). If you use these functions, set them carefully according to the application.

### **♦** ZONE Signals



### ◆ nZONE Signal



# Trial Operation and Actual Operation

7

This chapter provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.

7.1	Flow	of Trial Operation7-2
	7.1.1 7.1.2	Flow of Trial Operation for Rotary Servomotors 7-2 Flow of Trial Operation for Linear Servomotors 7-4
7.2	Inspec	tions and Confirmations before Trial Operation 7-6
7.3	Trial O	peration for the Servomotor without a Load7-7
	7.3.1 7.3.2 7.3.3	Preparations
7.4	Trial Op	peration with EtherCAT (CoE) Communications7-10
7.5	Trial Ope	eration with the Servomotor Connected to the Machine7-11
	7.5.1 7.5.2 7.5.3	Precautions.7-11Preparations.7-11Operating Procedure.7-12
7.6	Conve	nient Function to Use during Trial Operation7-13
	7.6.1 7.6.2 7.6.3	Program Jogging

# 7.1 Flow of Trial Operation

# 7.1.1 Flow of Trial Operation for Rotary Servomotors

The procedure for trial operation is given below.

• Preparations for Trial Operation

Step	Meaning	Reference
1	Installation Install the Servomotor and SERVOPACK according to the installation conditions. First, operation is checked with no load. Do not connect the Servomotor to the machine.	Chapter 3 SERVOPACK Installation
2	Wiring and Connections Wire and connect the SERVOPACK. First, Servomotor operation is checked without a load. Do not connect the CN1 connector on the SERVOPACK.	Chapter 4 Wiring and Connecting SERVOPACKs
3	Confirmations before Trial Operation	7.2 Inspections and Confirmations before Trial Operation on page 7-6
4	Power ON	_
5	Resetting the Absolute Encoder This step is necessary only for a Servomotor with an Absolute Encoder.	5.15 Resetting the Absolute Encoder on page 5-49

### 7.1.1 Flow of Trial Operation for Rotary Servomotors

### • Trial Operation

Step	Meaning	Reference
Otep	Trial Operation for the Servomotor without	1 1010101100
1	a Load  To power supply  Secure the motor flange to the machine. Do not connect the motor shaft to the load shaft.	7.3 Trial Operation for the Servomotor without a Load on page 7-7
2	Trial Operation with EtherCAT (CoE) Communications  CN6A, to host controller  To power supply  CN1, to host controller  Secure the motor flange to the machine. Do not connect the motor shaft to the load shaft.	7.4 Trial Operation with EtherCAT (CoE) Communications on page 7-10
3	Trial Operation with the Servomotor Connected to the Machine  CN6A, to host controller  To power supply  CN1, to host controller  Secure the motor flange to the machine, and connect the motor shaft to the load shaft with a coupling or other means.	7.5 Trial Operation with the Servomotor Connected to the Machine on page 7-11

# 7.1.2 Flow of Trial Operation for Linear Servomotors

The procedure for trial operation is given below.

· Preparations for Trial Operation

Step	Meaning	Reference
1	Installation Install the Servomotor and SERVOPACK according to the installation conditions. First, operation is checked with no load. Do not connect the Servomotor to the machine.	Chapter 3 SERVOPACK Installation
2	Wiring and Connections Wire and connect the SERVOPACK. First, Servomotor operation is checked without a load. Do not connect the CN1 connector on the SERVOPACK.	Chapter 4 Wiring and Connecting SERVOPACKs
3	Confirmations before Trial Operation	7.2 Inspections and Confirmations before Trial Operation on page 7-6
4	Power ON	_

### Setting Parameters in the SERVOPACK

	Step	No. of Parameter to Set	Description	Remarks	Reference
	5-1	Pn282 (2282 hex)	Linear Encoder Pitch	Set this parameter only if you are using a Serial Converter Unit.	page 5-15
	5-2	-	Writing Parameters to the Linear Servomotor	Set this parameter only if you are not using a Serial Converter Unit.	page 5-16
5	5-3	Pn080 (2080 hex) = n.□□X□	Motor Phase Sequence Selection	_	page 5-20
	5-4	Pn080 (2080 hex) = n. □ □ □ □ X	Polarity Sensor Selection	_	page 5-22
	5-5	_	Polarity Detection	This step is necessary only for a Linear Servomotor without a Polarity Sensor.	page 5-23
	5-6	Pn50A (250A hex) = n.X□□□ and Pn50B (250B hex) = n.□□□X	Overtravel Signal Allocations	_	page 5-26
	5-7	Pn483 (2483 hex), Pn484 (2484 hex)	Force Control	_	page 6-26

Setting the Origin of the Absolute Linear Encoder

Note: This step is necessary only for an Absolute.

Note: This step is necessary only for an Absolute Linear Servomotor from Mitutoyo Corporation.

5.16.2 Setting the Origin of the Absolute Linear Encoder on page 5-52

### • Trial Operation


	Meaning	Reference
Step 1	Trial Operation for the Servomotor without a Load  To power supply	Reference  7.3 Trial Operation for the Servomotor without a Load on page 7-7
2	Trial Operation with EtherCAT (CoE) Communications  CN6A, to host controller  To power supply  CN1, to host controller	7.4 Trial Operation with EtherCAT (CoE) Communications on page 7-10
3	Trial Operation with the Servomotor Connected to the Machine  CN6A, to host controller  To power supply  CN1, to host controller	7.5 Trial Operation with the Servomotor Connected to the Machine on page 7-11

## 7.2

# Inspections and Confirmations before Trial Operation

To ensure safe and correct trial operation, check the following items before you start trial operation.

- Make sure that the SERVOPACK and Servomotor are installed, wired, and connected correctly.
- Make sure that the correct power supply voltage is supplied to the SERVOPACK.
- Make sure that there are no loose parts in the Servomotor mounting.
- If you are using a Servomotor with an Oil Seal, make sure that the oil seal is not damaged. Also make sure that oil has been applied.
- If you are performing trial operation on a Servomotor that has been stored for a long period of time, make sure that all Servomotor inspection and maintenance procedures have been completed.
  - Refer to the manual for your Servomotor for Servomotor maintenance and inspection information.
- If you are using a Servomotor with a Holding Brake, make sure that the brake is released in advance. To release the brake, you must apply the specified voltage of 24 VDC to the brake. A circuit example for trial operation is provided below.



# 7.3 Trial Operation for the Servomotor without a Load

You use jogging for trial operation of the Servomotor without a load.

Jogging is used to check the operation of the Servomotor without connecting the SERVOPACK to the host controller. The Servomotor is moved at the preset jogging speed.

### **⚠** CAUTION

 During jogging, the overtravel function is disabled. Consider the range of motion of your machine when you jog the Servomotor.

# 7.3.1 Preparations

Confirm the following conditions before you jog the Servomotor.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- The jogging speed must be set considering the operating range of the machine. The jogging speed is set with the following parameters.
  - · Rotary Servomotors

Pn304	Jogging Speed			Speed Position Torque	
(2304	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 min <sup>-1</sup>	500	Immediately	Setup
Pn305	Soft Start Acceler	ation Time		Speed	
(2305	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 ms	0	Immediately	Setup
Pn306	Soft Start Deceleration Time			Speed	
(2306	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 ms	0	Immediately	Setup

Linear Servomotors

Pn383	Jogging Speed			Speed	osition Force
(2383	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 mm/s	50	Immediately	Setup
Pn305	Soft Start Acceler	ation Time		Speed	
(2305	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 ms	0	Immediately	Setup
Pn306 (2306 hex)	Soft Start Deceler	ation Time		Speed	
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

### 7.3.2 Applicable Tools

The following table lists the tools that you can use to perform jogging and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn002	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Test Run - Jog	Operating Procedure on page 7-8

### 7.3.3 Operating Procedure

Use the following procedure to jog the motor.

- 1. Click the 🏴 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select JOG Operation in the Menu Dialog Box. The Jog Operation Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.




4. Check the jogging speed and then click the Servo ON Button.



The display in the Operation Area will change to Servo ON.

Information To change the speed, click the **Edit** Button and enter the new speed.

5. Click the Forward Button or the Reverse Button.



**6.** After you finish jogging, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the jogging procedure.

# 7.4

# Trial Operation with EtherCAT (CoE) Communications

A trial operation example for EtherCAT (CoE) communications is given below.

In this example, operation in Profile Position Mode is described.

Refer to the following chapter for details on operation with EtherCAT (CoE) communications. Chapter 13 CiA402 Drive Profile

1. Confirm that the wiring is correct, and then connect the I/O signal connector (CN1) and EtherCAT communications connector (CN6A).

Refer to the following chapter for details on wiring.

Chapter 4 Wiring and Connecting SERVOPACKs

- 2. Set the EtherCAT (CoE) communications station address and PDO mappings.
- 3. Turn ON the power supplies to the SERVOPACK.

If power is being supplied correctly, the CHARGE indicator on the SERVOPACK will light.

Note: If the COM indicator does not light, recheck the settings of EtherCAT setting switches (S1 and S2) and then turn the power supply OFF and ON again.

4. Place the EtherCAT communications in the Operational state.

Refer to the following chapter for details on the EtherCAT communications status.

12.2 EtherCAT State Machine on page 12-3

5. Set the modes of operation to Profile Position Mode.

Refer to the following section for details on modes of operation.

Modes of Operation (6060 Hex) on page 14-27

**6.** Change the *controlword* to supply power to the motor.

When statusword shows the Operation Enabled state, power is supplied to the motor.

Note: Manipulate the objects that were mapped to PDOs. Values will not be written if you manipulate SDOs.

7. Set target position, profile velocity, profile acceleration, and profile deceleration, and then manipulate controlword to start positioning.

Note: Manipulate the objects that were mapped to PDOs. Values will not be written if you manipulate SDOs.

**8.** While operation is in progress for step 6, confirm the following items.

Confirmation Item	Reference	
Confirm that the rotational direction of the Servomotor agrees with the forward or reverse reference. If they do not agree, correct the rotation direction of the Servomotor.	5.4 Motor Direction Setting on page 5-14	
Confirm that no abnormal vibration, noise, or temperature rise occurs. If any abnormalities are found, implement corrections.	15.4 Troubleshooting Based on the Operation and Conditions of the Servomotor on page 15-51	

Note: If the load machine is not sufficiently broken in before trial operation, the Servomotor may become over-

# 7.5 Trial Operation with the Servomotor Connected to the Machine

This section provides the procedure for trial operation with both the machine and Servomotor.

### 7.5.1 Precautions

### **MARNING**

 Operating mistakes that occur after the Servomotor is connected to the machine may not only damage the machine, but they may also cause accidents resulting in personal injury.



If you disabled the overtravel function for trial operation of the Servomotor without a load, enable the overtravel function (P-OT and N-OT signal) before you perform trial operation with the Servomotor connected to the machine in order to provide protection.

If you will use a brake, observe the following precautions during trial operation.

- Before you check the operation of the brake, implement measures to prevent vibration from being caused by the machine falling due to gravity or an external force.
- First check the Servomotor operation and brake operation with the Servomotor uncoupled from the machine. If no problems are found, connect the Servomotor to the machine and perform trial operation again.

Control the operation of the brake with the /BK (Brake) signal output from the SERVOPACK. Refer to the following sections for information on wiring and the related parameter settings.

\*\*## 4.4.4 Wiring the SERVOPACK to the Holding Brake on page 4-25

5.11 Holding Brake on page 5-32



Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the SERVOPACK, damage the equipment, or cause an accident resulting in death or injury.

Observe the precautions and instructions for wiring and trial operation precisely as described in this manual.

### 7.5.2 Preparations

Confirm the following items before you perform the trial operation procedure for both the machine and Servomotor.

- Make sure that the procedure described in 7.4 Trial Operation with EtherCAT (CoE) Communications on page 7-10 has been completed.
- Make sure that the SERVOPACK is connected correctly to both the host controller and the peripheral devices.
  - · Safety Function Wiring
    - If you are not using the safety function, leave the Safety Jumper Connector (provided as an accessory with the SERVOPACK) connected to CN8.
    - If you are using the safety function, remove the Safety Jumper Connector from CN8 and connect the safety function device.
  - Overtravel wiring
  - · Brake wiring
  - Allocation of the /BK (Brake) signal to a pin on the I/O signal connector (CN1)
  - · Emergency stop circuit wiring
  - · Host controller wiring

### 7.5.3 Operating Procedure

1. Enable the overtravel signals.

5.10.2 Setting to Enable/Disable Overtravel on page 5-27

2. Make the settings for the protective functions, such as the safety function, overtravel, and the brake.

4.6 Connecting Safety Function Signals on page 4-35


5.10 Overtravel and Related Settings on page 5-26

5.11 Holding Brake on page 5-32

3. Turn OFF the power supplies to the SERVOPACK.

The control power supply and main circuit power supply will turn OFF.

4. Couple the Servomotor to the machine.



- 5. Turn ON the power supplies to the machine and host controller and turn ON the control power supply and main circuit power supply to the SERVOPACK.
- **6.** Check the protective functions, such overtravel and the brake, to confirm that they operate correctly.

Note: Enable activating an emergency stop so that the Servomotor can be stopped safely should an error occur during the remainder of the procedure.

7. Input the Enable Operation command from the host controller. The servo will turn ON.

- **8.** Perform trial operation according to *7.4 Trial Operation with EtherCAT (CoE) Communications* on page 7-10 and confirm that the same results are obtained as when trial operation was performed on the Servomotor without a load.
- **9.** If necessary, adjust the servo gain to improve the Servomotor response characteristics. The Servomotor and machine may not be broken in completely for the trial operation. Therefore, let the system run for a sufficient amount of time to ensure that it is properly broken in.

10. For future maintenance, save the parameter settings with one of the following methods.

- Use the SigmaWin+ to save the parameters as a file.
- Use the Parameter Copy Mode of the Digital Operator.
- · Record the settings manually.

This concludes the procedure for trial operation with both the machine and Servomotor.

# 7.6 Convenient Function to Use during Trial Operation

This section describes some convenient operations that you can use during trial operation. Use them as required.

### 7.6.1 Program Jogging

You can use program jogging to perform continuous operation with a preset operation pattern, travel distance, movement speed, acceleration/deceleration time, waiting time, and number of movements.

You can use this operation when you set up the system in the same way as for normal jogging to move the Servomotor without connecting it to the host controller in order to check Servomotor operation and execute simple positioning operations.

### **Preparations**

Confirm the following conditions before you perform program jogging.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- The range of machine motion and the safe movement speed of your machine must be considered when you set the travel distance and movement speed.
- There must be no overtravel.


### Additional Information

- You can use the functions that are applicable to position control. However, functions for motions through EtherCAT communications are disabled.
- The overtravel function is enabled.

### 7.6.1 Program Jogging


### **Program Jogging Operation Pattern**

An example of a program jogging operation pattern is given below. In this example, the Servo-motor direction is set to  $Pn000 = n.\square\square\square\square$  (Use CCW as the forward direction).



Continued on next page.

Continued from previous page.



Information

If Pn530 is set to n.□□□0, n.□□□1, n.□□□4, or n.□□□5, you can set Pn536 (Program Jogging Number of Movements) to 0 to perform infinite time operation. You cannot use infinite time operation if Pn530 is set to n.□□□2 or n.□□□3. If you perform infinite time operation from the Digital Operator, press the **JOG/SVON** Key to turn OFF the servo to end infinite time operation.

### 7.6.1 Program Jogging

### **Related Parameters**

Use the following parameters to set the program jogging operation pattern. Do not change the settings while the program jogging operation is being executed.

### • Rotary Servomotors

Pn530	Program Jogging-Related Selections			Speed Position Torque		
(2530	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0000 to 0005	_	0000	Immediately	Setup	
Pn531	Program Jogging Travel Distance			Speed Position Torque		
(2531	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	1 to 1,073,741,824	1 reference unit	32,768	Immediately	Setup	
Pn533	Program Jogging M	lovement Speed		Speed Po	Speed Position Torque	
(2533	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	1 to 10,000	1 min <sup>-1</sup>	500	Immediately	Setup	
Pn534	Program Jogging Acceleration/Deceleration Time			Speed Position Torque		
(2534	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	2 to 10,000	1 ms	100	Immediately	Setup	
Pn535	Program Jogging W	aiting Time		Speed Posit	ion Torque	
(2535	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 10,000	1 ms	100	Immediately	Setup	
Pn536	Program Jogging Number of Movements			Speed Po	sition Torque	
(2536	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 1,000	1	1	Immediately	Setup	

### • Linear Servomotors

Pn530	Program Jogging-Related Selections			Speed Position Force	
(2530	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0000 to 0005	-	0000	Immediately	Setup
Pn531	Program Jogging Travel Distance			Speed Position Force	
(2531	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 1,073,741,824	1 reference unit	32,768	Immediately	Setup
Pn585	Program Jogging M	Program Jogging Movement Speed		Speed Position Force	
(2585	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 10,000	1 mm/s	50	Immediately	Setup
Pn534	Program Jogging Acceleration/Deceleration Time			Speed Position Force	
(2534	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	2 to 10,000	1 ms	100	Immediately	Setup
Pn535	Program Jogging Waiting Time		Speed Position Force		
(2535	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 ms	100	Immediately	Setup
Pn536	Program Jogging Number of Movements		Speed Position Force		
(2536 hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	1	1	Immediately	Setup

### **Applicable Tools**


The following table lists the tools that you can use to perform program jogging and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn004	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Test Run - Program JOG Operation	© Operating Procedure on page 7-17


### **Operating Procedure**

Use the following procedure for a program jog operation.

- 1. Click the P Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select JOG Program in the Menu Dialog Box. The Jog Program Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.




**4.** Set the operating conditions, click the Apply Button, and then click the Run Button. A graph of the operation pattern will be displayed.



### 7.6.1 Program Jogging

**5.** Click the **Servo ON** Button and then the **Execute** Button. The program jogging operation will be executed.



# **A** CAUTION

- Be aware of the following points if you cancel the program jogging operation while the motor is operating.
  - If you cancel operation with the **Servo OFF** Button, the motor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□X).
  - If you cancel operation with the **Cancel** Button, the motor will decelerate to a stop and then enter a zero-clamped state.

This concludes the program jogging procedure.

## 7.6.2 Origin Search


The origin search operation positions the motor to the origin within one rotation and the clamps it there.

## **⚠** CAUTION

Make sure that the load is not coupled when you execute an origin search.
 The Forward Drive Prohibit (P-OT) signal and Reverse Drive Prohibit (N-OT) signal are disabled during an origin search.

Use an origin search when it is necessary to align the origin within one rotation with the machine origin. The following speeds are used for origin searches.

Rotary Servomotors: 60 min<sup>-1</sup>
Linear Servomotors: 15 mm/s



### **Preparations**

Confirm the following conditions before you start an origin search.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.

## **Applicable Tools**

The following table lists the tools that you can use to perform an origin search and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn003	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Origin Search	Operating Procedure on page 7-20

7.6.2 Origin Search


### **Operating Procedure**

Use the following procedure to perform an origin search.

- 1. Click the P Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Search Origin in the Menu Dialog Box. The Origin Search Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.




4. Click the Servo ON Button.



5. Click the Forward Button or the Reverse Button.

An origin search will be performed only while you hold down the mouse button. The motor will stop when the origin search has been completed.




This concludes the origin search procedure.

### Test without a Motor

7.6.3

A test without a motor is used to check the operation of the host controller and peripheral devices by simulating the operation of the Servomotor in the SERVOPACK, i.e., without actually operating a Servomotor. This test allows you to check wiring, debug the system, and verify parameters to shorten the time required for setup work and to prevent damage to the machine that may result from possible malfunctions. The operation of the motor can be checked with this test regardless of whether the motor is actually connected or not.



Use  $Pn00C = n.\square\square\square\square X$  to enable or disable the test without a motor.

Р	arameter	Meaning	When Enabled	Classification
Pn00C (200C	n.□□□0 (default setting)	Disable tests without a motor.	After restart	Setup
hex)	n.□□□1	Enable tests without a motor.		

Information

An asterisk is displayed on the status display of the Digital Operator while a test without a motor is being executed.

### **Motor Information and Encoder Information**

The motor and encoder information is used during tests without a motor. The source of the information depends on the device connection status.

#### · Rotary Servomotor

Motor Connection Status	Information That Is Used	Source of Information
	Motor information	
Connected	<ul><li>Encoder information</li><li>Encoder resolution</li><li>Encoder type</li></ul>	Information in the motor that is connected
Not connected	Motor information • Rated motor speed • Maximum motor speed	Setting of Pn000 = n.X□□□ (Rotary/Linear Startup Selection When Encoder Is Not Connected)     Rated motor speed and maximum motor speed The values previously saved in the SERVOPACK will be used for the rated motor speed and maximum motor speed.     Use the monitor displays (Un020: Rated Motor Speed and Un021: Maximum Motor Speed) to check the values.
	Encoder information • Encoder resolution • Encoder type	<ul> <li>Encoder resolution: Setting of Pn00C = n.□□X□ (Encoder Resolution for Tests without a Motor)</li> <li>Encoder type: Setting of Pn00C = n.□X□□ (Encoder Type Selection for Tests without a Motor)</li> </ul>

If you use fully-closed loop control, the external encoder information is also used.

External Encoder Connection Status	Information That Is Used	Source of Information
Connected	External encoder information	Information in the external encoder that is connected
Not connected	<ul><li>Resolution</li><li>Encoder type</li></ul>	Resolution: 256     Encoder type: Incremental encoder

#### 7.6.3 Test without a Motor

#### · Linear Servomotors

Motor Connection Status	Information That Is Used	Source of Information
	Motor information	Information in the motor that is connected
Connected	Linear encoder information  Resolution  Encoder pitch  Encoder type	Information in the linear encoder that is connected
Not connected	Motor information	Setting of Pn000 = n.X□□□ (Rotary/Linear Startup Selection When Encoder Is Not Connected)
	Linear encoder information  Resolution  Encoder pitch  Encoder type	<ul> <li>Resolution: 256</li> <li>Encoder pitch: Setting of Pn282 (Linear Encoder Pitch)</li> <li>Encoder type: Setting of Pn00C = n.□X□□ (Encoder Type Selection for Tests without a Motor)</li> </ul>

#### · Related Parameters

F	arameter	Meaning			When Enabl	ed	Classification
Pn000 (2000	n.0□□□ (default setting)	When an encoder is SERVOPACK for Rot	After restar	+	Setup		
hex)	n.1□□□	When an encoder is not connected, start as SERVOPACK for Linear Servomotor.			Aiter restait		Setup
Pn282	Linear Encoder F		Speed	osi	tion Force		
(2282	Setting Range	Setting Unit	Default Setting Wh		When Enabled (		Classification
hex)	0 to 6,553,600	0.01 μm	0	Aft	er restart		Setup

Pa	arameter	Meaning	When Enabled	Classification
n.□□1□  Pn00C (200C hex)  n.□□2□  n.□□3□  n.□□3□	n.□□0□ (default setting)	Use 13 bits as encoder resolution for tests without a motor.		
	n.□□1□	Use 20 bits as encoder resolution for tests without a motor.		
	n.□□2□	Use 22 bits as encoder resolution for tests without a motor.	After restart	Setup
	n.□□3□	Use 24 bits as encoder resolution for tests without a motor.	Aiter restart	Jetup
	n.□0□□ (default setting)	Use an incremental encoder for tests without a motor.		
	n.0100	Use an absolute encoder for tests without a motor.		

## **Motor Position and Speed Responses**

For a test without a motor, the following responses are simulated for references from the host controller according to the gain settings for position or speed control.

- Servomotor position
- Motor speed
- External encoder position

The load model will be for a rigid system with the moment of inertia ratio that is set in Pn103.

## Restrictions

The following functions cannot be used during the test without a motor.

- Regeneration and dynamic brake operation
- Brake output signal
   Refer to the following section for information on confirming the brake output signal.
   9.2.3 I/O Signal Monitor on page 9-5
- Items marked with "x" in the following utility function table

SigmaWin+		Digital Operator		Execu		
Button in Menu Dialog Box	SigmaWin+ Function Name	Fn No.	Utility Function Name	Motor Not Connected	Motor Connected	Reference
	Origin Search	Fn003	Origin Search	0	0	page 7-19
	Absolute Encoder Reset	Fn008	Reset Absolute Encoder	×	0	page 5-50
	Analog Monitor Out-	Fn00C	Adjust Analog Monitor Output Offset	0	0	page 9-9
	put Adjustment	Fn00D	Adjust Analog Monitor Output Gain	0	0	page 9-9
	Motor Current Detection Offset Adjust-	Fn00E	Autotune Motor Cur- rent Detection Signal Offset	×	0	page 6-50
	ment	Fn00F	Manually Adjust Motor Current Detection Sig- nal Offset	×	0	page 0-30
	Parameter Write Pro- hibition Setting	Fn010	Write Prohibition Set- ting	0	0	page 5-7
Setup	Multiturn Limit Setting	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm	×	0	page 6-37
	Reset Configuration Error of Option Mod- ule	Fn014	Reset Option Module Configuration Error	0	0	page 15-42
	Initializing the Vibration Detection Level	Fn01B	Initialize Vibration Detection Level	×	×	page 6-46
	Set Origin	Fn020	Set Absolute Linear Encoder Origin	×	0	page 5-52
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm	0	0	_
	Software Reset	Fn030	Software Reset	0	0	page 6-44
	Polarity Detection	Fn080	Polarity Detection	×	×	page 5-23
	Tuning-less Level Setting	Fn200	Tuning-less Level Set- ting	×	×	page 8-16
	Easy FFT	Fn206	Easy FFT	×	×	page 8-92
Parameter	Initialize*	Fn005	Initialize Parameters	0	0	page 5-10
	Autotuning without Host Reference	Fn201	Advanced Autotuning without Reference	×	×	page 8-23
	Autotuning with Host Reference	Fn202	Advanced Autotuning with Reference	×	×	page 8-34
Tuning	Custom Tuning	Fn203	One-Parameter Tuning	×	×	page 8-41
	Adjust Anti-reso- nance Control	Fn204	Adjust Anti-resonance Control	×	×	page 8-50
	Vibration Suppression	Fn205	Vibration Suppression	×	×	page 8-55
					Continued or	nevt nage

Continued on next page.

## 7.6.3 Test without a Motor

Continued from previous page.

SigmaWin+			Digital Operator	Execu		
Button in Menu Dialog Box	SigmaWin+ Function Name	Fn No.	Utility Function Name	Motor Not Connected	Motor Connected	Reference
			Display Servomotor Model	0	0	nago 0 2
Monitoring	Product Information	Fn012	Display Software Version	0	0	page 9-2
		Fn01E	Display SERVOPACK and Servomotor IDs	0	0	
			Fn01F	Display Servomotor ID from Feedback Option Module	0	0
Test Oper-	Jogging	Fn002	Jogging	0	0	page 7-7
ation	Program Jogging	Fn004	Program Jogging	0	0	page 7-13
Alarmo	Display Alarm	Fn000	Display Alarm History	0	0	page 15-40
Alarms	Display Alarm	Fn006	Clear Alarm History	0	0	page 15-41

 $<sup>\</sup>ensuremath{\ast}$  An  $\ensuremath{\mbox{\sc Initialize}}$  Button is displayed in the Parameter Editing Dialog Box.

This chapter provides information on the flow of tuning, details on tuning functions, and related operating procedures.

8.1	Over	view and Flow of Tuning8-4
	8.1.1 8.1.2	Tuning Functions
8.2	Monit	toring Methods8-7
8.3	Preca	autions to Ensure Safe Tuning8-8
	8.3.1 8.3.2 8.3.3	Overtravel Settings
	8.3.4 8.3.5	Alarm Level
		Alarm Level at Servo ON 8-10
8.4	Tunin	g-less Function8-12
	8.4.1 8.4.2 8.4.3 8.4.4 8.4.5 8.4.6	Application Restrictions
8.5	Estim	nating the Moment of Inertia8-16
	8.5.1 8.5.2 8.5.3 8.5.4	Outline       8-16         Restrictions       8-16         Applicable Tools       8-17         Operating Procedure       8-17

8.6	Autot	uning without Host Reference8-23
	8.6.1 8.6.2 8.6.3 8.6.4 8.6.5	Outline8-23Restrictions8-24Applicable Tools8-25Operating Procedure8-25Troubleshooting Problems in Autotuningwithout a Host Reference8-29
	8.6.6 8.6.7	Automatically Adjusted Function Settings 8-31 Related Parameters
8.7	Autot	uning with a Host Reference 8-34
	8.7.1 8.7.2 8.7.3 8.7.4 8.7.5 8.7.6 8.7.7	Outline8-34Restrictions8-35Applicable Tools8-35Operating Procedure8-36Troubleshooting Problems in Autotuningwith a Host Reference8-39Automatically Adjusted Function Settings8-39Related Parameters8-40
8.8	Custo	om Tuning
	8.8.1 8.8.2 8.8.3 8.8.4 8.8.5 8.8.6 8.8.7	Outline8-41Preparations8-41Applicable Tools8-42Operating Procedure8-42Automatically Adjusted Function Settings8-48Tuning Example for Tuning Mode 2 or 38-48Related Parameters8-49
8.9	Anti-F	Resonance Control Adjustment 8-50
	8.9.1 8.9.2 8.9.3 8.9.4 8.9.5 8.9.6	Outline8-50Preparations8-50Applicable Tools8-51Operating Procedure8-51Related Parameters8-53Suppressing Different Vibration Frequencieswith Anti-resonance Control8-53
8.10	Vibrat	tion Suppression 8-55
	8.10.1 8.10.2 8.10.3 8.10.4 8.10.5 8.10.6	Outline8-55Preparations8-56Applicable Tools8-56Operating Procedure8-56Setting Combined Functions8-58Related Parameters8-58
8.11	Speed	d Ripple Compensation 8-59
	8.11.1 8.11.2 8.11.3	Outline

8.12	Addit	ional Adjustment Functions8-65
	8.12.1 8.12.2 8.12.3 8.12.4 8.12.5 8.12.6 8.12.7	Gain Switching8-65Friction Compensation8-68Current Control Mode Selection8-69Current Gain Level Setting8-70Speed Detection Method Selection8-70Speed Feedback Filter8-70Backlash Compensation8-71
8.13	Manu	al Tuning8-76
	8.13.1 8.13.2	Tuning the Servo Gains 8-76 Compatible Adjustment Functions 8-86
8.14	Diagn	ostic Tools8-90
	8.14.1 8.14.2	Mechanical Analysis         8-90           Easy FFT         8-92


## 8.1 Overview and Flow of Tuning

Tuning is performed to optimize response by adjusting the servo gains in the SERVOPACK.

The servo gains are set using a combination of parameters, such as parameters for the speed loop gain, position loop gain, filters, friction compensation, and moment of inertia ratio. These parameters influence each other, so you must consider the balance between them.

The servo gains are set to stable settings by default. Use the various tuning functions to increase the response even further for the conditions of your machine.

The basic tuning procedure is shown in the following flowchart. Make suitable adjustments considering the conditions and operating requirements of your machine.



## 8.1.1 Tuning Functions

The following table provides an overview of the tuning functions.

Tuning Function	Outline	Applicable Control Methods	Reference
Tuning-less Function	This automatic adjustment function is designed to enable stable operation without servo tuning. This function can be used to obtain a stable response regardless of the type of machine or changes in the load. You can use it with the default settings.	Speed control or position control	page 8-12
Moment of Inertia Estimation	The moment of inertia ratio is calculated by operating the Servomotor a few times.  The moment of inertia ratio that is calculated here is used in other tuning functions.	Speed control, position control, or torque control	page 8-16
Autotuning without Host Reference	The following parameters are automatically adjusted in the internal references in the SERVO-PACK during automatic operation.  • Gains (e.g., position loop gain and speed loop gain)  • Filters (torque reference filter and notch filters)  • Friction compensation  • Anti-resonance control  • Vibration suppression	Speed control or position control	page 8-23
Autotuning with Host Reference	The following parameters are automatically adjusted with the position reference input from the host controller while the machine is in operation. You can use this function for fine-tuning after you perform autotuning without a host reference.  • Gains (e.g., position loop gain and speed loop gain)  • Filters (torque reference filter and notch filters)  • Friction compensation  • Anti-resonance control  • Vibration suppression	Position control	page 8-34
Custom Tuning	The following parameters are adjusted with the position reference or speed reference input from the host controller while the machine is in operation.		page 8-41
Anti-resonance Control Adjustment			page 8-50
Vibration Suppression	This function effectively suppresses residual vibration if it occurs when positioning.	Position control	page 8-55
Speed Ripple Compensation	This function reduces the ripple in the motor speed.	Speed control, position control, or torque control	page 8-59
Additional Adjustment Function	This function combines autotuning with custom tuning. You can use it to improve adjustment results.	Depends on the functions that you use.	page 8-65
Manual Tuning	You can manually adjust the servo gains to adjust the response.	Speed control, position control, or torque control	page 8-76

8.1.2 Diagnostic Tool

## 8.1.2 Diagnostic Tool

You can use the following tools to measure the frequency characteristics of the machine and set notch filters.

Diagnostic Tool	Outline	Applicable Control Methods	Reference
Mechanical Analysis	The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed as waveforms or numeric data.	Speed control, position control, or torque control	page 8-90
Easy FFT	The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed only as numeric data.	Speed control, position control, or torque control	page 8-92

## 8.2 Monitoring Methods

You can use the data tracing function of the SigmaWin+ or the analog monitor signals of the SERVOPACK for monitoring. If you perform custom tuning or manual tuning, always use the above functions to monitor the machine operating status and SERVOPACK signal waveform while you adjust the servo gains.

Check the adjustment results with the following response waveforms.

#### Position Control

Item	Unit		
Item	Rotary Servomotor	Linear Servomotor	
Torque reference	%		
Feedback speed	min <sup>-1</sup>	mm/s	
Position reference speed	min <sup>-1</sup>	mm/s	
Position deviation	Refere	nce units	

#### • Speed Control

Item	Unit		
Item	Rotary Servomotor	Linear Servomotor	
Torque reference	reference %		
Feedback speed	min <sup>-1</sup>	mm/s	
Reference speed	min <sup>-1</sup>	mm/s	

#### • Torque Control

Item	Unit		
	Rotary Servomotor	Linear Servomotor	
Torque reference		%	
Feedback speed	min <sup>-1</sup>	mm/s	

#### 8.3.1 Overtravel Settings

## 8.3

## **Precautions to Ensure Safe Tuning**

## **CAUTION**

- Observe the following precautions when you perform tuning.
  - Do not touch the rotating parts of the motor when the servo is ON.
  - Before starting the Servomotor, make sure that an emergency stop can be performed at any time.
  - Make sure that trial operation has been successfully performed without any problems.
  - Provide an appropriate stopping device on the machine to ensure safety.

Perform the following settings in a way that is suitable for tuning.

## 8.3.1 Overtravel Settings

Overtravel settings are made to force the Servomotor to stop for a signal input from a limit switch when a moving part of the machine exceeds the safe movement range.

Refer to the following section for details.

5.10 Overtravel and Related Settings on page 5-26

## 8.3.2 Torque Limit Settings

You can limit the torque that is output by the Servomotor based on calculations of the torque required for machine operation. You can use torque limits to reduce the amount of shock applied to the machine when problems occur, such as collisions or interference. If the torque limit is lower than the torque that is required for operation, overshooting or vibration may occur. Refer to the following section for details.

6.7 Selecting Torque Limits on page 6-26

## 8.3.3 Setting the Position Deviation Overflow Alarm Level

The position deviation overflow alarm is a protective function that is enabled when the SERVO-PACK is used in position control.

If the alarm level is set to a suitable value, the SERVOPACK will detect excessive position deviation and will stop the Servomotor if the Servomotor operation does not agree with the reference.

The position deviation is the difference between the position reference value and the actual position.

You can calculate the position deviation from the position loop gain (Pn102) and the motor speed with the following formula.

#### Rotary Servomotors

Position deviation [reference units] = 
$$\frac{\text{Motor speed [min}^{-1}]}{60} \times \frac{\text{Encoder resolution}^{*1}}{\text{Pn102 [0.1/s]/10}^{*2, *3}} \times \frac{\text{Denominator not of the properties of the properties}}{\text{Numerator not of the properties of the properties}}$$

#### Linear Servomotors

Position deviation [reference units] = 
$$\frac{\text{Motor speed [mm/s]}}{\text{Pn102 [0.1/s]/10}^{*2,*3}} \times \frac{\text{Resolution}}{\text{Linear encoder pitch [$\mu m$]/1,000}} \times \frac{\text{Denominator of the permission}}{\text{Numerator of the permission}}$$

#### 8.3.3 Setting the Position Deviation Overflow Alarm Level

Position Deviation Overflow Alarm Level (Pn520) [setting unit: reference units]

Rotary Servomotors

Pn520 > 
$$\frac{\text{Maximum motor speed [min}^{-1}]}{60} \times \frac{\text{Encoder resolution}^{*1}}{\text{Pn102 [0.1/s]/10}^{*2,*3}} \times \frac{\text{Denominator}}{\text{Numerator}} \times \frac{\text{(1.2 to 2)}^{*4}}{\text{(1.2 to 2)}^{*4}}$$

Linear Servomotors

Pn520 > 
$$\frac{\text{Maximum motor speed [mm/s]}}{\text{Pn102 [0.1/s]/10*}^{2,*3}} \times \frac{\text{Resolution}}{\text{Linear encoder pitch [µm]/1,000}} \times \frac{\text{Denominator}}{\text{Numerator}} \times \frac{(1.2 \text{ to 2})^{*2}}{\text{Numerator}}$$

\*1. Refer to the following section for details.

5.14 Setting Unit Systems on page 5-42

- \*2. When model following control (Pn140 = n.□□□1) is enabled, use the setting of Pn141 (Model Following Control Gain) instead of the setting of Pn102 (Position Loop Gain).
- \*3. To check the setting of Pn102 on the Digital Operator, change the parameter display setting to display all parameters (Pn00B = n.□□□1).
- \*4. The underlined coefficient "× (1.2 to 2)" adds a margin to prevent an A.d00 alarm (Position Deviation Overflow) from occurring too frequently.

If you set a value that satisfies the formula, an A.d00 alarm (Position Deviation Overflow) should not occur during normal operation.

If the Servomotor operation does not agree with the reference, position deviation will occur, an error will be detected, and the motor will stop.

The following calculation example uses a Rotary Servomotor with a maximum motor speed of

6,000 and an encoder resolution of 16,777,216 (24 bits). Pn102 is set to 400.  $\frac{\text{Denominator}}{\text{Numerator}} = \frac{1}{16}$ 

$$Pn520 = \frac{6,000}{60} \times \frac{16,777,216}{400/10} \times \frac{1}{16} \times 2$$
$$= 2,621,440 \times 2$$

= 5,242,880 (default setting of Pn520)

If the acceleration/deceleration rate required for the position reference exceeds the tracking capacity of the Servomotor, the tracking delay will increase and the position deviation will no longer satisfy the above formulas. If this occurs, lower the acceleration/deceleration rate so that the Servomotor can follow the position reference or increase the position deviation over-flow alarm level.

#### **Related Parameters**

Pn520	Position Deviation Overflow Alarm Level			Position	
(2520	Setting Range Setting Unit Default Setting		When Enabled	Classification	
hex)	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup
Pn51E	Position Deviation Overflow Warning Level Position				ion
(251E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	10 to 100	1%	100	Immediately	Setup

#### **Related Alarms**

Alarm Number	Alarm Name	Alarm Meaning
A.d00	Position Deviation Overflow	This alarm occurs if the position deviation exceeds the setting of Pn520 (2520 hex) (Position Deviation Overflow Alarm Level).

## **Related Warnings**

Warning Number	Warning Name	Warning Meaning
A.900	Position Deviation Overflow	This warning occurs if the position deviation exceeds the specified percentage (Pn520 $\times$ Pn51E/100).

## 8.3.4 Vibration Detection Level Setting

You can set the vibration detection level (Pn312) to more accurately detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration Warning) when vibration is detected during machine operation.

Set the initial vibration detection level to an appropriate value. Refer to the following section for details.

6.11 Initializing the Vibration Detection Level on page 6-46

# 8.3.5 Setting the Position Deviation Overflow Alarm Level at Servo ON

If the servo is turned ON when there is a large position deviation, the Servomotor will attempt to return to the original position to bring the position deviation to 0, which may create a hazardous situation. To prevent this, you can set a position deviation overflow alarm level at servo ON to restrict operation.

The related parameters and alarms are given in the following tables.

#### **Related Parameters**

Pn526	Position Deviation Overflow Alarm Level at Servo ON Position				ion
(2526	Setting Range Setting Unit Default Setting		When Enabled	Classification	
hex)	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup
Pn528	Position Deviation Overflow Warning Level at Servo ON Position				ion
(2528	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	10 to 100	1%	100	Immediately	Setup

#### · Rotary Servomotors

Pn529	Speed Limit Level at Servo ON			Position	on
(2529	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 min <sup>-1</sup>	10,000	Immediately	Setup

#### Linear Servomotors

Pn584	Speed Limit Level at Servo ON			Position	on
(2584	Setting Range Setting Unit		Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 mm/s	10,000	Immediately	Setup

#### **Related Alarms**

Alarm Number	Alarm Name	Alarm Meaning
A.d01	Position Deviation Overflow Alarm at Servo ON	This alarm occurs if Servo ON command (Enable Operation command) is executed after the position deviation exceeded the setting of Pn526 (Excessive Position Deviation Alarm Level at Servo ON) while the servo was OFF.
A.d02	Position Deviation Overflow Alarm for Speed Limit at Servo ON	If position deviation remains in the deviation counter, the setting of Pn529 or Pn584 (Speed Limit Level at Servo ON) will limit the speed when the servo is turned ON. This alarm occurs if a position reference is input and the setting of Pn520 (Excessive Position Deviation Alarm Level) is exceeded.

Refer to the following section for information on troubleshooting alarms.

15.2.3 Resetting Alarms on page 15-39

8.3.5 Setting the Position Deviation Overflow Alarm Level at Servo ON

## **Related Warnings**

Warning Number	Warning Name	Warning Meaning
A.901	Position Deviation Overflow Warning at Servo ON	This warning occurs if the servo is turned ON while the position deviation exceeds the specified percentage (Pn526 × Pn528/100).

#### 8.4.1 Application Restrictions

## 8.4

## **Tuning-less Function**

The tuning-less function performs autotuning to obtain a stable response regardless of the type of machine or changes in the load. Autotuning is started when the servo is turned ON.

## **CAUTION**

- The tuning-less function is disabled during torque control.
- The Servomotor may momentarily emit a sound the first time the servo is turned ON after the Servomotor is connected to the machine. This sound is caused by setting the automatic notch filter. It does not indicate a problem. The sound will not be emitted from the next time the servo is turned ON.
- The Servomotor may vibrate if it exceeds the allowable load moment of inertia.
   If that occurs, set the tuning-less load level to 2 (Pn170 = n.2□□□) or reduce the Tuning-less Rigidity Level (Pn170 = n.□X□□).
- To ensure safety, make sure that you can perform an emergency stop at any time when you execute the tuning-less function.

## 8.4.1 Application Restrictions

The following application restrictions apply to the tuning-less function.

Function	Executable*	Remarks
Vibration Detection Level Initialization	0	-
Moment of Inertia Estimation	×	Disable the tuning-less function (Pn170 = n.□□□0) before you execute moment of inertia estimation.
Autotuning without Host Reference	×	Disable the tuning-less function (Pn170 = n.□□□0) before you execute autotuning without a host reference.
Autotuning with Host Reference	×	-
Custom Tuning	×	-
Anti-Resonance Control Adjustment	×	-
Vibration Suppression	×	-
Easy FFT	0	The tuning-less function is disabled while you execute Easy FFT and then it is enabled when Easy FFT has been completed.
Friction Compensation	×	-
Gain Selection	×	-
Mechanical Analysis	0	The tuning-less function is disabled while you execute mechanical analysis and then it is enabled when mechanical analysis has been completed.

<sup>\*</sup> O: Yes x: No

## 8.4.2 Operating Procedure

The tuning-less function is enabled in the default settings. No specific procedure is required. You can use the following parameter to enable or disable the tuning-less function.

Parameter		Meaning	When Enabled	Classification
	n.□□□0	Disable tuning-less function.		
Pn170	n.□□□1 (default setting)	Enable tuning-less function.		
(2170 hex)	n.□□0□ (default setting)	Use for speed control.	After restart	Setup
	n.□□1□	Use for speed control and use host controller for position control.		

When you enable the tuning-less function, you can select the tuning-less type. Normally, set Pn14F to  $n.\square\square2\square$  (Use tuning-less type 3) (default setting). If compatibility with previous models is required, set Pn14F to  $n.\square\square0\square$  (Use tuning-less type 1) or  $n.\square\square1\square$  (Use tuning-less type 2).

Parameter		Meaning	When Enabled	Classification
	n.□□0□	Use tuning-less type 1.		
Pn14F (214F	n.□□1□	Use tuning-less type 2. (The noise level is improved more than with tuning-less type 1.)	After restart	Tuning
	n.□□2□ (default setting)	Use tuning-less type 3.		

## **Tuning-less Level Settings**

If vibration or other problems occur, change the tuning-less levels. To change the tuning-less levels, use the SigmaWin+.

### Preparations

Check the following settings before you set the tuning-less levels.

- The tuning-less function must be enabled (Pn170 = n.□□□1).
- The test without a motor function must be disabled (Pn00C = n.□□□0).

#### Procedure

Use the following procedure to set the tuning-less levels.

In addition to the following procedure, you can also set the parameters directly. Refer to *Related Parameters*, below, for the parameters to set.

1. Select Setup - Response Level Setting from the menu bar of the Main Window of the SigmaWin+.

The Response Level Setting Dialog Box will be displayed.

#### 8.4.3 Troubleshooting Alarms

2. Click the ▲ or ▼ Button to adjust the response level setting. Increase the response level setting to increase the response. Decrease the response level setting to suppress vibration.

The default response level setting is 4.

Response Level Setting	Description	Remarks
7	Response level: High	V
6		You cannot select these levels if tuning-less type 1 or 2 (Pn14F = n.□□0□ or n.□□1□) is used.
5		(· · · · · · · · · · · · · · · · · · ·
4 (default setting)		
3		
2		_
1	7	
0	Response level: Low	

#### 3. Click the Completed Button.

The adjustment results will be saved in the SERVOPACK.

#### Related Parameters

#### ■ Tuning-less Rigidity Level

If you use tuning-less type 1 or 2 (Pn14F = n. $\square\square$ 0 $\square$ 0 or n. $\square$ 1 $\square$ 1), set the tuning-less level to between 0 and 4 (Pn170 = n. $\square$ 0 $\square$ 1 to n. $\square$ 4 $\square$ 1). Do not set the tuning-less level to between 5 and 7 (Pn170 = n. $\square$ 5 $\square$ 1 to n. $\square$ 7 $\square$ 1).

Parameter		Description		When Enabled	Classification
	n.□0□□	Tuning-less rigidity level 0 (low rigi	idity)		
	n.🗆 1 🗆 🗆	Tuning-less rigidity level 1	7		
	n.□2□□	Tuning-less rigidity level 2			
Pn170	n.□3□□	Tuning-less rigidity level 3			
(2170 hex)	n. 🗆 4 🗆 🗆	Tuning-less rigidity level 4		Immediately	Setup
Hex)	(default setting)	0 0 1			
	n.□5□□	Tuning-less rigidity level 5			
	n.□6□□	Tuning-less rigidity level 6			
	n.0700	Tuning-less rigidity level 7 (high rig	gidity)		

#### ■ Tuning-less Load Level

Р	arameter	Description	When Enabled	Classification
D-470	n.0□□□	Tuning-less load level 0		
Pn170 (2170 hex)	n.1□□□ (default setting)	Tuning-less load level 1	Immediately	Setup
iicx)	n.2000	Tuning-less load level 2		

## 8.4.3 Troubleshooting Alarms

An A.521 alarm (Autotuning Alarm) will occur if a resonant sound occurs or if excessive vibration occurs during position control. If an alarm occurs, implement the following measures.

- · Resonant Sound
  - Decrease the setting of Pn170 =  $n.X\square\square\square$  or the setting of Pn170 =  $n.\square X\square\square$ .
- Excessive Vibration during Position Control Increase the setting of Pn170 = n.X□□□ or decrease the setting of Pn170 = n.□X□□.

## 8.4.4 Parameters Disabled by Tuning-less Function

When the tuning-less function is enabled (Pn170 =  $n.\Box\Box\Box$ 1) (default setting), the parameters in the following table are disabled.

Item	Item Parameter Name	
	Speed Loop Gain Second Speed Loop Gain	Pn100 (2100 hex) Pn104 (2104 hex)
Gain-Related Parameters	Speed Loop Integral Time Constant Second Speed Loop Integral Time Constant	Pn101 (2101 hex) Pn105 (2105 hex)
	Position Loop Gain Second Position Loop Gain	Pn102 (2102 hex) Pn106 (2106 hex)
	Moment of Inertia Ratio	Pn103 (2103 hex)
Advanced Control-Related Parameters	Friction Compensation Function Selection	Pn408 (2408 hex) = n.X□□□
	Anti-Resonance Control Selection	Pn160 (2160 hex)= n.□□□X
Gain Selection-Related Parameters	Gain Switching Selection	Pn139 (2139 hex)= n.□□□X

The tuning-less function is disabled during torque control, Easy FFT, and mechanical analysis for a vertical axis. The gain-related parameters in the above table are enabled for torque control, Easy FFT, and mechanical analysis. Of these, Pn100, Pn103, and Pn104 are enabled for torque control.

## 8.4.5 Automatically Adjusted Function Setting

You can also automatically adjust notch filters.

Normally, set Pn460 to n. \$\square\$1 (Adjust automatically) (default setting). Vibration is automatically detected and a notch filter is set.

Set Pn460 to n.  $\square 0 \square \square$  (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute the tuning-less function.

Parameter		Meaning	When Enabled	Classification
Pn460 (2460	n.□0□□	Do not adjust the second stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.  Immediately  Tunir		Tuning
hex)	n.□1□□ (default setting)	Adjust the second stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	IIIIIIedialely	Turning

## 8.4.6 Related Parameters

The following parameters are automatically adjusted when you execute the tuning-less function.

Do not manually change the settings of these parameters after you have enabled the tuningless function.

Parameter	Name
Pn401 (2401 hex)	First Stage First Torque Reference Filter Time Constant
Pn40C (240C hex) Second Stage Notch Filter Frequency	
Pn40D (240D hex)	Second Stage Notch Filter Q Value

8.5.1 Outline

## 8.5

## **Estimating the Moment of Inertia**

This section describes how the moment of inertia is calculated.

The moment of inertia ratio that is calculated here is used in other tuning functions. You can also estimate the moment of inertia during autotuning without a host reference. Refer to the following section for the procedure.

8.6.4 Operating Procedure on page 8-25

#### 8.5.1 Outline


The moment of inertia during operation is automatically calculated by the SERVOPACK for round-trip (forward and reverse) operation. A reference from the host controller is not used.

The moment of inertia ratio (i.e., the ratio of the load moment of inertia to the motor moment of inertia) is a basic parameter for adjusting gains. It must be set as accurately as possible.

Although the load moment of inertia can be calculated from the weight and structure of the mechanisms, doing so is very troublesome and calculating it accurately can be very difficult with the complex mechanical structures that are used these days. With moment of inertia estimation, you can get an accurate load moment of inertia simply by operating the motor in the actual system in forward and reverse a few times.

The motor is operated with the following specifications.

- Maximum speed: ±1,000 min<sup>-1</sup> (can be changed)
- Acceleration rate: ±20,000 min<sup>-1</sup>/s (can be changed)
- Travel distance: ±2.5 rotations max. (can be changed)



Note: Execute moment of inertia estimation after jogging to a position that ensures a suitable range of motion.

## 8.5.2 Restrictions

The following restrictions apply to estimating the moment of inertia.

## Systems for which Execution Cannot Be Performed

- When the machine system can move only in one direction
- When the range of motion is 0.5 rotations or less

# Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- When the moment of inertia changes within the set operating range
- When the machine has high dynamic friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- · When proportional control is used

• When mode switching is used

Note:If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.

When speed feedforward or torque feedforward is input

### **Preparations**

Check the following settings before you execute moment of inertia estimation.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The first gains must be selected.
- The test without a motor function must be disabled ( $Pn00C = n.\square\square\square\square0$ ).
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 = n.□□□0).

## 8.5.3 Applicable Tools

The following table lists the tools that you can use to estimate the moment of inertia and the applicable tool functions.

Tool	Function	Operating Procedure Reference
SigmaWin+	Tuning - Tuning	8.5.4 Operating Procedure on page 8-17

## 8.5.4 Operating Procedure

Use the following procedure to set the moment of inertia ratio.

## **↑** WARNING

- Estimating the moment of inertia requires operating the motor and therefore presents hazards. Observe the following precaution.
  - Confirm safety around moving parts.

    This function involves automatic operation with vibration. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

## **CAUTION**


- Be aware of the following points if you cancel the moment of inertia estimation while the motor is operating.
  - If you cancel operation with the Servo OFF Button, the motor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□□X).
  - If you cancel operation with the Cancel Button, the motor will decelerate to a stop and then enter a zero-clamped state.
- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.

#### 8.5.4 Operating Procedure


#### 2. Select Tuning in the Menu Dialog Box.

The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.


3. Click the Execute Button.



4. Click the Execute Button.



**5.** Set the conditions as required.



#### ① Speed Loop Setting Area

Make the speed loop settings in this area.

If the speed loop response is too bad, it will not be possible to measure the moment of inertia ratio accurately.

The values for the speed loop response that are required for moment of inertia estimation are set for the default settings. It is normally not necessary to change these settings. If the default speed loop gain is too high for the machine (i.e., if vibration occurs), lower the setting. It is not necessary to increase the setting any farther.

#### ② Identification Start Level Group

This is the setting of the moment of inertia calculation starting level.

If the load is large or the machine has low rigidity, the torque limit may be applied, causing moment of inertia estimation to fail.

If that occurs, estimation may be possible if you double the setting of the start level.

#### 3 Edit Buttons

Click the button to display a dialog box to change the settings related to the speed loop or estimation start level.

#### 4 Help Button

Click this button to display guidelines for setting the reference conditions. Make the following settings as required.

- Operate the motor to measure the load moment of inertia of the machine in comparison with the rotor moment of inertia.
- Set the operation mode, reference pattern (maximum acceleration rate, maximum speed, and maximum travel distance), and speed loop-related parameters.
- Correct measurement of the moment of inertia ratio may not be possible depending on the settings. Set suitable settings using the measurement results as reference.


#### S Reference Selection Area

Either select the reference pattern for estimation processing from the box, or set the values in the **Detailed Setting** Group. Generally speaking, the larger the maximum acceleration rate is, the more accurate the moment of inertia estimation will be.

Set the maximum acceleration range within the possible range of movement considering the gear ratio, e.g., the pulley diameters or ball screw pitch.

#### **© Confirm** Button

Click this button to display the Reference Confirmation Dialog Box.



#### ② Detailed Setting Area

You can change the settings by moving the bars or directly inputting the settings to create the required reference pattern.

® Next Button

Click this button to display the Reference Transmission Dialog Box.

Click this button to return to the Tuning Dialog Box.

## **CAUTION**

- The travel distance is the distance for one operation in the forward or reverse direction. During multiple operations, the operation starting position may move in one direction or the other. Confirm the possible operating range for each measurement or operation.
- Depending on the parameter settings and the moment of inertia of the machine, overshooting and undershooting may occur and may cause the maximum speed setting to be exceeded temporarily. Allow sufficient leeway in the settings.

#### 8.5.4 Operating Procedure

#### Information


#### When Measurement Is Not Correct

Estimating the moment of inertia ratio cannot be performed correctly if the torque limit is activated. Adjust the limits or reduce the acceleration rate in the reference selection so that the torque limit is not activated.

#### 6. Click the Next Button.

The Reference Transmission Dialog Box will be displayed.

#### 7. Click the Start Button.



#### ① Start Button

The reference conditions will be transferred to the SERVOPACK. A progress bar will show the progress of the transfer.

#### ② Cancel Button

The **Cancel** Button is enabled only while data is being transferred to the SERVOPACK. You cannot use it after the transfer has been completed.

#### 3 Back Button

This button returns you to the Condition Setting Dialog Box. It is disabled while data is being transferred.

#### Mext Button

This button is enabled only when the data has been transferred correctly. You cannot use it if an error occurs or if you cancel the transfer before it is completed.

Click the **Next** Button to display the Operation/Measurement Dialog Box.

#### S Cancel Button

This button cancels processing and returns you to the Tuning Dialog Box.

#### 8. Click the Next Button.

The Operation/Measurement Dialog Box will be displayed.

#### 9. Click the Servo On Button.



#### 10. Click the Forward Button.

The shaft will rotate in the forward direction and the measurement will start. After the measurement and data transfer have been completed, the **Reverse** Button will be displayed in color.

#### 11. Click the Reverse Button.



The shaft will rotate in the reverse direction and the measurement will start. After the measurement and data transfer have been completed, the **Forward** Button will be displayed in color.



#### 12. Repeat steps 9 to 11 until the Next Button is enabled.

Measurements are performed from 2 to 7 times and then verified. The number of measurements is displayed in upper left corner of the dialog box. A progress bar at the bottom of the dialog box will show the progress of the transfer each time.

13. When the measurements have been completed, click the Servo On Button to turn OFF the servo.

#### 14. Click the Next Button.

The Write Results Dialog Box will be displayed.


Information

If you click the  $\bf Next$  Button before you turn OFF the servo, the following Dialog Box will be displayed. Click the  $\bf OK$  Button to turn OFF the servo.



#### 8.5.4 Operating Procedure

#### 15. Click the Writing Results Button.



#### ① Identified Moment of Inertia Ratio Box

The moment of inertia ratio that was found with operation and measurements is displayed here.

#### 2 Writing Results Button

If you click this button, Pn103 (Moment of Inertia Ratio) in the SERVOPACK is set to the value that is displayed for the identified moment of inertia ratio.

#### 3 Pn103: Moment of Inertia Ratio Box

The value that is set for the parameter is displayed here.

After you click the **Writing Results** Button, the value that was found with operation and measurements will be displayed as the new setting.

Back Button


This button is disabled.

S Cancel Button

This button will return you to the Tuning Dialog Box.

## **16.** Confirm that the **Identified Moment of Inertia Ratio** Box and the **Pn103: Moment of Inertia Ratio** Box show the same value and then click the **Finish** Button.

#### 17. Click the OK Button.



#### 18. Click the Execute Button.



If the setting of the moment of inertia ratio (Pn103) was changed, the new value will be saved and the Tuning Dialog Box will be displayed again.

This concludes the procedure to estimate the moment of inertia ratio.

## .6 Autotuning without Host Reference

This section describes autotuning without a host reference.



- Autotuning without a host reference performs adjustments based on the setting of the speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.
- You cannot execute autotuning without a host reference if the tuning-less function is enabled (Pn170 = n.□□□1 (default setting)). Disable the tuning-less function (Pn170 = n.□□□0) before you execute autotuning without a host reference.
- If you change the machine load conditions or drive system after you execute autotuning without a host reference and then you execute autotuning without a host reference with moment of inertia estimation specified, use the following parameter settings. If you execute autotuning without a host reference for any other conditions, the machine may vibrate and may be damaged.

Pn140 = n. \( \subseteq \subseteq 0 \) (Do not use model following control.)

Pn160 = n.□□□0 (Do not use anti-resonance control.)

Pn408 = n.00 \( \text{D}\) (Disable friction compensation, first stage notch filter, and second stage notch filter.)

Note: If you are using the Digital Operator and the above parameters are not displayed, change the parameter display setting to display all parameters (Pn00B = n.□□□1) and then turn the power supply OFF and ON again.

## 8.6.1 Outline

For autotuning without a host reference, operation is automatically performed by the SERVO-PACK for round-trip (forward and reverse) operation to adjust for machine characteristics during operation. A reference from the host controller is not used.

The following items are adjusted automatically.

- · Moment of inertia ratio
- Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control
- Vibration suppression (only for mode 2 or 3)


Refer to the following section for details on the parameters that are adjusted.

8.6.7 Related Parameters on page 8-33

The motor is operated with the following specifications.

Maximum Speed	Rated motor speed $\times \frac{2}{3}$	
Acceleration Torque	Rated motor torque: Approx. 100%  Note: The acceleration torque depends on the setting of the influence of the moment of inertia ratio (Pn103), machine friction, and external disturbance.	
Travel Distance	Rotary Servomotors	You can set the desired travel distance. The default setting is for a value equivalent to 3 motor shaft rotations.
navei distance	Linear Servomotors	You can set the desired travel distance in increments of 1,000 reference units. (The default setting is for 90 mm.)

#### 8.6.2 Restrictions



## **MARNING**

- Autotuning without a host reference requires operating the motor and therefore presents hazards. Observe the following precaution.
  - Confirm safety around moving parts.
     This function involves automatic operation with vibration. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

### 8.6.2 Restrictions

The following restrictions apply to autotuning without a host reference.

If you cannot use autotuning without a host reference because of these restrictions, use autotuning with a host reference or custom tuning. Refer to the following sections for details.

8.7 Autotuning with a Host Reference on page 8-34

8.8 Custom Tuning on page 8-41

## Systems for Which Execution Cannot Be Performed

- When the machine system can move only in one direction
- When the range of motion is 0.5 rotations or less

# Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- When the moment of inertia changes within the set operating range
- When the machine has high friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- · When the position integration function is used
- · When proportional control is used
- When mode switching is used

Note:If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.

- When speed feedforward or torque feedforward is input
- When the positioning completed width (Pn522) is too narrow

### **Preparations**

Check the following settings before you execute autotuning without a host reference.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C = n.□□□0).
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 = n.□□□0), or the tuning-less function must be enabled (Pn170 = n.□□□1) and moment of inertia estimation must be specified.
- If you execute autotuning without a host reference during speed control, set the mode to 1.



If you start autotuning without a host reference while the SERVOPACK is in speed control
for mode 2 or 3, the SERVOPACK will change to position control automatically to perform
autotuning without a host reference. The SERVOPACK will return to speed control after
autotuning has been completed.

## 8.6.3 Applicable Tools

The following table lists the tools that you can use to perform autotuning without a host reference and the applicable tool functions.

Tool	Function	Operating Procedure Reference		
Digital Operator	Fn201	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)		
SigmaWin+	Tuning - Tuning	8.6.4 Operating Procedure on page 8-25		

## 8.6.4 Operating Procedure


Use the following procedure to perform autotuning without a host reference.

## **A** CAUTION


- If you specify not estimating the moment of inertia, set the moment of inertia ratio (Pn103) correctly. If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may result.
- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 3. Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the Cancel Button to cancel tuning.

#### 8.6.4 Operating Procedure

4. Click the Execute Button.




5. Select the No Reference Input Option in the Autotuning Area and then click the Autotuning Button.




Information

When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).



6. Set the conditions in the Switching the load moment of inertia (load mass) identification Box, the Mode selection Box, the Mechanism selection Box, and the Distance Box, and then click the Next Button.



#### Distance Box

Set the travel distance.

Movement range: -99,990,000 to +99,990,000 [reference units]
Minimum setting increment for travel distance: 1,000 [reference units]

Negative values are for reverse operation and positive values are for forward operation from the current position.

Default settings:

Rotary Servomotors: Approx. 3 rotations Linear Servomotors: Approx 90 mm Set the distance to the following values or higher. To ensure tuning precision, we recommend that you use approximately the default distance setting.

Rotary Servomotors: 0.5 rotations Linear Servomotors: 5 mm

#### Switching the load moment of inertia (load mass) identification Box

Specify whether to estimate the moment of inertia.

0: A moment of inertia is presumed. (default setting)1: A moment of inertia is not presumed.

#### Mode selection Box

Set the mode.

Mode Selection	Description
1: Standard	Standard gain adjustment is per- formed. In addition to gain adjust- ment, notch filters and anti-resonance control are automatically adjusted.
2: For positioning	Tuning is performed for positioning applications. In addition to gain adjustment, model following control, notch filters, anti-resonance control, and vibration suppression are automatically adjusted.
3: For positioning especially to prevent overshooting	Tuning is performed for positioning applications with emphasis on eliminating overshooting. In addition to gain adjustment, notch filters, antiresonance control, and vibration suppression are automatically adjusted.

#### Mechanism selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description
1: Belt mechanism	Tuning is performed for a mechanism with relatively low rigidity, e.g., a belt.
2: Ball screw mech- anism or linear motor	Tuning is performed for a mechanism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.
3: Rigid model	Tuning is performed for a mechanism with high rigidity, e.g., a rigid body system.

#### • Tuning parameters Box

Specify the parameters to use for tuning. If you select the **Start tuning using the default settings** Check Box, the tuning parameters will be returned to the default settings before tuning is started.

#### 8.6.4 Operating Procedure

7. Click the Servo ON Button.



8. Click the Start tuning Button.




#### 8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

9. Confirm safety around moving parts and click the Yes Button.



The motor will start operating and tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.



#### **10.** When tuning has been completed, click the **Finish** Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure to perform autotuning without a host reference.

# 8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning without a host reference.

### ◆ Autotuning without a Host Reference Was Not Performed

Possible Cause	Corrective Action	
Main circuit power supply is OFF.	Turn ON the main circuit power supply.	
An alarm or warning occurred.	Remove the cause of the alarm or warning.	
Overtraveling occurred.	Remove the cause of overtraveling.	
The second gains were selected with the gain selection.	Disable automatic gain switching.	
The HWBB was activated.	Release the HWBB.	
The setting of the travel distance is too small.	Set the travel distance again in step 6 of the procedure.	
The settings for the tuning-less function are not correct.	<ul> <li>Disable the tuning-less function (Pn170 = n.□□□0).</li> <li>Enable the tuning-less function (Pn170 = n.□□□1) and specify moment of inertia estimation.</li> </ul>	

#### 8.6.5 Troubleshooting Problems in Autotuning without a Host Reference

#### When an Error Occurs during Execution of Autotuning without a Host Reference

Error	Possible Cause	Corrective Action	
The gain adjustments were not successfully completed.	Machine vibration occurs or the positioning completion signal is not stable when the Servomotor stops.	<ul> <li>Increase the setting of the positioning completed width (Pn522).</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.</li> </ul>	
An error occurred during calculation of the moment of inertia.	Refer to the following section for troubleshooting information.		
Positioning was not completed within approximately 10 seconds after position adjustment was completed.	The positioning completed width is too narrow or proportional control is being used.	Increase the setting of the positioning completed width (Pn522).	

#### ◆ When an Error Occurs during Calculation of Moment of Inertia

Possible Cause	Corrective Action
The SERVOPACK started calculating the moment of inertia but the calculation was not completed.	<ul> <li>Increase the setting of the speed loop gain (Pn100).</li> <li>Increase the stroke (travel distance).</li> </ul>
The moment of inertia fluctuated greatly and did not converge within 10 tries.	Set Pn103 (Moment of Inertia Ratio) from the machine specifications and specify not estimating the moment of inertia.
Low-frequency vibration was detected.	Double the setting of moment of inertia calculation starting level (Pn324).
The torque limit was reached.	<ul> <li>If you are using the torque limit, increase the torque limit.</li> <li>Double the setting of moment of inertia calculation starting level (Pn324).</li> </ul>
Speed control changed to proportional control during calculation of the moment of inertia.	Use PI control when calculating the moment of inertia.

#### ◆ Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and position reference unit (position user unit (2701 hex)).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
  This will allow tuning with overshooting that is equivalent to the positioning completed width.
- Pn561 = 0%
   This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

Pn561	Overshoot Detection Level			Speed Posit	ion Torque
(2561	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 100	1%	100	Immediately	Setup

## **Automatically Adjusted Function Settings**

You can specify whether to automatically adjust the following functions during autotuning.

#### Automatic Notch Filters

8.6.6

Normally, set Pn460 to n. \$\Pi\$1 (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and a notch filter will be adjusted.

Set Pn460 to n.  $\square 0 \square \square$  (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute this function.

Parameter		Function	When Enabled	Classification
Pn460 (2460 hex)	n.□□□0	Do not adjust the first stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		Tuning
	n.□□□1 (default setting)	Adjust the first stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		
	n.□0□□	Do not adjust the second stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		
	n.□1□□ (default setting)	djust the second stage notch filter automatially during execution of autotuning without a ost reference, autotuning with a host reference, and custom tuning.		

## ◆ Anti-Resonance Control Adjustment

This function reduces low vibration frequencies, for which the notch filters cannot be used.

Normally, set Pn160 to n. □□1□ (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and anti-resonance control will be automatically adjusted.

Parameter		Function	When Enabled	Classification
Pn160	n.□□0□  Do not adjust anti-resonance control automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.  Immediately		Tuning	
(2160 hex)	n.□□1□ (default setting)	Adjust anti-resonance control automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning	IIIIIIediately	Tuning

## ◆ Vibration Suppression

You can use vibration suppression to suppress transitional vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning.

Normally, set Pn140 to n. D1 D (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and vibration suppression control will be automatically set.

Set  $Pn140 = n.\Box 0\Box\Box$  (Do not adjust automatically) only if you do not change the settings for vibration suppression before you execute autotuning without a host reference.

Note: Autotuning without a host reference uses model following control. Therefore, it can be executed only if the mode is set to 2 or 3.

#### 8.6.6 Automatically Adjusted Function Settings

Parameter		Function	When Enabled	Classification
Pn140 (2140	n.□0□□	Do not adjust vibration suppression automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	out a fer- Immediately Tuning host	
hex)	n.□1□□ (default setting)	Adjust vibration suppression automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		

#### Friction Compensation

Friction compensation compensates for changes in the following conditions.

- Changes in the viscous resistance of the lubricant, such as grease, on the sliding parts of the machine
- · Changes in the friction resistance resulting from variations in the machine assembly
- · Changes in the friction resistance due to aging

The conditions for applying friction compensation depend on the mode selection.

Mode Selection Settings	Friction Compensation	
1: Standard	Based on the setting of Pn408 = n.X□□□ (Friction Compensation Function Selection)*	
2: For position control	Adjusted with friction compensation.	
3: For position control (emphasis on overshooting)		

Parameter F		Function	When Enabled	Classification
Pn408 (2408	n. 0□□□ (default setting)	Disable friction compensation.	Immediately	Setup
hex)	n. 1000	Enable friction compensation.		

<sup>\*</sup> Refer to the following section for details.

#### ◆ Feedforward

If Pn140 is set to n.0 \(\sigma\) (Do not use model following control and speed/torque feedforward together (default setting)) and tuning is performed with the mode selection set to 2 or 3, feedforward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) will be disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1 \(\sigma \sigma \) (Use model following control and speed/torque feedforward together).

Parameter		Function	When Enabled	Classification
Pn140 (2140	n.0□□□ (default setting)	Do not use model following control and speed/torque feedforward together.	_ Immediately Tuning	
hex)  n.1□□□  Use model following control at feedforward together.		Use model following control and speed/torque feedforward together.	ITITIOGIALGIY	raning



When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (TFF) if required. An unsuitable feedforward input may result in overshooting.

Required Parameter Settings on page 8-68

## 8.6.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning without a host reference.

Do not change the settings while autotuning without a host reference is being executed.

Parameter	Name	Automatic Changes
Pn100 (2100 hex)	Speed Loop Gain	Yes
Pn101 (2101 hex)	Speed Loop Integral Time Constant	Yes
Pn102 (2102 hex)	Position Loop Gain	Yes
Pn103 (2103 hex)	Moment of Inertia Ratio	Yes
Pn121 (2121 hex)	Friction Compensation Gain	Yes
Pn123 (2123 hex)	Friction Compensation Coefficient	Yes
Pn124 (2124 hex)	Friction Compensation Frequency Correction	No
Pn125 (2125 hex)	Friction Compensation Gain Correction	Yes
Pn401 (2401 hex)	First Stage First Torque Reference Filter Time Constant	Yes
Pn408 (2408 hex)	Torque-Related Function Selections	Yes
Pn409 (2409 hex)	First Stage Notch Filter Frequency	Yes
Pn40A (240A hex)	First Stage Notch Filter Q Value	Yes
Pn40C (240C hex)	Second Stage Notch Filter Frequency	Yes
Pn40D (240D hex)	Second Stage Notch Filter Q Value	Yes
Pn140 (2140 hex)	Model Following Control-Related Selections	Yes
Pn141 (2141 hex)	Model Following Control Gain	Yes
Pn142 (2142 hex)	, , ,	
Pn143 (2143 hex)	Model Following Control Bias in the Forward Direction	Yes
Pn144 (2144 hex)	Model Following Control Bias in the Reverse Direction	Yes
Pn145 (2145 hex)	Vibration Suppression 1 Frequency A	Yes
Pn146 (2146 hex)	Vibration Suppression 1 Frequency B	Yes
Pn147 (2147 hex)	Model Following Control Speed Feedforward Compensation	Yes
Pn160 (2160 hex)	Anti-Resonance Control-Related Selections	Yes
Pn161 (2161 hex)	Anti-Resonance Frequency	Yes
Pn163 (2163 hex)	Anti-Resonance Damping Gain	Yes
Pn531 (2531 hex)	Program Jogging Travel Distance	No
Pn533 (2533 hex)	Program Jogging Movement Speed for Rotary Servomotor	No
Pn585 (2585 hex)	Program Jogging Movement Speed for Linear Servomotor	No
Pn534 (2534 hex)	Program Jogging Acceleration/Deceleration Time	No
Pn535 (2535 hex)	Program Jogging Waiting Time	No
Pn536 (2536 hex)	Program Jogging Number of Movements	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

#### 8.7.1 Outline

# 8.7

# Autotuning with a Host Reference

This section describes autotuning with a host reference.



Autotuning with a host reference makes adjustments based on the set speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.

## 8.7.1 Outline


Autotuning with a host reference automatically makes optimum adjustments for operation references from the host controller.

The following items are adjusted automatically.

- Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- · Anti-resonance control
- Vibration suppression

Refer to the following section for details on the parameters that are adjusted.

8.7.7 Related Parameters on page 8-40



# **M** CAUTION

 Because autotuning with a host reference adjusts the SERVOPACK during automatic operation, vibration or overshooting may occur. To ensure safety, make sure that you can perform an emergency stop at any time.

## Systems for Which Adjustments Cannot Be Made Accurately

Adjustments will not be made correctly for autotuning with a host reference in the following cases. Use custom tuning.

- When the travel distance for the reference from the host controller is equal to or lower than the setting of the positioning completed width (Pn522)
- Rotary Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the rotation detection level (Pn502)
- Linear Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the zero speed level (Pn581)
- When the time required to stop is 10 ms or less
- · When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- When proportional control is used
- When mode switching is used
- When the positioning completed width (Pn522) is too narrow

Refer to the following sections for details on custom tuning.

8.8 Custom Tuning on page 8-41

## **Preparations**

Restrictions

8.7.2

Check the following settings before you execute autotuning with a host reference.

- The servo must be in ready status.
- There must be no overtravel.
- · The servo must be OFF.
- Position control must be selected if power is supplied to the motor (i.e., when the servo is ON).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C = n.□□□0).
- There must be no warnings.
- The tuning-less function must be disabled (Pn170 = n.□□□0).
- The parameters must not be write prohibited.

#### 8.7.3 **Applicable Tools**


The following table lists the tools that you can use to perform autotuning with a host reference and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn202	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	8.7.4 Operating Procedure on page 8-36


# 8.7.4 Operating Procedure

Use the following procedure to perform autotuning with a host reference.

- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 4. Click the Execute Button.



5. Select the Position reference input Option in the Autotuning Area and then click the Autotuning Button.




Information

When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).



# **6.** Set the conditions in the **Mode selection** Box and the **Mechanism selection** Box, and then click the **Next** Button.

If you select the **Start tuning using the default settings** Check Box in the **Tuning parameters** Area, the tuning parameters will be returned to the default settings before tuning is started.



• Tuning parameters Box
Specify the parameters to use for tuning.
If you select the Start tuning using the
default settings Check Box, the tuning
parameters will be returned to the default
settings before tuning is started.

• Mode selection Box Set the mode.

Mode Selection	Description
1: Standard	Standard gain adjustment is performed. In addition to gain adjustment, notch filters and antiresonance control are automatically adjusted.
2: For positioning	Tuning is performed for positioning applications. In addition to gain adjustment, model following control, notch filters, anti-resonance control, and vibration suppression are automatically adjusted.
3: For positioning especially to prevent overshooting	Tuning is performed for positioning applications with emphasis on eliminating overshooting. In addition to gain adjustment, notch filters, antiresonance control, and vibration suppression are automatically adjusted.

#### Mechanism selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description
1: Belt mechanism	Tuning is performed for a mechanism with relatively low rigidity, e.g., a belt.
2: Ball screw mechanism or linear motor	Tuning is performed for a mechanism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.
3: Rigid model	Tuning is performed for a mechanism with high rigidity, e.g., a rigid body system.

7. Click the Yes Button.



#### 8.7.4 Operating Procedure

8. Input the correct moment of inertia ratio and click the **Next** Button.



**9.** Turn ON the servo, enter a reference from the host controller, and then click the **Start tuning** Button.



**10.** Confirm safety around moving parts and click the **Yes** Button.



The motor will start operating and tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.



#### 8.7.5 Troubleshooting Problems in Autotuning with a Host Reference

#### 11. When tuning has been completed, click the Finish Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure to perform autotuning with a host reference.

# 8.7.5 Troubleshooting Problems in Autotuning with a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning with a host reference.

### ◆ Autotuning with a Host Reference Was Not Performed

Possible Cause	Corrective Action
Main circuit power supply is OFF.	Turn ON the main circuit power supply.
An alarm or warning occurred.	Remove the cause of the alarm or warning.
Overtraveling occurred.	Remove the cause of overtraveling.
The second gains were selected with the gain selection.	Disable automatic gain switching.
The HWBB was activated.	Release the HWBB.

### ◆ Troubleshooting Errors

Error	Possible Cause	Corrective Action
The gain adjustments were not successfully completed.	Machine vibration occurs or positioning completion is not stable when the Servomotor stops.	<ul> <li>Increase the setting of Pn522 (2522 hex) (Positioning Completed Width).</li> <li>Change the mode from 2 to 3.</li> <li>If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.</li> </ul>
Positioning was not completed within approximately 10 seconds after position adjustment was completed.	The positioning completed width is too narrow or proportional control is being used.	Increase the setting of Pn522 (2522 hex) (Positioning Completed Width).

## ◆ Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and position reference unit (position user unit (2701 hex)).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
  This will allow tuning with overshooting that is equivalent to the positioning completed width.
- This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

Pn561	Overshoot Detection Level			Speed Position Torque		
(2561	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 100	1%	100	Immediately	Setup	

# 8.7.6 Automatically Adjusted Function Settings

These function settings are the same as for autotuning without a host reference. Refer to the following section.

8.6.6 Automatically Adjusted Function Settings on page 8-31

## 8.7.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning with a host reference.

Do not change the settings while autotuning with a host reference is being executed.

Parameter	Name	Automatic Changes
Pn100 (2100 hex)	Speed Loop Gain	Yes
Pn101 (2101 hex)	Speed Loop Integral Time Constant	Yes
Pn102 (2102 hex)	Position Loop Gain	Yes
Pn103 (2103 hex)	Moment of Inertia Ratio	No
Pn121 (2121 hex)	Friction Compensation Gain	Yes
Pn123 (2123 hex)	Friction Compensation Coefficient	Yes
Pn124 (2124 hex)	Friction Compensation Frequency Correction	No
Pn125 (2125 hex)	Friction Compensation Gain Correction	Yes
Pn401 (2401 hex)	First Stage First Torque Reference Filter Time Constant	Yes
Pn408 (2408 hex)	Torque-Related Function Selections	Yes
Pn409 (2409 hex)	First Stage Notch Filter Frequency	Yes
Pn40A (240A hex)	First Stage Notch Filter Q Value	Yes
Pn40C (240C hex)	Second Stage Notch Filter Frequency	Yes
Pn40D (240D hex)	Second Stage Notch Filter Q Value	Yes
Pn140 (2140 hex)	Model Following Control-Related Selections	Yes
Pn141 (2141 hex)	Model Following Control Gain	Yes
Pn142 (2142 hex)	Model Following Control Gain Correction	Yes
Pn143 (2143 hex)	Model Following Control Bias in the Forward Direction	Yes
Pn144 (2144 hex)	Model Following Control Bias in the Reverse Direction	Yes
Pn145 (2145 hex)	Vibration Suppression 1 Frequency A	Yes
Pn146 (2146 hex)	Vibration Suppression 1 Frequency B	Yes
Pn147 (2147 hex)	Model Following Control Speed Feedforward Compensation	Yes
Pn160 (2160 hex)	Anti-Resonance Control-Related Selections	Yes
Pn161 (2161 hex)	Anti-Resonance Frequency	Yes
Pn163 (2163 hex)	Anti-Resonance Damping Gain	Yes

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

# 8.8 Custom Tuning

This section describes custom tuning.

## 8.8.1 Outline

You can use custom tuning to manually adjust the servo during operation using a speed or position reference input from the host controller. You can use it to fine-tune adjustments that were made with autotuning.

The following items are adjusted automatically.

- Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control

Refer to the following section for details on the parameters that are adjusted.

8.8.7 Related Parameters on page 8-49

There are two adjustment methods that you can use for custom tuning.

■ Tuning Mode 0 (Setting Servo Gains Giving Priority to Stability) or 1 (Setting Servo Gains Giving Priority to Good Response)

These modes allow you to set stable control conditions for multiple servo gains by manipulating only one tuning level. Automatic setting of notch filters and anti-resonance control is provided if vibration is detected. Manual anti-resonance control adjustment is also possible during custom tuning.

 Tuning Mode 2 (Setting Servo Gains Giving Priority to Position Control Applications) or 3 (Setting Servo Gains Giving Priority to Preventing Overshooting in Position Control Applications)

Two tuning levels are manipulated to reduce positioning time even further and set multiple servo gains.

Model following control is used to reduce the positioning time. If vibration is detected, notch filters and anti-resonance control are automatically adjusted, and friction compensation is automatically set. Manual anti-resonance control adjustment and vibration suppression are also possible during custom tuning.

# **↑** CAUTION

Vibration or overshooting may occur during custom tuning. To ensure safety, make sure that
you can perform an emergency stop at any time.

## 8.8.2 Preparations

Check the following settings before you execute custom tuning.

- The test without a motor function must be disabled (Pn00C =  $n.\square\square\square\square$ 0).
- The tuning-less function must be disabled (Pn170 = n.□□□0).
- If speed control is used, tuning mode 0 or 1 must be set.
- The parameters must not be write prohibited.

# 8.8.3 Applicable Tools

The following table lists the tools that you can use to perform custom tuning and the applicable tool functions.


Tool	Function	Operating Procedure Reference
Digital Operator	Fn203	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning – Tuning	8.8.4 Operating Procedure on page 8-42

# 8.8.4 Operating Procedure


Use the following procedure to perform custom tuning.

# WARNING

- Before you execute custom tuning, check the information provided in the SigmaWin+ operating manual.
  - Observe the following precautions.
  - Make sure that you can perform an emergency stop at any time.
     When custom tuning is started, several parameters will be overwritten with the recommended settings, which may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time.
  - Set the moment of inertia correctly before you execute custom tuning. If the setting greatly differs from the actual moment of inertia, vibration may occur.
  - If you change the feedforward level, the new setting will not be used immediately. It will be used after positioning is completed.
- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 4. Click the Execute Button.




#### 5. Click the Advanced adjustment Button.



Information

When the following dialog box is displayed, click the  $\mathbf{OK}$  Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).




6. Click the Custom tuning Button.



#### 8.8.4 Operating Procedure

Set the Tuning mode Box and Mechanism selection Box, and then click the Next Button.



Tuning mode Box Mode Selection Description This setting gives priority to stability and preventing overshooting. In addi-0: Set servo gains tion to gain adjustment, notch filters with priority given and anti-resonance control (except to stability. during torque control) are automatically Overshooting may occur because priority is given to response. In addition to 1: Set servo gains gain adjustment, notch filters and antiwith priority given resonance control (except during to response. torque control) are automatically adjusted. Tuning is performed for positioning 2: Set servo gains applications. In addition to gain adjustfor positioning ment, notch filters, anti-resonance application. control, and vibration suppression are adjusted. Tuning is performed for positioning 3: Set servo gains applications with emphasis on elimiespecially to prenating overshooting. In addition to gain vent overshooting adjustment, notch filters, anti-resoduring positioning nance control, and vibration suppresapplication. sion are adjusted.

#### Mechanism Selection Box

Select the type according to the machine element to drive.


If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description
1: Belt mechanism	Tuning is performed for a mechanism with relatively low rigidity, e.g., a belt.
2: Ball screw mechanism or Linear motor	Tuning is performed for a mechanism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.
3: Rigid body system	Tuning is performed for a mechanism with high rigidity, e.g., a rigid body system.

Information


The tuning modes that you can select depend on the SERVOPACK setting.

8. If the moment of inertia ratio is not set correctly, correct the setting and then click the Next Button.




# 9. Turn ON the servo, enter a reference from the host controller, and then click the Start tuning Button.

Tuning Mode 0 or 1



Tuning Mode 2 or 3




#### **10.** Use the ▲ and ▼ Buttons to change the tuning level.

Click the **Back** Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.


#### Tuning Mode 0 or 1

Increase the tuning level until overshooting occurs.



#### Tuning Mode 2 or 3

Increase the feedforward level until overshooting occurs and then increase the feedback level until overshooting is eliminated. Repeat these changes to make the adjustment.



Information

The new feedforward level will not be used until the positioning completed signal is output.

**11.** You can set the functions to suppress vibration (notch filters, automatic anti-resonance setting, anti-resonance control adjustment, and autotuning with a host reference) as required.


Refer to the following section for details.

Wibration Suppression Functions on page 8-46

#### 8.8.4 Operating Procedure

#### **12.** When tuning has been completed, click the **Completed** Button.

The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.



This concludes the procedure to set up custom tuning.

# **Vibration Suppression Functions**


### ◆ Notch Filters and Automatic Anti-resonance Setting

If the vibration frequency that occurs when you increase the servo gains is at 1,000 Hz or higher, notch filters are effective to suppress vibration. If the vibration is between 100 Hz and 1,000 Hz, anti-resonance control is effective.

### Automatic Setting

To set vibration suppression automatically, use the parameters to enable notch filters and automatic anti-resonance control setting.

The notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the vibration that was detected during tuning will be automatically set.



#### • Auto-setting Cancel Buttons

The automatically set notch filter frequencies or the anti-resonance control frequencies may not always suppress vibration. Click the **Cancel** Button to reset the notch filter frequencies or the anti-resonance control frequencies to the values from just before these frequencies were set automatically.

When they are reset, vibration detection will start again.

#### • Vib Detect Button

While the notch filter or anti-resonance control adjustment automatic setting function is enabled, you can click the **Vib Detect** Button to manually detect vibration. When you click the **Vib Detect** Button, the SERVOPACK will detect vibration at that time, and set the notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the detected vibration. You can also perform manual vibration detection even when the SERVOPACK does not detect vibration.

#### Anti-res Ctrl Adj Button

You can use the **Anti-res Ctrl Adj** Button to execute the anti-resonance control function if fine-tuning is required. Refer to the following section.

8.9 Anti-Resonance Control Adjustment on page 8-50

#### Vib Suppress Button

Click the **Vib Suppress** Button to suppress low and transient vibration (oscillation) of approximately 1 Hz to 100 Hz that occurs during positioning. Refer to the following section.

8.10 Vibration Suppression on page 8-55

## ◆ Autotuning with a Host Reference

You can perform autotuning with a host reference. Refer to the following section for details. 8.7 Autotuning with a Host Reference on page 8-34

# 8.8.5 Automatically Adjusted Function Settings

You cannot use vibration suppression functions at the same time. Other automatic function settings are the same as for autotuning without a host reference. Refer to the following section.

8.6.6 Automatically Adjusted Function Settings on page 8-31

# 8.8.6 Tuning Example for Tuning Mode 2 or 3

Step	Measurement Display Examples	Operation
1	Position deviation  Reference speed  Positioning completion signal	The positioning time is measured after the moment of inertia ratio (Pn103) is set correctly.  Tuning is completed if the specifications are met.  The tuning results are saved in the SERVOPACK.
2		The positioning time will be reduced if the feedforward level is increased.  Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK.  If overshooting occurs before the specifications are met, proceed to step 3.
3		Overshooting will be reduced if the feedback level is increased.  If the overshooting is eliminated, proceed to step 4.
4		The graph shows overshooting that occurred when the feed-forward level was increased even more after step 3. In this state, overshooting occurs, but the positioning settling time is shorter. Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK. If overshooting occurs before the specifications are met, repeat steps 3 and 4. If vibration occurs before the overshooting is eliminated, the vibration is suppressed with the notch filters and anti-resonance control.
5	-	The tuning results are saved in the SERVOPACK.

## 8.8.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute custom tuning.

Do not change the settings while custom tuning is being executed.

Parameter	Name	Automatic Changes
Pn100 (2100 hex)	Speed Loop Gain	Yes
Pn101 (2101 hex)	Speed Loop Integral Time Constant	Yes
Pn102 (2102 hex)	Position Loop Gain	Yes
Pn103 (2103 hex)	Moment of Inertia Ratio	No
Pn121 (2121 hex)	Friction Compensation Gain	Yes
Pn123 (2123 hex)	Friction Compensation Coefficient	Yes
Pn124 (2124 hex)	Friction Compensation Frequency Correction	No
Pn125 (2125 hex)	Friction Compensation Gain Correction	Yes
Pn401 (2401 hex)	First Stage First Torque Reference Filter Time Constant	Yes
Pn408 (2408 hex)	Torque-Related Function Selections	Yes
Pn409 (2409 hex)	First Stage Notch Filter Frequency	Yes
Pn40A (240A hex)	First Stage Notch Filter Q Value	Yes
Pn40C (240C hex)	Second Stage Notch Filter Frequency	Yes
Pn40D (240D hex)	Second Stage Notch Filter Q Value	Yes
Pn140 (2140 hex)	Model Following Control-Related Selections	Yes
Pn141 (2141 hex)	Model Following Control Gain	Yes
Pn142 (2142 hex)	Model Following Control Gain Correction	Yes
Pn143 (2143 hex)	Model Following Control Bias in the Forward Direction	Yes
Pn144 (2144 hex)	Model Following Control Bias in the Reverse Direction	Yes
Pn145 (2145 hex)	Vibration Suppression 1 Frequency A	No
Pn146 (2146 hex)	Vibration Suppression 1 Frequency B	No
Pn147 (2147 hex)	Model Following Control Speed Feedforward Compensation	Yes
Pn160 (2160 hex)	Anti-Resonance Control-Related Selections	Yes
Pn161 (2161 hex)	Anti-Resonance Frequency	Yes
Pn163 (2163 hex)	Anti-Resonance Damping Gain	Yes

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

8.9.1 Outline

# 8.9

# **Anti-Resonance Control Adjustment**

This section describes anti-resonance control.

## 8.9.1 Outline

Anti-resonance control increases the effectiveness of vibration suppression after custom tuning.

Anti-resonance control is effective for suppression of continuous vibration frequencies from 100 to 1,000 Hz that occur when the control gain is increased. Vibration can be eliminated by setting vibration frequencies through automatic detection or by manually setting them to adjust the damping gain. Input an operation reference and execute this anti-resonance control adjustment when there is vibration.

Anti-resonance control is automatically set by autotuning without a host reference or autotuning with a host reference. Use anti-resonance control adjustment only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration.

Perform custom tuning if required to increase the response after performing anti-resonance control adjustment. If the control gain is increased, e.g., when custom tuning is performed, vibration may occur again. If that occurs, perform anti-resonance control adjustment again to fine-tune the parameters.

# **A** CAUTION

- Related parameters will be set automatically when anti-resonance control adjustment is executed. This may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time.
- Before you execute anti-resonance control adjustment, set the correct moment of inertia ratio (Pn103). If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may occur.



- Anti-resonance control adjustment detects vibration frequencies between 100 Hz and 1,000 Hz. If the vibration frequency is not within this range, use custom tuning with tuning mode 2 selected to automatically set a notch filter or use vibration suppression.
- Vibration reduction can be made more effective by increasing the anti-resonance damping gain (Pn163), but the vibration may become larger if the damping gain is too high. Increase the damping gain by approximately 0% to 200% in 10% increments while checking the effect on vibration. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the control gain by using a different method, such as custom tuning.

## 8.9.2 Preparations

Check the following settings before you execute anti-resonance control adjustment.

- The tuning-less function must be disabled (Pn170 = n. □□□0).
- The test without a motor function must be disabled (Pn00C =  $n.\square\square\square\square$ 0).
- The control method must not be set to torque control.
- The parameters must not be write prohibited.

## 8.9.3 Applicable Tools

The following table lists the tools that you can use to perform anti-resonance control adjustment and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn204	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	8.9.4 Operating Procedure on page 8-51

# 8.9.4 Operating Procedure

To execute anti-resonance control adjustment, an operation reference is input, and the adjustment is executed while vibration is occurring.

The following methods can be used to execute anti-resonance control adjustment.

- To automatically detect the vibration frequency
- · To manually set the vibration frequency

Use the following procedure.

# ♠ CAUTION

- Before you execute anti-resonance control adjustment, check the information provided in the SigmaWin+ operating manual.
   Observe the following precautions.
  - Make sure that you can perform an emergency stop at any time.
     Parameters will be set automatically when anti-resonance control adjustment is executed. This may greatly affect the response before and after execution. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time.
  - Set the moment of inertia correctly before you execute anti-resonance control adjustment. If the setting greatly differs from the actual moment of inertia, effective vibration reduction may not be possible.
  - If you have already performed anti-resonance control adjustment and then you change the frequency, the current anti-resonance control effect may be lost. Caution is particularly required when automatically detecting the vibration frequency.
  - If effective vibration reduction is not achieved even after you execute anti-resonance control adjustment, cancel the function and lower the control gain by using a different method, such as custom tuning.
  - Perform custom tuning separately if required to increase the response after performing anti-resonance control adjustment.
  - If the servo gain is increased, e.g., when custom tuning is performed, vibration may occur again. If that occurs, perform anti-resonance control adjustment again to fine-tune the parameters.
- 1. Perform steps 1 to 7 of the procedure for custom tuning. Refer to the following section for details.

8.8.4 Operating Procedure on page 8-42

#### 8.9.4 Operating Procedure

2. Click the Anti-res Ctrl Adj Button.


The rest of the procedure depends on whether you know the vibration frequency.




**3.** If you do not know the vibration frequency, click the **Auto Detect** Button. If you know the vibration frequency, click the **Manual Set** Button.

To Automatically Detect the Vibration Frequency

The frequency will be set.



To Manually Set the Vibration Frequency



- 4. Click the Start adjustment Button.
- 5. Use the ▲ and ▼ Buttons in the Adjustment Area to change the settings.


  Click the Reset Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.

To Automatically Detect the Vibration Frequency

Change the setting of the damping gain.

To Manually Set the Vibration Frequency Change the settings of the frequency and damping gain.





#### 6. When the adjustment has been completed, click the Finish Button.

The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.



This concludes the procedure to set up anti-resonance control.

## 8.9.5 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute anti-resonance control adjustment.

Do not change the settings while anti-resonance control adjustment is being executed.

Parameter	Name	Automatic Changes
Pn160 (2160 hex)	Anti-Resonance Control-Related Selections	Yes
Pn161 (2161 hex)	Anti-Resonance Frequency	Yes
Pn162 (2162 hex)	Anti-Resonance Gain Correction	No
Pn163 (2163 hex)	Anti-Resonance Damping Gain	Yes
Pn164 (2164 hex)	Anti-Resonance Filter Time Constant 1 Correction	No
Pn165 (2165 hex)	Anti-Resonance Filter Time Constant 2 Correction	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

# 8.9.6 Suppressing Different Vibration Frequencies with Anti-resonance Control

When you use anti-resonance control and increase the control gain, for some mechanism, vibration can occur at a higher frequency than the frequency for which vibration was suppressed. If this occurs, you can suppress vibration for more than one frequency by adjusting Pn166 (Anti-Resonance Damping Gain 2).

#### Information

#### Guidelines for Vibration That Can Be Suppressed

Anti-resonance frequency (Pn161): fa [Hz], Another vibration frequency that occurs when the control gain is increased: fb [Hz]

- Vibration frequencies: 100 Hz to 1,000 Hz
- Range of different vibration frequencies: 1 < (fb/fa) ≤ 3 to 4

## **Required Parameter Settings**

The following parameter settings are required to use anti-resonance control for more than one vibration frequency.

Parameter		Description			When Enabled		Classifi- cation
Pn160 (2160	n.□□□0 (default setting)	Do not use anti-resonance control.		After restart		Setup	
hex)	n.001	Use anti-resonance control.					
Pn161	Anti-Resonance Fr	equency		Speed	Positio	n	Torque
(2161	Setting Range	Setting Unit	Default Setting	When Ena	abled	Clas	ssification
hex)	10 to 20,000	0.1 Hz	1000	Immedia	itely		Tuning
Pn162	Anti-Resonance G	ain Correction		Speed	Positio	n	Torque
(2162	Setting Range	Setting Unit	Default Setting	When Ena	abled	Clas	ssification
hex)	1 to 1,000	1%	100	Immedia	itely		Tuning
Pn163	Anti-Resonance Damping Gain			Speed	Positio	n	Torque
(2163	Setting Range	Setting Unit	Default Setting	When Ena	abled	Cla	ssification
hex)	0 to 300	1%	0	Immedia	itely	,	Tuning
Pn164	Anti-Resonance Fi	nce Filter Time Constant 1 Correction		Speed	Positio	n	Torque
(2164	Setting Range	Setting Unit	Default Setting	When Ena	abled	Cla	ssification
hex)	-1,000 to 1,000	0.01 ms	0	Immedia	itely	,	Tuning
Pn165	Anti-Resonance Fi	Iter Time Constant 2 C	orrection	Speed	Positio	n	Torque
(2165	Setting Range	Setting Unit	Default Setting	When Ena	abled	Clas	ssification
hex)	-1,000 to 1,000	0.01 ms	0	Immedia	itely		Tuning
Pn166	Anti-Resonance Da	amping Gain 2		Speed	Positio	n	Torque
(2166	Setting Range	Setting Unit	Default Setting	When Ena	abled	Clas	ssification
hex)	0 to 1,000	1%	0	Immedia	itely		Tuning

# Adjustment Procedure for Suppressing Different Vibration Frequencies with Anti-resonance Control

Use the following procedure to make adjustments to suppress different vibration frequencies with anti-resonance control.

Step	Operation
1	Use the gain adjustment and anti-resonance control. Refer to the following section for details.  8.9.4 Operating Procedure on page 8-51
2	If there is vibration at a higher frequency than the vibration suppressed with anti-resonance control in step 1, adjust Pn166 (Anti-Resonance Damping Gain 2).
3	Adjust Pn166 (Anti-Resonance Damping Gain 2) while checking to see if vibration reduction is effective.  To adjust Pn166 (Anti-Resonance Damping Gain 2), increase the setting by 10% at a time starting from the value that resulted in Pn163 (Anti-Resonance Damping Gain) from the adjustment in step 1.
4	If the vibration disappears, the adjustment is completed.  However, if the vibration does not disappear even when you adjust Pn166 (Anti-Resonance Damping Gain 2), reduce the tuning level or feedback level until vibration does not occur.

## ۶

# 8.10 Vibration Suppression

This section describes vibration suppression.

## 8.10.1 Outline

You can use vibration suppression to suppress transient vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning. This is effective for vibration frequencies for which notch filters and anti-resonance control adjustment are not effective.

Vibration suppression is automatically set by autotuning without a host reference or autotuning with a host reference. Use vibration suppression only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration. To execute vibration suppression, input an operation reference and execute the function when there is vibration.

Perform custom tuning if required to increase the response after performing vibration suppression.

# **⚠** CAUTION

- Related parameters will be set automatically when vibration suppression is executed. This
  may greatly affect the response before and after execution. Make sure that you can perform
  an emergency stop at any time.
- Before you execute vibration suppression, set the correct moment of inertia ratio (Pn103) with autotuning without a host reference or another method. If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may occur.



- Vibration suppression detects vibration frequencies between 1 Hz and 100 Hz.
- Frequency detection will not be performed if there is no vibration in the position deviation or if the vibration frequency is outside the range of detectable frequencies. If that is a problem, use a device such as a displacement meter or vibration sensor to measure the vibration frequency.
- If an automatically detected vibration frequency is not suppressed, the actual frequency and the detected frequency may be different. Fine-tune the detected frequency if necessary.

## **Items That Influence Performance**

If continuous vibration occurs while the Servomotor is stopping, vibration suppression cannot be used to suppress the vibration effectively. In this case, use anti-resonance control adjustment or custom tuning.

## **Detection of Vibration Frequencies**

Frequency detection may not be possible if vibration does not appear in the position deviation or the vibration that results from the position deviation is too small. You can adjust the detection sensitivity by changing the setting of the residual vibration detection width (Pn560), which is set as a percentage of the positioning completed width (Pn522). Perform the detection of vibration frequencies again after adjusting the setting of Pn560.

Pn560	Residual Vibration Detection Width			Position		
(2560	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	1 to 3,000	0.1%	400	Immediately	Setup	

Note: As a guideline, change the setting 10% at a time. If the setting of this parameter is lowered, the detection sensitivity will be increased. Vibration may not be detected accurately if the setting is too small.



The vibration frequencies that are automatically detected may vary somewhat with each positioning operation. Perform positioning several times and make adjustments while checking the effect of vibration suppression.

## 8.10.2 Preparations

Check the following settings before you execute vibration suppression.

- · Position control must be used.
- The tuning-less function must be disabled (Pn170 = n. □□□0).
- The test without a motor function must be disabled (Pn00C = n.□□□0).
- The parameters must not be write prohibited.

# 8.10.3 Applicable Tools


The following table lists the tools that you can use to perform vibration suppression and the applicable tool functions.

Tool	Function	Operating Procedure Reference
Digital Operator	Fn205	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	8.10.4 Operating Procedure on page 8-56

# 8.10.4 Operating Procedure

Use the following procedure to perform vibration suppression.


- **1.** Perform steps 1 to 7 of the procedure for custom tuning. Refer to the following section for details.
  - 8.8.4 Operating Procedure on page 8-42
- 2. Click the Vib Suppress Button.



3. Click the Import Button or click ▲ and ▼ Button to manually adjust the set frequency. When you click the Import Button, the residual vibration frequency in the motor is read as the set frequency. (The frequency can be read only when the residual vibration frequency is between 1.0 and 100.0.)




Frequency detection will not be performed if there is no vibration or if the vibration frequency is outside the range of detectable frequencies. If a vibration frequency is not detected, provide a means of measuring the vibration frequency.




4. Click the Set Button.



No settings related to vibration suppression are changed during operation. If the Servomotor does not stop within approximately 10 seconds after changing the setting, an update timeout will occur. The setting will be automatically returned to the previous value.



If the vibration is not eliminated, use the  $\triangle$  and  $\blacktriangledown$  Buttons for the set frequency to fine-tune the value and click the **Set** Button again.



Click the **Reset** Button during adjustment to restore the setting to its original value. The status from before when adjustment was started will be restored.

#### 8.10.5 Setting Combined Functions

5. When the vibration has been eliminated, click the Finish Button. The updated value will be saved in the SERVOPACK.



Vibration suppression will be enabled in step 5. The motor response, however, will change when the Servomotor comes to a stop with no reference input.

This concludes the procedure to set up vibration suppression.

## 8.10.5 Setting Combined Functions

You can also use the feedforward function when you execute vibration suppression.

In the default settings, feedforward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) are disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1 \(\sigma\sup \square\$\) (Use model following control and speed/torque feedforward together).

Parameter		Function	When Enabled	Classification
Pn140	n.0□□□ (default setting)	Do not use model following control and speed/torque feedforward together.	Immediately	Tuning
(2140 hex)	n.1000	Use model following control and speed/torque feedforward together.	iriiriediately	ruriirig



When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (TFF) if required. An unsuitable feedforward input may result in overshooting.

## 8.10.6 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute vibration suppression.

Do not change the settings while vibration suppression is being executed.

Parameter	Name	Automatic Changes
Pn140 (2140 hex)	Model Following Control-Related Selections	Yes
Pn141 (2141 hex)	Model Following Control Gain	Yes
Pn142 (2142 hex)	Model Following Control Correction	No
Pn143 (2143 hex)	Model Following Control Bias in the Forward Direction	No
Pn144 (2144 hex)	Model Following Control Bias in the Reverse Direction	No
Pn145 (2145 hex)	Vibration Suppression 1 Frequency A	Yes
Pn146 (2146 hex)	Vibration Suppression 1 Frequency B	Yes
Pn147 (2147 hex)	Model Following Control Speed Feedforward Compensation	No
Pn14A (214A hex)	Vibration Suppression 2 Frequency	No
Pn14B (214B hex)	Vibration Suppression 2 Correction	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

# **Speed Ripple Compensation**

This section describes speed ripple compensation.

## 8.11.1 Outline

Speed ripple compensation reduces the amount of ripple in the motor speed due to torque ripple or cogging torque. You can enable speed ripple compensation to achieve smoother operation. To enable it, you must set up ripple compensation on the SigmaWin+.

# WARNING

• Speed ripple compensation requires operating the motor and therefore presents hazards. Observe the following precaution.

Confirm safety around moving parts.

This function involves automatic operation. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time.



Execute speed ripple compensation only after adjusting the gains.

- Reset speed ripple compensation after you replace the Servomotor or SERVOPACK.
- Execute speed ripple compensation after jogging to a position that ensures a suitable range of motion.

# 8.11.2 Setting Up Speed Ripple Compensation

#### Restrictions

The following restrictions apply to the setup for speed ripple compensation.

◆ Systems for Which Execution Cannot Be Performed

There are no restrictions.

Systems for Which Adjustments Cannot Be Made Accurately

Systems for which there is not a suitable range of motion

### ◆ Preparations

Check the following items before you set up speed ripple compensation.

- The main circuit power supply must be ON.
- The servo must be OFF.
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.

8.11.2 Setting Up Speed Ripple Compensation

## **Applicable Tools**


The following table lists the tools that you can use to set up speed ripple compensation and the applicable tool functions.

Tool	Function	Reference	
Digital Operator	You cannot set up speed ripple compensation from the Digital Operator.		
SigmaWin+ Solutions - Ripple Compensation		© Operating Procedure on page 8-60	

## **Operating Procedure**


Use the following procedure to set up speed ripple compensation.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Ripple Compensation in the Menu Dialog Box. The Ripple Compensation Dialog Box will be displayed.
- 3. Click the OK Button.




Information

- 1. Click the **Cancel** Button to cancel ripple compensation. The Main Window will return.
- 2. If write protection is set, the following dialog box will be displayed.




Click the  ${\bf OK}$  Button to cancel write prohibition.


4. Click the Edit Button.



5. Enter the jogging speed in the Input Value Box and click the OK Button.



6. Click the Servo ON Button.




#### 8.11.2 Setting Up Speed Ripple Compensation


#### 7. Click the Forward Button or the Reverse Button.

Measurement operation is started.

The motor will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button and the speed ripple will be measured.

The feedback speed and torque reference graph will be displayed in the Ripple Compensation Dialog Box during jogging.





- **8.** After speed ripple measurement has been completed, click the Write Button. The ripple compensation value will be written to the SERVOPACK.
- 9. After writing has been completed, click the OK Button.




#### 10. Click the Forward Button or the Reverse Button.

Verification operation is started.

The motor will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button.

The waveform with speed ripple compensation applied to it will be displayed.



#### **11.** If the verification results are OK, click the **Finish** Button.

**Information** To discard the setup results, click the **Reset** Button.

This concludes the setup for speed ripple compensation.

# 8.11.3 Setting Parameters

The function is enabled when you perform the operating procedure on *Operating Procedure* on page 8-60. To cancel speed ripple compensation, use  $Pn423 = n.\square\square\square\square$ 0 (Disable speed ripple compensation) to disable it.

Parameter		Description		Classifi- cation
Pn423 (2423	n.□□□0 (default setting)	Disable speed ripple compensation.	After restart	Setup
hex)	n.□□□1	Enable speed ripple compensation.	ายรเสาเ	

If you enable speed ripple compensation, a compensation reference will be applied to reduce ripple even when stopped at a 0 speed reference. In speed control mode, this may result in the motor moving slightly. To prevent this, set Pn423 = n.  $\square X \square \square$  (Speed Ripple Compensation Selections) and Pn427 or Pn49F (Speed Ripple Compensation Enable Speed).

Parameter		Description	When Enabled	Classifi- cation
Pn423 (2423	n.□0□□ (default setting)	Speed reference	After restart	Setup
hex)	n.🗆1 🗆 🗆	Motor Speed	restart	


• For Rotary Servomotors

Pn427	Speed Ripple Compensation Enable Speed			Speed Position	n Torque
(2427	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 min <sup>-1</sup>	0	Immediately	Tuning

• For Linear Servomotors

Pn49F	Speed Ripple Compensation Enable Speed			Speed Position	Torque
(249F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 mm/s	0	Immediately	Tuning

#### 8.11.3 Setting Parameters



## **Speed Ripple Compensation Warnings**

The speed ripple compensation value is specific to each Servomotor. If you replace the Servomotor while speed ripple compensation is enabled, an A.942 warning (Speed Ripple Compensation Information Disagreement) will occur to warn you.

You can use any of the following methods to clear A.942.

- Reset the speed ripple compensation value on the SigmaWin+.
- Disable speed ripple compensation (Pn423 = n.□□□0).
- Disable detection of A.942 (Pn423 = n.□□1□).

Parameter		Description	When Enabled	Classifi- cation
Pn423 (2423	n.□□0□ (default setting)	Detect A.942 alarms.	After restart	Setup
hex)	n.0010	Do not detect A.942 alarms.	ายอเสก	

# 8.12 Additional Adjustment Functions

This section describes the functions that you can use to make adjustments after you perform autotuning without a host reference, autotuning with a host reference, and custom tuning.

Function	Applicable Control Methods	Reference
Gain Switching	Position control, speed control, or torque control*	page 8-65
Friction Compensation	Position control or speed control	page 8-68
Current Control Mode Selection	Position control, speed control, or torque control	page 8-69
Current Gain Level Setting	Position control or speed control	page 8-70
Speed Detection Method Selection	Position control, speed control, or torque control	page 8-70
Backlash Compensation	Position Control	page 8-71

<sup>\*</sup> Automatic gain switching is enabled only for position control.

# 8.12.1 Gain Switching

You can use gain switching to shorten the positioning time by increasing the gains during positioning and suppressing vibration by decreasing the gains while stopping.

Parameter		Function	When Enabled	Classification
Pn139 (2139	n.□□□0 (default setting)	Disable automatic gain switching.	Immediately	Tuning
hex)	n.□□□2	Enable automatic gain switching.		

Note: Pn139 = n. □□□1 is a reserved setting. Do not use this setting.

Refer to the following section for gain switching combinations.

Gain Switching Combinations on page 8-65

## **Gain Switching Combinations**

Selected Gains	Speed Loop Gain	Speed Loop Integral Time Constant	Position Loop Gain	Torque Reference Filter	Friction Compensation Gain
Gain Settings 1	Speed Loop Gain (Pn100)	Speed Loop Integral Time Constant (Pn101)	Position Loop Gain (Pn102)	First Stage First Torque Reference Filter Time Con- stant (Pn401)	Friction Compensation Gain (Pn121)
Gain Settings 2	Second Speed Loop Gain (Pn104)	Second Speed Loop Integral Time Constant (Pn105)	Second Position Loop Gain (Pn106)	First Stage Second Torque Reference Filter Time Con- stant (Pn412)	Second Friction Compensation Gain (Pn122)

Note: Automatic gain switching is not supported for Model Following Control Gain and Model Following Control Correction.

## **Automatic Gain Switching**

Automatic gain switching is enabled only for position control. The switching conditions are specified by using the following settings.


Parameter		Switching Condition	Selected Gains	Switching Waiting Time	Switching Time
Pn139	n.□□□2	Condition A satisfied	Gain settings 1 to gain settings 2	Gain Switching Waiting Time 1 Pn135	Gain Switching Time 1 Pn131
(2139 hex)		Condition A not satisfied	Gain settings 2 to gain settings 1	Gain Switching Waiting Time 2 Pn136	Gain Switching Time 2 Pn132

#### 8.12.1 Gain Switching

Select one of the following settings for switching condition A.


Parameter		Position Control Gain Switching Condition A	For Control Methods Other Than Position Control (No Switching)	When Enabled	Classification
Pn139 (2139 hex)	n.□□0□ (default setting)	/COIN (Positioning Completion) signal ON	Gain settings 1 used.	Immediately	Tuning
	n.0010	/COIN (Positioning Completion) signal OFF	Gain settings 2 used.		
	n.□□2□	/NEAR (Near) signal ON	Gain settings 1 used.		
	n.□□3□	/NEAR (Near) signal OFF	Gain settings 2 used.		
	n.□□4□	Position reference filter output is 0 and position reference input is OFF.	Gain settings 1 used.		
	n.□□5□	Position reference input is ON.	Gain settings 2 used.		

Automatic Switching Pattern 1 (Pn139 = n.□□□2)



#### Relationship between the Waiting Times and Switching Times for Gain Switching

In this example, an ON /COIN (Positioning Completion) signal is set as condition A for automatic gain switching. The position loop gain is changed from the value in Pn102 (Position Loop Gain) to the value in Pn106 (Second Position Loop Gain). When the /COIN signal turns ON, the switching operation begins after the waiting time (Pn135). The switching operation changes the position loop gain linearly from the gain set in Pn102 to the gain set in Pn106 over the switching time (Pn131).



## **Related Parameters**

Pn100	Speed Loop Gain			Speed Posit	ion	
(2100	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	10 to 20,000	0.1 Hz	400	Immediately	Tuning	
Pn101	Speed Loop Integra	l Time Constant		Speed Posit	ion	
(2101	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	15 to 51,200	0.01 ms	2,000	Immediately	Tuning	
Pn102	Position Loop Gain			Posit	ion	
(2102	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	10 to 20,000	0.1/s	400	Immediately	Tuning	
Pn401	First Stage First Tor	que Reference Filter	Time Constant	Speed Posit	ion Torque	
(2401	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 65,535	0.01 ms	100	Immediately	Tuning	
Pn121	Friction Compensation Gain Speed Position					
(2121	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	10 to 1,000	1%	100	Immediately	Tuning	
Pn104	Second Speed Loop Gain			Speed Posit	ion	
(2104	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	10 to 20,000	0.1 Hz	400	Immediately	Tuning	
Pn105	Second Speed Loop	Integral Time Cons	tant	Speed Posit	ion	
(2105	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	15 to 51,200	0.01 ms	2,000	Immediately	Tuning	
Pn106	Second Position Lo	op Gain		Position		
(2106	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	10 to 20,000	0.1/s	400	Immediately	Tuning	
Pn412		Torque Reference Fil		Speed Posit		
(2412	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 65,535	0.01 ms	100	Immediately	Tuning	
Pn122	Second Friction Cor	npensation Gain		Speed Posit		
(2122	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	10 to 1,000	1%	100	Immediately	Tuning	

## Parameters Related to Automatic Gain Switching

				•		
Pn131	Gain Switching Time	e 1		Posit	ion	
(2131	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 65,535	1 ms	0	Immediately	Tuning	
Pn132	Gain Switching Time	e 2		Posit	ion	
(2132	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 65,535	1 ms	0	Immediately	Tuning	
Pn135	Gain Switching Wait	ting Time 1	Position			
(2135	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 65,535	1 ms	0	Immediately	Tuning	
Pn136 (2136 hex)	Gain Switching Wait	ting Time 2		Position		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 65,535	1 ms	0	Immediately	Tuning	

8.12.2 Friction Compensation

## **Related Monitoring**

• SigmaWin+

You can monitor gain switching with the status monitor or with tracing.

· Analog Monitors

Parameter	Analog Monitor	Monitor Name	Output Value	Description
Pn006 (2006 hex) Pn007 (2007 hex)	ь ППОВ	Active Gain Monitor	1 V	Gain settings 1 are enabled.
Pn007 (2007 hex)	11.00	Active Gain Monitor	2 V	Gain settings 2 are enabled.

## 8.12.2 Friction Compensation

Friction compensation is used to compensate for viscous friction fluctuations and regular load fluctuations.

You can automatically adjust friction compensation with autotuning without a host reference, autotuning with a host reference, or custom tuning, or you can manually adjust it with the following procedure.

## **Required Parameter Settings**

The following parameter settings are required to use friction compensation.

Parameter		Function		When Enabled	Classification		
Pn408 (2408	n.0□□□ (default setting)	Disable friction comper	Disable friction compensation.		Setup		
hex)	n.1□□□	Enable friction compen	sation.				
Pn121	Friction Compen	sation Gain		Speed Posit	tion		
(2121	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
hex)	10 to 1,000	1%	100	Immediately	Tuning		
Pn122	Second Friction Compensation Gain		Speed Posit	Speed Position			
(2122	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
hex)	10 to 1,000	1%	100	Immediately	Tuning		
Pn123	Friction Compensation Coefficient			Speed Posit	Speed Position		
(2123	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
hex)	0 to 100	1%	0	Immediately	Tuning		
Pn124	Friction Compen	sation Frequency Corre	ction	Speed Posit	Speed Position		
(2124	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
hex)	-10,000 to 10,00	0 0.1 Hz	0	Immediately	Tuning		
Pn125	Friction Compen	sation Gain Correction		Speed Posit	Speed Position		
(2125	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
hex)	1 to 1,000	1%	100	Immediately	Tuning		

## **Operating Procedure for Friction Compensation**

Use the following procedure to perform friction compensation.

## **A** CAUTION

Before you execute friction compensation, set the moment of inertia ratio (Pn103) as accurately as possible. If the setting greatly differs from the actual moment of inertia, vibration may occur.

Step	Operation				
1	Set the following parameters related to friction compensation to their default settings.  Friction compensation gain (Pn121): 100 Second friction compensation gain (Pn122): 100 Friction compensation coefficient (Pn123): 0 Friction compensation frequency correction (Pn124): 0 Friction compensation gain correction (Pn125): 100 Note: Always use the default settings for the friction compensation frequency correction (Pn124) and friction compensation gain correction (Pn125).				
2	Gradually increase the friction compensation coefficient (Pn123) to check the effect of friction compensation.  Note:  Usually, set the friction compensation coefficient (Pn123) to 95% or less.  If the effect is insufficient, increase the friction compensation gain (Pn121) by 10% increments until vibration stops.  Effect of Adjusted Parameters  Pn121: Friction Compensation Gain and Pn122: Second Friction Compensation Gain  These parameters set the response to external disturbances. The higher the setting is, the better the response will be. If the machine has a resonance frequency, however, vibration may occur if the setting is too high.  Pn123: Friction Compensation Coefficient  This parameter sets the effect of friction compensation. The higher the setting is, the more effective friction compensation will be. If the setting is too high, however, vibration will occur more easily. Usually, set the value to 95% or less.				
3	Effect of Adjustments The following graphs show the response with and without adjustment.  Poor response because of friction Low friction Position deviation Position reference speed  Before Friction Compensation  After Friction Compensation				

## 8.12.3 Current Control Mode Selection

Current control mode selection reduces high-frequency noise while the Servomotor is being stopped.

Parameter		Meaning	When Enabled	Classification
D 000	n. □□0□	Use current control mode 1.		
(2009	n. □□1□ (default setting)	Use current control mode 2 (low noise).	After restart	Tuning
	n. □□2□	Reserved settings (Do not use.)		



If current control mode 2 is selected, the load ratio may increase while the Servomotor is being stopped.

## 8.12.4 Current Gain Level Setting

You can set the current gain level to reduce noise by adjusting the parameter for current control inside the SERVOPACK according to the speed loop gain (Pn100). The noise level can be reduced by decreasing the current gain level (Pn13D) from its default setting of 2,000% (disabled). However, if the setting is decreased, the level of noise will be lowered, but the response characteristic of the SERVOPACK will also be reduced. Adjust the current gain level within the range that maintains the SERVOPACK response characteristic.

Pn13D	Current Gain Level		Speed Position		
(213D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	100 to 2,000	1%	2,000	Immediately	Tuning



If the current gain level is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

## 8.12.5 Speed Detection Method Selection

You can use the speed detection method selection to ensure smooth Servomotor speed changes during operation. To ensure smooth motor speed changes during operation, set Pn009 to  $n.\Box 1\Box\Box$  (Use speed detection 2).

With a Linear Servomotor, you can reduce the noise level of the running motor when the linear encoder scale pitch is large.

Parameter		Meaning	When Enabled	Classification
Pn009 (2009	n. □0□□ (default setting)	Use speed detection 1.	After restart	Tuning
hex)	n. 🗆 1 🗆 🗆	Use speed detection 2.		



If the speed detection method is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

## 8.12.6 Speed Feedback Filter

You can set a first order lag filter for the speed feedback in the speed loop. This ensures smooth changes in the feedback speed to reduce vibration. If a large value is set, it will increase the delay and make response slower.


Pn308	Speed Feedback Filter Time Constant			Speed Position	
(2308	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 65,535 (0.00 ms to 655.35 ms)	0.01 ms	0 (0.00 ms)	Immediately	Setup

## 8.12.7 Backlash Compensation

### **Outline**

If you drive a machine that has backlash, there will be deviation between the travel distance in the position reference that is managed by the host controller and the travel distance of the actual machine. Use backlash compensation to add the backlash compensation value to the position reference and use the result to drive the Servomotor. This will ensure that the travel distance of the actual machine will be the same as the travel distance in the host controller.

- Note: 1. Backlash compensation can be used only with a Rotary Servomotor.
  - 2. Backlash compensation can be used only for position control.



### **Related Parameters**

Set the following parameters to use backlash compensation.

### Backlash Compensation Direction

Set the direction in which to apply backlash compensation.

Parameter		Meaning	When Enabled	Classification
	n. □□□0 (default setting)	Compensate forward references.	After restart	Setup
hex)	n. 🗆 🗆 🗆 1	Compensate reverse references.		

## ◆ Backlash Compensation Value

Set the amount of backlash compensation to add to the position reference.

The amount is set in increments of 0.1 reference unit. However, when the amount is converted to encoder pulses, it is rounded off at the decimal point.

Example

When Pn231 = 6553.6 [reference units] and position reference unit (Numerator/Denominator) = 1/1:

 $6,553.6 \times 1 = 6,553.6$  [pulses]

⇒ The backlash compensation will be 6,553 encoder pulses.

Pn231 (2231 hex)	Backlash Compensation			Position		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	-500,000 to 500,000	0.1 reference units	0	Immediately	Setup	

#### 8.12.7 Backlash Compensation



 The backlash compensation value is restricted by the following formula. Backlash compensation is not performed if this condition is not met.

$$Pn231 \leq \frac{Denominator}{Numerator} \times \frac{Pn210}{Pn20E} \times \frac{Maximum\ motor\ speed\ [min^{-1}]}{60} \times Encoder\ resolution* \times 0.00025$$

\*Refer to the following section for the encoder resolution.

5.14 Setting Unit Systems on page 5-42

With fully-closed loop control, substitute the number of external encoder pulses per motor rotation for the encoder resolution in the above formula.

#### Example 1:

Denominator = 1, Numerator = 1, Maximum motor speed = 6,000 [min<sup>-1</sup>], and Encoder resolution = 16,777,216 (24 bits)

 $1/1 \times 1/16 \times 6,000/60 \times 16,777,216 \times 0.00025 = 26,214.4$  [reference units]  $\Rightarrow$  The backlash compensation will be limited to 26,214.4 reference units.

#### Example 2:

Denominator = 1, Numerator = 1, Maximum motor speed = 6,000 [min<sup>-1</sup>], number of external encoder pitches (Pn20A) = 500, and Use of the JZDP-H00 $\square$ -000 (signal resolution: 1/256):  $1/4 \times 6,000/60 \times (500 \times 256) \times 0.00025 = 800.0$  [reference units]  $\Rightarrow$  The backlash compensation will be limited to 800.0 reference units.

• Do not exceed the upper limit of the backlash compensation value. You can check the upper limit on the operation monitor of the SigmaWin+.

### Backlash Compensation Time Constant

You can set a time constant for a first order lag filter for the backlash compensation value (Pn231) that is added to the position reference.

If you set Pn233 (Backlash Compensation Time Constant) to 0, the first order lag filter is disabled.

Pn233	Backlash Compensation Time Constant			Position	
(2233	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 65,535	0.01 ms	0	Immediately	Setup

Note: Changes to the settings are applied when there is no reference pulse input and the Servomotor is stopped. The current operation is not affected if the setting is changed during motor operation.

## **Related Monitoring**

You can monitor the following values on the operation monitor of the SigmaWin+.

Displayed Value	Setting Unit
Current Backlash Compensation Value	0.1 reference units
Backlash Compensation Value Setting Limit	0.1 reference units

## **Compensation Operation**

This section describes the operation that is performed for backlash compensation.

Note: The following figures are for when backlash compensation is applied to references in the forward direction (Pn230 = n.□□□0). The following monitor information is provided in the figures: target position (607A hex) (target position in the reference coordinate system), position demand value (6062 hex) (reference position in the reference coordinate system), and position actual value (6064 hex) (feedback position in the machine coordinate system). The monitor information includes the feedback position in machine coordinate system (position actual value) and other feedback information. The backlash compensation value is subtracted from the feedback positions in the monitor information, so it is not necessary for the host controller to consider the backlash compensation value.

## **⚠** CAUTION

The encoder divided pulse output will output the number of encoder pulses for which driving was actually performed, including the backlash compensation value. If you use the encoder output pulses for position feedback at the host controller, you must consider the backlash compensation value.

### ◆ Operation When the Servo Is ON


The backlash compensation value (Pn231) is added in the backlash compensation direction when the servo is ON (i.e., while power is supplied to the motor) and a reference is input in the same direction as the backlash compensation direction (Pn230.0 =  $n.\Box\Box\Box$ X). When there is a reference input in the direction opposite to the backlash compensation direction, the backlash compensation value is not added (i.e., backlash compensation is not performed).

The relationship between *position actual value* (6064 hex) and the motor shaft position is as follows:

- If a reference is input in the compensation direction: Position actual value (6064 hex) = Motor shaft position Pn231
- If a reference is input in the direction opposite to the compensation direction: Position actual value (6064 hex) = Motor shaft position

The following figure shows driving the Servomotor in the forward direction from Target Position 0 (*target position*: 607A hex) to Target Position 1 and then to Target Position 2, and then returning from Target Position 2 to Target Position 1 and then to Target Position 0.

Backlash compensation is applied when moving from Target Position 0 to Target Position 1, but not when moving from Target Position 2 to Target Position 1.



#### 8.12.7 Backlash Compensation


## ◆ Operation When the Servo Is OFF

Backlash compensation is not applied when the servo is OFF (i.e., when power is not supplied to motor). Therefore, the reference position (position demand value (6062 hex)) is moved by only the backlash compensation value.

The relationship between *position actual value* (6064 hex) and the motor shaft position is as follows:

• When servo is OFF: Position actual value (6064 hex) = Servomotor shaft position

The following figure shows what happens when the servo is turned OFF after driving the Servo-motor in the forward direction from target position Target Position 0 to Target Position 1. Backlash compensation is not applied when the servo is OFF. (The SERVOPACK manages the position data so that *position actual value* (6064 hex) and *position demand value* (6062 hex) are the same.)



### Operation When There Is Overtravel

When there is overtravel (i.e., when driving is prohibited due to an overtravel signal or software limit), the operation is the same as for when the servo is OFF ( → Operation When the Servo Is OFF on page 8-74), i.e., backlash compensation is not applied.

## Operation When Control Is Changed

Backlash compensation is performed only for position control.

Backlash compensation is not applied when position control is changed to any other control method

Backlash compensation is applied in the same way as when the servo is ON ( ◆ Operation When the Servo Is ON on page 8-73) if any other control method is changed to position control.

## Related Monitoring

You can monitor the following values on the operation monitor of the SigmaWin+.

Displayed Value	Unit	Specification
Input Reference Pulse Speed	min <sup>-1</sup>	Displays the input reference pulse speed before backlash compensation.
Position Deviation	Reference units	Displays the position deviation for the position reference after backlash compensation.
Input Reference Pulse Counter	Reference units	Displays the input reference pulse counter before backlash compensation.
Feedback Pulse Counter	Encoder pulses	Displays the number of pulses from the actually driven motor encoder.
Fully-Closed Feedback Pulse Counter	External encoder resolution	Displays the number of pulses of the actually driven external encoder.
Feedback Pulse Counter	Reference units	Displays the number of pulses from the actually driven encoder in reference units.

### ◆ Related Monitoring Diagrams

The following symbols are used in the related monitoring diagrams.


[A]: Analog monitor

[E]: EtherCAT monitor Information

[U]: Monitor mode (Un monitor)

[O]: Output signal

[T]: Trace data




#### 8.13.1 Tuning the Servo Gains

# 8.13 Manual Tuning

This section describes manual tuning.

## 8.13.1 Tuning the Servo Gains

### Servo Gains



It: First stage first torque reference filter time constant (Pn401)

In order to manually tune the servo gains, you must understand the configuration and characteristic of the SERVOPACK and adjust the servo gains individually. In most cases, if you greatly change any one parameter, you must adjust the other parameters again. To check the response characteristic, you must prepare a measuring instrument to monitor the output waveforms from the analog monitor.

The SERVOPACK has three feedback systems (the position loop, speed loop, and current loop), and the response characteristic must be increased more with the inner loops. If this relationship is not maintained, the response characteristic will suffer and vibration will occur more easily.

A sufficient response characteristic is ensured for the current loop. There is never a need for it to be adjusted by the user.

### **Outline**

You can use manual tuning to set the servo gains in the SERVOPACK to increase the response characteristic of the SERVOPACK. For example, you can reduce the positioning time for position control.

Use manual tuning in the following cases.

- When tuning with autotuning without a host reference or autotuning with a host reference does not achieve the desired results
- When you want to increase the servo gains higher than the gains that resulted from autotuning without a host reference or autotuning with a host reference
- When you want to determine the servo gains and moment of inertia ratio yourself

You start manual tuning either from the default parameter settings or from the gain settings that resulted from autotuning without a host reference or autotuning with a host reference.

### **Applicable Tools**

You can monitor the servo gains with the SigmaWin+ or with the analog monitor.

### **Precautions**

Vibration may occur while you are tuning the servo gains. We recommend that you enable vibration alarms (Pn310 =  $n.\Box\Box\Box$ 2) to detect vibration. Refer to the following section for information on vibration detection.

6.11 Initializing the Vibration Detection Level on page 6-46

Vibration alarms are not detected for all vibration. Also, an emergency stop method is necessary to stop the machine safely when an alarm occurs. You must provide an emergency stop device and activate it immediately whenever vibration occurs.

# Tuning Procedure Example (for Position Control or Speed Control)

Step	Description
1	Adjust the first stage first torque reference filter time constant (Pn401) so that vibration does not occur.
2	Increase the position loop gain (Pn100) and reduce the speed loop integral time constant (Pn101) as far as possible within the range that does not cause machine vibration.
3	Repeat steps 1 and 2 and return the settings about 10% to 20% from the values that you set.
4	For position control, increase the position loop gain (Pn102) within the range that does not cause vibration.

#### Information

If you greatly change any one servo gain parameter, you must adjust the other parameters again. Do not increase the setting of just one parameter. As a guideline, adjust the settings of the servo gains by approximately 5% each. As a rule, change the servo parameters in the following order.

- To Increase the Response Speed
- 1. Reduce the torque reference filter time constant.
- 2. Increase the speed loop gain.
- 3. Decrease the speed loop integral time constant.
- 4. Increase the position loop gain.
- To Reduce Response Speed and to Stop Vibration and Overshooting
- 1. Reduce the position loop gain.
- 2. Increase the speed loop integral time constant.
- 3. Decrease the speed loop gain.
- 4. Increase the torque filter time constant.

## Adjusted Servo Gains

You can set the following gains to adjust the response characteristic of the SERVOPACK.

- Pn100: Speed Loop Gain
- Pn101: Speed Loop Integral Time Constant
- Pn102: Position Loop Gain
- Pn401: First Stage First Torque Reference Filter Time Constant

## Position Loop Gain

The position loop gain determines the response characteristic of the position loop in the SER-VOPACK. If you can increase the setting of the position loop gain, the response characteristic will improve and the positioning time will be shortened. However, you normally cannot increase the position loop gain higher than the inherit vibration frequency of the machine system. Therefore, to increase the setting of the position loop gain, you must increase the rigidity of the machine to increase the inherit vibration frequency of the machine.

#### 8.13.1 Tuning the Servo Gains

Pn102	Position Loop Gain			Position		
(2102	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	10 to 20,000	0.1/s	400	Immediately	Tuning	

#### Information

For machines for which a high position loop gain (Pn102) cannot be set, overflow alarms can occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following condition as a guideline for determining the setting.

Pn520 
$$\geq \frac{\text{Maximum feed speed [reference units/s]}}{\text{Pn102} \div 10 (1/s)} \times 2.0$$

If you use a position reference filter, transient deviation will increase due to the filter time constant. When you make the setting, consider deviation accumulation that may result from the filter.

Pn520	Position Deviation	Overflow Alarm	Position		
(2520	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup

### Speed Loop Gain

This parameter determines the response characteristic of the speed loop. If the response characteristic of the speed loop is low, it becomes a delay factor for the position loop located outside of the speed loop. This will result in overshooting and vibration in the speed reference. Therefore, setting the speed loop gain as high as possible within the range that will not cause the machine system to vibrate will produce a stable Servo System with a good response characteristic.

D=100	Speed Loop Gain			Speed Positi	on Torque
Pn100 (2100 hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	10 to 20,000	0.1 Hz	400	Immediately	Tuning

Setting of Pn103 = 
$$\frac{\text{Load moment of inertia at motor shaft } (J_L)}{\text{Servomotor moment of inertia } (L_M)} \times 100(\%)$$

The default setting of Pn103 (Moment of Inertia Ratio) is 100. Before you tune the servo, calculate the moment of inertia ratio with the above formula and set Pn103 to the calculation result.

D=100	Moment of Inertia Ratio			Speed Positi	on Torque
Pn103 (2103 hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	0 to 20,000	1%	100	Immediately	Tuning

### ◆ Speed Loop Integral Time Constant


To enable response to even small inputs, the speed loop has an integral element. The integral element becomes a delay factor in the Servo System. If the time constant is set too high, overshooting will occur, positioning settling time will increase, and the response characteristic will suffer.

D=101	Speed Loop Integral Time Constant			Speed Position	
Pn101 (2101 hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	15 to 51,200	0.01 ms	2,000	Immediately	Tuning

### ◆ Torque Reference Filter

As shown in the following diagram, the torque reference filter contains a first order lag filter and notch filters arranged in series, and each filter operates independently.

The notch filters can be enabled and disabled with  $Pn408 = n.\Box X\Box X$  and  $Pn416 = n.\Box XXX$ .



<sup>\*</sup> The second stage second torque reference filter is disabled when Pn40F is set to 5,000 (default setting) and it is enabled when Pn40F is set to a value lower than 5,000.

#### ■ Torque Reference Filter

If you suspect that machine vibration is being caused by the Servo Drive, try adjusting the torque reference filter time constant. This may stop the vibration. The lower the value, the better the control response characteristic will be, but there may be a limit depending on the machine conditions.

Pn401	First Stage First Torque Reference Filter Time Constant			Speed Position Torque		
(2401	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 65,535	0.01 ms	100	Immediately	Tuning	
Pn40F	Second Stage Second Torque Reference Filter Frequency			Speed Position Torque		
(240F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	100 to 5,000	1 Hz	5000*	Immediately	Tuning	
Pn410	Second Stage Seco	nd Torque Reference	Filter Q Value	Speed Positi	ion Torque	
(2410	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	50 to 100	0.01	50	Immediately	Tuning	

<sup>\*</sup> The filter is disabled if you set the parameter to 5,000.

#### ■ Notch Filters

The notch filter can eliminate specific frequency elements generated by the vibration of sources such as resonance of the shaft of a ball screw.

The notch filter puts a notch in the gain curve at the specific vibration frequency (called the notch frequency). The frequency components near the notch frequency can be reduced or removed with a notch filter.


Notch filters are set with three parameters for the notch filter frequency, notch filter Q value, and notch filter depth. This section describes the notch filter Q value and notch filter depth.

#### · Notch filter Q Value

The setting of the notch filter Q value determines the width of the frequencies that are filtered for the notch filter frequency. The width of the notch changes with the notch filter Q value. The larger the notch filter Q value is, the steeper the notch is and the narrower the width of frequencies that are filtered is.

#### 8.13.1 Tuning the Servo Gains

The notch filter frequency characteristics for different notch filter Q values are shown below.




Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics.

#### · Notch Filter Depth

The setting of the notch filter depth determines the depth of the frequencies that are filtered for the notch filter frequency. The depth of the notch changes with the notch filter depth. The smaller the notch filter depth is, the deeper the notch is, increasing the effect of vibration suppression. However, if the value is too small, vibration can actually increase.

The notch filter is disabled if the notch filter depth, d, is set to 1.0 (i.e., if Pn419 is set to 1,000). The notch filter frequency characteristics for different notch filter depths are shown below.



Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics.

You can enable or disable the notch filter with Pn408.

F	Parameter	Meaning	When Enabled	Classification
D:- 400	n.□□□0 (default setting)	Disable first stage notch filter.		
Pn408 (2408	n.□□□1	Enable first stage notch filter.		
hex)	n.□0□□ (default setting)	Disable second stage notch filter.		Setup
	n.🗆1🗆 🗆	Enable second stage notch filter.		
	n.□□□0 (default setting)	Disable third stage notch filter.	Immediately	
	n.□□□1	Enable third stage notch filter.		
Pn416 (2416 hex)	n.□□0□ (default setting)	Disable fourth stage notch filter.		
	n.□□1□	Enable fourth stage notch filter.		
	n.□0□□ (default setting)	Disable fifth stage notch filter.		
	n.🗆1🗆 🗆	Enable fifth stage notch filter.		

Set the machine vibration frequencies in the notch filter parameters.

Pn409	First Stage Notch Fi	Iter Frequency		Speed Posit	ion Torque
(2409	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 5,000	1 Hz	5,000	Immediately	Tuning
Pn40A	First Stage Notch Fi	Iter Q Value		Speed Posit	ion Torque
(240A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 1,000	0.01	70	Immediately	Tuning
Pn40B	First Stage Notch Fi	Iter Depth		Speed Posit	ion Torque
(240B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 1,000	0.001	0	Immediately	Tuning
Pn40C	Second Stage Notc	h Filter Frequency		Speed Posit	ion Torque
(240C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 5,000	1 Hz	5,000	Immediately	Tuning
Pn40D	Second Stage Notc	h Filter Q Value		Speed Posit	ion Torque
(240D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 1,000	0.01	70	Immediately	Tuning
Pn40E	Second Stage Notc	h Filter Depth		Speed Posit	ion Torque
(240E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 1,000	0.001	0	Immediately	Tuning
Pn417	Third Stage Notch F	ilter Frequency		Speed Posit	ion Torque
(2417	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 5,000	1 Hz	5,000	Immediately	Tuning
Pn418	Third Stage Notch F	ilter Q Value		Speed Posit	ion Torque
(2418	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 1,000	0.01	70	Immediately	Tuning
Pn419	Third Stage Notch F	ilter Depth		Speed Posit	ion Torque
(2419	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 1,000	0.001	0	Immediately	Tuning
Pn41A	Fourth Stage Notch	Filter Frequency		Speed Posit	ion Torque
(241A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 5,000	1 Hz	5,000	Immediately	Tuning
Pn41B	Fourth Stage Notch	Filter Q Value		Speed Posit	ion Torque
(241B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 1,000	0.01	70	Immediately	Tuning
Pn41C	Fourth Stage Notch	<u> </u>		Speed Posit	
(241C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 1,000	0.001	0	Immediately	Tuning
Pn41D	Fifth Stage Notch F			Speed Posit	ion Torque
(241D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 5,000	1 Hz	5,000	Immediately	Tuning
Pn41E	Fifth Stage Notch F			Speed Posit	
(241E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	50 to 1,000	0.01	70	Immediately	Tuning
Pn41F	Fifth Stage Notch Fi	•		Speed Posit	
(241F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 1,000	0.001	0	Immediately	Tuning



- Do not set notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) that are close to the speed loop's response frequency. Set a frequency that is at least four times the speed loop gain (Pn100). (However, Pn103 (Moment of Inertia Ratio) must be set to an appropriate value.) If the setting is not correct, vibration may occur and the machine may be damaged.
  Change the notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) only while the
- Change the notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) only while the Servomotor is stopped. Vibration may occur if a notch filter frequency is changed during operation.

8.13.1 Tuning the Servo Gains

## **Guidelines for Manually Tuning Servo Gains**

When you manually adjust the parameters, make sure that you completely understand the information in the product manual and use the following conditional expressions as guidelines. The appropriate values of the parameter settings are influenced by the machine specifications, so they cannot be determined universally. When you adjust the parameters, actually operate the machine and use the SigmaWin+ or analog monitor to monitor operating conditions. Even if the status is stable while the motor is stopped, an unstable condition may occur when an operation reference is input. Therefore, input operation references and adjust the servo gains as you operate the motor.

Stable gain: Settings that provide a good balance between parameters.

However, if the load moment of inertia is large and the machine system contains elements prone to vibration, you must sometimes use a setting that is somewhat higher to prevent the machine from vibrating.

Critical gain: Settings for which the parameters affect each other

Depending on the machine conditions, overshooting and vibration may occur and operation may not be stable. If the critical gain condition expressions are not met, operation will become more unstable, and there is a risk of abnormal motor shaft vibration and round-trip operation with a large amplitude. Always stay within the critical gain conditions.

If you use the torque reference filter, second torque reference filter, and notch filters together, the interference between the filters and the speed loop gain will be superimposed. Allow leeway in the adjustments.



The following adjusted value guidelines require that the setting of Pn103 (Moment of Inertia Ratio) is correctly set for the actual machine.

### ◆ When Pn10B = n.□□0□ (PI Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

- Speed Loop Gain (Pn100 [Hz]) and Position Loop Gain (Pn102 [/s]) Stable gain: Pn102 [/s]  $\leq 2\pi \times \text{Pn100/4}$  [Hz] Critical gain: Pn102 [/s]  $< 2\pi \times \text{Pn100}$  [Hz]
- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms]  $\geq$  4,000/( $2\pi \times$  Pn100 [Hz]) Critical gain: Pn101 [ms] > 1,000/( $2\pi \times$  Pn100 [Hz])
- Speed Loop Gain (Pn100 [Hz]) and First Stage First Torque Reference Filter Time Constant (Pn401 [ms])

Stable gain: Pn401 [ms]  $\leq$  1,000/(2 $\pi$  × Pn100 [Hz] × 4) Critical gain: Pn401 [ms] < 1,000/(2 $\pi$  × Pn100 [Hz] × 1)

8

 Speed Loop Gain (Pn100 [Hz]) and Second Stage Second Torque Reference Filter Frequency (Pn40F [Hz])

Critical gain: Pn40F [Hz]  $> 4 \times$  Pn100 [Hz]

Note: Set the second stage second torque reference filter Q value (Pn410) to 0.70.

Speed Loop Gain (Pn100 [Hz]) and First Stage Notch Filter Frequency (Pn409 [Hz]) (or Second Stage Notch Filter Frequency (Pn40C [Hz]))
 Critical gain: Pn409 [Hz] > 4 x Pn100 [Hz]

• Speed Loop Gain (Pn100 [Hz]) and Speed Feedback Filter Time Constant (Pn308 [ms]) Stable gain: Pn308 [ms]  $\leq$  1,000/(2 $\pi$  × Pn100 [Hz] × 4) Critical gain: Pn308 [ms] < 1,000/(2 $\pi$  × Pn100 [Hz] × 1)

### ♦ When $Pn10B = n.\Box\Box1\Box$ (I-P Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

For I-P control, the relationships between the speed loop integral time constant, speed loop gain, and position loop gain are different from the relationships for PI control. The relationship between other servo gains is the same as for PI control.

- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn100 [Hz] ≥ 320/Pn101 [ms]
- Position Loop Gain (Pn102 [/s]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn102 [/s] ≤ 320/Pn101 [ms]

Information

Selecting the Speed Loop Control Method (PI Control or I-P Control)

Usually, I-P control is effective for high-speed positioning and high-speed, high-precision processing applications. With I-P control, you can use a lower position loop gain than for PI control to reduce the positioning time and reduce arc radius reduction. However, if you can use mode switching to change to proportional control to achieve the desired application, then using PI control would be the normal choice.

### ◆ Decimal Points in Parameter Settings

For the SGD7S SERVOPACKs, decimal places are given for the settings of parameters on the Digital Operator, Panel Operator, and in the manual. For example with Speed Loop Gain (Pn100), Pn100 = 40.0 is used to indicate a setting of 40.0 Hz. In the following adjusted value guidelines, the decimal places are also given.

Example

• Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms]  $\geq$  4,000/( $2\pi \times$  Pn100 [Hz]), therefore If Pn100 = 40.0 [Hz], then Pn101 = 4,000/( $2\pi \times$  40.0)  $\approx$  15.92 [ms].

## Model Following Control


You can use model following control to improve response characteristic and shorten positioning time. You can use model following control only with position control.

Normally, the parameters that are used for model following control are automatically set along with the servo gains by executing autotuning or custom tuning. However, you must adjust them manually in the following cases.

- When the tuning results for autotuning or custom tuning are not acceptable
- When you want to increase the response characteristic higher than that achieved by the tuning results for autotuning or custom tuning
- When you want to determine the servo gains and model following control parameters yourself

#### 8.13.1 Tuning the Servo Gains

The block diagram for model following control is provided below.



### Manual Tuning Procedure

Use the following tuning procedure for using model following control.

Step	Description
1	Friction compensation must also be used. Set the friction compensation parameters. Refer to the following section for the setting procedure.  8.12.2 Friction Compensation on page 8-68
	Adjust the servo gains. Refer to the following section for an example procedure.  Tuning Procedure Example (for Position Control or Speed Control) on page 8-77
2	Note: 1. Set the moment of inertia ratio (Pn103) as accurately as possible.  2. Refer to the guidelines for manually tuning the servo gains and set a stable gain for the position loop gain (Pn102).  Guidelines for Manually Tuning Servo Gains on page 8-82
3	Increase the model following control gain (Pn141) as much as possible within the range in which overshooting and vibration do not occur.
4	If overshooting occurs or if the response is different for forward and reverse operation, fine-tune model following control with the following settings: model following control bias in the forward direction (Pn143), model following control bias in the reverse direction (Pn144), and model following control speed feedforward compensation (Pn147).

#### Related Parameters

Next we will describe the following parameters that are used for model following control.

- Pn140 (Model Following Control-Related Selections)
- Pn141 (Model Following Control Gain)
- Pn143 (Model Following Control Bias in the Forward Direction)
- Pn144 (Model Following Control Bias in the Reverse Direction)
- Pn147 (Model Following Control Speed Feedforward Compensation)

#### ■ Model Following Control-Related Selections

Set  $Pn140 = n.\square\square\squareX$  to specify whether to use model following control.

If you use model following control with vibration suppression, set Pn140 to  $n.\Box\Box1\Box$  or Pn140 =  $n.\Box\Box2\Box$ . When you also perform vibration suppression, adjust vibration suppression with custom tuning in advance.

Note: If you use vibration suppression (Pn140 = n.□□1□ or Pn140 = n.□□2□), always set Pn140 to n.□□□1 (Use model following control).

Р	arameter	Function	When Enabled	Classification
	n.□□□0 (default setting)	Do not use model following control.		Tuning
	n.□□□1	Use model following control.	Immediately	
Pn140 (2140 hex)	n.□□0□ (default setting)	Do not perform vibration suppression.		
	n.□□1□	Perform vibration suppression for a specific frequency.		
	n.□□2□	Perform vibration suppression for two specific frequencies.		

#### ■ Model Following Control Gain

The model following control gain determines the response characteristic of the Servo System. If you increase the setting of the model following control gain, the response characteristic will improve and the positioning time will be shortened. The response characteristic of the Servo System is determined by this parameter, and not by Pn102 (Position Loop Gain).

Pn141	Model Following Co	ontrol Gain	Positi	on	
(2141	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	10 to 20,000	0.1/s	500	Immediately	Tuning

Information

For machines for which a high model following control gain cannot be set, the size of the position deviation in model following control will be determined by the setting of the model following control gain. For a machine with low rigidity, in which a high model following control gain cannot be set, position deviation overflow alarms may occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following conditional expression for reference in determining the setting.

$$Pn 520 \ge \frac{\text{Maximum feed speed [reference units/s]}}{Pn 141/10 [1/s]} \times 2.0$$

Pn520	Position Deviation	Overflow Alarm	Position		
(2520	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
(2520 hex)	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup

#### Model Following Control Bias in the Forward Direction and Model Following Control Bias in the Reverse Direction

If the response is different for forward and reverse operation, use the following parameters for fine-tuning.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

Pn143	Model Following Co	ntrol Bias in the For	Position			
(2143	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 10,000	0.1%	1,000	Immediately	Tuning	
Pn144	Model Following Co	ntrol Bias in the Rev	erse Direction	Position		
(2144	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 10,000	0.1%	1,000	Immediately	Tuning	

#### 8.13.2 Compatible Adjustment Functions

#### ■ Model Following Control Speed Feedforward Compensation

If overshooting occurs even after you adjust the model following control gain, model following control bias in the forward direction, and model following control bias in the reverse direction, you may be able to improve performance by setting the following parameter.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

Pn147	Model Following Co	ontrol Speed Feedfor	Position			
(2147	Setting Range	Setting Unit	Default Setting	Default Setting When Enabled Classifica		
hex)	0 to 10,000	0.1%	1,000	Immediately	Tuning	

#### ■ Model Following Control Type Selection

When you enable model following control, you can select the model following control type. Normally, set Pn14F to n. \$\square\$ (Use model following control type 2) (default setting). If compatibility with previous models is required, set Pn14F to n. \$\square\$ (Use model following control type 1).


Parameter		Meaning	When Enabled	Classification
Pn14F	n.□□□0	Use model following control type 1.		
(214F	n.□□□0	Llee model fellowing control type 0	After restart	Tuning
hex)	(default setting)	Use model following control type 2.		

## 8.13.2 Compatible Adjustment Functions

The compatible adjustment functions are used together with manual tuning. You can use these functions to improve adjustment results. These functions allow you to use the same functions as for  $\Sigma$ -III-Series SERVOPACKs to adjust  $\Sigma$ -7-Series SERVOPACKs.

### **Feedforward**

The feedforward function applies feedforward compensation to position control to shorten the positioning time.




Pn109	Feedforward		Position		
(2109	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 100	1%	0	Immediately	Tuning
Pn10A	Feedforward Filter Time Constant Position				
(210A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 6,400	0.01 ms	0	Immediately	Tuning

Note: If you set the feedforward value too high, the machine may vibrate. As a guideline, use a setting of 80% or

# Mode Switching (Changing between Proportional and Pl Control)

You can use mode switching to automatically change between proportional control and PI control

Overshooting caused by acceleration and deceleration can be suppressed and the settling time can be reduced by setting the switching condition and switching levels.



### ◆ Related Parameters

Select the switching condition for mode switching with  $Pn10B = n.\square\square\square\square X$ .

Parameter		Mode Switching	Parameter That Sets the Level		When	Classification
	-arameter	Selection	Rotary Servomotor	Linear Servomotor	Enabled	Ciassification
	n.□□□0 (default setting)	Use the internal torque reference as the condition.	Pn10C (2	10C hex)	Immediately	
Pn10B (210B hex)	n.□□□1	Use the speed reference as the condition.	Pn10D (210D hex)	Pn181 (2181 hex)		Setup
	n.□□□2	Use the acceleration reference as the condition.	Pn10E (210E hex)	Pn182 (2182 hex)		
	n.□□□3	Use the position deviation as the condition.	Pn10F (210F hex)			
	n.□□□4	Do not use mode switching.	_			

### ■ Parameters That Set the Switching Levels

· Rotary Servomotors

Pn10C	Mode Switching Level for Torque Reference			Speed	Position
(210C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 800	1%	200	Immediately	Tuning
Pn10D	Mode Switching L	evel for Speed Refe	erence	Speed	Position
(210D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 min <sup>-1</sup>	0	Immediately	Tuning
Pn10E	Mode Switching L	evel for Acceleration	Speed Position		
(210E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 30,000	1 min <sup>-1</sup> /s	0	Immediately	Tuning
Pn10F	Mode Switching L	evel for Position De	eviation	F	Position
(210F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 10,000	1 reference unit	0	Immediately	Tuning

#### 8.13.2 Compatible Adjustment Functions


#### Linear Servomotors

Pn10C	Mode Switching L	evel for Force Refe	rence	Speed Position		
(210C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 800	1%	200	Immediately	Tuning	
Pn181	Mode Switching L	evel for Speed Ref	erence	Speed	Position	
(2181	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 10,000	1 mm/s	0	Immediately	Tuning	
Pn182	Mode Switching L	evel for Acceleration	Speed Position			
(2182	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 30,000	1 mm/s <sup>2</sup>	0	Immediately	Tuning	
Pn10F	Mode Switching L	evel for Position De	eviation	Position		
(210F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
hex)	0 to 10,000	1 reference unit	0	Immediately	Tuning	

#### ■ Using the Torque Reference as the Mode Switching Condition (Default Setting)

When the torque reference equals or exceeds the torque set for the mode switching level for torque reference (Pn10C), the speed loop is changed to P control.


The default setting for the torque reference level is 200%.



#### ■ Using the Speed Reference as the Mode Switching Condition


### Rotary Servomotors

When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn10D), the speed loop is changed to P control.



#### Linear Servomotors


When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn181), the speed loop is changed to P control.



#### ■ Using the Acceleration as the Mode Switching Condition


#### Rotary Servomotors

When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn10E), the speed loop is changed to P control.



#### Linear Servomotors


When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn182), the speed loop is changed to P control.



### Using the Position Deviation as the Mode Switching Condition

When the position deviation equals or exceeds the value set for the mode switching level for position deviation (Pn10F), the speed loop is changed to P control.

This setting is enabled only for position control.



## **Position Integral**

The position integral is the integral function of the position loop. This parameter is effective for electronic cams and electronic shafts.

Pn11F	Position Integral Tin	ne Constant	Positi	ion	
(211F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 50,000	0.1 ms	0	Immediately	Tuning


## 8.14

## **Diagnostic Tools**

## 8.14.1 Mechanical Analysis

### Overview

You can connect the SERVOPACK to a computer to measure the frequency characteristics of the machine. This allows you to measure the frequency characteristics of the machine without using a measuring instrument.



The motor is used to cause machine vibration and then the speed frequency characteristics for the motor torque are measured. The measured frequency characteristics can be used to determine the machine resonance.

You determine the machine resonance for use in servo tuning and as reference for considering changes to the machine. The performance of the servo cannot be completely utilized depending on the rigidity of the machine. You may need to consider making changes to the machine. The information can also be used as reference for servo tuning to help you adjust parameters, such as the servo rigidity and torque filter time constant.

You can also use the information to set parameters, such as the notch filters.


## **MARNING**

Mechanical analysis requires operating the motor and therefore presents hazards.
 Before you execute mechanical analysis, check the information provided in the SigmaWin+ operating manual.

## **Frequency Characteristics**

The motor is used to cause the machine to vibrate and the frequency characteristics from the torque to the motor speed are measured to determine the machine characteristics. For a normal machine, the resonance frequencies are clear when the frequency characteristics are plotted on graphs with the gain and phase (bode plots). The bode plots show the size (gain) of the response of the machine to which the torque is applied, and the phase delay (phase) in the response for each frequency. Also, the machine resonance frequency can be determined from the maximum frequency of the valleys (anti-resonance) and peaks (resonance) of the gain and the phase delay.

For a motor without a load or for a rigid mechanism, the gain and phase change gradually in the bode plots.



- ① Toolbar
- ② **START** Button
  Click the **START** Button to start analysis.
- ③ Measurement and Notch Filter Setting Tab Pages Measurement Tab Page: Displays detailed information on the results of analysis. Notch Filter Setting Tab Page: Displays the notch filter frequencies. You can set these values in the parameters.

## 8.14.2 Easy FFT

The machine is made to vibrate and a resonance frequency is detected from the generated vibration to set notch filters according to the detected resonance frequencies. This is used to eliminate high-frequency vibration and noise.

During execution of Easy FFT, a frequency waveform reference is sent from the SERVOPACK to the Servomotor to automatically cause the shaft to rotate multiple times within 1/4th of a rotation, thus causing the machine to vibrate.


Execute Easy FFT after the servo is turned OFF if operation of the SERVOPACK results in high-frequency noise and vibration.

## **⚠ WARNING**

 Never touch the Servomotor or machine during execution of Easy FFT. Doing so may result in injury.

## **A** CAUTION

Use Easy FFT when the servo gain is low, such as in the initial stage of servo tuning. If you
execute Easy FFT after you increase the gain, the machine may vibrate depending on the
machine characteristics or gain balance.



Easy FFT is built into the SERVOPACK for compatibility with previous products. Normally use autotuning without a host reference for tuning.

## **Preparations**

Check the following settings before you execute Easy FFT.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- The test without a motor function must be disabled (Pn00C = n.□□□0).
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- There must be no overtravel.
- An external reference must not be input.

## **Operating Procedure**


Use the following procedure for Easy FFT.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Easy FFT in the Menu Dialog Box.

The Easy FFT Dialog Box will be displayed.


Click the **Cancel** Button to cancel Easy FFT. You will return to the main window.

3. Click the OK Button.



Another Easy FFT Dialog Box will be displayed.

4. Click the Servo ON Button.



### 8.14.2 Easy FFT


**5.** Select the instruction (reference) amplitude and the rotation direction in the **Measurement condition** Area, and then click the **Start** Button.

The motor shaft will rotate and measurements will start.




When measurements have been completed, the measurement results will be displayed.

**6.** Check the results in the **Measurement result** Area and then click the **Measurement complete** Button.



7. Click the Result Writing Button if you want to set the measurement results in the parameters.



This concludes the procedure to set up Easy FFT.

### **Related Parameters**

The following parameters are automatically adjusted or used as reference when you execute Easy FFT.

Do not change the settings of these parameters during execution of Easy FFT.

Parameter	Name	Automatic Changes
Pn408 (2408 hex)	Torque-Related Function Selections	Yes
Pn409 (2409 hex)	First Stage Notch Filter Frequency	Yes
Pn40A (240A hex)	First Stage Notch Filter Q Value	No
Pn40C (240C hex)	Second Stage Notch Filter Frequency	Yes
Pn40D (240D hex)	Second Stage Notch Filter Q Value	No
Pn456 (2456 hex)	Sweep Torque Reference Amplitude	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

This chapter provides information on monitoring SERVO-PACK product information and SERVOPACK status.

9.1	Monit	oring Product Information9-2	
	9.1.1 9.1.2	Items That You Can Monitor       9-2         Operating Procedures       9-2	
9.2	Monitoring SERVOPACK Status9-		
	9.2.1 9.2.2 9.2.3	Servo Drive Status	
9.3	Monitoring Machine Operation Status and Signal Waveforms9-6		
	9.3.1 9.3.2 9.3.3	Items That You Can Monitor9-6Using the SigmaWin+9-7Using a Measuring Instrument9-9	
9.4	Monitoring Product Life9-1		
	9.4.1 9.4.2 9.4.3	Items That You Can Monitor	
9.5	Alarm	Tracing9-16	
	9.5.1	Data for Which Alarm Tracing Is Performed 9-16 Applicable Tools	

## 9.1

# **Monitoring Product Information**


## 9.1.1 Items That You Can Monitor

Monitor Items			
Information on SERVOPACKs	Model/Type     Serial Number     Manufacturing Date     Software version (SW Ver.)     Remarks		
Information on Servomotors	Model/Type     Serial Number     Manufacturing Date     Remarks		
Information on Encoders	Model/Type     Serial Number     Manufacturing Date     Software version (SW Ver.)     Remarks		

## 9.1.2 Operating Procedures

Use the following procedure to display the Servo Drive product information.

• Select *Read Product Information* in the Menu Dialog Box of the SigmaWin+. The Read Product Information Window will be displayed.



Information

With the Digital Operator, you can use Fn011, Fn012, and Fn01E to monitor this information. Refer to the following manual for the differences in the monitor items compared with the SigmaWin+.

Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

# 9.2 Monitoring SERVOPACK Status

### 9.2.1 Servo Drive Status

Use the following procedure to display the Servo Drive status.

• Start the SigmaWin+. The Servo Drive status will be automatically displayed when you go online with a SERVOPACK.



The Servo Drive status is displayed.

The Servomotor type is displayed.

## 9.2.2 Monitoring Status and Operations

### Items That You Can Monitor

The items that you can monitor on the Status Monitor Window and Motion Monitor Window are listed below

Status Monitor Window

#### Monitor Items

- Polarity Sensor Signal Monitor
- · Active Gain Monitor
- · Main Circuit
- Encoder (PGRDY)
- Motor Power (Request)
- Motor Power ON
- Dynamic Brake (DB)
- Rotation (Movement) Direction
- Mode Switch
- Speed Reference (V-Ref)
- Torque Reference (T-Ref)
- Position Reference (PULS)
- ČLR (Position Deviation Clear Input Signal)

Status

Signal

- Position Reference
   Direction
- Surge Current Limiting
- Resistor Short Relay
- Regenerative TransistorRegenerative Error
- Detection
   AC Power ON
- Overcurrent
- Origin Not Passed
- Moment of Inertia Identification
- Polarity Detection in Progress
- Completion of Polarity Detection
- Ripple Compensation in Progress

- /P-CON (Proportional Control Input Signal)
- P-OT (Forward Drive Prohibit Input Signal)
- N-OT (Reverse Drive Prohibit Input Signal)
- /P-CL (Forward External Torque Limit Signal)
- /N-CL (Reverse External Torque Limit Signal)
- /ALM-RST (Alarm Reset Input Signal)
- /Probe1 (Probe 1 Latch Input Signal)
- /Probe2 (Probe 2 Latch Input Signal)
- /Home (Home Switch Input Signal)
- FSTP (Forced Stop Input Signal)

- ALM (Servo Alarm Output Signal)/COIN (Positioning Completion
- Output Signal)/V-CMP (Speed Coincidence
- V-CMP (Speed Collicidence Detection Output Signal)/TGON (Rotation Detection Out-
- TGON (Rotation Detection Output Signal)
   /S-RDY (Servo Ready Output Signal)
- nal)
   /CLT (Torque Limit Detection Out-
- put Signal)VLT (Speed Limit Detection Output Signal)
- /BK (Brake Output Signal)
- /WARN (Warning Output Signal)
- /NEAR (Near Output Signal)
- PAO (Encoder Divided Pulse Output Phase A Signal)
- PBO (Encoder Divided Pulse Output Phase B Signal)
- PCO (Encoder Divided Pulse Output Phase C Signal)
- /PM (Preventative Maintenance Output Signal)
- /ZONE0 (ZONE Signal 1 Output Signal)
- /ZONE1 (ZONE Signal 2 Output Signal)
- /ZONE2 (ZONE Signal 3 Output Signal)
- /ZONE3 (ZONE Signal 4 Output Signal)
- /nZONE (nZONE Signal Output Signal)

9-3

#### 9.2.2 Monitoring Status and Operations

#### Motion Monitor Window

### Monitor Items


- · Current Alarm State
- Motor Speed
- Speed Reference
- Internal Torque Reference
- Angle of Rotation 1 (number of encoder pulses from origin within one encoder rotation)
- Angle of Rotation 2 (angle from origin within one encoder rotation)
- Input Reference Pulse Speed
- Deviation Counter (Position Deviation)
- · Cumulative Load
- Regenerative Load
- DB Resistor Consumption Power
- · Absolute Encoder Multiturn Data
- Absolute Encoder Position within One Rotation
- Lower Bits of Absolute Encoder Position
- Lower Bits of Absolute Encoder Position
   Upper Bits of Absolute Encoder Position
- Reference Pulse Counter
- Feedback Pulse Counter
- Fully Closed Feedback Pulse Counter
- Total Operating Time
- Current Backlash Compensation Value
- Backlash Compensation Value Setting Limit
- Position Amplifier Deviation
- Feedback Position (APOS)
- Current Reference Position (CPOS)
- Position Deviation (PERR)

- Target Position (TPOS)
  - Latched Position 1 (LPOS1)
  - Latched Position 2 (LPOS2)
  - Latched Position 3 (LPOS3)
  - Target Speed (TSPD)
  - Feedback Speed (FSPD)
  - Current Position Command Speed (CSPD)
  - Torque Limit (TRQ\_LIM)
  - Speed Limit (SPD\_LIM)
  - 6041 hex: Statusword
  - 6061 hex: Modes of operation display
  - 6062 hex: Position demand value
  - 6063 hex: Position actual internal value
  - 6064 hex: Position actual value
  - 606B hex: Velocity demand value
  - 606C hex: Velocity actual value
  - 6074 hex: Torque demand value
  - 60B9 hex: Touch probe status
  - 60BA hex: Touch probe 1 position value
  - 60BC hex: Touch probe 2 position value
  - 60F4 hex: Following error actual value
  - 60FC hex: Position demand internal value
  - 1C32 hex, 01: Synchronization type
  - 1C32 hex, 02: Cycle time
  - 1C32 hex, 12: SM2 event miss count

## **Operating Procedure**

Use the following procedure to display the Motion Monitor and Status Monitor for the SERVO-PACK.

• Select *Monitor* in the Menu Dialog Box of the SigmaWin+. The Operation Pane and Status Pane will be displayed in the Monitor Window.



Information


You can flexibly change the contents that are displayed in the Monitor Window. Refer to the following manual for details.

Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)

## 9.2.3 I/O Signal Monitor

Use the following procedure to check I/O signals.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Wiring Check in the Menu Dialog Box. The Wiring Check Dialog Box will be displayed.
- 3. Click the Monitor Mode Button.



Information

You can also use the above window to check wiring.

- Checking Input Signal Wiring
   Change the signal status at the host controller. If the input signal status on the window changes accordingly, then the wiring is correct.
- Checking Output Signal Wiring
   Click the Force Output Mode Button. This will force the output signal status to change. If
   the signal status at the host controller changes accordingly, then the wiring is correct.
   You cannot use the Force Output Mode Button while the servo is ON.

## 9.3


# Monitoring Machine Operation Status and Signal Waveforms

To monitor waveforms, use the SigmaWin+ trace function or a measuring instrument, such as a memory recorder.


## 9.3.1 Items That You Can Monitor

You can use the SigmaWin+ or a measuring instrument to monitor the shaded items in the following block diagram.

· Rotary Servomotors



- \* This speed is available when fully-closed loop control is being used.
- Linear Servomotors



#### Using the SigmaWin+ 9.3.2


This section describes how to trace data and I/O with the SigmaWin+.

Refer to the following manual for detailed operating procedures for the SigmaWin+.

AC Servo Drive Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)

## **Operating Procedure**

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Trace in the Menu Dialog Box. The Trace Dialog Box will be displayed.



## **Trace Objects**

• Position Error (Deviation)

• Position Amplifier Error (Deviation)

You can trace the following items.

· Data Tracing

#### Trace Objects • Torque Reference · Motor - Load Position Deviation Feedback Speed · Speed Feedforward • Reference Speed Torque Feedforward · Position Reference Speed · Effective (Active) Gain

# 9.3.2 Using the SigmaWin+

### • I/O Tracing

	Trace Objects					
Input Signals	<ul> <li>/P-CON (Proportional Control Input Signal)</li> <li>P-OT (Forward Drive Prohibit Input Signal)</li> <li>N-OT (Reverse Drive Prohibit Input Signal)</li> <li>/ALM-RST (Alarm Reset Input Signal)</li> <li>/P-CL (Forward External Torque/Force Limit Input Signal)</li> <li>/N-CL (Reverse External Torque/Force Limit Input Signal)</li> <li>/Probe1 (Probe 1 Latch Input Signal)</li> <li>/Probe2 (Probe 2 Latch Input Signal)</li> <li>/Home (Home Switch Input Signal)</li> <li>FSTP (Forced Stop Input Signal)</li> <li>/HWBB1 (Hard Wire Base Block Input 1 Signal)</li> <li>/HWBB2 (Hard Wire Base Block Input 2 Signal)</li> </ul>	Output Signals	<ul> <li>ALM (Servo Alarm Output Signal)</li> <li>/COIN (Positioning Completion Output Signal)</li> <li>/V-CMP (Speed Coincidence Detection Output Signal)</li> <li>/TGON (Rotation Detection Output Signal)</li> <li>/S-RDY (Servo Ready Output Signal)</li> <li>/CLT (Torque Limit Detection Output Signal)</li> <li>/VLT (Speed Limit Detection Output Signal)</li> <li>/WLT (Speed Limit Detection Output Signal)</li> <li>/BK (Brake Output Signal)</li> <li>/WARN (Warning Output Signal)</li> <li>/NEAR (Near Output Signal)</li> <li>PAO (Encoder Divided Pulse Output Phase A Signal)</li> <li>PBO (Encoder Divided Pulse Output Phase B Signal)</li> <li>PCO (Encoder Divided Pulse Output Phase C Signal)</li> <li>/ZONE0 (ZONE Signal 1 Output Signal)</li> <li>/ZONE1 (ZONE Signal 2 Output Signal)</li> <li>/ZONE3 (ZONE Signal 3 Output Signal)</li> <li>/ZONE3 (ZONE Signal 4 Output Signal)</li> <li>/nZONE (nZONE Signal Output Signal)</li> <li>/nZONE (nZONE Signal Output Signal)</li> <li>PDETCMP (Polarity Detection Com-</li> </ul>			
		Status	pleted Signal)  • DEN (Position Reference Distribution Completed Signal)			

# 9.3.3 Using a Measuring Instrument

Connect a measuring instrument, such as a memory recorder, to the analog monitor connector (CN5) on the SERVOPACK to monitor analog signal waveforms. The measuring instrument is not provided by Yaskawa.

Refer to the following section for details on the connection.

4.9.3 Analog Monitor Connector (CN5) on page 4-41

# **Setting the Monitor Object**

Use  $Pn006 = n.\square\square XX$  and  $Pn007 = n.\square\square XX$  (Analog Monitor 1 and 2 Signal Selections) to set the items to monitor.

Line Color Signal		Parameter Setting	
White Analog monitor 1		Pn006 (2006 hex) = n.□□XX	
Red	Analog monitor 2	Pn007 (2007 hex) = n.□□XX	
Black (2 lines)	GND	_	

Parameter		Description			
Par	ameter	Monitor Signal	Output Unit	Remarks	
	n. □□00 (default setting of Pn007 (2007 hex))	Motor Speed	Rotary Servomotor: 1 V/1,000 min <sup>-1</sup> Linear Servomotor: 1 V/1,000 mm/s	_	
	n.□□01	Speed Reference	<ul> <li>Rotary Servomotor:1 V/1,000 min<sup>-1</sup></li> <li>Linear Servomotor:1 V/1,000 mm/s</li> </ul>	_	
	n.□□02 (default setting of Pn006 (2006 hex))	Torque Reference	1 V/100% rated torque	_	
	n.□□03	Position Deviation	0.05 V/Reference unit	0 V for speed or torque control	
Pn006 (2006 hex)	n.□□04	Position Amplifier Deviation	0.05 V/encoder pulse unit	Position deviation after electronic gear conversion	
	n.□□05	Position Command Speed	• Rotary Servomotor:1 V/1,000 min <sup>-1</sup> • Linear Servomotor:1 V/1,000 mm/s	-	
or Pn007 (2007	n.□□06	Reserved parameter (Do not change.)	_	-	
hex)	n.□□07	Motor - Load Position Deviation	0.01 V/Reference unit	-	
	n.□□08	Positioning Completion	Positioning completed: 5 V Positioning not completed: 0 V	Completion is indicated by the output voltage.	
	n.□□09	Speed Feedforward	• Rotary Servomotor:1 V/1,000 min <sup>-1</sup> • Linear Servomotor:1 V/1,000 mm/s	_	
	n.□□0A	Torque Feedforward	1 V/100% rated torque	_	
	n.□□0B	Active Gain*	1st gain: 1 V 2nd gain: 2 V	The gain that is active is indicated by the output voltage.	
	n.□□0C	Completion of Position Reference Distribution	Distribution completed: 5 V Distribution not completed: 0 V	Completion is indicated by the output voltage.	
	n.□□0D	External Encoder Speed	1 V/1,000 min <sup>-1</sup>	Value calculated at the motor shaft	
	n.□□10	Main Circuit DC Voltage	1 V/100 V (main circuit DC voltage)	-	
* Refer to t	* Refer to the following section for details.				

<sup>\*</sup> Refer to the following section for details.

<sup>8.12.1</sup> Gain Switching on page 8-65

### **Changing the Monitor Factor and Offset**

You can change the monitor factors and offsets for the output voltages for analog monitor 1 and analog monitor 2. The relationships to the output voltages are as follows:

Analog monitor 1 output voltage 
$$= (-1) \times \begin{cases} \text{Analog Monitor 1 Signal Selection (Pn006 = n. \square \square XX)} \times \text{Magnification (Pn552)}^+ \text{ Offset Voltage (Pn550)} \end{cases}$$

Analog monitor 2 output voltage  $= (-1) \times \begin{cases} \text{Analog Monitor 2 Signal Selection (Pn007 = n. \square \square XX)} \times \text{Magnification (Pn553)}^+ \end{cases}$ 

Analog Monitor 2 output voltage  $= (-1) \times \begin{cases} \text{Analog Monitor 2 Signal Selection (Pn007 = n. \square \square XX)} \times \text{Magnification (Pn553)}^+ \end{cases}$ 

The following parameters are set.


Pn550	Analog Monitor 1 Offset Voltage			Speed	osition Torque
(2550	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	-10,000 to 10,000	0.1 V	0	Immediately	Setup
Pn551	Analog Monitor 2 Of	fset Voltage		Speed	osition Torque
(2551	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	-10,000 to 10,000	0.1 V	0	Immediately	Setup
Pn552	Analog Monitor 1 Magnification Speed Position Torqu				
(2552	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	-10,000 to 10,000	×0.01	100	Immediately	Setup
Pn553	Analog Monitor 2 Ma	agnification		Speed	osition Torque
(2553	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	-10,000 to 10,000	×0.01	100	Immediately	Setup


Example

• Example for Setting the Item to Monitor to the Motor Speed (Pn006 = n.□□00)

When Pn552 = 100 (Setting Unit: ×0.01)

When Pn552 = 1,000 (Setting Unit:  $\times$ 0.01)





Note: The effective linearity range is  $\pm 8$  V. The resolution is 16 bits.

# Adjusting the Analog Monitor Output

You can manually adjust the offset and gain for the analog monitor outputs for the torque reference monitor and motor speed monitor.


The offset is adjusted to compensate for offset in the zero point caused by output voltage drift or noise in the monitoring system.

The gain is adjusted to match the sensitivity of the measuring system.

The offset and gain are adjusted at the factory. You normally do not need to adjust them.

### Adjustment Example

An example of adjusting the output of the motor speed monitor is provided below.



Gain Aujustinent				
Analog monitor output voltage				
1 [V]	Gain adjustment  Motor speed			
	1000 [min <sup>-1</sup> ]			

Gain Adjustment

Item	Specification
Offset Adjustment Range	-2.4 V to 2.4 V
Adjustment Unit	18.9 mV/LSB

Item	Specification
Gain Adjustment Range	100 ±50%
Adjustment Unit	0.4%/LSB

The gain adjustment range is made using a 100% output value (gain adjustment of 0) as the reference value with an adjustment range of 50% to 150%. A setting example is given below.

- Setting the Adjustment Value to -125  $100 + (-125 \times 0.4) = 50$  [%]
- Therefore, the monitor output voltage goes to 50% of the original value.
- Setting the Adjustment Value to 125  $100 + (125 \times 0.4) = 150$ [%] Therefore, the monitor output voltage goes to 150% of the original value.

Information

- · The adjustment values do not use parameters, so they will not change even if the parameter settings are initialized.
- · Adjust the offset with the measuring instrument connected so that the analog monitor output value goes to zero. The following setting example achieves a zero output.
- · While power is not supplied to the Servomotor, set the monitor signal to the torque reference.
- In speed control, set the monitor signal to the position deviation.

### Preparations

Confirm the following condition before you adjust the analog monitor output.

• The parameters must not be write prohibited.

### Applicable Tools

You can use the following tools to adjust analog monitor outputs. The function that is used is given for each tool.

Offset Adjustment

Tool Function		Operating Procedure Reference
Digital Operator	Fn00C	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Adjust Offset	

### 9.3.3 Using a Measuring Instrument


· Gain Adjustment

Tool	Function	Operating Procedure Reference
Digital Operator	Fn00D	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup - Adjust Offset	


### Operating Procedure

Use the following procedure to adjust the analog monitor output.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Adjust the Analog Monitor Output in the Menu Dialog Box. The Adjust the Analog Monitor Output Dialog Box will be displayed.
- 3. Click the Zero Adjustment or Gain Adjustment Tab.



**4.** While watching the analog monitor, use the +1 and -1 Buttons to adjust the offset. There are two channels: CH1 and CH2. If necessary, click the down arrow on the **Channel** Box and select the channel.



This concludes adjusting the analog monitor output.

# 9.4 Monitoring Product Life

# 9.4.1 Items That You Can Monitor


Monitor Item	Description
SERVOPACK Installation Envi- ronment	The operating status of the SERVOPACK in terms of the installation environment is displayed. Implement one or more of the following actions if the monitor value exceeds 100%.  • Lower the surrounding temperature.  • Decrease the load.
Servomotor Installation Environment	The operating status of the SERVOPACK in terms of the installation environment is displayed. Implement one or more of the following actions if the monitor value exceeds 100%.  • Lower the surrounding temperature.  • Decrease the load.
Built-in Fan Service Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.  [3] 15.1.2 Guidelines for Part Replacement on page 15-2
Capacitor Service Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.  15.1.2 Guidelines for Part Replacement on page 15-2
Surge Prevention Circuit Service Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.  15.1.2 Guidelines for Part Replacement on page 15-2
Dynamic Brake Circuit Service Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.  15.1.2 Guidelines for Part Replacement on page 15-2
Built-in Brake Relay Service Life Prediction	The unused status of the built-in brake relay is treated as the 100% value. The value decreases based on the number of operations of the built-in brake relay. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.  15.1.2 Guidelines for Part Replacement on page 15-2

# 9.4.2 Operating Procedure

Use the following procedure to display the installation environment and service life prediction monitor dialog boxes.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Life Monitor in the Menu Dialog Box. The Life Monitor Dialog Box will be displayed.

Information With the Digital Operator, you can use Un025 to Un02A to monitor this information.



A value of 100% indicates that the SERVOPACK has not yet been used. The percentage decreases as the SERVOPACK is used and reaches 0% when it is time to replace the SERVOPACK.

### Preventative Maintenance

9.4.3

You can use the following functions for preventative maintenance.

- Preventative maintenance warnings
- /PM (Preventative Maintenance Output) signal

The SERVOPACK can notify the host controller when it is time to replace any of the main parts.

### **Preventative Maintenance Warning**

An A.9b0 warning (Preventative Maintenance Warning) is detected when any of the following service life prediction values drops to 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life. You can change the setting of  $Pn00F = n.\Box\Box\Box\Box X$  to enable or disable these warnings.

Parameter Description		Description	When Enabled	Classifi- cation
Pn00F (200F	n.□□□0 (default setting)	Do not detect preventative maintenance warnings.	After restart	Setup
hex)	n.□□□1	Detect preventative maintenance warnings.	ายรเสาเ	

Note: Service life prediction of the built-in brake relay is performed as preventative maintenance for SERVOPACKs with built-in Servomotor brake control only when Pn023 is set to n.□□□0.

### /PM (Preventative Maintenance Output) Signal

The /PM (Preventative Maintenance Output) signal is output when any of the following service life prediction values reaches 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life. The /PM (Preventative Maintenance Output) signal must be allocated.

Even if detection of preventive maintenance warnings is disabled ( $Pn00F = n.\Box\Box\Box$ 0), the /PM signal will still be output as long as it is allocated.

Classifi- cation	Signal	Connector Pin No.	Signal Status	Description
Output	/PM	Must be allocated.	ON (closed)	One of the following service life prediction values reached 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life.
	71 101	Must be anocated.	OFF (open)	All of the following service life prediction values are greater than 10%: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life.

Note: You must allocate the /PM signal to use it. Use Pn514 = n. \(\subseteq \subseteq X\) (/PM (Preventative Maintenance Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following section for details.

6.1.2 Output Signal Allocations on page 6-5

9.5.1 Data for Which Alarm Tracing Is Performed

# **Alarm Tracing**

Alarm tracing records data in the SERVOPACK from before and after an alarm occurs. This data helps you to isolate the cause of the alarm.

You can display the data recorded in the SERVOPACK as a trace waveform on the SigmaWin+.

- Information
  Alarms that occur when the power supply is turned ON are not recorded.
  Alarms that occur during the recording of alarm trace data are not recorded.
  - · Alarms that occur while utility functions are being executed are not recorded.

#### 9.5.1 **Data for Which Alarm Tracing Is Performed**

Two types of data are recorded for alarm tracing: numeric data and I/O signal ON/OFF data.

Numeric Data					
Torque reference					
Feedback speed					
Reference speed					
Position command speed					
Position deviation					
Load – motor position deviation					
Main circuit bus voltage					

ON/OFF Data					
ALM					
Servo ON command (/S-ON)					
Proportional control command (/P-CON)					
Forward torque command (/P-CL)					
Reverse torque command (/N-CL)					
G-SEL1 signal (/G-SEL1)					
ACON					

#### Applicable Tools 9.5.2

The following table lists the tools that you can use to perform alarm tracing and the applicable tool functions.

Tool	Function Operating Procedure Reference			
Digital Operator	You cannot display alarm tracing data from the Digital Operator.			
SigmaWin+	Alarm – Alarm Tracing	AC Servo Drive Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)		

# Fully-Closed Loop Control

This chapter provides detailed information on performing fully-closed loop control with the SERVOPACK.


10.1	Fully-	Closed System10-2
10.2	SERV	OPACK Commissioning Procedure10-3
10.3	Parame	ter and Object Settings for Fully-closed Loop Control 10-5
	10.3.1	Control Block Diagram for Fully-Closed
	10.3.2	Loop Control
	10.0.2	Movement Direction
	10.3.3	Setting the Number of External Encoder Scale Pitches
	10.3.4	Setting the PAO, PBO, and PCO
	1005	(Encoder Divided Pulse Output) Signals 10-7
	10.3.5	External Absolute Encoder Data Reception Sequence
	10.3.6	Setting Unit Systems
	10.3.7	Alarm Detection Settings
	10.3.8	Analog Monitor Signal Settings 10-9
	10.3.9	Setting to Use an External Encoder
		for Speed Feedback
10.4	Monit	oring an External Encoder10-10
	10.4.1	Option Module Required for Monitoring 10-10 Related Parameters
	10.4.3	Block Diagrams

# 10.1

# **Fully-Closed System**

With a fully-closed system, an externally installed encoder is used to detect the position of the controlled machine and the machine's position information is fed back to the SERVOPACK. High-precision positioning is possible because the actual machine position is fed back directly. With a fully-closed system, looseness or twisting of mechanical parts may cause vibration or oscillation, resulting in unstable positioning.

The following figure shows an example of the system configuration.



<sup>\*</sup> The connected devices and cables depend on the type of external linear encoder that is used.

Note: Refer to the following section for details on connections that are not shown above, such as connections to power supplies and peripheral devices.

2.4 Examples of Standard Connections between SERVOPACKs and Peripheral Devices on page 2-18

# 10.2 SERVOPACK Commissioning Procedure

First, confirm that the SERVOPACK operates correctly with semi-closed loop control, and then confirm that it operates correctly with fully-closed loop control.

The commissioning procedure for the SERVOPACK for fully-closed loop control is given below.

Step	Description	Operation	Required Parameter and Object Settings	Con- trolling Device
1	Check operation of the entire sequence with semi-closed loop control and without a load. Items to Check Power supply circuit wiring Servomotor wiring Encoder wiring Wiring of I/O signal lines from the host controller Servomotor rotation direction, motor speed, and multiturn data Operation of safety mechanisms, such as the brakes and the overtravel mechanisms	Set the parameters so that the SERVOPACK operates correctly in semi-closed loop control without a load and check the following points. Set Pn002 to n.0□□□ to specify semi-closed loop control.  • Are there any errors in the SER-VOPACK?  • Does jogging function correctly when you operate the SERVO-PACK without a load?  • Do the I/O signals turn ON and OFF correctly?  • Is power supplied to the Servomotor when the Servo ON command (Enable Operation command) is sent from the host controller?  • Does the Servomotor operate correctly when a position reference is input by the host controller?	<ul> <li>Pn000 (Basic Function Select Switch 0)</li> <li>Pn001 (Basic Function Select Switch 1)</li> <li>Pn002 = n.X□□□ (External Encoder Usage)</li> <li>Position reference unit (position user unit (2701 hex))</li> <li>Pn50A, Pn50B, Pn511, and Pn516 (Input Signal Selections)</li> <li>Pn50E, Pn50F, Pn510, and Pn514 (Output Signal Selections)</li> </ul>	SERVO- PACK or host con- troller
2	Check operation with the Servomotor connected to the machine with semi-closed loop control. Items to Check Initial response of the system connected to the machine Movement direction, travel distance, and movement speed as specified by the references from the host controller	Connect the Servomotor to the machine. Set the moment of inertia ratio in Pn103 using autotuning without a host reference. Check that the machine's movement direction, travel distance, and movement speed agree with the references from the host controller.	Pn103 (Moment of Inertia Ratio)	Host controller
3	Check the external encoder. Items to Check • Is the signal from the external encoder received correctly?	Set the parameters related to fully-closed loop control and move the machine with your hand without turning ON the power supply to the Servomotor. Check the following status with the Digital Operator or SigmaWin+.  • Does the fully-closed feedback pulse counter count up when the Servomotor moves in the forward direction?  • Is the travel distance of the machine visually about the same as the amount counted by the fully-closed feedback pulse counter?  Note: The unit for the fully-closed feedback pulse counter is pulses, which is equivalent to the external encoder sine wave pitch.	Pn002 = n.X□□□ (External Encoder Usage) Pn20A (Number of External Scale Pitches) Position reference unit (position user unit (2701 hex)) Pn281 (Encoder Output Resolution) Pn51B (Excessive Error Level between Servomotor and Load Positions) Pn522 (Positioning Completed Width) Pn52A (Multiplier per One Fully-closed Rotation)	_

Continued on next page.

### Continued from previous page.

Step	Description	Operation	Required Parameter and Object Settings	Con- trolling Device
4	Perform a program jogging operation. Items to Check Does the fully-closed system operate correctly for the SERVOPACK without a load?	Perform a program jogging operation and confirm that the travel distance is the same as the reference value in Pn531.  When you perform program jogging, start from a low speed and gradually increase the speed.	Pn530 to Pn536 (program jogging-related parameters)	SERVO- PACK
5	Operate the SERVO-PACK. Items to Check Does the fully-closed system operate correctly, including the host controller?	Input a position reference and confirm that the SERVOPACK operates correctly. Start from a low speed and gradually increase the speed.	-	Host controller


# 10.3 Parameter and Object Settings for Fully-closed Loop Control

This section describes the parameter settings that are related to fully-closed loop control.

Parameter and Object to Set	Setting	Position Control	Speed Control	Torque Control	Reference
Pn000 (2000 hex) = n.□□□X	Motor direction	V	√	V	page 10-6
Pn002 (2002 hex) = n.X□□□	External encoder usage method	V	V	V	page 10-0
Pn20A (220A hex)	Number of external scale pitches	$\sqrt{}$			page 10-6
Pn281 (2281 hex)	Encoder divided pulse output signals (PAO, PBO, and PCO) from the SERVO-PACK	V	V	√	page 10-7
-	External absolute encoder data reception sequence	V	√	V	page 6-42
Position User Unit (2701 hex)	Electronic gear ratio	V	_	_	page 5-42
Pn51B (251B hex) Excessive deviation level between Serv motor and load positions		V	-	_	page 10-8
Pn52A (252A hex) Multiplier for one fully-closed rotation		$\sqrt{}$	_	_	
Pn006 (2006 hex)/ Pn007 (2007 hex)	Analog monitor signal	V	V	V	page 10-9
Pn22A (222A hex) = n.XDDD	Speed feedback method during fully- closed loop control	√	_	_	page 10-9

# 10.3.1 Control Block Diagram for Fully-Closed Loop Control

The control block diagram for fully-closed loop control is provided below.



<sup>\*</sup> The connected device depends on the type of external encoder.

Note: You can use either an incremental or an absolute encoder. If you use an absolute encoder, set Pn002 to n.□1□□ (Use the absolute encoder as an incremental encoder).

10.3.2 Setting the Motor Direction and the Machine Movement Direction

# 10.3.2 Setting the Motor Direction and the Machine Movement Direction

You must set the motor direction and the machine movement direction. To perform fully-closed loop control, you must set both  $Pn000 = n.\square\square\squareX$  (Direction Selection) and  $Pn002 = n.X\square\square\square$  (External Encoder Usage).

Parameter			Pn002 (2002 hex) = n.X□□□ (External Encoder Usage)			
Parameter		n.1E	100	n.3□□□		
		Reference direction	Forward reference	Reverse reference	Forward reference	Reverse reference
Pn000 (2000 hex) =n.□□□X (Direction Selection)	n.□□□0	Motor direction	CCW	CW	CCW	CW
		External encoder	Forward movement	Reverse movement	Reverse movement	Forward movement
	n.□□□1	Reference direction	Forward reference	Reverse reference	Forward reference	Reverse reference
		Motor direction	CW	CCW	CW	CCW
		External encoder	Reverse movement	Forward movement	Forward movement	Reverse movement

- Phase B leads in the divided pulses for a forward reference regardless of the setting of Pn000
   = n.□□□□X.
- Forward direction: The direction in which the pulses are counted up.
- Reverse direction: The direction in which the pulses are counted down.

### **Related Parameters**

◆ Pn000 = n.□□□X

Refer to the following section for details.

5.4 Motor Direction Setting on page 5-14

### ◆ Pn002 = n.X□□□

When you perform fully-closed loop control, set Pn002 to n.1 \( \sigma \sigma \) or n.3 \( \sigma \sigma \).

Parameter		Name	Meaning	When Enabled	Classifi- cation
n.0□□□ (default set- ting)			Do not use an external encoder.	∋r.	
Pn002 (2002	n.1□□□	External	External encoder moves in forward direction for CCW motor rotation.	After restart	Setup
hex)	n.2□□□	Encoder Usage	Reserved parameter (Do not change.)		
	n.3□□□		External encoder moves in reverse direction for CCW motor rotation.		
	n.4□□□		Reserved parameter (Do not change.)		

#### Information

Determine the setting of  $Pn002 = n.X\square\square\square$  as described below.

- Set Pn000 to n.□□□□ (Use the direction in which the linear encoder counts up as the forward direction) and set Pn002 to n.1□□□ (The external encoder moves in the forward direction for CCW motor rotation).
- Manually rotate the motor shaft counterclockwise.
- If the fully-closed feedback pulse counter counts up, do not change the setting of Pn002 (Pn002 = n.1□□□).
- If the fully-closed feedback pulse counter counts down, set Pn002 to n.3 \(\sigma\).

# 10.3.3 Setting the Number of External Encoder Scale Pitches

Set the number of external encoder scale pitches per motor rotation in Pn20A.


10.3.4 Setting the PAO, PBO, and PCO (Encoder Divided Pulse Output) Signals

### **Setting Example**

Specifications

External encoder scale pitch: 20  $\mu\text{m}$ 

Ball screw lead: 30 mm



If the external encoder is connected direct mm = 1,500).

Note: 1. If there is a fraction, round off the digits below the decimal point.

2. If the number of external encoder scale pitches per motor rotation is not an integer, there will be deviation in the position loop gain (Kp), feedforward, and position reference speed monitor. This is not relevant for the position loop and it therefore does not interfere with the position accuracy.

### **Related Parameters**

Pn20A (220A hex)	Number of Externa	umber of External Scale Pitches			
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	4 to 1,048,576	1 scale pitch/revo- lution	32,768	After restart	Setup

# 10.3.4 Setting the PAO, PBO, and PCO (Encoder Divided Pulse Output) Signals

Set the position resolution in Pn281 (Encoder Output Resolution).

Enter the number of phase A and phase B edges for the setting.

### **Setting Example**

Specifications


External encoder scale pitch: 20  $\mu m$ 

Ball screw lead: 30 mm Speed:1,600 mm/s

If a single pulse (multiplied by 4) is output for 1 μm, the setting would be 20.

If a single pulse (multiplied by 4) is output for 0.5 µm, the setting would be 40.

The encoder divided pulse output would have the following waveform if the setting is 20.



"1" indicates the edge positions. In this example, the set value is 20 and therefore the number of edges is 20.

Note: The upper limit of the encoder signal output frequency (multiplied by 4) is 6.4 Mpps. Do not set a value that would cause the output to exceed 6.4 Mpps.

If the output exceeds the upper limit, an A.511 alarm (Overspeed of Encoder Output Pulse Rate) will be output.

Example

If the setting is 20 and the speed is 1,600 mm/s, the output frequency would be 1.6 Mpps  $\frac{1600 \text{ mm/s}}{0.001 \text{ mm}} = 1,600,000 = 1.6 \text{ Mpps}$ 

Because 1.6 Mpps is less than 6.4 Mpps, this setting can be used.

10.3.5 External Absolute Encoder Data Reception Sequence

### **Related Parameters**

Pn281	Encoder Output Re	solution		Position	on
(2281	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	1 to 4,096	1 edge/pitch	20	After restart	Setup

Note: The maximum setting for the encoder output resolution is 4,096.

If the resolution of the external encoder exceeds 4,096, pulse output will no longer be possible at the resolution given in Feedback Resolution of Linear Encoder on page 5-44.

# 10.3.5 External Absolute Encoder Data Reception Sequence

Refer to the following section for details.

6.9.4 Reading the Position Data from the Absolute Linear Encoder on page 6-42

With fully-closed loop control, the same sequence as for a Linear Servomotor is used.

# 10.3.6 Setting Unit Systems

Refer to the following section for details.

5.14 Setting Unit Systems on page 5-42

With fully-closed loop control, the same setting as for a Linear Servomotor is used.

# 10.3.7 Alarm Detection Settings

This section describes the alarm detection settings (Pn51B and Pn52A).

# Pn51B (Excessive Error Level between Servomotor and Load Positions)

This setting is used to detect the difference between the feedback position of the motor encoder and the feedback load position of the external encoder for fully-closed loop control. If the detected difference exceeds the setting, an A.d10 alarm (Motor-Load Position Error Overflow) will be output.

	tions Posit	ion			
Pn51B (251B hex)	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
(ZOTB TICK)	0 to 1,073,741,823	1 reference unit	1000	Immediately	Setup

Note: If you set this parameter to 0, A.d10 alarms will not be output and the machine may be damaged.

### Pn52A (Multiplier per One Fully-closed Rotation)

Set the coefficient of the deviation between the motor and the external encoder per motor rotation.


This setting can be used to prevent the motor from running out of control due to damage to the external encoder or to detect belt slippage.

### Setting Example

Increase the value if the belt slips or is twisted excessively.

If this parameter is set to 0, the external encoder value will be read as it is.

If you use the default setting of 20, the second rotation will start with the deviation for the first motor rotation multiplied by 0.8.



### 10.3.8 Analog Monitor Signal Settings

### Related Parameters

Pn52A	Multiplier per One Fully-closed Rotation			Position	
(252A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
hex)	0 to 100	1%	20	Immediately	Setup

#### **Analog Monitor Signal Settings** 10.3.8

You can monitor the position deviation between the Servomotor and load with an analog monitor.

Para	Parameter Name		Meaning	When Enabled	Classifi- cation
Pn006 (2006 hex)	n.□□07	Analog Monitor 1 Signal Selection	Position deviation between motor and load (output unit: 0.01 V/reference unit).	Immedi-	Setup
Pn007 (2007 hex)	n.□□07	Analog Monitor 2 Signal Selection	Position deviation between motor and load (output unit: 0.01 V/reference unit).	ately	Setup

#### Setting to Use an External Encoder for Speed Feedback 10.3.9

For fully-closed loop control, you normally set a parameter to specify using the motor encoder speed (Pn22A =  $n.0\square\square\square$ ).

If you will use a high-resolution external encoder, set the parameter to specify using the speed of the external encoder (Pn22A =  $n.1\Box\Box\Box$ ).

Parameter		Meaning	When Enabled	Classification
Pn22A (222A hex)	n.0□□□ (default set- ting)	Use motor encoder speed.	After restart	Setup
riex)	n.1000	Use external encoder speed.		

Note: This parameter cannot be used if Pn002 is set to n.0 \(\subseteq \subseteq \) (Do not use external encoder).

10.4.1 Option Module Required for Monitoring

# 10.4

# Monitoring an External Encoder

You can monitor the current value of an external encoder attached to a machine without creating a fully-closed loop.

A dual encoder system with an encoder in the Rotary Servomotor and an external encoder attached to the machine is used, but only the encoder in the Rotary Servomotor is used in the control loop.

The external encoder is used only to monitor the current position of the machine. You can also use a touch probe to latch the current position of an external encoder.

# 10.4.1 Option Module Required for Monitoring

A Fully-closed Module (SGDV-OFA01A) is required to use this function.

Refer to the following manual for detailed information on installation.

Σ-V-Series/Σ-V-Series for Large-Capacity Models/Σ-7-Series Installation Guide Fully-closed Module (Manual No.: TOBP C720829 03)

Note: You cannot use a Safety Module (SGDV-OSA01A) if you install a Fully-closed Module.

### 10.4.2 Related Parameters


The parameter that is used to monitor the external encoder as the current value of the machine is given below.

Parameter		Meaning	When Enabled	Classification	
Pn00E	n.0□□□ (default set- ting)	Do not use the external encoder monitor.			
	n.1000	1□□□ Use CCW as the forward direction.		0.1	
	n.2000	Reserved setting (Do not use.)	After startup	Setup	
	n.3□□□	Use CW as the forward direction. (Reverse Rotation Mode)			
	n.4000	Reserved setting (Do not use.)			


Set Pn002 to n.0 \(\sigma \sigma \) (Do not use external encoder) if you will not use fully-closed loop control.

# 10.4.3 Block Diagrams

A simple block diagram is given below to provide an overall image of monitoring an external encoder.



The following block diagram shows monitoring an external encoder in the Profile Position Mode.



# **Safety Functions**

This chapter provides detailed information on the safety functions of the SERVOPACK.

11.1	Introd	uction to the Safety Functions11-2
	11.1.1 11.1.2	Safety Functions
11.2	Hard \	Wire Base Block (HWBB and SBB) 11-4
		Risk Assessment
11.3	EDM1	(External Device Monitor) 11-11
	11.3.1	EDM1 Output Signal Specifications 11-11
11.4	Applica	ations Examples for Safety Functions11-12
	11.4.1 11.4.2 11.4.3	Connection Example11-12Failure Detection Method11-12Procedure11-13
11.5	Valida	ting Safety Functions 11-14
11.6	Conne	ecting a Safety Function Device 11-15

11.1.1 Safety Functions

# 11.1

# Introduction to the Safety Functions

# 11.1.1 Safety Functions

Safety functions are built into the SERVOPACK to reduce the risks associated with using the machine by protecting workers from the hazards of moving machine parts and otherwise increasing the safety of machine operation.

Especially when working in hazardous areas inside guards, such as for machine maintenance, the safety function can be used to avoid hazardous moving machine parts.

You can implement the following four safety functions depending on the Safety Module that you use.

		SERVO-	Safety Module Function	
Function	Description	PACK Built- in Function		Active Mode Function*1
Hard Wire Base Block (HWBB and SBB)	This safety function is equivalent to the Safety Torque OFF function defined in IEC 61800-5-2.	Yes (HWBB)	Yes (SBB*2)	_
Safety Base Block with Delay (SBB-D)*2	This safety function is equivalent to the Safety Stop 1 function defined in IEC 61800-5-2.	_	Yes	Yes
Safe Position Monitor with Delay (SPM-D)*2	This safety function is equivalent to the Safety Stop 2 function defined in IEC 61800-5-2.	-	Yes	Yes
Safe Speed Limit with Delay (SLS-D)*2	This safety function is equivalent to the Safely-Limited Speed function defined in IEC 61800-5-2.	-	Yes	_

<sup>\*1.</sup> The Active Mode Function stops the motor according to the speed reference that is preset in a parameter in the SERVOPACK when the safety request input signal turns OFF during SBB-D or SPM-D.

The Active Mode Function is not a safety function in the applicable standards. Keep this in mind when you design the system.

Refer to the following section for information on the safety function and safety parameters.

Compliance with UL Standards, EU Directives, and Other Safety Standards on page xxii



Products that display the TÜV mark on the nameplate have met the safety standards.

<sup>\*2.</sup> A Safety Module (optional) must be connected to use this function. Refer to the following manual for application procedures.

Σ-V-Series/Σ-V-Series for Large-Capacity Models/Σ-7-Series Installation Guide Safety Module (Manual No.: SIEP C720829 06)

# 11.1.2 Precautions for Safety Functions

# **MARNING**

- To confirm that the HWBB function satisfies the safety requirements of the system, you
  must conduct a risk assessment of the system.
   Incorrect use of the safety function may cause injury.
- The Servomotor will move if there is an external force (e.g., gravity on a vertical axis) even when the HWBB function is operating. Use a separate means, such as a mechanical brake, that satisfies the safety requirements.
   Incorrect use of the safety function may cause injury.
- While the HWBB function is operating, the motor may move within an electric angle of 180° or less as a result of a SERVOPACK failure. Use the HWBB function for an application only after confirming that movement of the motor will not result in a hazardous condition.
   Incorrect use of the safety function may cause injury.
- The dynamic brake and the brake signal are not safety-related elements. You must design the system so that SERVOPACK failures will not cause a hazardous condition while the HWBB function is operating.
  - Incorrect use of the safety function may cause injury.
- Connect devices that satisfy the safety standards for the signals for safety functions. Incorrect use of the safety function may cause injury.
- The HWBB function does not shut OFF the power to the SERVOPACK or electrically isolate it. Implement measures to shut OFF the power supply to the SERVOPACK before you perform maintenance on it.
  - There is a risk of electric shock.
- Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.
  - If you use a power supply that is not SELV compliant, safety functions may be lost if the power supply fails, which may result in machine damage or injury.

11.2.1 Risk Assessment

# 11.2

# Hard Wire Base Block (HWBB and SBB)

A hard wire base block (abbreviated as HWBB) is a safety function that is designed to shut OFF the current to the motor with a hardwired circuit.

The drive signals to the Power Module that controls the motor current are controlled by the circuits that are independently connected to the two input signal channels to turn OFF the Power Module and shut OFF the motor current.



For safety function signal connections, the input signal is the 0-V common and the output signal is a source output.


This is opposite to other signals described in this manual.

To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

The input signal uses the 0-V common. The following figure shows a connection example.



# 11.2.1 Risk Assessment

When using the HWBB, you must perform a risk assessment of the Servo System in advance to confirm that the safety level of the standards is satisfied. Refer to the following section for details on the standards.

Compliance with UL Standards, EU Directives, and Other Safety Standards on page xxii

Note: To meet performance level e (PLe) in EN ISO 13849-1 and SIL3 in IEC 61508, the EDM1 signal must be monitored by the host controller. If the EDM1 signal is not monitored by the host controller, the level will be safety performance level c (Plc) and SIL1.

The following hazards exist even when the HWBB is operating. These hazards must be included in the risk assessment.

• The Servomotor will move if an external force is applied to it (for example, gravity on a vertical axis). Implement measures to hold the Servomotor, such as installing a separate mechanical brake.


The rotational angle or travel distance depends on the type of Servomotor as follows:

- Rotary Servomotor: 1/6 rotation max. (rotational angle calculated at the motor shaft)
- Linear Servomotor: 50 mm max.
- The HWBB does not shut OFF the power to the SERVOPACK or electrically isolate it. Implement measures to shut OFF the power supply to the SERVOPACK before you perform maintenance on it.


# 11.2.2 Hard Wire Base Block (HWBB) State

The SERVOPACK will be in the following state if the HWBB operates. If the /HWBB1 or /HWBB2 signal turns OFF, the HWBB will operate and the SERVOPACK will enter a HWBB state.

• When HWBB Operates after Servo OFF (Power Not Supplied to Motor)




• When HWBB Operates While Power Is Supplied to Servomotor




# 11.2.3 Resetting the HWBB State

Normally, after the Shutdown command is received and power is no longer supplied to the Servomotor, the /HWBB1 and /HWBB2 signals will turn OFF and the SERVOPACK will enter the HWBB state. If you turn ON the /HWBB1 and /HWBB2 signals in this state, the SERVOPACK will enter a base block (BB) state and will be ready to acknowledge the Servo ON command (Enable Operation command).



If the /HWBB1 and /HWBB2 signals are OFF and the Servo ON command (Enable Operation command) is received, the HWBB state will be maintained even after the /HWBB1 and /HWBB2 signals are turned ON.

Send the Shutdown command to place the SERVOPACK in the BB state and then send the Servo ON command (Enable Operation command).



Note: If the SERVOPACK is placed in the BB state while the main circuit power supply is OFF, the HWBB state will be maintained until the Shutdown command is received.

# 11.2.4 Recovery Method

### ■ Recovery Conditions

All of the following conditions must be met.

- · All safety request inputs are ON.
- The Servo ON command (Enable Operation command) was not sent.
- None of the following utility functions have been executed. (These functions execute the Servo ON command (Enable Operation command).)

The following utility functions execute the Servo ON command (Enable Operation command).

Utility Function No.	Function Name
Fn002	Jog
Fn003	Origin Search
Fn004	Jog Program
Fn00E	Autotune Motor Current Detection Signal Offset
Fn080	Polarity Detection
Fn201	Advanced Autotuning without Reference
Fn206	Easy FFT

Note: If any of the above utility functions was executed, the utility function must be ended. Perform the operation to return to the Main Menu for the utility functions on the Digital Operator. Refer to the following manual for operating procedures.

Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

#### ■ Recovery Procedure

- 1. Specify Shutdown in controlword (6040 hex, bits 0 to 3) to reset the Servo Drive.
- **2.** Specify Switch ON and the Servo ON command (Enable Operation command) in *controlword* (6040 hex, bits 0 to 3).

Power will be supplied to the motor.

# 11.2.5 Detecting Errors in HWBB Signal


If only the /HWBB1 or the /HWBB2 signal is input, an A.Eb1 alarm (Safety Function Signal Input Timing Error) will occur unless the other signal is input within 10 seconds. This makes it possible to detect failures, such as disconnection of an HWBB signal.

# **CAUTION**

• The A.Eb1 alarm (Safety Function Signal Input Timing Error) is not a safety-related element. Keep this in mind when you design the system.

# 11.2.6 HWBB Input Signal Specifications

If an HWBB is requested by turning OFF the two HWBB input signal channels (/HWBB1 and /HWBB2), the power supply to the Servomotor will be turned OFF within 8 ms.




Note: 1. The OFF status is not recognized if the OFF interval of the /HWBB1 or /HWBB2 signal is 0.5 ms or shorter.

- You can check the status of the input signals by using monitor displays. Refer to the following section for details.
  - 9.2.3 I/O Signal Monitor on page 9-5

# 11.2.7 Operation without a Host Controller

The HWBB will operate even for operation without a host controller.


However, if the HWBB operates during execution of the following functions, leave the execution mode for the function and then enter it again to restart operation. Operation will not be restarted simply by turning OFF the /HWBB1 and /HWBB2 signals.



# 11.2.8 /S-RDY (Servo Ready Output) Signal

The Servo ON command (Enable Operation command) will not be acknowledged in the HWBB state. Therefore, the Servo Ready Output Signal will turn OFF. The Servo Ready Output Signal will turn ON if both the /HWBB1 and /HWBB2 signals are ON and the servo is turned OFF (BB state).

An example is provided below for when the main circuit power supply is ON when there is no servo alarm.



# 11.2.9 /BK (Brake Output) Signal

If the HWBB operates when the /HWBB1 or /HWBB2 signal is OFF, the /BK (Brake) signal will turn OFF. At that time, the setting in Pn506 (Brake Reference - Servo OFF Delay Time) will be disabled. Therefore, the Servomotor may be moved by external force until the actual brake becomes effective after the /BK signal turns OFF.

# **A** CAUTION

• The brake signal is not a safety-related element. You must design the system so that a hazardous condition does not occur even if the brake signal fails in the HWBB state. Also, if a Servomotor with a Brake is used, keep in mind that the brake in the Servomotor is used only to prevent the moving part from being moved by gravity or an external force and it cannot be used to stop the Servomotor. 11.2.10 Stopping Methods

# 11.2.10 Stopping Methods

If the /HWBB1 or /HWBB2 signal turns OFF and the HWBB operates, the Servomotor will stop according to the stop mode that is set for stopping the Servomotor when the servo turns OFF (Pn001 =  $n.\Box\Box\Box\Box$ X). However, if the dynamic brake is enabled (Pn001 =  $n.\Box\Box\Box\Box$ 0 or  $n.\Box\Box\Box\Box$ 1), observe the following precautions.

# **A** CAUTION

- The dynamic brake is not a safety-related element. You must design the system so that a
  hazardous condition does not occur even if the Servomotor coasts to a stop in the HWBB
  state. Normally, we recommend that you use a sequence that returns to the HWBB state
  after stopping for a reference.
- If the application frequently uses the HWBB, stopping with the dynamic brake may result in the deterioration of elements in the SERVOPACK. To prevent internal elements from deteriorating, use a sequence in which the HWBB state is returned to after the Servomotor has come to a stop.

# 11.2.11 ALM (Servo Alarm) Signal

The ALM (Servo Alarm) signal is not output in the HWBB state.

# 11.3

# **EDM1** (External Device Monitor)

The EDM1 (External Device Monitor) signal is used to monitor failures in the HWBB. Connect the monitor signal as a feedback signal, e.g., to the Safety Unit.

Note: To meet performance level e (PLe) in EN ISO 13849-1 and SIL3 in IEC 61508, the EDM1 signal must be monitored by the host controller. If the EDM1 signal is not monitored by the host controller, the level will be safety performance level c (Plc) and SIL1.

### • Failure Detection Signal for EDM1 Signal

The relationship between the EDM1, /HWBB1, and /HWBB2 signals is shown below.

Detection of failures in the EDM1 signal circuit can be achieved by using the four status of the EDM1 signal in the following table. A failure can be detected by checking the failure status, e.g., when the power supply is turned ON.


Signal	Logic			
/HWBB1	ON	ON	OFF	OFF
/HWBB2	ON	OFF	ON	OFF
EDM1	OFF	OFF	OFF	ON

# **MARNING**

• The EDM1 signal is not a safety output. Use it only for monitoring for failures.

# 11.3.1 EDM1 Output Signal Specifications

If an HWBB is requested by turning OFF the two HWBB input signal channels (/HWBB1 and /HWBB2) when the safety function is operating normally, the EDM1 output signal will be turned ON within 8 ms.



11.4.1 Connection Example


# 11.4

# **Applications Examples for Safety Functions**

This section provides examples of using the safety functions.

# 11.4.1 Connection Example

In the following example, a Safety Unit is used and the HWBB operates when the guard is opened.



When the guard is opened, both the /HWBB1 and the /HWBB2 signals turn OFF, and the EDM1 signal turns ON. Because the feedback circuit is ON while the guard is closed, the Safety Unit is reset, the /HWBB1 and the / HWBB2 signals turn ON, and the operation is enabled.


Note: The EDM1 signal is used as a source output. Connect the EDM1 so that the current flows from EMD1+ to EMD1-.

# 11.4.2 Failure Detection Method

If a failure occurs (e.g., the /HWBB1 or the /HWBB2 signal remains ON), the Safety Unit is not reset when the guard is closed because the EDM1 signal remains OFF. Therefore starting is not possible and a failure is detected.

In this case the following must be considered: an error in the external device, disconnection of the external wiring, short-circuiting in the external wiring, or a failure in the SERVOPACK. Find the cause and correct the problem.

# 11.4.3 Procedure



# 11.5 Validating Safety Functions

When you commission the system or perform maintenance or SERVOPACK replacement, you must always perform the following validation test on the HWBB after completing the wiring. (It is recommended that you keep the confirmation results as a record.)

- When the /HWBB1 and /HWBB2 signals turn OFF, confirm that the Digital Operator displays **Hbb** and that the Servomotor does not operate.
- Monitor the ON/OFF status of the /HWBB1 and /HWBB2 signals.
   If the ON/OFF status of the signals do not coincide with the display, the following must be considered: an error in the external device, disconnection of the external wiring, short-circuiting in the external wiring, or a failure in the SERVOPACK. Find the cause and correct the problem.

Refer to the following sections for details on the monitor.


- 9.2.3 I/O Signal Monitor on page 9-5
- Confirm that the EDM1 signal is OFF while in normal operation by using the feedback circuit input display of the connected device.

# 11.6

# **Connecting a Safety Function Device**

Use the following procedure to connect a safety function device.

1. Remove the Safety Jumper Connector from the connector for the safety function device (CN8).



2. Connect the safety function device to the connector for the safety function device (CN8).

Note: If you do not connect a safety function device, leave the Safety Jumper Connector connected to the connector for the safety function device (CN8). If the SERVOPACK is used without the Safety Jumper Connector connected to CN8, no current will be supplied to the Servomotor and no motor torque will be output. In this case, **Hbb** will be displayed on the Digital Operator.

# EtherCAT Communications

This chapter provides basic information on EtherCAT communications.

12.1	Ether	CAT Slave Information12-2	
12.2	Ether	CAT State Machine12-3	
12.3	EtherC	CAT (CoE) Communications Settings12-5	
		Normal Device Recognition Process at Startup	
12.4	PDO N	Mappings12-6	
	12.4.1 12.4.2	Setting Procedure for PDO Mappings 12-7 Default PDO Mappings	
12.5	Synch	ronization with Distributed Clocks 12-8	
	_		
12.6	Emergency Messages 12-11		

## 12.1

## **EtherCAT Slave Information**


You can use EtherCAT slave information files (XML format) to configure the EtherCAT master. The XML file contains general information on EtherCAT communications settings that are related to the SERVOPACK settings.

The following file is provided for the SERVOPACK.

SERVOPACK	File Name
SGD7S-□□□DA0□	Yaskawa_SGD7S-xxxDA0xxxxF64.xml

## 12.2 EtherCAT State Machine

The EtherCAT state machine is used to manage the communications states between the master and slave applications when EtherCAT communications are started and during operation, as shown in the following figure. Normally, the state changes for requests from the master.



State	Description
INIT	<ul><li>Mailbox communications are not possible.</li><li>Process data communications are not possible.</li></ul>
INIT => PRE-OP	<ul> <li>The master sets the DL address and Sync Manager channels for mailbox communications.</li> <li>The master initializes DC clock synchronization.</li> <li>The master requests the Pre-Operational state.</li> <li>The master sets the AL control register.</li> <li>The slaves check whether the mailbox was initialized correctly.</li> </ul>
PRE-OPERATIONAL (PREOP)	<ul><li>Mailbox communications are possible.</li><li>Process data communications are not possible.</li></ul>
PREOP => SAFEOP	<ul> <li>The master sets the Sync Manager channels and FMMU channels for process data.</li> <li>The master uses SDOs to set the PDO mappings and the Sync Manager PDO Assignment parameters.</li> <li>The master requests the Safe-Operational state.</li> <li>The slaves check whether the Sync Manager channels for process data communications and, if required, the distributed clock settings are correct.</li> </ul>
SAFE-OPERA- TIONAL (SAFEOP)	<ul> <li>Mailbox communications are possible.</li> <li>Process data communications are possible. However, only the input data is valid. The output data is still not valid.</li> </ul>
SAFEOP => OP	<ul><li>The master sends valid output data.</li><li>The master requests the Operational state.</li></ul>
OPERATIONAL (OP)	<ul><li>Mailbox communications are possible.</li><li>Process data communications are possible.</li></ul>

- The SERVOPACK does not support EtherCAT Read/Write commands (APRW, FPRW, BRW, and LRW).
   For SDO and PDO communications through the EtherCAT data link layer, the FMMUs and Sync Managers must be set as follows:

#### • Sync Manager Settings

Sync Manager	Assignment (Fixed)	Size	Start Address (Fixed)
Sync Manager 0	Assigned to Receive Mailbox	128 bytes (fixed)	0x1000
Sync Manager 1	Assigned to Transmit Mailbox	128 bytes (fixed)	0x1080
Sync Manager 2	Assigned to Receive PDOs	0 to 256 bytes (0 to 200 bytes*)	0x1100
Sync Manager 3	Assigned to Transmit PDOs	0 to 256 bytes (0 to 200 bytes*)	0x1400 (0x1358*)


<sup>\*</sup> This is the size and first address for a SERVOPACK with a revision number (object 1018 hex: 03 hex) of 0x00020000 or lower. This setting can also be used with a revision number (object 1018 hex: 03 hex) of 0x00030001 or higher.

<sup>•</sup> FMMU Settings

FMMU	Setting
FMMU 0	Mapped in receive PDO (RxPDO) area.
FMMU 1	Mapped in transmit PDO (TxPDO) area.
FMMU 2	Mapped to the mailbox status.

## 12.3 EtherCAT (CoE) Communications Settings

You can use EtherCAT secondary addresses (station aliases) to identify devices or to specify addresses.



### 12.3.1 Normal Device Recognition Process at Startup

When communications are started, the master uses auto-increment addressing to detect the slaves. The Identity objects read from the slaves are compared with the master configuration information (set in advance with an EtherCAT configuration tool). Therefore, the slaves must normally be connected in the network in the same order as they appear in the master configuration. However, you can define station aliases to enable using other network topologies.

### 12.3.2 Application Example

With a machining center, there may be two identical drives for operation in the X and Y directions. When a device is replaced, there is a chance that the cable may be connected in the wrong order. To prevent the drives from receiving incorrect process data, you can use station aliases to use explicit addresses for the drives.

### 12.3.3 Device Recognition with Station Aliases

The master uses auto-increment addressing to read the station aliases. It then compares the detected station aliases with the master configuration to get the topology that was set as the network topology.

Station Alias Register (0x0012)

The station alias is set in the ESC Configured Station Alias register when the power supply is turned ON.

The value of the register can be read as follows:


Configured station alias =  $(S1 \text{ set value}) \times 16 + (S2 \text{ set value})$ 

## 12.4

## **PDO Mappings**

The process data that is used in process data communications is defined in the PDO mappings. POD mappings are definitions of the applications objects that are sent with PDOs. The PDO mapping tables are in indexes 1600 hex to 1603 hex for the RxPDOs and indexes 1400 hex to 1403 hex for the TxPDOs in the object dictionary.


The following figure shows an example of PDO mappings.



In addition to the above PDO mappings, PDOs have to be assigned to the Sync Managers to exchange EtherCAT process data.

The Sync Manager PDO assignment objects (1C12 hex and 1C13 hex) establish the relationship between these PDOs and the Sync Managers.

The following figure shows an example of a Sync Manager and the PDO mappings.



## **M** CAUTION

 The PDO mapping objects (indexes 1600 hex to 1603 hex and 1A00 hex to 1A03 hex) and the Sync Manager PDO assignment objects (index 1C12 hex and 1C13 hex) can be written only in Pre-Operation state.

### 12.4.1 Setting Procedure for PDO Mappings

- 1. Disable the assignments between the Sync Manager and PDOs. (Set subindex 0 of objects 1C12 hex to 1C13 hex to 0.)
- 2. Set all of the mapping entries for the PDO mapping objects. (Set objects 1600 hex to 1603 hex and 1A00 hex to 1A03 hex.)
- 3. Set the number of mapping entries for the PDO mapping objects. (Set subindex 0 of objects 1600 hex to 1603 hex and 1A00 hex to 1A03 hex.)
- 4. Set the assignments between the Sync Manager and PDOs. (Set subindex 1 of objects 1C12 hex to 1C13 hex.)
- 5. Enable the assignments between the Sync Manager and PDOs. (Set subindex 0 of objects 1C12 hex to 1C13 hex to 1.)

### 12.4.2 Default PDO Mappings

The following table shows the default PDO mappings for the SERVOPACK. These initial settings are also defined in the EtherCAT slave information file (XML format).

• 1st PDO Mapping (Position, Velocity, Torque, Torque Limit, and Touch Probe)

RxPDO (1600 hex)	Controlword (6040 hex)	Target position (607A hex)	Target velocity (60FF hex)	Target torque (6071 hex)	Maxtorque (6072 hex)	Mode of operation (6060 hex)	Padding (8 bits)	Touch probe function (60B8 hex)
TxPDO (1A00 hex)	Statusword (6041 hex)	Position actual value (6064 hex)	Torque actual value (6077 hex)	Following error actual value (60F4 hex)	Modes of operation display (6061 hex)	Padding (8 bits)	Touch probe status (60B9 hex)	Touch probe value (60BA hex)

• 2nd PDO Mapping (Cyclic Synchronous Position): Default PDO Assignments

RxPDO (1601 hex)	Controlword (6040 hex)	Target position (607A hex)	
TxPDO (1A01 hex)	Statusword (6041 hex)	Position actual value (6064 hex)	

• 3rd PDO Mapping (Cyclic Synchronous Velocity)

RxPDO	Controlword	Target velocity
(1602 hex)	(6040 hex)	(60FF hex)
TxPDO (1A02 hex)	Statusword (6041 hex)	Position actual value (6064 hex)

4th PDO Mapping (Cyclic Synchronous Torque)

RxPDO (1603 hex)	Controlword (6040 hex)	Target torque (6071 hex)	
TxPDO (1A03 hex)	Statusword (6041 hex)	Position actual value (6064 hex)	Torque actual value (6077 hex)

## 12.5


## Synchronization with Distributed Clocks

The synchronization of EtherCAT communications is based on a mechanism called a distributed clock. With the distributed clock, all devices are synchronized with each other by sharing the same reference clock. The slave devices synchronize the internal applications to the Sync0 events that are generated according to the reference clock.

You can use the following synchronization modes with EtherCAT (CoE). You can change the synchronization mode in the Sync Control registers (ESC registers 0x980 and 0x981).

- Free-Run (ESC register 0x980 = 0x0000) In Free-Run mode, the local cycle is independent from the communications cycle and master cycle.
- DC Mode (ESC register 0x980 = 0x0300)
   In this mode, the SERVOPACK is synchronized with the host controller (master) on the Sync0 event.


The following figure gives a timing chart for DC synchronization.




Index	Sub- index	Name	Access	PDO Map- ping	Data Type	Description
	Sync	manager channel 2 sy	nchronizati	on		
	1	Synchronization type	RO	No	UINT	Current status of DC mode 0: Free-run 2: DC mode (synchronous with Sync0)
1C32 hex 3	2	Cycle time	RO	No	UDINT	Sync0 event cycle [ns] (The value is set by the master via an ESC register.) Range: 125,000 × n (n = 1 to 32) [ns]
	Shift time	RO	No	UDINT	125,000 [ns] (fixed) The time between the Sync0 event and Outputs Valid (i.e., the time from Sync0 until the output data is input to the SER-VOPACK).	
	6	Calc and copy time	RO	No	UDINT	62,500 [ns] (fixed) The time from the Sync0 event until the output data from Sync Manager 2 is read.
	Sync	manager channel 3 sy	nchronizati	on		
1C33 hex 6	3	Shift time	RW	No	UDINT	125,000 × n (n = 1 to 32) [ns] Range: 0 to (Sync0 event cycle - 125,000) [ns] The time between the Sync0 event and Inputs Latch (i.e., when the input data is obtained from the SERVOPACK).
	6	Calc and copy time	RO	No	UDINT	62,500 [ns] (fixed) The time for copying the input process data to the Sync Manager 3 area.

## Example of PDO Data Exchange Timing in DC Mode

• DC Cycle Time = 1 ms, Input Shift Time = 500 μs



• DC Cycle Time = 125  $\mu$ s, Input Shift Time = 0  $\mu$ s



## 12.6 Emergency Messages

Emergency messages are triggered by alarms and warnings detected within the SERVOPACK. They are sent via the mailbox interface.

An emergency message consists of eight bytes of data as shown in the following table.

Byte	0	1	2	3	4	5	6	7
	_		Error reg-		Mar	nufacturer-sp	pecific error t	field
Descrip- tion		ncy error 00 hex)*1	ister (object 1001 hex)	Reserved.	SERVOPA warning	CK alarm/ code <sup>*2</sup>	Rese	rved.

<sup>\*1.</sup> The manufacturer-specific error code is always FF00 hex.

<sup>\*2.</sup> For details on SERVOPACK alarms and warnings, refer to the following sections.

<sup>15.2.2</sup> Troubleshooting Alarms on page 15-11


<sup>15.3.2</sup> Troubleshooting Warnings on page 15-46

13.1	Devic	e Control
	13.1.1 13.1.2 13.1.3	State Machine Control Commands
13.2	Mode	es of Operation13-5
	13.2.1 13.2.2	Related Objects
13.3	Positi	on Control Modes 13-6
	13.3.1 13.3.2 13.3.3	Profile Position Mode
13.4	Homi	ng13-14
13.4	Homin 13.4.1 13.4.2	ng        13-14         Related Objects        13-14         Homing Method (6098 Hex)        13-14
13.4	13.4.1 13.4.2	Related Objects
	13.4.1 13.4.2	Related Objects
	13.4.1 13.4.2 <b>Veloc</b> 13.5.1 13.5.2	Related Objects       13-14         Homing Method (6098 Hex)       13-14         ity Control Modes       13-17         Profile Velocity Mode       13-17
13.5	13.4.1 13.4.2 <b>Veloc</b> 13.5.1 13.5.2	Related Objects

13.8	Digita	l I/O Signals13-22
13.9	Touch	Probe
		Related Objects
		for a Touch Probe13-24
13.10	Fully-	Closed Loop Control13-25

## 13.1 Device Control

You use the *controlword* (6040 hex) to execute device control for the Servo Drive according to the following state transitions. You can use the *statusword* (6041 hex) to monitor the device status of the Servo Drive.



- \*1. In the Quick Stop Active state, the SERVOPACK automatically moves to the Switch ON Disabled state in the following cases:
  - The main power supply was turned OFF.
  - The HWBB signal was input.
  - The motor was stopped.
- \*2. In the Switched ON state, the SERVOPACK automatically moves to the Switch ON Disabled state in the following cases:
  - The main power supply was turned OFF.
  - The HWBB signal was input.
  - Motor operation was already enabled by the Digital Operator or the SigmaWin+.
- \*3. In the Ready to Switch ON state, the SERVOPACK moves to the next state in the following cases:
  - The main circuit power supply is ON.
  - The EtherCAT state machine (ESM) is in the Operational state.
  - The Servomotor is not being operated by the Digital Operator or the SigmaWin+.
- \*4. In the Operation Enabled state, the SERVOPACK automatically moves to the Switch ON Disabled state in the following cases:
  - The main power supply was turned OFF.
  - The HWBB signal was input.
- Note: 1. \_\_\_\_: The states are shown in white boxes.
  - 2. STW indicates the statusword (6041 hex).
  - 3. : Underlines indicate control commands in the *controlword* (6040 hex).

## 13.1.1 State Machine Control Commands

Command	Bits in Controlword (6040 Hex)						
Command	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0		
Shutdown	0	_	1	1	0		
Switch ON	0	0	1	1	1		
Switch ON + Enable Operation	0	1	1	1	1		
Disable Voltage	0	_	_	0	_		
Quick Stop	0	_	0	1	_		
Disable Operation	0	0	1	1	1		
Enable Operation	0	1	1	1	1		
Fault Reset	0 → 1	_	_	_	_		

## 13.1.2 Bits in Statusword (6041 Hex)

Bit	Data Description	Remarks
0	Ready to Switch ON	
1	Switched ON	
2	Operation Enabled	
3	Fault	
4	Voltage Enabled	
5	Quick Stop	
6	Switch ON Disabled	
7	Warning	Refer to the following section for details.
8	Active Mode Stop	☐ 14.6 Device Control on page 14-21
9	Remote	
10	Target Reached	
11	Internal Limit Active	
12	Operation Mode Specific	
13	Operation wode Specific	
14	Torque Limit Active	
15	Safety Active	

## 13.1.3 Related Objects

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6040 hex	0	Controlword	RW	Yes	_	UINT
6041 hex	0	Statusword	RO	Yes	_	UINT
605A hex	0	Quick stop option code	RW	No	_	INT
605B hex	0	Shutdown option code	RW	No	_	INT
605C hex	0	Disable operation option code	RW	No	_	INT
605D hex	0	Halt option code	RW	No	_	INT
605E hex	0	Fault reaction option code	RW	No	_	INT

## 13.2 Modes of Operation

The SERVOPACK supports the following modes of operation.

- Profile Position Mode
- · Homing Mode
- Interpolated Position Mode
- Profile Velocity Mode
- Torque Profile Velocity Mode
- Cyclic Sync Position Mode
- Cyclic Sync Velocity Mode
- Cyclic Sync Torque Mode

### 13.2.1 Related Objects

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6060 hex	0	Modes of operation	RW	Yes	_	SINT
6061 hex	0	Modes of operation display	RO	Yes	-	SINT
6502 hex	0	Supported drive modes	RO	No	-	UDINT

## 13.2.2 Dynamic Mode Changes

You can change the operation mode with *modes of operation* (6060 hex). The master must update all operation mode-specific process data objects at the same time when it changes the operation mode during motor operation. If the master selects a new operation mode, the SER-VOPACK will change to the new operation mode immediately. The following table describes operation when the operation mode is changed to a new mode.


New Operation Mode	Operation When Operation Mode Is Changed
Profile Position Mode	Controlword bit 4 = 0: The motor is stopped in the current position control mode.  Controlword bit 4 = 1: A new positioning operation is started immediately.
Homing Mode	Controlword bit 4 = 0: The motor is stopped in the current position control mode.  Controlword bit 4 = 1: Homing is started immediately.
Interpolated Position Mode	Controlword bit 4 = 0: The motor is stopped in the current position control mode.  Controlword bit 4 = 1: A new positioning operation is started immediately.
Profile Velocity Mode	The new operation mode is started immediately.
Torque Profile Velocity Mode	The new operation mode is started immediately.
Cyclic Sync Position Mode	The new operation mode is started immediately.
Cyclic Sync Velocity Mode	The new operation mode is started immediately.
Cyclic Sync Torque Mode	The new operation mode is started immediately.

## 13.3 Position Control Modes

### 13.3.1 Profile Position Mode

The Profile Position Mode is used to position to the target position at the profile velocity and the profile acceleration.

The following figure shows the block diagram for the Profile Position Mode.




Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6040 hex	0	Controlword	RW	Yes	_	UINT
6041 hex	0	Statusword	RO	Yes	_	UINT
607A hex	0	Target position	RW	Yes	Pos unit	DINT
	Software posi	tion limit				
607D hex	1	Min position limit	RW	No	Pos unit	DINT
	2	Max position limit	RW	No	Pos unit	DINT
607F hex	0	Max profile velocity	RW	Yes	Vel unit	UDINT
6081 hex	0	Profile velocity	RW	Yes	Vel unit	UDINT
6083 hex	0	Profile acceleration	RW	Yes	Acc unit	UDINT
6084 hex	0	Profile deceleration	RW	Yes	Acc unit	UDINT
6085 hex	0	Quick stop deceleration	RW	Yes	Acc unit	UDINT
6086 hex	_	Motion profile type	RW	Yes	_	INT
60A4 hex	Profile jerk		•			
	1	Profile jerk 1	RW	No	%	UDINT

In the Profile Position Mode, the following two methods can be used to start positioning.


#### ◆ Single Set Point (When Change Set Immediately Bit in Controlword Is 1)

When a new command is input to the New Set Point bit (bit 4) in *controlword* during positioning, positioning for the new command is started immediately.



#### ◆ Set of Set Points (When Change Set Immediately Bit in Controlword Is 0)


When a new command is input in the New Set Point bit (bit 4) in *controlword* during positioning, positioning for the new command is started as soon as the current positioning operation is completed. The dotted line in the following figure shows the actual speed if the Change of Set Point bit (bit 9) is set to 1.



#### 13.3.1 Profile Position Mode

#### ◆ SPOSING (S-curve Acceleration/Deceleration Positioning)

If you set *Motion profile type* to 2, S-curve acceleration/deceleration will be used for positioning to *Target position*.



Acceleration time: Tacc = Profile velocity (6081 hex)

/Profile acceleration (6083 hex)

S-curve acceleration time: Taj = Tacc  $\times$  Profile jerk (60A4 hex)

Deceleration time: Tdec = Profile velocity (6081 hex)

/Profile deceleration (6084 hex)

S-curve deceleration time:  $Tdj = Tdec \times Profile jerk (60A4 hex)$ 



- 1. If you change the *Target position* (607A hex), *Profile velocity* (6081 hex), *Profile acceleration* (6083 hex), or *Profile deceleration* (6084 hex), do so either while positioning is stopped or while positioning at a constant speed.
- 2. Set the S-curve acceleration/deceleration time in Profile jerk (60A4 hex).

### 13.3.2 Interpolated Position Mode

The Interpolated Position Mode is used to control multiple coordinated axes or to control a single axis that requires time interpolation of the set point data. There are the following two submodes for the Interpolated Position Mode.

Interpolation submode select (60C0 hex) is used to change the submode. Refer to the following section for details.


14.10 Interpolated Position Mode on page 14-35

Inter	polated Position Mode	Number of Data	Number of Profiles
Mode 1	No position reference filter	1	1
Mode 1	Position reference filter	l	l
Mode 2	No position reference filter	1 to 254	0
Mode 2	Position reference filter	1 10 254	2

#### Mode 1

This submode normally uses a time (communications) synchronization mechanism to synchronize the Servo Drives. The Interpolation Time Period defines the update cycle of the Interpolation Data (i.e., the interpolation position). The interpolation processing in the SERVOPACK is based on this setting. The Interpolation Data is interpreted as an absolute value.

The following figure shows the block diagram for mode 1.



### ◆ Related Objects

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6040 hex	0	Controlword	RW	Yes	_	UINT
6041 hex	0	Statusword	RO	Yes	_	UINT
60C1 hex	1	Interpolation data record	RW	Yes	Pos unit	DINT

#### 13.3.2 Interpolated Position Mode


O 11 1	•		
Continued	trom	previous	page.

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type	
	Interpolation t	ime period	•	•	•		
60C2 hex	1	Interpolation time period value	RO	No	_	USINT	
	2	Interpolation time index	RO	No	-	SINT	
	Software position limit						
607D hex	1	Min position limit	RW	No	Pos unit	DINT	
	2	Max position limit	RW	No	Pos unit	DINT	
6084 hex	0	Profile deceleration	RW	Yes	Acc unit	UDINT	
6085 hex	0	Quick stop deceleration	RW	Yes	Acc unit	UDINT	

#### Mode 2

This submode is used to perform interpolation feeding control for an individual axis. Unlike mode 1, mode 2 has reference input buffers (*interpolation data record for 1st profile* and *interpolation data record for 2nd profile*) that you can set to different interpolation positions (*interpolation data record*). The interpolation positions that are set in the reference input buffers are read each *interpolation time period* to perform interpolation processing.

The following figure shows the block diagram for mode 2.



#### Related Objects

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type	
6040 hex	0	Controlword	RW	Yes	-	UINT	
6041 hex	0	Statusword	RO	Yes	_	UINT	
	Interpolation time period						
60C2 hex	1	Interpolation time period value	RW	No	_	USINT	
	2	Interpolation time index	RW	No	-	SINT	

Continued from previous page.

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
	Interpolation	data configuration for 1st profile				
	1	Maximum buffer size	RO	No	_	UDINT
	2	Actual buffer size	RW	No	_	UDINT
	3	Buffer organization	RW	No	_	USINT
	4	Buffer position	RW	Yes	_	UINT
2730 hex	5	Size of data record	RO	No	-	USINT
	6	Buffer clear	RO	No	-	USINT
	7	Position data definition	RW	Yes	-	USINT
	8	Position data polarity	RW	Yes	_	USINT
	9	Behavior after reaching buffer position	RW	Yes	_	USINT
	Interpolation	data configuration for 2nd profile				
	1	Maximum buffer size	RO	No	_	UDINT
	2	Actual buffer size	RW	No	-	UDINT
	3	Buffer organization	RW	No	_	USINT
	4	Buffer position	RW	Yes	_	UINT
2731 hex	5	Size of data record	RO	No	_	USINT
	6	Buffer clear	RO	No	_	USINT
	7	Position data definition	RW	Yes	_	USINT
	8	Position data polarity	RW	Yes	_	USINT
	9	Behavior after reaching buffer position	RW	Yes	_	USINT
2732 hex	0	Interpolation profile select	RW	Yes	_	USINT
27C0 hex	1-254	Interpolation data record for 1st profile	RW	No	Pos unit	DINT
27C1 hex	1-254	Interpolation data record for 2 <sup>nd</sup> profile	RW	No	Pos unit	DINT
	Interpolation (	data read/write pointer position m	onitor			
2741 hex	1	Interpolation data read pointer position	RO	Yes	_	UINT
	2	Interpolation data write pointer position	RO	Yes	_	UINT
	Software pos	ition limit				
607D hex	1	Min position limit	RW	No	Pos unit	DINT
	2	Max position limit	RW	No	Pos unit	DINT
6084 hex	0	Profile deceleration	RW	Yes	Acc unit	UDINT
6085 hex	0	Quick stop deceleration	RW	Yes	Acc unit	UDINT

#### 13.3.3 Cyclic Synchronous Position Mode

#### ◆ Object Setting Procedure

The recommended object setting procedure to use mode 2 is given in the following table.


Step	Description
1	Set interpolation submode select (60C0 hex).
2	Set interpolation profile select (2732 hex).
3	Set interpolation data configuration for 1st profile (2730 hex) and interpolation data configuration for 2nd profile (2731 hex).
4	Set interpolation data record for 1st profile (27C0 hex) and interpolation data record for 2nd profile (27C1 hex).
5	Set mode of operation (6060 hex).
6	Set enable interpolation (6060 hex bit 4).

## 13.3.3 Cyclic Synchronous Position Mode

The Cyclic Synchronous Position Mode is used for the interpolated positioning in the same way as the Interpolated Position Mode. In this mode, speed and torque compensations can be specified by the master to enable speed and torque feedforward.

The *interpolation time period* defines the interval at which the target position is updated. Interpolation is performed in the SERVOPACK according to this setting. The target position is interpreted as an absolute value.

The following figure shows the block diagram for the Cyclic Synchronous Position Mode.



#### ◆ Related Objects

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
607A hex	0	Target position	RW	Yes	Pos unit	DINT
	Software posit	ion limit				
607D hex	1	Min position limit	RW	No	Pos unit	DINT
	2	Max position limit	RW	No	Pos unit	DINT
6084 hex	0	Profile deceleration	RW	Yes	Acc unit	UDINT
6085 hex	0	Quick stop deceleration	RW	Yes	Acc unit	UDINT

#### 13.3.3 Cyclic Synchronous Position Mode

Continued from previous page.


Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
60B1 hex	0	Velocity offset	RW	Yes	Vel unit	DINT
60B2 hex	0	Torque offset	RW	Yes	Trq unit	INT
	Interpolation t	ime period				
60C2 hex	1	Interpolation time period value	RO	No	_	USINT
	2	Interpolation time index	RO	No	_	SINT

#### 13.4.1 Related Objects

## 13.4

## **Homing**

The following figure shows the relationship between the input objects and the output objects in the Homing Mode. You can specify the speeds, acceleration rate, and homing method. You can also use *home offset* to offset zero in the user coordinate system from the home position.



## 13.4.1 Related Objects

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6040 hex	0	Controlword	RW	Yes	-	UINT
6041 hex	0	Statusword	RO	Yes	-	UINT
607C hex	0	Home offset	RW	No	Pos unit	DINT
6098 hex	0	Homing method	RW	Yes	-	SINT
	Homing speed	ls				
6099 hex	1	Speed during search for switch	RW	Yes	Vel unit	UDINT
	2	Speed during search for zero	RW	Yes	Vel unit	UDINT
609A hex	0	Homing acceleration	RW	Yes	Acc unit	UDINT

## 13.4.2 Homing Method (6098 Hex)

Value	Definition	Description
0	_	No homing (default setting)
		With this method, homing starts in the negative direction if the negative limit switch is inactive. The home position is the first index pulse that is detected after the negative limit switch becomes inactive.
1	Homing with the negative limit switch and index pulse	Index pulse Negative limit switch (N-OT)

Continued from previous page.

Value	Definition	Description
		With this method, homing starts in the positive direction if the positive limit switch is inactive. The home position is the first index pulse that is detected after the positive limit switch becomes inactive.
	Homing with the posi-	
2	tive limit switch and index pulse	
		Index pulse Positive limit switch
		(P-OT) With methods 7 to 10, homing starts in the positive direction. However,
		if the /Home signal is already active when homing is started, the initial homing direction depends on the required edge.  The home position will be the index pulse on either the rising or falling edge side of the /Home signal.  If the initial movement direction is away from the /Home signal, the motor will reverse direction when the limit switch in the movement direction is input.
7 to 10	Homing with the home switch input (/Home) signal and index pulse and starting in the positive direction	
		Index pulse /Home signal Positive limit switch (P-OT)
		These methods are similar to methods 7 to 10 except that homing starts in the negative direction.
11 to 14	Homing with the home switch input (/Home) signal and index pulse and starting in the negative direction	
		Index pulse // /Home signal Negative limit switch (N-OT)

#### 13.4.2 Homing Method (6098 Hex)

Continued from previous page.

Value	Definition	Description
24	Homing with the home switch input (/Home) signal and starting in the positive direction	This method is same as method 8 except that the home position does not depend on the index pulse. Here, it depends only on changes in the relevant /Home signal or limit switch.  /Home signal Positive limit switch (P-OT)
28	Homing with the home switch input (/Home) signal and starting in the negative direction	This method is same as method 12 except that the home position does not depend on the index pulse. Here, it depends only on changes in the relevant /Home signal or limit switch.  /Home signal Negative limit switch (N-OT)
33, 34	Homing with the index pulse	Index pulse
35	Homing with the cur- rent position	With this method, the current position is defined as the home position. You can execute this method even if the Servo Drive is not in the Operation Enabled state.


Note: The index pulse is the encoder's zero signal (phase C).

## 13.5 Velocity Control Modes

### 13.5.1 Profile Velocity Mode

In the Profile Velocity Mode, the speed is output according to the *profile acceleration* and *profile deceleration* until it reaches the *target velocity*.

The following figure shows the block diagram for the Profile Velocity Mode.




Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
60FF hex	0	Target velocity	RW	Yes	Vel unit	DINT
607F hex	0	Max profile velocity	RW	Yes	Vel unit	UDINT
6083 hex	0	Profile acceleration	RW	Yes	Acc unit	UDINT
6084 hex	0	Profile deceleration	RW	Yes	Acc unit	UDINT
6085 hex	0	Quick stop deceleration	RW	Yes	Acc unit	UDINT
606B hex	0	Velocity demand value	RO	Yes	Vel unit	DINT
606C hex	0	Velocity actual value	RO	Yes	Vel unit	DINT
606D hex	0	Velocity window	RW	No	Vel unit	UINT
606E hex	0	Velocity window time	RW	No	ms	UINT

## 13.5.2 Cyclic Synchronous Velocity Mode

In the Cyclic Synchronous Velocity Mode, the master provides the target speed to the Servo Drive, which performs speed control. In this mode, a torque compensation can be specified by the master to enable torque feedforward.

The following figure shows the block diagram for the Cyclic Synchronous Velocity Mode.



Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
60FF hex	0	Target velocity	RW	Yes	Vel unit	DINT
60B1 hex	0	Velocity offset	RW	Yes	Vel unit	DINT
60B2 hex	0	Torque offset	RW	Yes	0.1% *	INT
6084 hex	0	Profile deceleration	RW	Yes	Acc unit	UDINT
6085 hex	0	Quick stop deceleration	RW	Yes	Acc unit	UDINT
606B hex	0	Velocity demand value	RO	Yes	Vel unit	DINT
606C hex	0	Velocity actual value	RO	Yes	Vel unit	DINT
606D hex	0	Velocity window	RW	No	Vel unit	UINT
606E hex	0	Velocity window time	RW	No	ms	UINT


<sup>\*</sup> The rated motor torque is 100%.

## 13.6 Torque Control Modes

## 13.6.1 Profile Torque Mode

In the Profile Torque Mode, the torque is output up to the *target torque* according to the *torque* slope setting.

The following figure shows the block diagram for the Profile Torque Mode.




Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6071 hex	0	Target torque	RW	Yes	0.1%*	INT
6087 hex	0	Torque slope	RW	Yes	0.1%/s*	UDINT
6074 hex	0	Torque demand value	RO	Yes	0.1%*	INT
6077 hex	0	Torque actual value	RO	Yes	0.1%*	INT
6072 hex	0	Max torque	RW	Yes	0.1%*	UINT
60E0 hex	0	Positive torque limit value	RW	Yes	0.1%*	UINT
60E1 hex	0	Negative torque limit value	RW	Yes	0.1%*	UINT

<sup>\*</sup> The rated motor torque is 100%.

## 13.6.2 Cyclic Sync Torque Mode

In the Cyclic Synchronous Torque Mode, the master provides the *target torque* to the Servo Drive, which performs torque control.




Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6071 hex	0	Target torque	RW	Yes	0.1%*	INT
6074 hex	0	Torque demand value	RO	Yes	0.1%*	INT
6077 hex	0	Torque actual value	RO	Yes	0.1%*	INT
60B2 hex	0	Torque offset	RW	Yes	0.1%*	INT
6072 hex	0	Max torque	RW	Yes	0.1%*	UINT
60E0 hex	0	Positive torque limit value	RW	Yes	0.1%*	UINT
60E1 hex	0	Negative torque limit value	RW	Yes	0.1%*	UINT

<sup>\*</sup> The rated motor torque is 100%.

## 13.7 Torque Limits

The following figure shows the block diagram for the torque limits. The torque is limited by the lowest limit value.



Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
6072 hex	0	Max torque	RW	Yes	0.1%*	UINT
60E0 hex	0	Positive torque limit value	RW	Yes	0.1%*	UINT
60E1 hex	0	Negative torque limit value	RW	Yes	0.1%*	UINT

st The rated motor torque is 100%.

## 13.8 Digital I/O Signals

The digital inputs and digital outputs are used to control the I/O signals of the CN1 connector on the SERVOPACK.

Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
60FD hex	0	Digital inputs	RO	Yes	_	UDINT
	Digital outputs	3				
60FE hex	1	Physical outputs	RW	Yes	_	UDINT
	2	Bit mask	RW	No	_	UDINT

## 13.9 Touch Probe

You can latch the feedback position with the following trigger events.

- Trigger with probe 1 input (Probe 1 Latch Input (/Probe1) signal)
- Trigger with probe 2 input (Probe 2 Latch Input (/Probe2) signal)
- Trigger with encoder zero signal (phase C)

The following two touch probe latches can be used at the same time.

#### ■ Touch Probe 1 Latch

- Latch control object: 60B8 hex (bits 0 to 7)
- Latch status object: 60B9 hex (bits 0 to 7)
- The latched position is always stored in touch probe 1 position value (60BA hex).
- Trigger signal: Encoder zero signal or /Probe1 signal

#### ■ Touch Probe 2 Latch

- Latch control object: 60B8 hex (bits 8 to 15)
- Latch status object: 60B9 hex (bits 8 to 15)
- The latched position is always stored in touch probe 2 position value (60BC hex).
- Trigger signal: /Probe2 signal

You can change the connector pin assignments and the /Probe1 and /Probe2 signal logic in the Probe 1 Latch Input Signal parameter (Pn511 =  $\square\square$ X $\square$ ) and the Probe 2 Latch Input Signal parameter (Pn511 =  $\square$ X $\square$ D).


Note: Touch probe 1 cannot be used during homing. If touch probe 1 was already active, it will be switched OFF.

### 13.9.1 Related Objects


Index	Subindex	Name	Access	PDO Mapping	Unit	Data Type
60B8 hex	0	Touch probe function	RW	Yes	-	UINT
60B9 hex	0	Touch probe status	RO	Yes	_	UINT
60BA hex	0	Touch probe 1 position value	RO	Yes	Pos unit	DINT
60BC hex	0	Touch probe 2 position value	RO	Yes	Pos unit	DINT

## 13.9.2 Example of Execution Procedure for a Touch Probe

• Single Trigger Mode (60B8 hex bit 1 = 0 or bit 9 = 0)




• Continuous Trigger Mode (60B8 hex bit 1 = 1 or bit 9 = 1)



## 13.10 Fully-Closed Loop Control

The following figure shows the block diagram for the fully-closed loop control.



The basic setting procedure for the related parameters is given in the following table.

Step	Description	Parameter Setting
1	Set the speed feedback method to use during fully-closed loop control.	Fully-closed Control Selections (Pn22A (222A hex))
2	Set the motor rotation direction.	Rotation Direction Selection (Pn000 (2000 hex) = n. \$\Pi\Pi\Pi\Pi\X\$) External Encoder Usage (Pn002 (2002 hex) = n. \$X\Pi\Pi\Pi\Pi\Pi\Pi\Pi\Pi\Pi\Pi\Pi\Pi\Pi\
3	Set the number of pitches (cycles) of the sine wave for the external encoder.	Number of External Scale Pitches (Pn20A (220A hex))
4	Set the position reference unit (electronic gear).	Position user unit (2701 hex)
5	Set the alarm detection level for the external encoder.	Motor-Load Position Deviation Overflow Detection Level (Pn51B (251B hex)) Multiplier per Fully-closed Rotation (Pn52A (252A hex))

# **Object Dictionary**

This chapter provides tables of the objects that are supported by an EtherCAT SERVOPACK. Each object is described.

14.1	Object Dictionary List14-3
14.2	General Objects
14.3	PDO Mapping Objects14-9
14.4	Sync Manager Communications Objects14-13
14.5	Manufacturer-Specific Objects14-17
14.6	
14.7	Profile Position Mode14-29
14.8	
14.9	Position Control Function 14-33
14.10	Interpolated Position Mode 14-35
14.11	Cyclic Synchronous Position Mode14-41
14.12	Profile Velocity/Cyclic Synchronous Velocity Mode 14-42
14.13	Profile Torque/Cyclic Synchronous Torque Mode14-43

14.14 Torque Limit Function14-44	
14.15 Touch Probe Function14-45	
14.16 Digital Inputs/Outputs14-47	
14.17 Dual Encoder Feedback14-49	

# 14.1 Object Dictionary List

The following table lists the dictionary objects.

Device type	Functional Classification	Object Name	Index	Refer to
Manufacturer device name		Device type	(1000 hex)	14.2
General Objects         Manufacturer software version         (100A hex)         14.2           Store parameters field         (1010 hex)         14.2           Restore default parameters         (1011 hex)         14.2           Identity object         (1018 hex)         14.2           Identity object         (1018 hex)         14.2           PDO Mapping Objects         Receive PDO mapping         (1600 hex to 1603 hex)         14.3           Transmit PDO mapping         (1600 hex to 14.03 hex)         14.4           Sync manager communication type         (1000 hex to 1603 hex)         14.4           Sync manager PDO assignment         (1612 hex and 1613 hex)         14.4           Sync manager synchronization         (1623 hex and 1613 hex)         14.4           Sync manager synchronization         (1601 hex)         14.5           SERVOPACK parameters         (2000 hex to 26FF hex)         14.5           User parameter configuration         (2700 hex)         14.5           Velocity user unit         (2700 hex)         14.5           Velocity user unit         (2700 hex)         14.5           SERVOPACK adjusting command object         (2710 hex)         14.5           SERVOPACK adjusting command object         (2710 hex)         14.5		Error register	(1001 hex)	14.2
Store parameters field   (1010 hex)   14.2     Restore default parameters   (1011 hex)   14.2     Identity object   (1018 hex)   14.2     Receive PDO mapping   (1600 hex to 1603 hex)     Transmit PDO mapping   (1600 hex to 1603 hex)     Transmit PDO mapping   (1600 hex to 1603 hex)   14.3     Sync manager communication type   (1000 hex)   14.4     Sync manager pDO assignment   (1721 hex and 1613 hex)     Sync manager synchronization   (1622 hex and 1613 hex)     Sync manager synchronization   (1623 hex)   14.4     Sync error setting   (10F1 hex)   14.4     Sync error setting   (10F1 hex)   14.5     SERVOPACK parameters   (2000 hex to 26FF hex)     User parameter configuration   (2700 hex)   14.5     User parameter configuration   (2700 hex)   14.5     Velocity user unit   (2701 hex)   14.5     SERVOPACK adjusting command object   (2710 hex)   14.5     SERVOPACK adjusting command object   (2710 hex)   14.5     SERVOPACK adjusting command object   (2710 hex)   14.6     Statusword   (6041 hex)   14.6     Statusword   (6041 hex)   14.6     Statusword   (6041 hex)   14.6     Statusword   (6056 hex)   14.6     Statusword   (6056 hex)   14.6     Disable operation option code   (6056 hex)   14.6     Shutdown option code   (6056 hex)   14.6     Halt option code   (6056 hex)   14.6     Halt option code   (6056 hex)   14.6     Fault reaction option code   (6056 hex)   14.6     Modes of operation display   (6061 hex)   14.6     Modes of operation display   (6061 hex)   14.6     Supported drive modes   (6076 hex)   14.7     Software position limit   (6070 hex)   14.7     Software position limit   (6076 hex)   14.7     Profile deceleration   (6083 hex)   14.7     Profile deceleration   (6083 hex)   14.7     Profile deceleration   (6083 hex)   14.7     Profile deceleration   (6088 hex)   14.8     Homing speeds   (6099 hex)   14.8		Manufacturer device name	(1008 hex)	14.2
Restore default parameters	General Objects	Manufacturer software version	(100A hex)	14.2
Identity object		Store parameters field	(1010 hex)	14.2
PDO Mapping Objects   Receive PDO mapping   (1600 hex to 1603 hex)   14.3   14.4   16.1   16.3   16.3   14.4   16.3   1		Restore default parameters	(1011 hex)	14.2
PDO Mapping Objects   Facebre PLO Imapping   1603 hex)   14.3   14.3   14.3   14.3   14.3   14.3   14.3   14.3   14.3   14.4   14.3   14.4   14.4   14.4   16.3   16.2   16.3		Identity object	(1018 hex)	14.2
Transmit PDO mapping	PDO Manning Objects	Receive PDO mapping		14.3
Sync Manager Communication Objects         Sync manager PDO assignment         (1C12 hex and 1C13 hex)         14.4           Sync manager synchronization         (1G32 hex and 1C33 hex)         14.4           Sync error setting         (10F1 hex)         14.4           Manufacturer Specific Objects         SERVOPACK parameters         (2000 hex to 26FF hex)         14.5           Manufacturer Specific Objects         Position user unit         (2700 hex)         14.5           Position user unit         (2701 hex)         14.5           Velocity user unit         (2702 hex)         14.5           Acceleration user unit         (2703 hex)         14.5           SERVOPACK adjusting command object         (2710 hex)         14.5           SERVOPACK adjusting command object         (2710 hex)         14.5           Error code         (603F hex)         14.6           Controlword         (6041 hex)         14.6           Statusword         (6041 hex)         14.6           Statusword         (605A hex)         14.6           Device Control         Disable operation option code         (605B hex)         14.6           Mate treaction option code         (605D hex)         14.6           Hat option code         (605D hex)         14.6	T DO Mapping Objects	Transmit PDO mapping		14.3
Sync Manager Communication Objects         Sync manager PDO assignment         10.13 hex)         14.4           Sync manager synchronization         (1032 hex and 1.33 hex)         14.4           Sync error setting         (10F1 hex)         14.4           Manufacturer Specific Objects         User parameters         (2000 hex to 26FF hex)         14.5           Manufacturer Specific Objects         User parameter configuration         (2700 hex)         14.5           Menufacturer Specific Objects         Position user unit         (2701 hex)         14.5           Velocity user unit         (2702 hex)         14.5           Velocity user unit         (2703 hex)         14.5           Acceleration user unit         (2703 hex)         14.5           Error code         (603F hex)         14.6           Error code         (6040 hex)         14.6           Controlword         (6040 hex)         14.6           Statusword         (6041 hex)         14.6           Statusword         (6041 hex)         14.6           Authown option code         (605A hex)         14.6           Halt option code         (605B hex)         14.6           Halt option code         (605E hex)         14.6           Halt option code <t< td=""><td></td><td>Sync manager communication type</td><td>(1C00 hex)</td><td>14.4</td></t<>		Sync manager communication type	(1C00 hex)	14.4
Sync manager synchronization   1C33 hex   14.4		Sync manager PDO assignment		14.4
SERVOPACK parameters	nication Objects	Sync manager synchronization		14.4
Manufacturer Specific Objects         SERVOPACK parameters         26FF hex)         14.5           Manufacturer Specific Objects         User parameter configuration         (2700 hex)         14.5           Position user unit         (2701 hex)         14.5           Velocity user unit         (2702 hex)         14.5           Acceleration user unit         (2703 hex)         14.5           Acceleration user unit         (2701 hex)         14.5           SERVOPACK adjusting command object         (2710 hex)         14.5           Error code         (603F hex)         14.6           Controlword         (6040 hex)         14.6           Statusword         (6041 hex)         14.6           Statusword         (605A hex)         14.6           Shutdown option code         (605B hex)         14.6           Halt option code         (605B hex)         14.6           Halt option code         (605C hex)         14.6           Halt option code         (605E hex)         14.6           Modes of operation display         (		Sync error setting	(10F1 hex)	14.4
Manufacturer Specific Objects         Position user unit         (2701 hex)         14.5           Velocity user unit         (2702 hex)         14.5           Acceleration user unit         (2703 hex)         14.5           SERVOPACK adjusting command object         (2710 hex)         14.5           SERVOPACK adjusting command object         (2710 hex)         14.6           Controlword         (603F hex)         14.6           Controlword         (6040 hex)         14.6           Statusword         (6041 hex)         14.6           Quick stop option code         (605A hex)         14.6           Shutdown option code         (605B hex)         14.6           Shutdown option code         (605B hex)         14.6           Halt option code         (605D hex)         14.6           Halt option code         (605E hex)         14.6           Fault reaction option code         (605E hex)         14.6           Modes of operation         (6060 hex)         14.6           Modes of operation display         (6061 hex)         14.6           Supported drive modes         (6502 hex)         14.6           Profile Position Mode         (607A hex)         14.7           Max profile velocity         (607F he		SERVOPACK parameters		14.5
Position Mode		User parameter configuration	(2700 hex)	14.5
Velocity user unit		Position user unit	(2701 hex)	14.5
SERVOPACK adjusting command object (2710 hex) 14.5	Objects	Velocity user unit	(2702 hex)	14.5
Error code		Acceleration user unit	(2703 hex)	14.5
Controlword		SERVOPACK adjusting command object	(2710 hex)	14.5
Statusword		Error code	(603F hex)	14.6
Quick stop option code   (605A hex)   14.6		Controlword	(6040 hex)	14.6
Shutdown option code   (605B hex)   14.6		Statusword	(6041 hex)	14.6
Device Control         Disable operation option code         (605C hex)         14.6           Halt option code         (605D hex)         14.6           Fault reaction option code         (605E hex)         14.6           Modes of operation         (6060 hex)         14.6           Modes of operation display         (6061 hex)         14.6           Supported drive modes         (6502 hex)         14.6           Target position         (607A hex)         14.7           Software position limit         (607D hex)         14.7           Max profile velocity         (6081 hex)         14.7           Profile velocity         (6081 hex)         14.7           Profile deceleration         (6084 hex)         14.7           Profile deceleration         (6084 hex)         14.7           Quick stop deceleration         (6085 hex)         14.7           Home offset         (607C hex)         14.8           Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Quick stop option code	(605A hex)	14.6
Halt option code   (605D hex)   14.6		Shutdown option code	(605B hex)	14.6
Fault reaction option code   (605E hex)   14.6	Device Control	Disable operation option code	(605C hex)	14.6
Modes of operation         (6060 hex)         14.6           Modes of operation display         (6061 hex)         14.6           Supported drive modes         (6502 hex)         14.6           Target position         (607A hex)         14.7           Software position limit         (607D hex)         14.7           Max profile velocity         (6081 hex)         14.7           Profile velocity         (6081 hex)         14.7           Profile deceleration         (6084 hex)         14.7           Profile deceleration         (6085 hex)         14.7           Quick stop deceleration         (607C hex)         14.8           Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Halt option code	(605D hex)	14.6
Modes of operation display		Fault reaction option code	(605E hex)	14.6
Supported drive modes   (6502 hex)   14.6		Modes of operation	(6060 hex)	14.6
Target position   (607A hex)   14.7		Modes of operation display	(6061 hex)	14.6
Software position limit   (607D hex)   14.7     Max profile velocity   (607F hex)   14.7     Profile Position Mode   Profile velocity   (6081 hex)   14.7     Profile acceleration   (6083 hex)   14.7     Profile deceleration   (6084 hex)   14.7     Quick stop deceleration   (6085 hex)   14.7     Home offset   (607C hex)   14.8     Homing method   (6098 hex)   14.8     Homing speeds   (6099 hex)   14.8		Supported drive modes	(6502 hex)	14.6
Profile Position Mode         Max profile velocity         (607F hex)         14.7           Profile velocity         (6081 hex)         14.7           Profile acceleration         (6083 hex)         14.7           Profile deceleration         (6084 hex)         14.7           Quick stop deceleration         (6085 hex)         14.7           Homing offset         (607C hex)         14.8           Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Target position	(607A hex)	14.7
Profile Position Mode         Profile velocity         (6081 hex)         14.7           Profile acceleration         (6083 hex)         14.7           Profile deceleration         (6084 hex)         14.7           Quick stop deceleration         (6085 hex)         14.7           Home offset         (607C hex)         14.8           Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Software position limit	(607D hex)	14.7
Profile acceleration         (6083 hex)         14.7           Profile deceleration         (6084 hex)         14.7           Quick stop deceleration         (6085 hex)         14.7           Home offset         (607C hex)         14.8           Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Max profile velocity	(607F hex)	14.7
Profile deceleration (6084 hex) 14.7	Profile Position Mode	Profile velocity	(6081 hex)	14.7
Quick stop deceleration         (6085 hex)         14.7           Home offset         (607C hex)         14.8           Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Profile acceleration	(6083 hex)	14.7
Home offset         (607C hex)         14.8           Homing Mode         Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Profile deceleration	(6084 hex)	14.7
Homing Mode         Homing method         (6098 hex)         14.8           Homing speeds         (6099 hex)         14.8		Quick stop deceleration	(6085 hex)	14.7
Homing Mode Homing speeds (6099 hex) 14.8		Home offset	(607C hex)	14.8
Homing speeds (6099 hex) 14.8	Lleveine Med-	Homing method	(6098 hex)	14.8
Homing acceleration (609A hex) 14.8	Horning Iviode	Homing speeds	(6099 hex)	14.8
1 (*** * / 1 * ***		Homing acceleration	(609A hex)	14.8

Continued from previous page.

Position demand value
Position actual internal value   (6063 hex)   14.9
Position Control Function   Position actual value   Rosition actual value   Position demand internal value   Rosition demand inter
Position Control Function   Position demand internal value   GoFC hex)   14.9
Following error window   Following error window   Following error time out   Following error time out   Following error time out   Following error actual value   Following error window   14.9   14.10   Interpolation data record   Following error window   14.9   Id.9   I
Following error window   Following error window   Following error time out   Following error time out   Following error actual value   Following error actual value   (6066 hex)   14.9     Position window   Following error actual value   (6067 hex)   14.9     Position window   Position window time   (6068 hex)   14.9     Interpolation sub mode select   (6000 hex)   14.10     Interpolation data record   (6001 hex)   14.10     Interpolation time period   (6002 hex)   14.10     Manufacturer interpolation data configuration for 1st profile   (2730 hex)   14.10     Interpolation profile select   (2732 hex)   14.10     Interpolation data record for 1st profile   (2700 hex)   14.10     Interpolation data record for 2nd profile   (2701 hex)   14.10     Interpolation data read/write pointer position   (2741 hex)   14.10     Cyclic Synchronous   Velocity offset   (6081 hex)   14.11
Following error actual value   (60F4 hex)   14.9     Position window   (6067 hex)   14.9     Position window time   (6068 hex)   14.9     Interpolation sub mode select   (60C0 hex)   14.10     Interpolation data record   (60C1 hex)   14.10     Interpolation time period   (60C2 hex)   14.10     Interpolation time period   (60C2 hex)   14.10     Manufacturer interpolation data configuration for 1st profile     Manufacturer interpolation data configuration for 2nd profile   (2731 hex)   14.10     Interpolation profile select   (2732 hex)   14.10     Interpolation data record for 1st profile   (27C0 hex)   14.10     Interpolation data record for 2nd profile   (27C1 hex)   14.10     Interpolation data read/write pointer position   (2741 hex)   14.10     Cyclic Synchronous   Velocity offset   (60B1 hex)   14.11
Position window   (6067 hex)   14.9
Position window time (6068 hex) 14.9  Interpolation sub mode select (60C0 hex) 14.10  Interpolation data record (60C1 hex) 14.10  Interpolation time period (60C2 hex) 14.10  Manufacturer interpolation data configuration for 1st profile (2730 hex) 14.10  Manufacturer interpolation data configuration for 2nd profile linterpolation profile select (2732 hex) 14.10  Interpolation data record for 1st profile (27C0 hex) 14.10  Interpolation data record for 2nd profile (27C1 hex) 14.10  Interpolation data read/write pointer position (2741 hex) 14.10  Cyclic Synchronous Velocity offset (60B1 hex) 14.11
Interpolation sub mode select (60C0 hex) 14.10  Interpolation data record (60C1 hex) 14.10  Interpolation time period (60C2 hex) 14.10  Manufacturer interpolation data configuration for 1st profile  Manufacturer interpolation data configuration for 2nd profile  Interpolation profile select (2732 hex) 14.10  Interpolation data record for 1st profile (27C0 hex) 14.10  Interpolation data record for 2nd profile (27C1 hex) 14.10  Cyclic Synchronous Velocity offset (60B1 hex) 14.11
Interpolation data record (60C1 hex) 14.10 Interpolation time period (60C2 hex) 14.10  Manufacturer interpolation data configuration for 1st profile (2730 hex) 14.10  Manufacturer interpolation data configuration for 2nd profile (2731 hex) 14.10  Interpolation profile select (2732 hex) 14.10  Interpolation data record for 1st profile (27C0 hex) 14.10  Interpolation data record for 2nd profile (27C1 hex) 14.10  Interpolation data read/write pointer position (2741 hex) 14.10  Cyclic Synchronous Velocity offset (60B1 hex) 14.11
Interpolation time period (60C2 hex) 14.10  Manufacturer interpolation data configuration for 1st profile (2730 hex) 14.10  Manufacturer interpolation data configuration for 2nd profile (2731 hex) 14.10  Interpolation profile select (2732 hex) 14.10  Interpolation data record for 1st profile (27C0 hex) 14.10  Interpolation data record for 2nd profile (27C1 hex) 14.10  Interpolation data read/write pointer position (2741 hex) 14.10  Cyclic Synchronous Velocity offset (60B1 hex) 14.11
Interpolated Position Mode  Manufacturer interpolation data configuration for 1st profile  Manufacturer interpolation data configuration for 2nd profile  Interpolation profile select  Interpolation data record for 1st profile  Interpolation data record for 2nd profile  (2731 hex)  14.10  (2731 hex)  14.10  (2700 hex)  14.10  Interpolation data record for 2nd profile  (27C1 hex)  14.10  Cyclic Synchronous  Velocity offset  (60B1 hex)  14.11
Interpolated Position Mode    Manufacturer interpolation data configuration for 2nd profile   Manufacturer interpolation data configuration for 2nd profile   (2731 hex)   14.10     Interpolation profile select   (2732 hex)   14.10     Interpolation data record for 1st profile   (27C0 hex)   14.10     Interpolation data record for 2nd profile   (27C1 hex)   14.10     Interpolation data read/write pointer position   (2741 hex)   14.10     Cyclic Synchronous   Velocity offset   (60B1 hex)   14.11
Mode   Manufacturer Interpolation data configuration for 2nd profile   (2731 hex)   14.10     Interpolation profile select   (2732 hex)   14.10     Interpolation data record for 1st profile   (27C0 hex)   14.10     Interpolation data record for 2nd profile   (27C1 hex)   14.10     Interpolation data read/write pointer position   (2741 hex)   14.10     Cyclic Synchronous   Velocity offset   (60B1 hex)   14.11
Interpolation data record for 1st profile (27C0 hex) 14.10 Interpolation data record for 2nd profile (27C1 hex) 14.10 Interpolation data read/write pointer position (2741 hex) 14.10  Cyclic Synchronous Velocity offset (60B1 hex) 14.11
Interpolation data record for 2nd profile (27C1 hex) 14.10 Interpolation data read/write pointer position (2741 hex) 14.10  Cyclic Synchronous Velocity offset (60B1 hex) 14.11
Interpolation data read/write pointer position (2741 hex) 14.10  Cyclic Synchronous Velocity offset (60B1 hex) 14.11
Cyclic Synchronous Velocity offset (60B1 hex) 14.11
System System and de
Position Mode Torque offset (60B2 hex) 14.11
Velocity demand value (606B hex) 14.12
Profile Velocity/Cyclic Velocity actual value (606C hex) 14.12
Synchronous Velocity Velocity window (606D hex) 14.12
Mode Velocity window time (606E hex) 14.12
Target velocity (60FF hex) 14.12
Target torque (6071 hex) 14.13
Profile Torque/Cyclic Torque demand value (6074 hex) 14.13
Synchronous Velocity Torque slope (6087 hex) 14.13
Mode Motor rated torque (6076 hex) 14.13
Torque actual value (6077 hex) 14.13
Max torque (6072 hex) 14.14
Torque Limit Function Positive torque limit value (60E0 hex) 14.14
Negative torque limit value (60E1 hex) 14.14
Touch probe function (60B8 hex) 14.15
Touch probe status (60B9 hex) 14.15
Touch Probe Function  Touch probe 1 position value  (60BA hex)  Touch probe 1 position value
Touch probe 2 position value (60BC hex) 14.15
Digital Digital inputs (60FD hex) 14.16
Inputs/Outputs Digital outputs (60FE hex) 14.16

## 14.2 General Objects

### Device Type (1000 Hex)

This object contains the device type and functionality.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1000 hex	0	Device type	UDINT	RO	No	0x00020192	No

### ◆ Data Description

Bit 3	1	16	15	0
	Additional Information		Device profile number	

Additional information: 0002 (Servo Drive) Device profile number: 0192 (DS402)

### Error Register (1001 Hex)

This object contains the error status of the device. The value of this object is stored as part of an emergency message.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1001 hex	0	Error register	USINT	RO	No	0x00	No

### Data Description

Bit	Data	Description
0	Generic error	0: No error, 1: Error
1 to 7	Reserved.	0: Always 0

### Manufacturer Device Name (1008 Hex)

This object contains the SERVOPACK model name.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1008 hex	0	Manufacturer device name	STRING	RO	No	-	No

### Manufacturer Software Version (100A Hex)

This object contains the software version of the SERVOPACK.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
100A hex	0	Manufacturer software version	STRING	RO	No	-	No

### Data Description

The following string is saved. "xxxx.\*\*\*\* (D:000)"

xxxx.\*\*\*\*: Software version of EtherCAT (CoE) oooo: Software version of the SERVOPACK

### Store Parameters Field (1010 Hex)

You can use this object to save the parameter settings in non-volatile memory.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Largest subindex supported	USINT	RO	No	4	No
1010 hex	1	Save all parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No
	2	Save communication parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No
	3	Save application parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No
	4	Save manufacturer defined parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No

If you read the object entry data, a value will be returned that tells whether the SERVOPACK can save the parameters.

Bit	Value	Meaning
1	0	The SERVOPACK does not save the parameters autonomously.
0	0 1	The SERVOPACK does not save the parameters for a command. The SERVOPACK saves the parameters for a command.

To prevent saving parameters by mistake, they are saved only when a specific signature is written to the appropriate subindex. The signature is "save."

Signature N	MSB L					
ASCII	е	٧	а	s		
hex	65 hex	76 hex	61 hex	73 hex		

If you write "save" to subindex 1, all parameters are saved.

If you write "save" to subindex 2, the communications parameters (objects 1000 hex to 1FFF hex) are saved.

If you write "save" to subindex 3, the application parameters (objects  $27 \square \square$  hex and  $6 \square \square \square$  hex) are saved.

If you write "save" to subindex 4, the SERVOPACK parameters (objects 2000 hex to 26FF hex) are saved.

Note: 1. If an incorrect signature is written, the SERVOPACK refuses to save the parameters and returns an SDO abort code.

- 2. If you read the object entry data while parameters are being saved, 0 will be returned.
- 3. Subindex 1 and subindex 4 can be written only in the Switch ON Disabled state (servo OFF).
- 4. After storing parameters with subindex 1 or subindex 4, you must turn the power supply OFF and ON again to move to the Operation Enabled state.

### Restore Default Parameters (1011 Hex)

You can use this object to restore the parameters to the default values.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Largest subindex supported	USINT	RO	No	4	No
1011 hex	1	Restore all default parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No
	2	Restore communication default parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No
	3	Restore application default parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No
	4	Restore manufacturer defined default parameters	UDINT	RW	No	0x00000000 to 0xFFFFFFF (default: 0x00000001)	No

If you read the object entry data, a value will be returned that tells whether the SERVOPACK can initialize the parameters.

Bit	Value	Description
0		The SERVOPACK does not restore the parameters to the default values. The SERVOPACK restores the parameters to the default values.

To prevent restoring the parameters to the default values by mistake, the parameters are restored to the default values only when a specific signature is written to the appropriate subindex. The signature is "load."

Signature	MSB	LSI	В		
ASCII	d a		0 1		
hex	64 hex	61 hex	6F hex	6C hex	

If you write "load" to subindex 1, all parameters are restored to the default values.

If you write "load" to subindex 2, the communications parameters (objects  $1\square\square\square$  hex) are restored to the default values.

If you write "load" to subindex 3, the application parameters (objects  $27 \square \square$  hex and  $6 \square \square \square$  hex) are restored to the default values.

If you write "load" to subindex 4, the SERVOPACK parameters (objects 2000 hex to 26FF hex) are restored to the default values.

Note: 1. If an incorrect signature is written, the SERVOPACK refuses to restore the default values and returns an SDO abort code.

- 2. Subindex 1 and subindex 4 can be written only in the Switch ON Disabled state (servo OFF).
- 3. If you read this object while the default values are being restored, 0 will be returned.
- 4. The default values are enabled after the SERVOPACK is reset or after the power supply to the SERVO-PACK is turned OFF and ON again.

### Identity Object (1018 Hex)

This object contains general information on the device.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	4	No
	1	Vendor ID	UDINT	RO	No	0x00000539	No
1018 hex	2	Product code	UDINT	RO	No	0x02200401*1	No
	3	Revision number *2	UDINT	RO	No	-	No
	4	Serial number *3	UDINT	RO	No	0x00000000	No

<sup>\*1.</sup> For SGD7S-□□□DA0□: 0x02200401

<sup>\*2.</sup> The revision number is saved as follows:

Bit 31		16	15	0
	Major version		Minor version	

The major version identifies the operating specifications of EtherCAT (CoE). If the CoE functionality is expanded, the major version has to be increased. The minor version number identifies different versions with the same operating specifications.

\*3. Serial number is not used. (It is always 0.)

## 14.3 PDO Mapping Objects

The CANopen over EtherCAT protocol allows the user to map objects to process data objects (PDOs) in order to use the PDOs for realtime data transfer.

The PDO mappings define which objects will be included in the PDOs.

A mapping entry (subindexes 1 to 8) is defined as shown below.

Bit 31	16	15 8	7	0
	Object index	Subindex	Length	

Bits 0 to 7: The length of the mapped object in bits. (If there is a gap in the PDOs, the bit length of the gap is given.)

Bits 8 to 15: The subindex of the mapped object (0 if there is a gap in the PDOs).

Bits 16 to 31: The index of the mapped object (0 if there is a gap in the PDOs).

Information

The objects mapped to PDOs can be changed only when the EtherCAT (CoE) Network Module is in the Pre-Operational state.

Set the mapping entries (subindexes 1 to 8) only after you write 0 to subindex 0.

### Receive PDO Mapping (1600 Hex to 1603 Hex)

#### ◆ 1st Receive PDO Mapping

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 8)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFFF (default: 0x60400010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x607A0020)	Yes
	3	Mapping entry 3	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60FF0020)	Yes
1600 hex	4	Mapping entry 4	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60710010)	Yes
	5	Mapping entry 5	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60720010)	Yes
	6	Mapping entry 6	UDINT	RW	No	0 0xFFFFFFF (default: 0x60600008)	Yes
	7	Mapping entry 7	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x00000008)	Yes
	8	Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60B80010)	Yes

## ◆ 2nd Receive PDO Mapping

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1601 hex	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 2)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60400010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x607A0020)	Yes
	3 to 8	Mapping entry 3 to Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0)	Yes

### ◆ 3rd Receive PDO Mapping

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1602 hex	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 2)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60400010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60FF0020)	Yes
	3 to 8	Mapping entry 3 to Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0)	Yes

### ◆ 4th Receive PDO Mapping

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1603 hex	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 2)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60400010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60710010)	Yes
	3 to 8	Mapping entry 3 to Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0)	Yes

## Transmit PDO Mapping (1A00 Hex to 1A03 Hex)

### ◆ 1st Transmit PDO Mapping

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 8)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60410010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60640020)	Yes
	3	Mapping entry 3	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60770010)	Yes
1A00 hex	4	Mapping entry 4	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60F40020)	Yes
	5	Mapping entry 5	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60610008)	Yes
	6	Mapping entry 6	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x00000008)	Yes
	7	Mapping entry 7	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60B90010)	Yes
	8	Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60BA0020)	Yes

### ◆ 2nd Transmit PDO Mapping

		1-1- 5					
Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1A01 hex	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 2)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFFF (default: 0x60410010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60640020)	Yes
	3 to 8	Mapping entry 3 to Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0)	Yes

### ◆ 3rd Transmit PDO Mapping

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1A02 hex	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 2)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60410010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60640020)	Yes
	3 to 8	Mapping entry 3 to Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0)	Yes

### ♦ 4th Transmit PDO Mapping

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1A03 hex	0	Number of objects in this PDO	USINT	RW	No	0 to 8 (default: 3)	Yes
	1	Mapping entry 1	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60410010)	Yes
	2	Mapping entry 2	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60640020)	Yes
	3	Mapping entry 3	UDINT	RW	No	0 to 0xFFFFFFF (default: 0x60770010)	Yes
	4 to 8	Mapping entry 4 to Mapping entry 8	UDINT	RW	No	0 to 0xFFFFFFF (default: 0)	Yes

### 14.4

## **Sync Manager Communications Objects**

### Sync Manager Communications Type (1C00 Hex)

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of used Sync Manager channels	USINT	RO	No	4	No
	1	Communication type sync manager 0	USINT	RO	No	1: Mailbox reception (master to slave)	No
1C00 hex	2	Communication type sync manager 1	USINT	RO	No	2: Mailbox send (slave to master)	No
	3	Communication type sync manager 2	USINT	RO	No	3: Process data output (master to slave)	No
	4	Communication type sync manager 3	USINT	RO	No	4: Process data input (slave to master)	No

### Sync Manager PDO Assignment (1C10 Hex to 1C13 Hex)

This object defines which PDOs will be transferred in the process data communications.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
1C10 hex	0	Sync manager PDO assignment 0	USINT	RO	No	0	No
1C11 hex	0	Sync manager PDO assignment 1	USINT	RO	No	0	No
	0	Number of assigned PDOs	USINT	RW	No	0 to 2 (default: 1)	Yes
1C12 hex	1	Index of assigned RxPDO 1	UINT	RW	No	1600 hex to 1603 hex (default: 1601 hex)	Yes
	2	Index of assigned RxPDO 2	UINT	RW	No	1600 hex to 1603 hex (default: 1600 hex)	Yes
	0	Number of assigned PDOs	USINT	RW	No	0 to 2 (default: 1)	Yes
1C13 hex	1	Index of assigned TxPDO 1	UINT	RW	No	1A00 hex to 1A03 hex (default: 1A01 hex)	Yes
	2	Index of assigned TxPDO 2	UINT	RW	No	1A00 hex to 1A03 hex (default: 1A00 hex)	Yes

Objects 1C12 hex and 1C13 hex can be changed when the EtherCAT (CoE) Network Module is in the Pre-Operational state. Set subindex 1 or 2 only after you write 0 to subindex 0.

## Sync Manager Synchronization (1C32 Hex and 1C33 Hex)

## ◆ Sync Manager 2 (Process Data Output) Synchronization

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of synchroni- zation parameters	USINT	RO	No	10	No
	1	Synchronization type	UINT	RO	No	0: Free-Run (DC not used) 2: DC Sync0 (DC used)	No
	2	Cycle time	UDINT	RO	No	Sync0 event cycle [ns]	No
	3	Shift time	UDINT	RO	No	125,000 [ns]	No
1C32 hex	4	Synchronization types supported	UINT	RO	No	Bit 0 = 1: Free-Run supported  Bits 2 to 4 = 001: DC Sync0 supported  Bits 5 and 6 = 00: Output shift not supported.	No
	5	Minimum cycle time	UDINT	RO	No	62,500 [ns]	No
	6	Calc and copy time	UDINT	RO	No	62,500 [ns]	No
	7	Reserved	UDINT	RO	No	_	No
	8	Reserved	UINT	RO	No	_	No
-	9	Delay time	UDINT	RO	No	0 [ns]	No
	10	Sync0 cycle time	UDINT	RO	No	Same as 1C32 hex: 02.	No
	11	Reserved	UDINT	RO	No	_	No
	12	SM2 event miss count	UDINT	RO	No	_	No

#### ◆ Sync Manager 3 (Process Data Input) Synchronization

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of synchroni- zation parameters	USINT	RO	No	10	No
1C33 hex	1	Synchronization type	UINT	RO	No	Same as 1C32 hex: 01.	No
	2	Cycle time	UDINT	RO	No	Same as 1C32 hex: 02.	No
	3	Shift time	UDINT	RW	No	125,000 × n [ns] (n = 1, 2, 3) Range: 0 to (Sync0 event cycle -125,000)	Yes
	4	Synchronization types supported	UINT	RO	No	Bit 0 = 1: Free-Run supported.  Bits 2 to 4 = 001: DC Sync0 supported  Bits 5 and 6 = 01: Input shift with local timer supported.	No
	5	Minimum cycle time	UDINT	RO	No	Same as 1C32 hex: 05.	No
	6	Calc and copy time	UDINT	RO	No	62,500 [ns]	No
	7	Reserved	UDINT	RO	No	_	No
	8	Reserved	UINT	RO	No	_	No
	9	Delay time	UDINT	RO	No	0	No
	10	Sync0 cycle time	UDINT	RO	No	Same as 1C32 hex: 10.	No

### Sync Error Settings (10F1 Hex)

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
10F1 hex	1	Reserved	UDINT	RO	No	0	No
	2	Sync error counter limit	UDINT	RW	No	0 to 15 (default: 9)	Yes

Note: Both 10F1 hex and 1F01 hex have the same function. You can set either object.

### ◆ 0x10F1 Hex: 2 Sync Error Counter Limit

This object defines the allowable number of failures when receiving process data. If the value of the internal error counter in the SERVOPACK exceeds the value of this object, the SERVOPACK will detect an alarm (A12 hex) and change the ESM state to SAFEOP.

The SERVOPACK increments the internal error counter by 3 if the process output data is not updated (i.e., if a reception event does not occur) when the synchronization event (SyncO) occurs. When the process output data is updated normally, the internal error counter is decremented by 1. The internal error counter is reset when the EtherCAT communications state changes from SAFEOP to OP.

An example of internal error counter operation is shown below.

Reception (SM2) event	1	0	1	0	1	0	1	0	1	0	1
SERVOPACK internal error counter (Error Counter Limit = 9)	0	3	2	5	4	7	6	9 (Error)	9	9	9

In this example, a failure in receiving the process data occurs every other DC (Sync0) cycle. After eight DC cycles, the internal error count reaches the Sync Error Count Limit, and an error occurs.

No alarm will be detected if the DC mode is disabled or when the Sync Error Count Limit is set to 0.



- 1. Set a suitable cycle time for updating the process data according to the requirements of the application.
- 2. Determine if the default setting of the Sync Error Counter Limit is suitable for the requirements of the application. With the default value of 9, network frames will be lost (SM2 reception events will not occur) three times consecutively before an alarm occurs in the SERVOPACK. If the setting of the Sync Error Counter Limit is too small, alarms will occur even when there is no problem in the application.
- Noise may cause communications errors in the SERVOPACK. Check the SERVOPACK wiring and make sure that it has been performed to minimize the influence of noise. Implement noise countermeasures if necessary. Refer to the following section for information on noise countermeasures.

4.1.2 Countermeasures against Noise on page 4-5

## 14.5 Manufacturer-Specific Objects

### SERVOPACK Parameters (2000 Hex to 26FF Hex)

Objects 2000 hex to 26FF hex are mapped to SERVOPACK parameters (Pn DD).

Object index 2 \( \sigma \sigma \) hex corresponds to Pn \( \sigma \sigma \) in the SERVOPACK parameters (e.g., object 2100 hex is the same as Pn100).

### **User Parameter Configuration (2700 Hex)**

This object enables all user parameter settings and initializes all of the position data.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
2700 hex	0	User parameter configuration	UDINT	RW	No	0 to 0xFFFFFFF (default: 0)	No

If you change any of the following objects and restart operation without turning the power supply OFF and then ON again, you must execute this object to enable the new settings.

- Objects 2701 hex, 2702 hex, 2703 hex, and 2704 hex
- SERVOPACK parameters that require that the power supply be turned OFF and ON again to enable changes to the parameter settings

#### Procedure

- 1. Change the SERVOPACK to the Switch ON Disabled state.
- 2. Set the new parameter settings.
- 3. Set user parameter configuration (2700 hex) to 1. The parameter settings will be enabled.

After execution, object 2700 hex will automatically be reset to 0.

### Position User Unit (2701 Hex)

This object sets the user-defined position reference unit (Pos unit).

The user-defined position reference unit is calculated with the following formula.

1 [Pos unit] = (Numerator/Denominator) [inc]

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
2701 hex	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes

Setting range: 1/4,096 < Numerator/Denominator < 65,536

(Alarm A.A20 will be detected if the setting exceeds the setting range.)

### Velocity User Unit (2702 Hex)

This object sets the user-defined speed reference unit (Vel unit).

The user-defined speed reference unit is calculated with the following formula.

1 [Vel unit] = (Numerator/Denominator) [inc/sec]

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
2702 hex	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes

Setting range: 1/128 ≤ Numerator/Denominator ≤ 8,388,608

(Alarm A.A20 will be detected if the setting exceeds the setting range.)

### Acceleration User Unit (2703 Hex)

This object sets the user-defined acceleration reference unit (Acc unit).

The user-defined acceleration reference unit is calculated with the following formula.

1 [Acc unit] = (Numerator/Denominator)  $\times$  10<sup>4</sup> [inc/sec<sup>2</sup>]

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
2703 hex	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes

Setting range: 1/128 ≤ Numerator/Denominator ≤ 262,144

(Alarm A.A20 will be detected if the setting exceeds the setting range.)

### Torque User Unit (2704 Hex)

This object sets the user-defined torque reference unit (Torque unit).

The user-defined torque reference unit is calculated with the following formula.

1 [Trq. unit] = (Numerator/Denominator) [%]

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
2704 hex	1	Numerator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes
	2	Denominator	UDINT	RW	No	1 to 1,073,741,823 (default: 1)	Yes

Setting range: 1/256 ≤ Numerator/Denominator ≤ 1

(Alarm A.A20 will be detected if the setting exceeds the setting range.)

The objects that are related to the user-defined torque reference unit setting are given in the following table.

The reference unit for the following objects is 0.1%.

EtherCAT(CoE) Communications Object	Data Type
Target torque (6071 hex)	INT
Torque demand value (6074 hex)	INT
Torque slope (6087 hex)	UDINT
Torque actual value (6077 hex)	INT
Max torque (6072 hex)	UINT

Continued on next page.

Continued from previous page.

EtherCAT(CoE) Communications Object	Data Type
Positive torque limit value (60E0 hex)	UINT
Negative torque limit value (60E1 hex)	UINT
Torque offset (60B2 hex)	INT

### SERVOPACK Adjusting Command (2710 Hex)

This object is used for SERVOPACK adjustment services (e.g., encoder setup or multiturn reset). Write data to subindex 1 to start command execution. Also, read the subindex 3 to obtain the response. If you cannot obtain the response by reading subindex 3, the first byte of the response data will give information about the progress of execution.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	3	No
2710 hex	1	Command	STRING	RW	No	Bytes 0 to n: Service Request Data The command is executed when command data is written.	No
	2	Status	USINT	RO	No	O: Command completed, no errors, and no response data 1: Command completed, no errors, and response data provided 2: Command completed, error, and no response data 3: Command completed, error, response data provided 255: Command is being executed	No
	3	Reply	STRING	RO	No	Byte 0: Subindex 2 Byte 1: Not used 2 to n: Service response data	No

### ◆ Command/Response Data Format

Com	Command Data (Service Request Data)				
Byte	Description				
0	Reserved.				
1	Reserved.				
2	CCMD (command code) 00: Read request 01: Write request				
3	CSIZE (CDATA data byte size)				
4 to 7	CADDRESS (address)				
8 to 15	CDATA (writing data)				

Resp	Response Data (Service Response Data)			
Byte	Description			
0	Status (Same data as subindex 2)			
1	Reserved.			
2	RCMD (echoback of CCMD)			
3	RSIZE (R_DATA data byte size)			
4 to 7	RADDRESS (echoback of CADDRESS)			
8 to 15	RDATA (read data)/ERROCODE			

#### ◆ Executable Adjustment Services

Adjustment Service	Request Code	Preparation before Execution	Processing Time	Execution Conditions
Absolute Encoder Reset	1008 hex	Required	5 s max.	If an incremental encoder is used, it is not possible to reset the encoder while the servo is ON.
Autotune Motor Current Detection Signal Offset	100E hex	Not required	5 s max.	<ul> <li>Adjustment is disabled in the following cases.</li> <li>While the main circuit power supply is OFF</li> <li>While the servo is ON</li> <li>While the Servomotor is not stopped</li> </ul>
Multiturn Limit Setting	1013 hex	Required	5 s max.	If an incremental encoder is used, the setting is disabled unless a Multiturn Limit Disagreement alarm has occurred.
Software Reset*	2006 hex	Not required	5 s max.	The software cannot be reset in the following cases.  • While the servo is ON  • While the Servomotor is not stopped

<sup>\*</sup> EtherCAT (CoE) communications will be disconnected after the software is reset. Repeat the operation sequence and establish communications again. Refer to the following sections for precautions required when resetting the software.

#### How to Send a Command for Adjustment

To execute the adjustment service, use the following procedure to send the adjustment command. Step 4 is not required when the software is reset.

1. Send the following data and set the request code for the adjustment service to execute.

CCMD = 0001 hex

CSIZE = 02 hex

CADDRESS = 00002000 hex

CDATA = Request code of the adjustment service to execute\*

If the slave station receives the command normally, the status field will be set to 1. If an error occurs, perform step 4 to stop execution.

**2.** For an adjustment that requires preparations, send the following data. If preparations before execution are not required, perform step 3.

 $C\dot{C}M\dot{D} = 0001 \text{ hex}$ 

CSIZE = 02 hex

CADDRESS = 00002001 hex

CDATA = 0002 hex

If the slave station receives the command normally, the status field will be set to 1. If an error occurs, perform step 4 to stop execution.

3. Send the following data to execute the adjustment service.

CCMD = 0001 hex

CSIZE = 02 hex

CADDRESS = 00002001 hex

CDATA = 0001 hex

If the slave station receives the command normally, the status field will be set to 1. If an error occurs, perform step 4 to stop execution.

4. Send the following data to stop execution.

CCMD = 0001 hex

CSIZE = 02 hex

CADDRESS = 00002000 hex

CDATA = 0000 hex

If the slave station receives the command normally, the status field will be set to 1.

Note: If no command is received within 10 seconds after step 1, the adjustment service will be automatically stopped.

<sup>6.10</sup> Software Reset

<sup>\*</sup> Select the request code from the table in *◆ Executable Adjustment Services* on page 14-20.

# 14.6 Device Control

### Error Code (603F Hex)

This object provides the SERVOPACK alarm/warning code of the last error that occurred.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
603F hex	0	Error code	UINT	RO	Yes	0	No

### Controlword (6040 Hex)

This object controls the device and operation mode.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6040 hex	0	Controlword	UINT	RW	Yes	0 to 0xFFFF (default: 0)	No

#### Controlword Bits

Bit	Function	Description		
0	Switch on			
1	Enable voltage	Refer to ■ Details on Bits 0 to 3.		
2	Quick stop	neier to - Details off bits of to 3.		
3	Enable operation			
4 to 6	Operation mode specific	Refer to ■ Details on Bits 4 to 9.		
7	Fault reset	0 → 1: Alarm/warning reset.		
8	Halt	Refer to ■ Details on Bits 4 to 9.		
9	Operation mode specific	There to Details on Dits 4 to 9.		
10	- (Reserved)	-		
11	Positive torque limit	0: Disables torque limit parameter (object 2404 hex). 1: Enables torque limit parameter (object 2404 hex).		
12	Negative torque limit	0: Disables torque limit parameter (object 2405 hex). 1: Enables torque limit parameter (object 2405 hex).		
13 to 15	- (Reserved)	-		

#### ■ Details on Bits 0 to 3

• Bits 0 to 3: These bits function as the control command for the Servo Drive's state.

Command	Controlword Bits						
Command	Bit 7	Bit 3	Bit 2	Bit 1	Bit 0		
Shutdown	0	X	1	1	0		
Switch on	0	0	1	1	1		
Switch on + Enable operation	0	1	1	1	1		
Disable voltage	0	X	Х	0	X		
Quick stop	0	X	0	1	X		
Disable operation	0	0	1	1	1		
Enable operation	0	1	1	1	1		

#### ■ Details on Bits 4 to 9

#### • Bits 4, 5, and 9: Profile Position Mode

Bit 9	Bit 5	Bit 4	Description
0	0	0 → 1	Starts the next positioning operation after the current positioning operation is completed (i.e., after the target is reached).
X	1	0 → 1	Starts the next positioning operation immediately.
1	0	0 → 1	Continues positioning with the current profile speed up to the current target position and then start the next positioning operation.

#### • Bits 6 and 8: Profile Position Mode

Bit	Function	Value	Description
		0	Treats the target position as an absolute value.
6	6 Abs/rel	1	Treats the target position as a relative value. (Treats it as the movement distance from the current target position.)
· · · · · · · · · · · · · · · · · · ·	Halt	0	Executes or continues positioning.
0		1	Stops axis according to halt option code (605D hex).

#### • Bits 4, 5, 6, 8, and 9: Homing Mode

Bit	Function	Value	Description		
	Homing	0	Does not start homing.		
4	operation start	1	Starts or continues homing.		
5	_	0	Reserved.		
6	_	0	Reserved.		
0	8 Halt	0	Enables bit 4.		
0		1	Stops the axis according to halt option code (605D hex).		
9	_	0	Reserved.		

#### • Bits 4, 5, 6, 8, and 9: Cyclic Synchronous Position, Velocity, or Torque Mode

Bit	Function	Value	Description		
4	_	0	Reserved.		
5	_	0	Reserved.		
6	_	0	Reserved.		
8	8 Halt	0	Executes or continues operation.		
o Hall	1	Stops axis according to halt option code (605D hex).			
9	_	0	Reserved.		

#### • Bits 4, 5, 6, 8, and 9: Interpolated Position Mode

Bit	Function	Value	Description		
4	Enable	0	Disables interpolation.		
4	interpolation	1	Enables interpolation.		
5	_	0	Reserved.		
6	_	0	Reserved.		
0	8 Halt	0	Executes specification for bit 4.		
0		1	Stops the axis according to halt option code (605D hex).		
9	_	0	Reserved.		

#### • Bits 4, 5, 6, 8, and 9: Profile Velocity/Torque Mode

Bit	Function	Value	Description		
4	_	0	Reserved.		
5	_	0	Reserved.		
6	_	0	Reserved.		
8	8 Halt		Executes or continues operation.		
o Hait	Пан	1	Stops the axis according to halt option code (605D hex).		
9	_	0	Reserved.		

### Statusword (6041 Hex)

Statusword contains the bits that give the current state of the Servo Drive and the operating state of the operation mode.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6041 hex	0	Statusword	UINT	RO	Yes	0	No

#### ◆ Statusword Bits

Bit	State	Description		
0	Ready to switch on			
1	Switched on			
2	Operation enabled			
3	Fault	— Refer to ■ Details on Bits 0 to 7.		
4	Voltage enabled	nelel to Details off bits ofto 7.		
5	Quick stop			
6	Switch on disabled			
7	Warning			
8	Active mode stop	1: Active mode function execution is in progress.		
9	Remote	Controlword (6040 hex) is being processed		
10	Operation mode specific	Refer to ■ Details on Bits 10, 12, and 13.		
11	Internal limit active	Refer to ■ Details on Bit 11.		
12, 13	Operation mode specific	Refer to ■ Details on Bits 10, 12, and 13.		
14	Torque limit active	0: Torque limit is disabled. 1: Torque limit is enabled.		
15	Safety active	1: Safety function is active.		

#### ■ Details on Bits 0 to 7

#### • Bits 0 to 7: Current State of Servo Drive

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Servo Drive State
Χ	0	Χ	X	0	0	0	0	Not ready to switch on
Χ	1	X	X	0	0	0	0	Switch on disabled
X	0	1	Х	0	0	0	1	Ready to switch on
X	0	1	Х	0	0	1	1	Switched on
X	0	1	Х	0	1	1	1	Operation enabled
Χ	0	0	X	0	1	1	1	Quick stop active
Χ	0	X	X	1	1	1	1	Fault reaction active
Χ	0	X	X	1	0	0	0	Fault
X	Х	Х	1	Х	X	X	Х	Main power on
1	Х	Х	Х	Х	X	X	X	Warning occurred

#### ■ Details on Bit 11

· Bit 11: Internal limit active

The internal limit is activated in the following cases:

- The target position was limited by a software limit.
- The N-OT or P-OT signal was activated.
- The interpolation speed was exceeded in Interpolated Position Mode or Cyclic Position Mode.

If the interpolated reference speed exceeds the following speed range, the target position will be ignored.

(Target position – position demand value) × (2701 hex: 01)/(2701 hex: 02)

Interpolation time period < 4,194,304 [inc/ms]

#### ■ Details on Bits 10, 12, and 13

### • Bits 10, 12, and 13: Profile Position Mode

Bit	Meaning	Value	Description
10	10 Target reached	0	Halt (bit 8 in controlword) = 0: The target position has not been reached.  Halt (bit 8 in controlword) = 1: The axis is decelerating.
		1	Halt (bit 8 in controlword) = 0: The target position was reached. Halt (bit 8 in controlword) = 1: The axis is stopped.
10	12 Set-point acknowledge	0	Processing of previous set point (reference) was completed and Servo Drive is waiting for a new set point.
12		1	Processing the previous set point is still in process or a set point was acknowledged.
10	Following orror	0	No following error has occurred.
13 Follov	Following error	1	A following error occurred.

#### • Bits 10, 12, and 13: Homing Mode

Bit 13	Bit 12	Bit 10		
Homing error	Homing attained	Target reached	Description	
0	0	0	Homing is in progress.	
0	0	1	Homing was interrupted or has not yet started.	
0	1	0	Home has been defined, but the operation is still in progress.	
0	1	1	Homing was completed normally.	
1	0	0	A homing error occurred and the speed is not 0.	
1	0	1	A homing error occurred and the speed is 0.	

#### • Bits 10, 12, and 13: Cyclic Synchronous Position, Velocity, or Torque Mode

Bit	State	Value	Description
10	Target reached	0	The target (position, speed, or torque) has not been reached.
10	raiget reached	1	The target (position, speed, or torque) was reached.
12	Target value	0	The target value (position, speed, or torque) was disabled.
12	ignored	1	Target value (position, speed, or torque) was enabled.
13 Fo	Following error	0	There is no following error (always 0 in Cyclic Velocity or Torque Mode).
	o .	1	A following error occurred.

#### • Bits 10, 12, and 13: Interpolated Position Mode

Bit	State	Value	Description
10	10 Target reached	0	Halt (bit 8 in controlword) = 0: The target position has not been reached.  Halt (bit 8 in controlword) = 1: The axis is decelerating.
		1	Halt (bit 8 in controlword) = 0: The target position was reached. Halt (bit 8 in controlword) = 1: The axis is stopped.
10	12 Ip mode active	0	Interpolation is disabled.
12		1	Interpolation is enabled.
13	_	0	Reserved.

#### • Bits 10, 12, and 13: Profile Velocity Mode

Bit	State	Value	Description
10	Target reached	0	Halt (bit 8 in controlword) = 0: The target speed has not been reached. Halt (bit 8 in controlword) = 1: The axis is decelerating.
10	rarget reached	1	Halt (bit 8 in controlword) = 0: The target speed was reached. Halt (bit 8 in controlword) = 1: The axis is stopped.
12	Speed	0	The speed is not 0.
12	12 Speed		The speed is 0.
13	_	0	Reserved.

#### • Bits 10, 12, and 13: Profile Torque Mode

Bit	State	Value	Description
10	Target reached	0	Halt (bit 8 in controlword) = 0: The target torque has not been reached.  Halt (bit 8 in controlword) = 1: The axis is decelerating.
		1	Halt (bit 8 in controlword) = 0: The target torque was reached.  Halt (bit 8 in controlword) = 1: The axis is stopped.
12	_	0	Reserved.
13	_	0	Reserved.

### **Quick Stop Option Code (605A Hex)**

This object determines what operation will be performed if a Quick Stop is executed.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
605A hex	0	Quick stop option code	INT	RW	No	0 to 4 (default: 2)	Yes

### ◆ Data Description

Value	Description
0	Disables the Servo Drive (moves to the Switch ON Disabled state).
1	Decelerates at the deceleration rate for decelerating to a stop and moves to the Switch ON Disabled state.*1,*2
2	Decelerates at the deceleration rate for a quick stop and moves to the Switch ON Disabled state.*1,*3
3	Decelerates at the torque limit and moves to the Switch ON Disabled state.*1

<sup>\*1.</sup> The motor is always stopped according to option code 0 (servo OFF stop) in Profile Torque Mode or Cyclic Torque Mode.

- \*2. The deceleration rate for decelerating to a stop is defined in the following object.
  - Profile Position, Interpolated Position, Cyclic Position, or Cyclic Velocity Mode: 6084 Hex
  - Homing Mode: 609A Hex
- st3. Quick stop deceleration (6085 hex) is the deceleration rate for a quick stop.

### Shutdown Option Code (605B Hex)

This object defines the operation that is performed if there is a move from Operation Enable state to Ready to Switch ON state.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
605B hex	0	Shutdown option code	INT	RW	No	0 to 1 (default: 0)	Yes

#### ◆ Data Description

Value	Description
0	Disables the Servo Drive (moves to the Switch ON Disabled state).
1	Decelerates at the deceleration rate for decelerating to a stop and moves to the Switch ON Disabled state.*1,*2

<sup>\*1.</sup> The motor is always stopped according to option code 0 (servo OFF stop) in Profile Torque Mode or Cyclic Torque Mode.

### Disable Operation Option Code (605C Hex)

This object defines the operation that is performed if there is a move from Operation Enable state to Switched ON state.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
605C hex	0	Disable operation option code	INT	RW	No	0 to 1 (default: 1)	Yes

#### Data Description

Value	Description
0	Disables the Servo Drive (moves to the Switch ON Disabled state).
1	Decelerates at the deceleration rate for decelerating to a stop and moves to the Switch ON Disabled state.*1,*2

<sup>\*1.</sup> The motor is always stopped according to option code 0 (servo OFF stop) in Profile Torque Mode or Cyclic Torque Mode.

### Halt Option Code (605D Hex)

This object defines the operation that is performed if bit 8 (Halt) in controlword is active.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
605D hex	0	Halt option code	INT	RW	No	0 to 4 (default: 1)	Yes

### ◆ Data Description

Value	Description
1	Decelerates at the deceleration rate for decelerating to a stop and moves to the Operation Enabled state.*1,*2
2	Decelerates at the deceleration rate for a quick stop and moves to the Operation Enabled state.*1,*3
3	Decelerates at the torque limit and moves to the Operation Enabled state.*1

<sup>\*1.</sup> If bit 8 (Halt) is 1 in Profile Torque Mode or Cyclic Torque Mode, the torque reference value is reduced to zero.

<sup>\*2.</sup> The deceleration rate for decelerating to a stop is defined in the following object.

<sup>•</sup> Profile Position, Interpolated Position, Cyclic Position, or Cyclic Velocity Mode: 6084 Hex

<sup>•</sup> Homing Mode: 609A Hex

<sup>\*2.</sup> The deceleration rate for decelerating to a stop is defined in the following object.

<sup>•</sup> Profile Position, Interpolated Position, Cyclic Position, or Cyclic Velocity Mode: 6084 Hex

<sup>•</sup> Homing Mode: 609A Hex

<sup>\*2.</sup> The deceleration rate for decelerating to a stop is defined in the following object.

Profile Position, Interpolated Position, Cyclic Position, or Cyclic Velocity Mode: 6084 Hex

Homing Mode: 609A Hex

<sup>\*3.</sup> Quick stop deceleration (6085 hex) is the deceleration rate for a quick stop.

### Fault Reaction Option Code (605E Hex)

This object defines the operation that is performed when an alarm is detected in the Servo Drive system.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
605E hex	0	Fault reaction option code	INT	RW	No	0	Yes

#### Data Description

Value	Description
0	Disables the Servo Drive. (Turns OFF the servo.)

### Modes of Operation (6060 Hex)

This object is used to select the operation mode. The Servo Drive gives the actual operation mode in the *modes of operation display* object.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6060 hex	0	Modes of operation	SINT	RW	Yes	0 to 10 (default: 0)	Yes

#### ◆ Data Description

Value	Description
0	There is no mode change or no mode assigned.
1	Profile Position Mode
2	Reserved (continue previous mode).
3	Profile Velocity Mode
4	Torque Profile mode
6	Homing Mode
7	Interpolated Position Mode
8	Cyclic Sync Position Mode
9	Cyclic Sync Velocity Mode
10	Cyclic Sync Torque Mode
Other value	Reserved (continue previous mode).

### Modes of Operation Display (6061 Hex)

This object gives the current mode of operation.

The values that are returned are the same as the object codes for *modes of operation* (6060 hex).

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6061 hex	0	Modes of operation display	SINT	RO	Yes	0	No

### Supported Drive Modes (6502 Hex)

This object gives the operation modes that are supported by the device.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6502 hex	0	Supported drive modes	UDINT	RO	No	03ED hex	No

### ◆ Data Description

Bit	Applicable Mode	Definition
0	Pp (Profile position mode)	1: Supported.
1	VI (Velocity mode)	0: Not supported.
2	Pv (Profile velocity mode)	1: Supported.
3	Tq (Torque profile mode)	1: Supported.
4	Reserved.	0
5	Hm (Homing mode)	1: Supported.
6	Ip (Interpolated position mode)	1: Supported.
7	Csp (Cyclic sync position mode)	1: Supported.
8	Csv (Cyclic sync velocity mode)	1: Supported.
9	Cst (Cyclic sync torque mode)	1: Supported.
10 to 31	Reserved.	0

### 14.7 Profile Position Mode

### Target Position (607A Hex)

This object contains the target position for the Profile Position Mode or Cyclic Synchronous Position Mode.

In Profile Position Mode, the value of this object is interpreted as either an absolute or relative value depending on the Abs/Rel Flag in controlword. In Cyclic Synchronous Position Mode, the value is always interpreted as an absolute value.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
607A hex	0	Target position	DINT	RW	Yes	-2,147,483,648 to 2,147,483,647 (default: 0) [Pos. unit]	No

### Software Position Limits (607D Hex)

This object defines the absolute positions of the limits to the target position (position demand value). Every target position is checked against these limits.

The limit positions are specified in user-defined position reference units, the same as for target positions, and are always relative to the machine home position.

The limit values are corrected internally for the home offset as given below. The target positions are compared with the corrected values.

- Corrected minimum position limit = Min position limit Home offset (607C hex)
- Corrected maximum position limit = Max position limit Home offset (607C hex)

The software position limits are enabled at the following times:

- · When homing is completed
- · When an absolute encoder is connected

The software limits are disabled if they are set as follows:

Min position limit ≥ Max position limit

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
607D hex	0	Number of entries	USINT	RO	No	2	No
	1	Min position limit	DINT	RW	No	-536,870,912 to 536,870,911 (default: 0) [Pos. unit]	Yes
	2	Max position limit	DINT	RW	No	-536,870,912 to 536,870,911 (default: 0) [Pos. unit]	Yes

### Max Profile Velocity (607F Hex)

This object contains the maximum speed during a Profile Mode operation.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
607F hex	0	Max profile velocity	UDINT	RW	Yes	0 to 4,294,967,295 (default: 2,147,483,647) [Vel. unit]	Yes

### Profile Velocity (6081 Hex)

This object contains the final movement speed at the end of acceleration for a Profile Mode operation.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6081 hex	0	Profile velocity	UDINT	RW	Yes	0 to 4,294,967,295 (default: 0) [Vel. unit]	Yes

### Profile Acceleration (6083 Hex)

This object specifies the acceleration rate for Profile Mode operations.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6083 hex	0	Profile acceleration	UDINT	RW	Yes	0 to 4,294,967,295 (default: 1,000) [Acc. unit]	Yes

### Profile Deceleration (6084 Hex)

This object specifies the deceleration rate for Profile Mode operations.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6084 hex	0	Profile deceleration	UDINT	RW	Yes	0 to 4,294,967,295 (default: 1,000) [Acc. unit]	Yes

### Quick Stop Deceleration (6085 Hex)

This object contains the deceleration rate that is used to stop the motor if the *quick stop option* code (605A hex) is set to 2 and the Quick Stop command is given.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6085 hex	0	Quick stop deceleration	UDINT	RW	Yes	0 to 4,294,967,295 (default: 1,000) [Acc. unit]	Yes

## 14.8 Homing Mode

### Home Offset (607C Hex)

This object contains the offset between the zero position for the application and the machine home position (found during homing).


Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
607C hex	0	Home offset	DINT	RW	No	-536,870,912 to 536,870,911 (default: 0) [Pos. unit]	Yes

#### Incremental Encoder

The machine home position is found during homing. After homing is completed, the zero position is offset from the home position by adding the home offset to the home position.

#### · Absolute Encoder

If an absolute encoder is connected to the SERVOPACK, the home offset is added to the encoder absolute position when the power supply to the SERVOPACK is turned ON.



### Homing Method (6098 Hex)

This object specifies the homing method. Refer to the following section for details on the operations that are performed.

(3.4 Homing on page 13-14

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6098 hex	0	Homing method	SINT	RW	Yes	0 to 35 (default: 35)	No

### Data Description

Value (Method)	Description
0	Homing is disabled.
1	Homing with the negative limit switch and index pulse
2	Homing with the positive limit switch and index pulse
7 to 14	Homing with the home switch and index pulse
24	Homing with the home switch
28	Homing with the home switch
33 or 34	Homing with the index pulse
35	Homing with the current position

### Homing Speeds (6099 Hex)

This object defines the speeds that are used during homing. The speeds are given in user speed reference units.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6099 hex	0	Number of entries	USINT	RO	No	2	No
	1	Speed during search for switch	UDINT	RW	Yes	0 to 4,294,967,295 (default: 500,000) [Vel. unit]	Yes
	2	Speed during search for zero	UDINT	RW	Yes	0 to 4,294,967,295 (default: 100,000) [Vel. unit]	Yes

### Homing Acceleration (609A Hex)

This object defines the acceleration that is used during homing. The rate is given in user acceleration reference units.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
609A hex	0	Homing acceleration	UDINT	RW	Yes	0 to 4,294,967,295 (default: 1,000) [Acc. unit]	Yes

## 14.9 Position Control Function

### Position Demand Value (6062 Hex)

This object specifies the current reference position in user position reference units.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6062 hex	0	Position demand value	DINT	RO	Yes	- [Pos. unit]	No

### Position Actual Internal Value (6063 Hex)

This object gives the current feedback position in encoder pulse units.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6063 hex	0	Position actual inter- nal value	DINT	RO	Yes	- [inc]	No

### Position Actual Value (6064 Hex)

This object gives the current feedback position in user position reference units.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6064 hex	0	Position actual value	DINT	RO	Yes	– [Pos. unit]	No

### Position Demand Internal Value (60FC Hex)

This object gives the output of the trajectory generator during position control (the position that is input to the position loop). The value is given in encoder pulses.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60FC hex	0	Position demand internal value	DINT	RO	Yes	- [inc]	No

### Following Error Window (6065 Hex)

This object defines the detection range for the following error (bit 13 of statusword).

If the position deviation exceeds the *following error window* for the *following error time out* (6066 hex), bit 13 in *statusword* changes to 1 to indicate following error. A following error can occur when the Servo Drive is blocked, when the profile speed is too high, or when the gain settings are not correct.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6065 hex	0	Following error window	UDINT	RW	No	0 to 1,073,741,823 (default: 5,242,880) [Pos. unit]	Yes

### Following Error Time Out (6066 Hex)

If the position deviation exceeds the *following error window* for the time specified in this object, bit 13 in *statusword* changes to 1 to indicate following error.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6066 hex	0	Following error time out	UINT	RW	No	0 to 65,535 (default: 0) [ms]	Yes

### Following Error Actual Value (60F4 Hex)

This object provides the current following error.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60F4 hex	0	Following error actual value	DINT	RO	Yes	– [Pos. unit]	No

### Position Window (6067 Hex)

This object defines the positioning completed width for the target position. When the Servo Drive has completed outputting the reference to the target position and the time specified in *position window time* (6068 hex) has passed after the distance between the target position and the *position actual value* is within the value of this object, bit 10 (*target reached*) in *statusword* changes to 1.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6067 hex	0	Position window	UDINT	RW	No	0 to 1,073,741,823 (default: 30) [Pos. unit]	Yes

### Position Window Time (6068 Hex)

When the Servo Drive has completed outputting the reference to the target position and the time specified in this object has passed after the distance between the target position and the position actual value is within the position window (6067 hex), bit 10 (target reached) in statusword changes to 1.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6068 hex	0	Position window time	UINT	RW	No	0 to 65,535 (default: 0) [ms]	Yes

## 14.10 Interpolated Position Mode

### Interpolation Submode Select (60C0 Hex) (Object Shared by Mode 1 and Mode 2)

This object is used to select the submode for the Interpolated Position Mode. To use Interpolated Position Mode, set this object first.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60C0 hex	0	Interpolation sub mode select	INT	RW	No	-3 to 0 (default: 0)	No

#### Data Description

Value (Method)	Des	cription	
0	Selects mode 1 with no position reference filter.	Interpolation data record (60C1 hex) is used	
-1	Selects mode 1 with a position reference filter.*	as the interpolation position reference.	
-2	Selects mode 2 with no position reference filter.	Interpolation data record for 1st profile (27C0 hex) and interpolation data record for 2nd	
-3	Selects mode 2 with a position reference filter.*	profile (27C1 hex) are used as the interpolation position references.	

<sup>\*</sup> If a reference filter is used, the moving average of the interpolation position over the interpolation time period (60C2 hex) is used.

### Interpolation Data Record (60C1 Hex) (Object Shared by Mode 1 and Mode 2)

This object gives the interpolation position reference for Interpolated Position Mode.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	1	No
60C1 hex	1	Interpolation data record	DINT	RW	Yes	-2,147,483,648 to 2,147,483,647 (default: 0) [Pos. unit]	No

### Interpolation Time Period (60C2 hex) (Object Shared by Mode 1 and Mode 2)

This object defines the interpolated position reference period for Interpolation Position Mode. If DC Sync0 Mode is selected, the interpolation time period is automatically stored as the Sync0 Cycle Time. If DC Free-Run Mode is selected, set the object manually.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	2	No
60C2 hex	1	Interpolation time period value	USINT	RW	No	1 to 250 (default:125)	No
	2	Interpolation time index	SINT	RW	No	-6 to -3 (default: -3)	No

Interpolation time = (Interpolation time period (60C2 hex: 01))  $\times$  10 Interpolation time index (60C2 hex: 02) [s]

Note: You can change this object only under the following conditions.

- When DC Sync0 Mode Is Selected:
- EtherCAT (CoE) is in the Switch ON Disable state.

   When DC Free-run Mode Is Selected:
- EtherCAT (CoE) is in the Switch ON Disable state.

Or, EtherCAT (CoE) is in Interpolated Position Mode and enable interpolation equals 0.

### Manufacturer Interpolation Data Configuration for 1st Profile (2730 hex) (Mode 2 Object)

This object sets how to use the interpolation position reference in interpolation data record for 1st profile (27C0 hex).

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	9	No
	1	Maximum buffer size	UDINT	RO	No	254	No
	2	Actual buffer size	UDINT	RW	No	254	No
	3	Buffer organization	USINT	RW	No	0 or 1 (default: 0)	No
	4	Buffer position	UINT	RW	Yes	1 to 254 (default: 1)	No
	5	Size of data record	USINT	RO	No	1	No
2730 hex	6	Buffer clear	USINT	RO	No	0 or 1 (default: 0)	No
	7	Position data definition	USINT	RW	Yes	0 or 1 (default: 1)	No
	8	Position data polarity	USINT	RW	Yes	0 or 1 (default: 0)	No
	9	Behavior after reaching buffer position	USINT	RW	Yes	0 or 1 (default: 0)	No

### ◆ 2730 Hex: 3 Buffer Organization

Value (Method)	Description
0	Uses the reference input buffer as a FIFO buffer.
1	Uses the reference input buffer is as a ring buffer.

Note: Do not change this value while enable interpolation (6040 hex bit 4) is 1.

#### ◆ 2730 Hex: 4 Buffer Position

The object contains the entry point for the available area in the reference input buffer.

Note: Do not change this value while enable interpolation (6040 hex bit 4) is 1.

#### ◆ 2730 Hex: 6 Buffer Clear

Value (Method)	Description
0	Disables the reference input buffer.
1	Enables the reference input buffer.

#### ◆ 2730 Hex: 7 Position Data Definition

Value (Method)	Description
0	Uses the value in the reference input buffer as an absolute value.
1	Uses the value in the reference input buffer as a relative value.

To enable changing this value, set the write pointer (2741 hex: 2) and the read pointer (2741 hex: 1) to the same value.

#### ◆ 2730 Hex: 8 Position Data Polarity

Value (Method)	Description
0	Multiplies the value in the reference input buffer by 1.
1	Multiplies the value in the reference input buffer by -1.

This value is valid when position data definition (2730 hex: 7) is 1.

To enable changing this value, set the write pointer (2741 hex: 2) and the read pointer (2741 hex: 1) to the same value.

### ◆ 2730 Hex: 9 Behavior after Reaching Buffer Position

Value (Method)	Description
0	Holds the value of the read pointer (2741 hex: 1) when the read pointer (2741 hex: 1) equals the write pointer (2741 hex: 2) and <i>enable interpolation</i> is 0.
1	Initializes the value of the read pointer (2741 hex: 1) when the read pointer (2741 hex: 1) equals the write pointer (2741 hex: 2) and <i>enable interpolation</i> is 0.

This value is valid when buffer organization (2731 hex: 3) is 0.

# Manufacturer Interpolation Data Configuration for 2nd Profile (2731 Hex) (Mode 2 Object)

This object sets how to use the interpolation position reference in *interpolation data record for 2nd profile* (27C1 hex).

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
2731 hex	0	Number of entries	USINT	RO	No	9	No
	1	Maximum buffer size	UDINT	RO	No	254	No
	2	Actual buffer size	UDINT	RW	No	254	No
	3	Buffer organization	USINT	RW	No	0 or 1 (default: 0)	No
	4	Buffer position	UINT	RW	Yes	1 to 255 (default: 1)	No
	5	Size of data record	USINT	RO	No	1	No
	6	Buffer clear	USINT	RO	No	0 or 1 (default: 0)	No
	7	Position data definition	USINT	RW	Yes	0 or 1 (default: 0)	No
	8	Position data polarity	USINT	RW	Yes	0 or 1 (default: 0)	No
	9	Behavior after reaching buffer position	USINT	RW	Yes	0 or 1 (default: 0)	No

#### ◆ 2731 Hex: 3 Buffer Organization

Value (Method)	Description
0	Uses the reference input buffer as a FIFO buffer.
1	Uses the reference input buffer is as a ring buffer.

Note: Do not change this value while enable interpolation (6040 hex bit 4) is 1.

#### ◆ 2731 Hex: 4 Buffer Position

This object contains the entry point for the available area in the reference input buffer.

Note: Do not change this value while enable interpolation (6040 hex bit 4) is 1.

#### ◆ 2731 Hex: 6 Buffer Clear

Value (Method)	Description
0	Disables the reference input buffer.
1	Enables the reference input buffer.

#### ◆ 2731 Hex: 7 Position Data Definition

Value (Method)	Description
0	Uses the value in the reference input buffer as an absolute value.
1	Uses the value in the reference input buffer as a relative value.

To enable changing this value, set the write pointer (2741 hex: 2) and the read pointer (2741 hex: 1) to the same value.

#### ◆ 2731 Hex: 8 Position Data Polarity

Value (Method)	Description
0	Multiplies the value in the reference input buffer by 1.
1	Multiplies the value in the reference input buffer by -1.

This value is valid when position data definition (2731 hex: 7) is 1.

To enable changing this value, set the write pointer (2741 hex: 2) and the read pointer (2741 hex: 1) to the same value.

#### ◆ 2731 Hex: 9 Behavior after Reaching Buffer Position

Value (Method)	Description
0	Holds the value of the read pointer (2741 hex: 1) when the read pointer (2741 hex: 1) equals the write pointer (2741 hex: 2) and <i>enable interpolation</i> is 0.
1	Initializes the value of the read pointer (2741 hex: 1) when the read pointer (2741 hex: 1) equals the write pointer (2741 hex: 2) and <i>enable interpolation</i> is 0.

This value is valid when buffer organization (2731 hex: 3) is 0.

#### Interpolation Profile Select (2732 Hex) (Mode 2 Object)

This object is used to select the type of interpolation profile to use.

Change the interpolation profile only after execution of the current profile has been completed. You can change the object when *enable interpolation* (6040 hex bit 4) is 0.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
2732 hex	0	Interpolation profile select	USINT	RW	Yes	0 or 1 (default: 0)	No

#### ◆ Data Description

Value (Method)	Description
0	Uses the 1st profile. (interpolation data record for 1st profile (27C0 hex) and manufacturer interpolation data configuration for 1st profile (2730 hex) are enabled.)
1	Uses the 2nd profile. (interpolation data record for 2nd profile (27C1 hex) and manufacturer interpolation data configuration for 2nd profile (2731 hex) are enabled.)

Note: Do not change this value while enable interpolation (6040 hex bit 4) is 1.

# Interpolation Data Record for 1st Profile (27C0 Hex) (Mode 2 Object)

This object is used to set the interpolation position reference for the 1st profile in Buffer Strategies for the Interpolated Position Mode.

Set this object only after setting all of the items in *manufacturer interpolation data configuration* for 1st profile (2730 hex).

After you set this object, set enable interpolation (6040 hex bit 4) to 1.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	254	No
27C0 hex	1 to 254	1st set point to 254th set point	DINT	RW	No	-2,147,483,648 to 2,147,483,647 (default:0)	No

# Interpolation Data Record for 2nd Profile (27C1 Hex) (Mode 2 Object)

This object is used to set the interpolation position reference for the 2nd profile in Buffer Strategies for the Interpolated Position Mode.

Set this object only after setting all of the items in *manufacturer interpolation data configuration* for 2nd profile (2731 hex).

After you set this object, set enable interpolation (6040 hex bit 4) to 1.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	254	No
27C1 hex	1 to 254	1st set point to 254th set point	DINT	RW	No	-2,147,483,648 to 2,147,483,647 (default:0)	No

# Interpolation Data Read/Write Pointer Position Monitor (2741 Hex) (Mode 2 Object)

This object gives the current values of the read and write pointers for the reference input buffers in the EtherCAT (CoE) Network Module.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
2741 hex	0	Number of entries	USINT	RO	No	2	No
	1	Interpolation data read pointer position	UINT	RO	Yes	1 to 254	No
	2	Interpolation data write pointer position	UINT	RO	Yes	1 to 254	No

#### ◆ 2741 Hex: 1 Interpolation Data Read Pointer Position

This object gives the current value of the read pointer for the reference input buffer in the Ether-CAT (CoE) Network Module.

#### ◆ 2741 Hex: 2 Interpolation Data Write Pointer Position

This object gives the current value of the write pointer for the reference input buffer in the EtherCAT (CoE) Network Module.

### 14.11

# Cyclic Synchronous Position Mode

### Velocity Offset (60B1 Hex)

In Cyclic Synchronous Position Mode, this object contains the speed feedforward value.

In Cyclic Synchronous Velocity Mode, this object contains the offset value to add to the speed reference.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60B1 hex	0	Velocity offset	DINT	RW	Yes	-2,147,483,648 to 2,147,483,647 (default: 0) [Vel. unit]	No

#### Torque Offset (60B2 Hex)

In Cyclic Synchronous Position Mode or Cyclic Synchronous Velocity Mode, this object contains the torque feedforward value. In Cyclic Synchronous Torque Mode, this object contains the offset value to add to the torque reference.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60B2 hex	0	Torque offset	INT	RW	Yes	-32,768 to 32,767 (default: 0) [0.1%]	No

# 14.12 Profile Velocity/Cyclic Synchronous Velocity Mode

#### Velocity Demand Value (606B Hex)

This object contains the output value from the velocity trajectory generator or the output value from the position control function (i.e., the input reference for the speed loop).

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
606B hex	0	Velocity demand value	DINT	RO	Yes	- [Vel. unit]	No

#### Velocity Actual Value (606C Hex)

This object contains the motor speed.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
606C hex	0	Velocity actual value	DINT	RO	Yes	– [Vel. unit]	No

#### **Velocity Window (606D Hex)**

This object sets the speed coincidence detection width.

When the time specified in velocity window time (606E hex) has passed after the difference between the target speed (target velocity) and the velocity actual value is within the setting of the velocity window, bit 10 (target reached) in statusword is set to 1.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
606D hex	0	Velocity window	UINT	RW	No	0 to 65,535 (default: 20,000) [Vel. unit]	Yes

#### Velocity Window Time (606E Hex)

When the time specified in velocity window time (606E hex) has passed after the difference between the target speed (target velocity) and the velocity actual value is within the setting of the velocity window, bit 10 (target reached) in statusword is set to 1.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
606E hex	0	Velocity window time	UINT	RW	No	0 to 65,535 (default: 0) [ms]	Yes

#### Target Velocity (60FF Hex)

This object specifies the target speed for Profile Velocity Mode or Cyclic Synchronous Velocity Mode in user defined speed reference units.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60FF hex	0	Target velocity	DINT	RW	Yes	-2,147,483,648 to 2,147,483,647 (default: 0) [Vel. unit]	No

## 14.13 Profile Torque/Cyclic Synchronous Torque Mode

#### Target Torque (6071 Hex)

This object specifies the input torque reference value for Torque Control Mode. Set the value in units of 0.1% of the motor rated torque.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6071 hex	0	Target torque	INT	RW	Yes	-32,768 to 32,767 (default: 0) [0.1%]	No

#### Torque Demand Value (6074 Hex)

This object gives the currently output torque reference value. The value is given in units of 0.1% of the motor rated torque.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6074 hex	0	Torque demand value	INT	RO	Yes	- [0.1%]	No

#### Torque Slope (6087 Hex)

This object sets the torque output slope to use in Profile Torque Mode. Set the value as the rate of change per second (0.1%/s) in respect to the motor rated torque.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6087 hex	0	Torque slope	UDINT	RW	Yes	0 to 4,294,967,295 (default:1,000) [0.1%/s]	Yes

#### Motor Rated Torque (6076 Hex)

This object gives the motor rated torque (rated force for a Linear Servomotor). The value is given in m Nm for a Rotary Servomotor, and in m N for a Linear Servomotor.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6076 hex	0	Motor rated torque	UDINT	RO	No	-[mNm] or [mN]	No

#### Torque Actual Value (6077 Hex)

For a SERVOPACK, this object contains the same value as the torque reference output value.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6077 hex	0	Torque actual value	INT	RO	Yes	- [0.1%]	No

# 14.14 Torque Limit Function

#### Max Torque (6072 Hex)

This object sets the maximum output torque for the motor. Set the value in units of 0.1% of the motor rated torque.

The maximum motor torque is automatically set in this object when the power is turned ON.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
6072 hex	0	Max torque	UINT	RW	Yes	0 to 65,535 (default: maximum motor torque) [0.1%]	No

#### Positive Torque Limit Value (60E0 Hex)

This object sets the positive torque limit. Set the value in units of 0.1% of the motor rated torque.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60E0 hex	0	Positive torque limit value	UINT	RW	Yes	0 to 65,535 (default: 8,000) [0.1%]	Yes

#### Negative Torque Limit Value (60E1 Hex)

This object sets the negative torque limit. Set the value in units of 0.1% of the motor rated torque.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	EEPROM
60E1 hex	0	Negative torque limit value	UINT	RW	Yes	0 to 65,535 (default: 8,000) [0.1%]	Yes

# 14.15 Touch Probe Function

#### Touch Probe Function (60B8 Hex)

This object sets the touch probes.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60B8 hex	0	Touch probe function	UINT	RW	Yes	0 to 0xFFFF (default: 0)	No

#### Data Description

Bit	Value	Description			
0	0	Disables touch probe 1.			
U	1	Enables touch probe 1.			
4	0	Single Trigger Mode (Latches the position at the first trigger event.)			
ı	1	Continuous Trigger Mode (Latches the position every trigger event.)			
2	0	Triggers on probe 1 input (SERVOPACK CN1/Probe 1 (SI4) signal).			
2	1	Triggers on encoder zero signal (phase C).			
3	-	Reserved.			
4	0	Stops sampling at touch probe 1.			
4	1	Starts sampling at touch probe 1			
5 to 7	-	Reserved.			
8	0	Disables touch probe 2.			
0	1	Enables touch probe 2.			
9	0	Single Trigger Mode (Latches the position at the first trigger event.)			
9	1	Continuous Trigger Mode (Latches the position every trigger event.)			
10	0	Triggers on probe 2 input (SERVOPACK CN1/Probe 2 (SI5) signal).			
10	1	Reserved.			
11	-	Reserved.			
12	0	Stops sampling at touch probe 2.			
12	1	Starts sampling at touch probe 2			
13 to 15	-	Reserved.			

Note: 1. Bits 0 to 7: For touch probe 1. Bits 8 to 15: For touch probe 2.

- 2. Touch probe 1 cannot be used during execution of homing. If touch probe 1 was already enabled, it will be disabled when homing is started.
- 3. If 1 is specified for bit 1 (i.e., if Continuous Trigger Mode is set), the setting of bit 2 (Trigger Selection Signal) will be read each time the latch is started. To continuously latch with the same trigger signal, do not change the status of bit 2.

#### Touch Probe Status (60B9 Hex)

This object gives the status of the touch probes.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60B9 hex	0	Touch probe status	UINT	RO	Yes	_	No

#### ◆ Data Description

Bit	Value	Description			
0	0	Touch probe 1 is disabled.			
O	1	Touch probe 1 is enabled.			
	0	No latched position is stored for touch probe 1.			
1	1	A latch position is stored for touch probe 1.			
2 to 6	-	Reserved.			
7	0 or 1	Saving the latched position for Continuous Trigger Mode for touch probe 1 was completed.* (Status toggles every time a position is latched.)			
8	0	Touch probe 2 is disabled.			
0	1	Touch probe 2 is enabled.			
9	0	No latched position is stored for touch probe 2.			
9	1	A latch position is stored for touch probe 2.			
10 to 14	-	Reserved.			
15	1	Saving the latched position for Continuous Trigger Mode for touch probe 2 was completed.* (Status toggles every time a position is latched.)			

<sup>\*</sup> If the continuous latch is enabled (60B8 hex bit 1 = 1 or bit 9 = 1), bit 7 or bit 15 of object 60B9 hex is toggled every time the latched position is updated.

#### Touch Probe 1 Position Value (60BA Hex)

This object gives the latched position for touch probe 1. The value is given in user position units (Pos. unit).

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60BA hex	0	Touch probe 1 position value	DINT	RO	Yes	- [Pos. unit]	No

#### Touch Probe 2 Position Value (60BC Hex)

This object gives the latched position for touch probe 2. The value is given in user position units (Pos. unit).

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60BC hex	0	Touch probe 2 position value	DINT	RO	Yes	- [Pos. unit]	No

# 14.16 Digital Inputs/Outputs

### Digital Inputs (60FD Hex)

This object gives the status of the digital inputs to CN1 on the SERVOPACK.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60FD hex	0	Digital inputs	UDINT	RO	Yes	_	No

#### ◆ Data Description

Bit	Signal	Description
0	N-OT: Negative limit switch	0: OFF, 1: ON
1	P-OT: Positive limit switch	0: OFF, 1: ON
2	Home switch	0: OFF, 1: ON
3 to 15	-	Reserved.
16	SIO	0: OFF (open), 1: ON (closed)
17	SI1	0: OFF (open), 1: ON (closed)
18	SI2	0: OFF (open), 1: ON (closed)
19	SI3	0: OFF (open), 1: ON (closed)
20	SI4	0: OFF (open), 1: ON (closed)
21	SI5	0: OFF (open), 1: ON (closed)
22	SI6	0: OFF (open), 1: ON (closed)
23	-	Reserved.
24	HWBB1	Hardwired base block signal input 1 (0: Open, 1: Closed)
25	HWBB2	Hardwired base block signal input 2 (0: Open, 1: Closed)
26 to 31	_	Reserved.

#### Digital Outputs (60FE Hex)

This object controls the status of the general-purpose output signals (SO1 to SO5) from CN1 on the SERVOPACK.

Subindex 1 is used to control the status of the output signals. Subindex 2 determines which output signals in subindex 1 are enabled.

If SERVOPACK status outputs are assigned to the SO1 to SO5 signals in objects 250E hex, 250F hex, and 2510 hex, the status will be output using ORs with the settings in this object. If any of these signals (SO1 to SO5) are assigned to functions that are enabled with objects 250E hex, 250F hex, or 2510 hex, use the Bit Masks in subindex 2 to disable the corresponding signals so that the signals are not duplicated.

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
60FE hex	0	Number of entries	USINT	RO	No	2	No
	1	Physical outputs*1	UDINT	RW	Yes	0 to 0xFFFFFFF (default: 0)	No
•	2	Bit mask*2	UDINT	RW	No	0 to 0xFFFFFFFF (default: 0x000C0000)	Yes

<sup>\*1.</sup> Data Description of Physical Outputs:

Bit	Signal	Description
0 to 16	-	Reserved.
17	SO1	0: OFF, 1: ON
18	SO2	0: OFF, 1: ON
19	SO3	0: OFF, 1: ON
20	SO4	0: OFF, 1: ON
21	SO5	0: OFF, 1: ON
22 to 31	-	Reserved.

#### \*2. Data Description of Bit Masks:

Bit	Signal	Description
0 to 16	_	Reserved.
17	SO1	0: Disables physical output. 1: Enables physical output.
18	SO2	0: Disables physical output. 1: Enables physical output.
19	SO3	0: Disables physical output. 1: Enables physical output.
20	SO4	0: Disables physical output. 1: Enables physical output.
21	SO5	0: Disables physical output. 1: Enables physical output.
22 to 31	-	Reserved.

# 14.17 Dual Encoder Feedback

You can monitor the position of the external encoder in dual encoder feedback (60E4 hex).

Index	Subin- dex	Name	Data Type	Access	PDO Mapping	Value	Saving to EEPROM
	0	Number of entries	USINT	RO	No	1	No
60E4 hex	1	External encoder position	DINT	RO	Yes	(Default: 0)	Yes

# Maintenance

This chapter provides information on the meaning of, causes of, and corrections for alarms and warnings. In this chapter, the object index number (2000 hex) for EtherCAT communications is given after the SERVOPACK parameter number (Pn000)

15.1	Inspe	ctions and Part Replacement 15-2
	15.1.1 15.1.2 15.1.3	Inspections
15.2	Alarm	Displays15-5
	15.2.1 15.2.2 15.2.3 15.2.4 15.2.5 15.2.6	List of Alarms
15.3	Warni	ng Displays
	15.3.1 15.3.2	List of Warnings
15.4	Troublesh	ooting Based on the Operation and Conditions of the Servomotor15-51

#### 15.1.1 Inspections

### 15.1 Ir

## **Inspections and Part Replacement**

This section describes inspections and part replacement for SERVOPACKs.

### 15.1.1 Inspections

Perform the inspections given in the following table at least once every year for the SERVO-PACK. Daily inspections are not required.

Item	Frequency	Inspection	Correction
Exterior		Check for dust, dirt, and oil on the surfaces.	Clean with compressed air or a cloth.
Loose Screws	At least once a year	Check for loose terminal block and connector screws and for other loose parts.	Tighten any loose screws or other loose parts.

### 15.1.2 Guidelines for Part Replacement

The following electric or electronic parts are subject to mechanical wear or deterioration over time. Use one of the following methods to check the standard replacement period.

- Use the service life prediction function of the SERVOPACK.
   Refer to the following section for information on service life predictions.
   9.4 Monitoring Product Life on page 9-13
- Use the following table.

Part	Standard Replace- ment Period	Remarks
Cooling Fan	4 to 5 years	The standard replacement periods given on the left are for
Electrolytic Capacitor	10 years	<ul> <li>the following operating conditions.</li> <li>Surrounding air temperature: Annual average of 30°C</li> <li>Load factor: 80% max.</li> <li>Operation rate: 20 hours/day max.</li> </ul>
Inrush Current Limit- ing Circuit Relay	100,000 power ON operations	Power ON frequency: Once an hour
Battery	3 years without power supplied	Surrounding temperature without power supplied: 20°C
Built-in Brake Relay*	30,000 operations	Allowable number of operations: 30 operations per minute max.

<sup>\*</sup> Only SERVOPACKs with built-in Servomotor brake control have a built-in brake relay.

When any standard replacement period is close to expiring, contact your Yaskawa representative. After an examination of the part in question, we will determine whether the part should be replaced.



The parameters of any SERVOPACKs that are sent to Yaskawa for part replacement are reset to the factory settings before they are returned to you. Always keep a record of the parameter settings. And, always confirm that the parameters are properly set before starting operation.

15

#### 15.1.3 Replacing the Battery

If the battery voltage drops to approximately 2.7 V or less, an A.830 alarm (Encoder Battery Alarm) or an A.930 warning (Encoder Battery Warning) will be displayed.

If this alarm or warning is displayed, the battery must be replaced.

Refer to the following section for the battery replacement procedure.

Battery Replacement Procedure on page 15-3


#### **Battery Alarm/Warning Selection**

Whether to display an alarm or a warning is determined by the setting of  $Pn008 = n.\Box\Box\Box X$  (Low Battery Voltage Alarm/Warning Selection).

Parameter		Meaning	When Enabled	Classification
Pn008 (2008 hex)	n.□□□0 (default setting)	Output alarm (A.830) for low battery voltage.	After restart	Setup
(2006 Hex)	n. 🗆 🗆 🗆 1	Output warning (A.930) for low battery voltage.		

- $Pn008 = n.\Box\Box\Box0$
- The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply
  is turned ON, and then the battery voltage is monitored for four seconds.
   No alarm will be displayed even if the battery voltage drops below the specified value after
  these four seconds.
- Pn008 = n.□□□1

The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored continuously.



#### **Battery Replacement Procedure**

- When Installing a Battery on the Host Controller
- 1. Turn ON only the control power supply to the SERVOPACK.
- 2. Remove the old battery and mount a new battery.
- 3. Turn OFF the control power supply to the SERVOPACK to clear the A.830 alarm (Absolute Encoder Battery Error).
- 4. Turn ON the control power supply to the SERVOPACK again.
- 5. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.

#### 15.1.3 Replacing the Battery


#### ◆ When Using an Encoder Cable with a Battery Case

1. Turn ON only the control power supply to the SERVOPACK.




If you remove the battery or disconnect the Encoder Cable while the control power supply to the SERVOPACK is OFF, the absolute encoder data will be lost.


2. Open the cover of the Battery Case.



3. Remove the old battery and mount a new battery.



4. Close the cover of the Battery Case.



- **5.** Turn OFF the power supply to the SERVOPACK to clear the A.830 alarm (Absolute Encoder Battery Error).
- 6. Turn ON the power supply to the SERVOPACK.
- 7. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.

# 15

# 15.2 Alarm Displays

If an error occurs in the SERVOPACK, an alarm number will be displayed on the panel display.

Panel display on SERVOPACK	If there is an alarm, the code will be displayed one character at a time, as shown below.  Example: Alarm A.020  Status display  Not lit.
Digital Operator	The alarm code will be displayed.
Statusword (6041 hex)	Bit 3 (fault) in the statusword will change to 1. (Bit 3 is 0 during normal operation.)
Error Code (603F hex)	A current alarm code is stored in object 603F hex.
Emergency message	The Controller is notified of any alarm that occurs. (Notification may not be possible if EtherCAT communications are unstable.)

This section provides a list of the alarms that may occur and the causes of and corrections for those alarms.

#### 15.2.1 List of Alarms

The following alarm tables gives the alarm name, alarm meaning, alarm stopping method, and alarm reset possibility in order of the alarm codes.

#### **Servomotor Stopping Method for Alarms**

Refer to the following section for information on the stopping method for alarms.

5.12.2 Servomotor Stopping Method for Alarms on page 5-38

#### **Alarm Reset Possibility**

Yes: You can use an alarm reset to clear the alarm. However, this assumes that the cause of the alarm has been removed.

No: You cannot clear the alarm.

#### **List of Alarms**

Alarm Code	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
020 hex	Parameter Checksum Error	There is an error in the parameter data in the SERVOPACK.	Gr.1	No
021 hex	Parameter Format Error	There is an error in the parameter data format in the SERVOPACK.	Gr.1	No
022 hex	System Checksum Error	There is an error in the parameter data in the SERVOPACK.	Gr.1	No
024 hex	System Alarm	An internal program error occurred in the SER-VOPACK.	Gr.1	No
025 hex	System Alarm	An internal program error occurred in the SER-VOPACK.	Gr.1	No
030 hex	Main Circuit Detector Error	There is an error in the detection data for the main circuit.	Gr.1	Yes

#### 15.2.1 List of Alarms

Continued from previous page.

		Continued		ao pago.
Alarm Code	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
040 hex	Parameter Setting Error	A parameter setting is outside of the setting range.	Gr.1	No
041 hex	Encoder Output Pulse Setting Error	The setting of Pn212 (2212 hex) (Encoder Output Pulses) or Pn281 (2281 hex) (Encoder Output Resolution) is outside of the setting range or does not satisfy the setting conditions.	Gr.1	No
042 hex	Parameter Combination Error	<ul> <li>The value of the program jogging movement speed (Pn533 (2533 hex) or Pn585 (2585 hex)) is below the setting range.</li> <li>The required parameters (Pn001, Pn601, and Pn604) have not been set.</li> </ul>	Gr.1	No
044 hex	Semi-Closed/Fully-Closed Loop Control Parameter Setting Error	The settings of the Option Module and Pn002 = n.XDDD (External Encoder Usage) do not match.	Gr.1	No
050 hex	Combination Error	The capacities of the SERVOPACK and Servomotor do not match.	Gr.1	Yes
051 hex	Unsupported Device Alarm	An unsupported device was connected.	Gr.1	No
070 hex	Motor Type Change Detected	The connected motor is a different type of motor from the previously connected motor.	Gr.1	No
080 hex	Linear Encoder Pitch Set- ting Error	The setting of Pn282 (2282 hex) (Linear Encoder Pitch) has not been changed from the default setting.	Gr.1	No
0b0 hex	Invalid Servo ON Com- mand Alarm	The Servo ON command (Enable Operation command) was sent from the host controller after a utility function that turns ON the Servomotor was executed.	Gr.1	Yes
100 hex	Overcurrent Detected	An overcurrent flowed through the power transformer or the heat sink overheated.	Gr.1	No
101 hex	Motor Overcurrent Detected	The current to the motor exceeded the allowable current.	Gr.1	No
231 hex	Built-in Brake Relay Answer Error	The built-in brake relay malfunctioned.	Gr.1	No
232 hex	Built-in Brake Relay Life Alarm	The number of built-in brake relay operations exceeded the service life of the relay.	Gr.1	No
300 hex	Regeneration Error	There is an error related to regeneration.	Gr.1	Yes
320 hex	Regenerative Overload	A regenerative overload occurred.	Gr.2	Yes
330 hex	Main Circuit Power Supply Wiring Error	<ul> <li>The AC power supply input setting or DC power supply input setting is not correct.</li> <li>The power supply wiring is not correct.</li> </ul>	Gr.1	Yes
400 hex	Overvoltage	The main circuit DC voltage is too high.	Gr.1	Yes
410 hex	Undervoltage	The main circuit DC voltage is too low.	Gr.2	Yes
450 hex	Main-Circuit Capacitor Overvoltage	The capacitor in the main circuit has deteriorated or is faulty.	Gr.1	No
510 hex	Overspeed	The motor exceeded the maximum speed.	Gr.1	Yes
511 hex	Encoder Output Pulse Overspeed	<ul> <li>Rotary Servomotor: The pulse output speed for the setting of Pn212 (2212 hex) (Encoder Output Pulses) was exceeded.</li> <li>Linear Servomotor: The motor speed upper limit for the setting of Pn281 (2281 hex) (Encoder Output Resolution) was exceeded.</li> </ul>	Gr.1	Yes
520 hex	Vibration Alarm	Abnormal oscillation was detected in the motor speed.	Gr.1	Yes

15

Continued from previous page.

Alarm Code	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
521 hex	Autotuning Alarm	Vibration was detected during autotuning for the tuning-less function.	Gr.1	Yes
550 hex	Maximum Speed Setting Error	The setting of Pn385 (2385 hex) (Maximum Motor Speed) is greater than the maximum motor speed.	Gr.1	Yes
710 hex	Instantaneous Overload	The Servomotor was operating for several seconds to several tens of seconds under a torque that largely exceeded the rating.	Gr.2	Yes
720 hex	Continuous Overload	The Servomotor was operating continuously under a torque that exceeded the rating.	Gr.1	Yes
730 hex 731 hex	Dynamic Brake Overload	When the dynamic brake was applied, the rotational or linear kinetic energy exceeded the capacity of the Dynamic Brake Resistor.	Gr.1	Yes
740 hex	Inrush Current Limiting Resistor Overload	The main circuit power supply was frequently turned ON and OFF.	Gr.1	Yes
7A1 hex	Internal Temperature Error 1 (Control Board Tempera- ture Error)	The surrounding temperature of the control PCB is abnormal.	Gr.2	Yes
7A2 hex	Internal Temperature Error 2 (Power Board Tempera- ture Error)	The surrounding temperature of the power PCB is abnormal.	Gr.2	Yes
7A3 hex	Internal Temperature Sensor Error	An error occurred in the temperature sensor circuit.	Gr.2	No
7A4 hex	Power Transistor Over- heated (Abnormal power transistor temperature.)	The temperature of the power transistor is abnormal.	Gr.2	No
7Ab hex	SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Gr.1	Yes
810 hex	Encoder Backup Alarm	The power supplies to the encoder all failed and the position data was lost.	Gr.1	No
820 hex	Encoder Checksum Alarm	There is an error in the checksum results for encoder memory.	Gr.1	No
830 hex	Encoder Battery Alarm	The battery voltage was lower than the specified level after the control power supply was turned ON.	Gr.1	Yes
840 hex	Encoder Data Alarm	There is an internal data error in the encoder.	Gr.1	No
850 hex	Encoder Overspeed	The encoder was operating at high speed when the power was turned ON.	Gr.1	No
860 hex	Encoder Overheated	The internal temperature of encoder is too high.	Gr.1	No
861 hex	Motor Overheated	The internal temperature of motor is too high.	Gr.1	No
890 hex	Encoder Scale Error	A failure occurred in the linear encoder.	Gr.1	No
891 hex	Encoder Module Error	An error occurred in the linear encoder.	Gr.1	No
8A0 hex*2	External Encoder Error	An error occurred in the external encoder.	Gr.1	Yes
8A1 hex*2	External Encoder Module Error	An error occurred in the Serial Converter Unit.	Gr.1	Yes
8A2 hex*2	External Incremental Encoder Sensor Error	An error occurred in the external encoder.	Gr.1	Yes
8A3 hex*2	External Absolute Encoder Position Error	An error occurred in the position data of the external encoder.	Gr.1	Yes
8A5 hex*2	External Encoder Over- speed	An overspeed error occurred in the external encoder.	Gr.1	Yes
	1	Conti	nued on n	

#### 15.2.1 List of Alarms

Continued from previous page.

		Continued t	rom previo	ous page.
Alarm Code	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
8A6 hex <sup>*2</sup>	External Encoder Over- heated	An overheating error occurred in the external encoder.	Gr.1	Yes
A10 hex	EtherCAT DC Synchroni- zation Error *1	The SERVOPACK and Sync0 events cannot be synchronized.	Gr.2	Yes
A11 hex	EtherCAT State Error	The EtherCAT AL does not move to the Operational state when the DS402 drive is in Operation Enabled state.	Gr.2	Yes
A12 hex	EtherCAT Outputs Data Synchronization Error *1	The process data reception events and Sync0 events cannot be synchronized. (Process data communications failed.)	Gr.2	Yes
A20 hex	Parameter Setting Error	A parameter setting exceeds the setting range.	Gr.1	No
A40 hex	System Initialization Error	Initialization failed when the power supply was turned ON.	Gr.1	No
A41 hex	Communication Device Initialization Error	An error occurred during ESC initialization.	Gr.1	No
A47 hex	Loading Servo Information Error	Loading SERVOPACK information failed.	Gr.1	No
A48 hex	EEPROM Parameter Data Error	A checksum error occurred in the EEPROM.	Gr.1	No
b33 hex	Current Detection Error 3	An error occurred in the current detection circuit.	Gr.1	No
bF0 hex	System Alarm 0	Internal program error 0 occurred in the SERVO-PACK.	Gr.1	No
bF1 hex	System Alarm 1	Internal program error 1 occurred in the SERVO-PACK.	Gr.1	No
bF2 hex	System Alarm 2	Internal program error 2 occurred in the SERVO-PACK.	Gr.1	No
bF3 hex	System Alarm 3	Internal program error 3 occurred in the SERVO-PACK.	Gr.1	No
bF4 hex	System Alarm 4	Internal program error 4 occurred in the SERVO-PACK.	Gr.1	No
C10 hex	Servomotor Out of Control	The Servomotor ran out of control.	Gr.1	Yes
C20 hex	Phase Detection Error	The detection of the phase is not correct.	Gr.1	No
C21 hex	Polarity Sensor Error	An error occurred in the polarity sensor.	Gr.1	No
C22 hex	Phase Information Disagreement	The phase information does not match.	Gr.1	No
C50 hex	Polarity Detection Failure	The polarity detection failed.	Gr.1	No
C51 hex	Overtravel Detected during Polarity Detection	The overtravel signal was detected during polarity detection.	Gr.1	Yes
C52 hex	Polarity Detection Not Completed	The servo was turned ON before the polarity was detected.	Gr.1	Yes
C53 hex	Out of Range of Motion for Polarity Detection	The travel distance exceeded the setting of Pn48E (248E hex) (Polarity Detection Range).	Gr.1	No
C54 hex	Polarity Detection Failure 2	The polarity detection failed.	Gr.1	No
C80 hex	Encoder Clear Error or Multiturn Limit Setting Error	The multiturn data for the absolute encoder was not correctly cleared or set.	Gr.1	No
C90 hex	Encoder Communications Error	Communications between the encoder and SER-VOPACK is not possible.	Gr.1	No
C91 hex	Encoder Communications Position Data Acceleration Rate Error	An error occurred in calculating the position data of the encoder.	Gr.1	No
	•	01	nued on n	

Continued from previous page.

		Continued	rom previo	rus page.
Alarm Code	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
C92 hex	Encoder Communications Timer Error	An error occurred in the communications timer between the encoder and SERVOPACK.	Gr.1	No
CA0 hex	Encoder Parameter Error	The parameters in the encoder are corrupted.	Gr.1	No
Cb0 hex	Encoder Echoback Error	The contents of communications with the encoder are incorrect.	Gr.1	No
CC0 hex	Multiturn Limit Disagree- ment	Different multiturn limits have been set in the encoder and the SERVOPACK.	Gr.1	No
CF1 hex*2	Reception Failed Error in Feedback Option Module Communications	Receiving data from the Feedback Option Module failed.	Gr.1	No
CF2 hex*2	Timer Stopped Error in Feedback Option Module Communications	An error occurred in the timer for communications with the Feedback Option Module.	Gr.1	No
d00 hex	Position Deviation Over- flow	The setting of Pn520 (2520 hex) (Excessive Position Deviation Alarm Level) was exceeded by the position deviation while the servo was ON.	Gr.1	Yes
d01 hex	Position Deviation Over- flow Alarm at Servo ON	The servo was turned ON after the position deviation exceeded the setting of Pn526 (2526 hex) (Excessive Position Deviation Alarm Level at Servo ON) while the servo was OFF.	Gr.1	Yes
d02 hex	Position Deviation Over- flow Alarm for Speed Limit at Servo ON	If position deviation remains in the deviation counter, the setting of Pn529 (2529 hex) or Pn584 (2584 hex) (Speed Limit Level at Servo ON) will limit the speed when the servo is turned ON. This alarm occurs if a position reference is input and the setting of Pn520 (2520 hex) (Excessive Position Deviation Alarm Level) is exceeded before the limit is cleared.	Gr.2	Yes
d10 hex*2	Motor-Load Position Deviation Overflow	There was too much position deviation between the motor and load during fully-closed loop control.	Gr.2	Yes
d30 hex	Position Data Overflow	The position feedback data exceeded ±1,879,048,192.	Gr.1	No
E00 hex	EtherCAT Module Inter- face Initialization Timeout Error	Communications initialization failed between the SERVOPACK and the EtherCAT Module.	Gr.2	Yes
E02 hex	EtherCAT Internal Syn- chronization Error 1	A synchronization error occurred during Ether-CAT communications with the SERVOPACK.	Gr.1	Yes
E03 hex	EtherCAT Module Inter- face Communications Data Error	There is an error in the communications data between the SERVOPACK and the EtherCAT Module.	Gr.1	Yes
E71 hex	Safety Option Module Detection Failure	Detection of the Safety Option Module failed.	Gr.1	No
E72 hex	Feedback Option Module Detection Failure	Detection of the Feedback Option Module failed.	Gr.1	No
E74 hex	Unsupported Safety Option Module Alarm	An unsupported Safety Option Module was connected.	Gr.1	No
E75 hex*2	Unsupported Feedback Option Module Alarm	An unsupported Feedback Option Module was connected.	Gr.1	No
EA0 hex	Command-Option IF Servo Unit Initial Error	Communications could not be initialized between the SERVOPACK and EtherCAT (CoE) Network Module within 10 seconds.	Gr.1	No

#### 15.2.1 List of Alarms

Continued from previous page.

Alarm Code	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
EA1 hex	Command-Option IF Memory Check Error	An error occurred in communications memory between the SERVOPACK and EtherCAT (CoE) Network Module.	Gr.1	No
EA2 hex	Command-Option IF Servo Synchronization Error *1	Communications could not be synchronized between the SERVOPACK and EtherCAT (CoE) Network Module.	Gr.1	Yes
EA3 hex	Command-Option IF Servo Data Error *1	An error occurred in communications data between the SERVOPACK and EtherCAT (CoE) Network Module.	Gr.1	Yes
Eb1 hex	Safety Function Signal Input Timing Error	An error occurred in the input timing of the safety function signal.	Gr.1	No
EC8 hex	Gate Drive Error 1	An error occurred in the gate drive circuit.	Gr.1	No
EC9 hex	Gate Drive Error 2	An error occurred in the gate drive circuit.	Gr.1	No
Ed1 hex	Command Execution Timeout	A timeout error occurred for a EtherCAT command.	Gr.2	Yes
F10 hex	Power Supply Line Open Phase	The voltage was low for more than one second for phase R, S, or T when the main power supply was ON.	Gr.2	Yes
F50 hex	Servomotor Main Circuit Cable Disconnection	The Servomotor did not operate or power was not supplied to the Servomotor even though the Servo ON command (Enable Operation command) was input when the Servomotor was ready to receive it.	Gr.1	Yes
FL-1*3				
FL-2*3		An internal program error occurred in the SER-		N.1
FL-3*3 FL-4*3	System Alarm	VOPACK.	_	No
FL-4 <sup>3</sup> FL-5*3				
CPF00	Digital Operator Commu- nications Error 1	Communications were not possible between the		No
CPF01	Digital Operator Commu- nications Error 2	Digital Operator (model: JUSP-OP05A-1-E) and the SERVOPACK (e.g., a CPU error occurred).	_	INO

<sup>\$1.</sup> The EtherCAT communications state moved to SAFEOP after an alarm was detected.

Note: The Eb0 hex, Eb2 hex to Eb9 hex, and EC0 hex to EC2 hex alarms can occur when a Safety Module is connected. Refer to the following manual for details.

<sup>\*2.</sup> This alarm can occur when a Fully-closed Option Module is mounted.

<sup>\*3.</sup> These alarms are not stored in the alarm history. They are only displayed on the panel display.

AC Servo Drive Σ-V-Series/Σ-V-Series for Large-Capacity Models/Σ-7-Series User's Manual Safety Module (Manual No.: SIEP C720829 06)

### Troubleshooting Alarms

15.2.2

The causes of and corrections for the alarms are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	Set the power supply voltage within the specified range, and initialize the parameter settings.	page 5-10
	The power supply was shut OFF while writing parameter settings.	Check the timing of shutting OFF the power supply.	Initialize the parameter settings and then set the parameters again.	page e le
020 hex: Parameter	The number of times that parameters were written exceeded the limit.	Check to see if the parameters were frequently changed from the host controller.	The SERVOPACK may be faulty. Replace the SER-VOPACK. Reconsider the method for writing the parameters.	-
Checksum Error (There is an error in the parameter data in the SER- VOPACK.)	A malfunction was caused by noise from the AC power supply, ground, static electricity, or other source.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, noise may be the cause.	Implement countermeasures against noise.	page 4-5
	Gas, water drops, or cutting oil entered the SERVOPACK and caused failure of the internal components.	Check the installation conditions.	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
	A failure occurred in the SERVOPACK.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, the SERVOPACK may have failed.	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
021 hex: Parameter Format Error (There is an error in the parameter data format in the	The software version of the SERVOPACK that caused the alarm is older than the software version of the parameters specified to write.	Read the product information to see if the software versions are the same. If they are different, it could be the cause of the alarm.	Write the parameters from another SERVOPACK with the same model and the same software version, and then turn the power OFF and ON again.	page 9-2
SERVOPACK.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_
O22 hex: System Check- sum Error (There is an error in the parameter data in the SER- VOPACK.)	The power supply was shut OFF while setting a utility function.	Check the timing of shutting OFF the power supply.	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_
	A failure occurred in the SERVOPACK.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, the SERVOPACK may have failed.	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code:	Possible Cause	Confirmation	Correction	Reference
Alarm Name 024 hex:				
System Alarm (An internal program error occurred in the SERVOPACK.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
O25 hex: System Alarm (An internal pro- gram error occurred in the SERVOPACK.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
030 hex: Main Circuit Detector Error	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_
040 hex: Parameter Set-	The SERVOPACK and Servomotor capacities do not match each other.	Check the combination of the SERVOPACK and Servomotor capacities.	Select a proper combination of SERVOPACK and Servomotor capacities.	page 1-11
ting Error (A parameter set- ting is outside of	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
the setting range.)	A parameter setting is outside of the setting range.	Check the setting ranges of the parameters that have been changed.	Set the parameters to values within the setting ranges.	-
041 hex: Encoder Output Pulse Setting Error	The setting of Pn212 (2212 hex) (Encoder Output Pulses) or Pn281 (2281 hex) (Encoder Output Resolution) is outside of the setting range or does not satisfy the setting conditions.	Check the setting of Pn212 (2212 hex) or Pn281 (2281 hex).	Set Pn212 (2212 hex) or Pn281 (2281 hex) to an appropriate value.	page 6-23
042 hex:	The speed of program jogging went below the setting range when Pn533 (2533 hex) or Pn585 (2585 hex) (Program Jogging Speed) was changed.	Check to see if the detection conditions*1 are satisfied.	Increase the setting of Pn533 (2533 hex) or Pn585 (2585 hex).	page 7-13
Parameter Combination Error	There is an error in the settings for the Dynamic Brake Resistor (Pn601 and Pn604) in comparison with the dynamic brake stopping method setting (when Pn001 is set to n.□□□0).	Check Pn601 (Dynamic Brake Resistor Allow- able Energy Consump- tion) and Pn604 (Dynamic Brake Resis- tance).	Set Pn601 and Pn604 correctly.	-
044 hex: Semi-Closed/ Fully-Closed Loop Control Parameter Setting Error	The setting of the Fully-closed Module does not match the setting of Pn002 (2002 hex) = n.X□□□ (External Encoder Usage).	Check the setting of Pn002 (2002 hex) = n.X□□□.	Make sure that the setting of the Fully-closed Module agrees with the setting of Pn002 (2002 hex) = n.X□□□.	page 10-6

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
050 hex: Combination Error	The SERVOPACK and Servomotor capacities do not match each other.	Check the capacities to see if they satisfy the following condition:  1/4 ≤ Servomotor capacity / SERVOPACK capacity ≤ 4	Select a proper combination of the SERVOPACK and Servomotor capacities.	page 1-11
(The capacities of the SERVOPACK and Servomotor do not match.)	A failure occurred in the encoder.	Replace the encoder and check to see if the alarm still occurs.	Replace the Servomotor or encoder.	-
,	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
051 hex:	The motor parameter file was not written to the linear encoder. (This applies only when not using a Serial Converter Unit.)	Check to see if the motor parameter file was written to the linear encoder.	Write the motor parameter file to the linear encoder.	page 5-16
Unsupported Device Alarm	An unsupported Serial Converter Unit or encoder (e.g., an external encoder) is connected to the SERVOPACK.	Check the product combination specifications.	Change to a correct combination of models.	-
070 hex: Motor Type Change Detected (The connected motor is a differ- ent type of motor from the previ- ously connected motor.)	A Rotary Servomotor was removed and a Linear Servomotor was connected.	-	Set the parameters for a Linear Servomotor and reset the motor type alarm. Then, turn the power supply to the SER- VOPACK OFF and ON again.	page 15-43
	A Linear Servomotor was removed and a Rotary Servomotor was connected.	_	Set the parameters for a Rotary Servomotor and reset the motor type alarm. Then, turn the power supply to the SER- VOPACK OFF and ON again.	page 15-43
080 hex: Linear Encoder Pitch Setting Error	The setting of Pn282 (2282 hex) (Linear Encoder Pitch) has not been changed from the default setting.	Check the setting of Pn282 (2282 hex).	Correct the setting of Pn282 (2282 hex).	page 5-15
0b0 hex: Invalid Servo ON Command Alarm	The Servo ON command (Enable Operation command) was sent from the host controller after a utility function that turns ON the Servomotor was executed.	_	Turn the power supply to the SERVOPACK OFF and ON again. Or, execute a software reset.	page 6-44

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The Main Circuit Cable is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	
	There is a short-circuit or ground fault in a Main Circuit Cable.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, and W.	The cable may be short-circuited. Replace the cable.	
	There is a short-circuit or ground fault inside the Servomotor.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, or W.	The Servomotor may be faulty. Replace the Servomotor.	page 4-19
	There is a short-circuit or ground fault inside the SERVOPACK.	Check for short-circuits across the Servomotor connection terminals U, V, and W on the SER-VOPACK, or between the ground and terminals U, V, or W.	The SERVOPACK may be faulty. Replace the SER-VOPACK.	
100 hex: Overcurrent Detected (An overcurrent	The Regenerative Resistor is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	page 4-18
(An overcurrent flowed through the power transformer or the heat sink overheated.)	The dynamic brake (DB, emergency stop executed from the SERVOPACK) was frequently activated, or a DB overload alarm occurred.	Check the power consumed by the DB resistor to see how frequently the DB is being used. Or, check the alarm display to see if a DB overload alarm (A.730 or A.731) has occurred.	Change the SERVOPACK model, operating methods, or the mechanisms so that the dynamic brake does not need to be used so frequently.	-
	The regenerative processing capacity was exceeded.	Check the regenerative load ratio in the SigmaWin+ Motion Monitor Tab Page to see how frequently the Regenerative Resistor is being used.	Recheck the operating conditions and load.	*2
	The SERVOPACK regenerative resistance is too small.	Check the regenerative load ratio in the SigmaWin+ Motion Monitor Tab Page to see how frequently the Regenerative Resistor is being used.	Change the regenerative resistance to a value larger than the SERVO-PACK minimum allowable resistance.	-
	A heavy load was applied while the Servomotor was stopped or running at a low speed.	Check to see if the operating conditions exceed Servo Drive specifications.	Reduce the load applied to the Servomotor. Or, increase the operating speed.	-

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
100 hex: Overcurrent Detected (An overcurrent	A malfunction was caused by noise.	Improve the noise environment, e.g. by improving the wiring or installation conditions, and check to see if the alarm still occurs.	Implement countermeasures against noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVO-PACK's main circuit wire size.	-
flowed through the power trans- former or the heat sink overheated.)	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The Main Circuit Cable is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	
	There is a short-circuit or ground fault in a Main Circuit Cable.	Check for short-circuits across cable phases U, V, and W, or between the ground and cable phases U, V, and W.	The cable may be short-circuited. Replace the cable.	
	There is a short-circuit or ground fault inside the Servomotor.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, or W.	The Servomotor may be faulty. Replace the Servomotor.	page 4-19
101 hex: Motor Overcurrent Detected (The current to the motor exceeded the	There is a short-circuit or ground fault inside the SERVOPACK.	Check for short-circuits across the Servomotor connection terminals U, V, and W on the SER-VOPACK, or between the ground and terminals U, V, or W.	The SERVOPACK may be faulty. Replace the SER-VOPACK.	
allowable cur- rent.)	A heavy load was applied while the Servomotor was stopped or running at a low speed.	Check to see if the operating conditions exceed Servo Drive specifications.	Reduce the load applied to the Servomotor. Or, increase the operating speed.	_
	A malfunction was caused by noise.	Improve the noise environment, e.g. by improving the wiring or installation conditions, and check to see if the alarm still occurs.	Implement countermea- sures against noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVO- PACK's main circuit wire size.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
231 hex: Built-in Brake Relay Answer Error	A malfunction was caused by noise.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, noise may be the cause.	Implement countermea- sures against noise.	-
	The built-in brake relay failed.	_	Replace the part. Contact your Yaskawa representative for replacement.	-

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
232 hex: Built-in Brake Relay Life Alarm	The service life of the built-in brake relay was exceeded.	_	Replace the part. Contact your Yaskawa representative for replacement.	-
	The jumper between the Regenerative Resistor terminals (B2 and B3) was removed from an SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, or -170D SERVOPACK.	Check to see if the jumper is connected between power supply terminals B2 and B3.	Correctly connect a jumper.	page 4-18
300 hex: Regeneration Error	The External Regenerative Resistor is not wired correctly, or was removed or disconnected.	Check the wiring of the External Regenerative Resistor.	Correct the wiring of the External Regenerative Resistor.	
	A failure occurred in the SERVOPACK.	_	While the main circuit power supply is OFF, turn the control power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the power supply voltage within the specified range.	_
	The external regenerative resistance value or Regenerative Resistor capacity is too small, or there has been a continuous regeneration state.	Check the operating conditions or the capacity.	Change the regenerative resistance value or capacity. Reconsider the operating conditions.	*2
	There was a continuous regeneration state because a negative load was continuously applied.	Check the load applied to the Servomotor during operation.	Reconsider the system including the servo, machine, and operating conditions.	-
320 hex: Regenerative Overload	The setting of Pn600 (2600 hex) (Regenerative Resistor Capacity) is smaller than the capacity of the External Regenerative Resistor.	Check to see if a Regenerative Resistor is connected and check the setting of Pn600 (2600 hex).	Correct the setting of Pn600 (2600 hex).	page 5-55
	The setting of Pn603 (2603 hex) (Regenerative Resistance) is smaller than the capacity of the External Regenerative Resistor.	Check to see if a Regenerative Resistor is connected and check the setting of Pn603 (2603 hex).	Correct the setting of Pn603 (2603 hex).	page 5-55
	The external regenerative resistance is too high.	Check the regenerative resistance.	Change the regenerative resistance to a correct value or use an External Regenerative Resistor of an appropriate capacity.	*2
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	n next nage

15

Continued from previous page.

Alarm Code:	Possible Cause	Confirmation	Correction	Reference
Alarm Name	The Regenerative Resistor was discon- nected when the SERVOPACK power supply voltage was high.	Measure the resistance of the Regenerative Resistor using a measuring instrument.	If you are using the Regenerative Resistor built into the SERVOPACK, replace the SERVOPACK. If you are using an Exter- nal Regenerative Resis- tor, replace the External	-
330 hex: Main Circuit Power Supply Wiring Error (Detected when the main circuit power supply is	DC power was supplied when an AC power supply input was specified in the settings.	Check the power supply to see if it is a DC power supply.	Regenerative Resistor.  Correct the power supply setting to match the actual power supply.	- page 5-12
turned ON.)	AC power was supplied when a DC power supply input was specified in the settings.	Check the power supply to see if it is an AC power supply.	Correct the power supply setting to match the actual power supply.	page 3-12
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the AC/DC power supply voltage within the specified range.	-
	The power supply is not stable or was influenced by a lightning surge.	Measure the power supply voltage.	Improve the power supply conditions, install a Surge Absorber, and then turn the power supply OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SER-VOPACK.	-
400 hex: Overvoltage (Detected in the	The voltage for AC power supply was too high during acceleration or deceleration.	Check the power supply voltage and the speed and torque during operation.	Set the AC power supply voltage within the specified range.	-
main circuit power supply section of the SERVOPACK.)	The external regenerative resistance is too high for the operating conditions.	Check the operating conditions and the regenerative resistance.	Select a regenerative resistance value that is appropriate for the operating conditions and load.	*2
	The moment of inertia ratio or mass ratio exceeded the allowable value.	Check to see if the moment of inertia ratio or mass ratio is within the allowable range.	Increase the deceleration time, or reduce the load.	-
	A failure occurred in the SERVOPACK.	_	While the main circuit power supply is OFF, turn the control power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Cada			Continued from pre	avious page.
Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage went below the specified range.	Measure the power supply voltage.	Set the power supply voltage within the specified range.	_
	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.	_
410 hex: Undervoltage (Detected in the main circuit power supply	A momentary power interruption occurred.	Measure the power supply voltage.	If you have changed the setting of Pn509 (2509 hex) (Momentary Power Interruption Hold Time), decrease the setting.	page 6-14
section of the SERVOPACK.)	The SERVOPACK fuse is blown out.	-	Replace the SERVO- PACK and connect a reactor to the DC Reac- tor terminals (⊝1 and ⊝2) on the SERVOPACK.	-
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_
450 hex: Main-Circuit Capacitor Overvoltage (The capacitor in the main circuit has deteriorated or is faulty.)	A failure occurred in the SERVOPACK.	_	Replace the SERVO-PACK.	-
	The order of phases U, V, and W in the motor wiring is not correct.	Check the wiring of the Servomotor.	Make sure that the Servo- motor is correctly wired.	-
510 hex: Overspeed (The motor	A reference value that exceeded the over- speed detection level was input.	Check the input reference.	Reduce the reference value. Or, adjust the gain.	
exceeded the maximum speed.)	The motor exceeded the maximum speed.	Check the waveform of the motor speed.	Reduce the speed reference input gain and adjust the servo gain. Or, reconsider the operating conditions.	_
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_
511 hex: Encoder Output	The encoder output pulse frequency exceeded the limit.	Check the encoder output pulse setting.	Decrease the setting of Pn212 (2212 hex) (Encoder Output Pulses) or Pn281 (2281 hex) (Encoder Output Resolu- tion).	page 6-23
Pulse Overspeed	The encoder output pulse frequency exceeded the limit because the motor speed was too high.	Check the encoder output pulse setting and the motor speed.	Reduce the motor speed.	-

Continued from previous page.

Alarm Code: Continued from previous page.				
Alarm Name	Possible Cause	Confirmation	Correction	Reference
	Abnormal oscillation was detected in the motor speed.	Check for abnormal motor noise, and check the speed and torque waveforms during operation.	Reduce the motor speed. Or, reduce the setting of Pn100 (2100 hex) (Speed Loop Gain).	page 8-76
520 hex: Vibration Alarm	The setting of Pn103 (2103 hex) (Moment of Inertia Ratio) is greater than the actual moment of inertia or was greatly changed.	Check the moment of inertia ratio or mass ratio.	Correct the setting of Pn103 (2103 hex).	page 8-16
	The vibration detection level (Pn312 or Pn384) is not suitable.	Check that the vibration detection level (Pn312 or Pn384) is suitable.	Set a suitable vibration detection level (Pn312 or Pn384).	page 6-46
521 hex: Autotuning Alarm (Vibration was detected while executing the	The Servomotor vibrated considerably while performing the tuning-less function.	Check the waveform of the motor speed.	Reduce the load so that the moment of inertia ratio is within the allowable value. Or increase the load level or reduce the rigidity level in the tuning- less level settings.	page 8-13
custom tuning, Easy FFT, or the tuning-less func- tion.)	The Servomotor vibrated considerably while performing custom tuning or Easy FFT.	Check the waveform of the motor speed.	Check the operating procedure of corresponding function and implement corrections.	page 8-41, page 8-92
550 hex: Maximum Speed Setting Error	The setting of Pn385 (2385 hex) (Maximum Motor Speed) is greater than the maximum speed.	Check the setting of Pn385 (2385 hex), and the upper limits of the maximum motor speed setting and the encoder output resolution set- ting.	Set Pn385 (2385 hex) to a value that does not exceed the maximum motor speed.	page 6-17
	The wiring is not correct or there is a faulty contact in the motor or encoder wiring.	Check the wiring.	Make sure that the Servo- motor and encoder are correctly wired.	page 4-19
	Operation was performed that exceeded the overload protection characteristics.	Check the motor over- load characteristics and Run command.	Reconsider the load and operating conditions. Or, increase the motor capacity.	-
710 hex: Instantaneous Overload 720 hex:	An excessive load was applied during operation because the Servomotor was not driven due to mechanical problems.	Check the operation reference and motor speed.	Correct the mechanical problem.	-
Continuous Overload	There is an error in the setting of Pn282 (2282 hex) (Linear Encoder Pitch).	Check the setting of Pn282 (2282 hex).	Correct the setting of Pn282 (2282 hex).	page 5-15
	There is an error in the setting of Pn080 (2080 hex) = n.□□X□ (Motor Phase Selection).	Check the setting of Pn080 (2080 hex) = n.□□X□.	Set Pn080 (2080 hex) = n.□□X□ to an appropriate value.	page 5-20
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The Servomotor was rotated by an external force.	Check the operation status.	Implement measures to ensure that the motor will not be rotated by an external force.	-
730 hex and 731 hex: Dynamic Brake Overload (An excessive power consumption by the dynamic brake was detected.)	When the Servomotor was stopped with the dynamic brake, the rotational or linear kinetic energy exceeded the capacity of the Dynamic Brake Resistor.	Check the power consumed by the DB resistor to see how frequently the DB is being used.	Reconsider the following:  Reduce the Servomotor command speed.  Decrease the moment of inertia ratio or mass ratio.  Reduce the frequency of stopping with the dynamic brake.	-
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_
740 hex: Inrush Current Limiting Resistor Overload (The main circuit power supply	The allowable frequency of the inrush current limiting resistor was exceeded when the main circuit power supply was turned ON and OFF.	_	Reduce the frequency of turning the main circuit power supply ON and OFF.	-
was frequently turned ON and OFF.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surrounding temperature by improving the SERVO-PACK installation conditions.	page 3-6
7A1 hex:	An overload alarm was reset by turning OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
Internal Temperature Error 1 (Control Board Temperature Error)	There was an excessive load or operation was performed that exceeded the regenerative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenerative load ratio to check the regenerative processing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVOPACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_

Continued from previous page.

Continued from previous page.				
Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surrounding temperature by improving the SERVO-PACK installation conditions.	page 3-6
7A2 hex:	An overload alarm was reset by turning OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
Internal Temperature Error 2 (Power Board Temperature Error)	There was an excessive load or operation was performed that exceeded the regenerative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenerative load ratio to check the regenerative processing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVOPACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
7A3 hex: Internal Tempera- ture Sensor Error (An error occurred in the temperature sen- sor circuit.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
Sol Gircuit.)	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surrounding temperature by improving the SERVO-PACK installation conditions.	page 3-6
70.4 hove	An overload alarm was reset by turning OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
7A4 hex: Power Transistor Overheated (Abnormal power transistor tem- perature.)	There was an excessive load or operation was performed that exceeded the regenerative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenerative load ratio to check the regenerative processing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVOPACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
7Ab hex: SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Check for foreign matter inside the SERVOPACK.	Remove foreign matter from the SERVOPACK. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The power to the absolute encoder was turned ON for the first time.	Check to see if the power supply was turned ON for the first time.	Set up the encoder.	
810 hex:	The Encoder Cable was disconnected and then connected again.	Check to see if the power supply was turned ON for the first time.	Check the encoder connection and set up the encoder.	page 5-49
Encoder Backup Alarm (Detected at the encoder, but only when an abso- lute encoder is used.)	Power is not being supplied both from the control power supply (+5 V) from the SERVOPACK and from the battery power supply.	Check the encoder connector battery and the connector status.	Replace the battery or implement similar measures to supply power to the encoder, and set up the encoder.	
	A failure occurred in the absolute encoder.	_	If the alarm still occurs after setting up the encoder again, replace the Servomotor.	-
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
820 hex: Encoder Check- sum Alarm (Detected at the encoder.)	A failure occurred in the encoder.	_	■ When Using an Absolute Encoder Set up the encoder again. If the alarm still occurs, the Servomotor may be faulty. Replace the Servomotor. ■ When Using a Singleturn Absolute Encoder or Incremental Encoder or Incremental Encoder. • The Servomotor may be faulty. Replace the Servomotor. • The linear encoder may be faulty. Replace the linear encoder.	page 5-49
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER-VOPACK.	-
830 hex: Encoder Battery	The battery connection is faulty or a battery is not connected.	Check the battery connection.	Correct the battery connection.	page 4-20
Alarm (The absolute encoder battery voltage was lower	The battery voltage is lower than the specified value (2.7 V).	Measure the battery voltage.	Replace the battery.	page 15-3
than the speci- fied level.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_

15

Continued from previous page. Alarm Code: Possible Cause Confirmation Correction Reference Alarm Name Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still The encoder malfuncoccurs, the Servomotor or tioned. linear encoder may be faulty. Replace the Servomotor or linear encoder. The linear encoder is not mounted within an appro-An error occurred in reading data from the priate tolerance. Correct linear encoder. the mounting of the linear encoder. 840 hex: Control the motor speed **Encoder Data** within the range specified Excessive speed Alarm by the linear encoder occurred in the linear (Detected at the manufacturer and then encoder. encoder.) turn ON the control power supply. Correct the wiring around the encoder by separating The encoder malfuncthe Encoder Cable from tioned due to noise. the Servomotor Main Circuit Cable or by grounding the encoder. Correct the wiring of the The polarity sensor is Check the wiring of the not wired correctly. polarity sensor. polarity sensor. The polarity sensor Replace the polarity senfailed. Rotary Servomotor: Reduce the Servomotor The Servomotor Check the motor speed speed to a value less than speed was 200 min<sup>-1</sup> when the power supply 200 min<sup>-1</sup>, and turn ON or higher when the is turned ON. control power supply the control power supply. was turned ON. Linear Servomotor: Control the motor speed The Servomotor within the range specified Check the motor speed exceeded the speciby the linear encoder 850 hex: when the power supply manufacturer and then fied speed when the is turned ON. Encoder Overcontrol power supply turn ON the control power speed was turned ON. supply. (Detected at the Turn the power supply to encoder when the SERVOPACK OFF and the control power

supply is turned

ON.)

A failure occurred in

A failure occurred in the SERVOPACK.

the encoder.

Continued on next page.

ON again. If an alarm still

occurs, the Servomotor or

occurs, the SERVOPACK

may be faulty. Replace the

SERVOPACK.

linear encoder may be faulty. Replace the Servomotor or linear encoder.

Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Continued from previous page.				
Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
860 hex: Encoder Over- heated (Detected at the encoder, but only when an abso- lute encoder is used.)	The surrounding air temperature around the Servomotor is too high.	Measure the surrounding air temperature around the Servomotor.	Reduce the surrounding air temperature of the Servomotor to 40°C or less.	-
	The Servomotor load is greater than the rated load.	Use the accumulated load ratio to check the load.	Operate the Servo Drive so that the motor load remains within the specified range.	page 9-3
	A failure occurred in the encoder.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or absolute linear encoder may be faulty. Replace the Servomotor or absolute linear encoder.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
861 hex: Motor Over- heated	The surrounding temperature around the Servomotor is too high.	Measure the surrounding temperature around the Servomotor.	Reduce the surrounding air temperature of the Servomotor to 40° or less.	-
	The motor load is greater than the rated load.	Check the load with the accumulated load ratio on the Motion Monitor Tab Page on the SigmaWin+.	Operate the Servo Drive so that the motor load remains within the specified range.	page 9-3
	A failure occurred in the Serial Converter Unit.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Serial Con- verter Unit may be faulty. Replace the Serial Con- verter Unit.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
890 hex: Encoder Scale Error	A failure occurred in the linear encoder.	-	The linear encoder may be faulty. Replace the linear encoder.	-
891 hex: Encoder Module Error	A failure occurred in the linear encoder.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the linear encoder may be faulty. Replace the linear encoder.	-
8A0 hex: External Encoder Error	Setting the origin of the absolute linear encoder failed because the motor moved.	Before you set the origin, use the fully-closed feedback pulse counter to confirm that the motor is not moving.	The motor must be stopped while setting the origin position.	page 5-52
	A failure occurred in the external encoder.	_	Replace the external encoder.	_

Continued from previous page.

Continued from previous page.				
Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
8A1 hex:	A failure occurred in the external encoder.	_	Replace the external encoder.	_
External Encoder Module Error	A failure occurred in the Serial Converter Unit.	_	Replace the Serial Converter Unit.	-
8A2 hex: External Incremental Encoder Sensor Error	A failure occurred in the external encoder.	_	Replace the external encoder.	-
8A3 hex: External Absolute Encoder Position Error	A failure occurred in the external absolute encoder.	_	The external absolute encoder may be faulty. Refer to the encoder manufacturer's instruction manual for corrections.	-
8A5 hex: External Encoder Overspeed	An overspeed error was detected in the external encoder.	Check the maximum speed of the external encoder.	Keep the external encoder below its maximum speed.	-
8A6 hex: External Encoder Overheated	An overheating error was detected in the external encoder.	_	Replace the external encoder.	_
A10 hex: EtherCAT DC Synchronization Error	The synchronization timing (Sync0) for EtherCAT communications fluctuated.	_	Turn the power supply OFF and ON again and reestablish communications.	-
A11 hex: EtherCAT State Error	The EtherCAT communications state left the Operational state during motor operation.	_	Reset the alarm and then re-establish communications.	-
	Noise caused an error in EtherCAT communications.	_	Check the EtherCAT wiring and implement noise countermeasures.	-
A12 hex: EtherCAT Output Data Synchroni- zation Error	The controller did not update the process data during the fixed period.	Check the process data specified by the controller.	Correct the controller so that the process data is updated during the fixed period.	-
Zation Enoi	The EtherCAT Communications Cable or connector wiring is faulty.	Check the EtherCAT Communications Cable and connector wiring.	Wire the connections correctly.	-
	The position unit is outside of the setting range.	Make sure it is within the following range. 1/4,096 < Numerator (2701 hex: 1)/Denomi- nator (2701 hex: 2) < 65,536	Correct the setting of position user unit (2701 hex).	-
A20 hex: Parameter Set- ting Error	The speed unit is outside of the setting range.	Make sure it is within the following range. 1/128 ≤ Numerator (2702 hex: 1)/Denomi- nator (2702 hex: 2) ≤ 8,388,608	Correct the setting of velocity user unit (2702 hex).	-
	The acceleration unit is outside of the setting range.	Make sure it is within the following range. 1/128 ≤ Numerator (2703 hex: 1)/Denominator (2703 hex: 2) ≤ 262,144	Correct the setting of acceleration user unit (2703 hex).	-

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A40 hex: System Initializa- tion Error	A failure occurred in the SERVOPACK.	_	Replace the SERVO-PACK.	-
A41 hex: Communications Device Initializa- tion Error	A failure occurred in the SERVOPACK.	-	Replace the SERVO-PACK.	-
	User parameter configuration (2700 hex) was executed while a utility function (Fn□□□) was being executed from the Digital Operator or SigmaWin+.		Turn the power supply OFF and ON again.	-
A47 hex: Loading Servo Information Error	The power supply was turned ON or user parameter configuration (2700 hex) was executed when an encoder was not connected.	Check the wiring of the encoder.	Turn OFF the power supply, correct the encoder connection, and then turn the power supply back ON.	-
	The power supply was turned ON or user parameter configuration (2700 hex) was executed when there was a Parameter Setting Error (alarm 040 hex).	Check the parameter settings.	Correct the parameter settings and turn the power supply OFF and ON again.	-
	A failure occurred in the SERVOPACK.	_	Replace the SERVO- PACK.	_
	The power supply was shut OFF while writing parameter settings.	Check the timing of shutting OFF the power supply.	Initialize the parameter settings (restore default parameters (1011 hex)) and then set the parameters again.	_
A48 hex: EEPROM Param-	The number of times that parameters were written exceeded the limit.	_	Repair or replace the SERVOPACK. Reconsider the method for writing the parameters.	-
eter Data Error	The power supply voltage suddenly dropped.	Measure the power supply voltage.	Set the power supply voltage within the specified range, and initialize the parameter settings (restore default parameters (1011 hex)).	-
	A failure occurred in the SERVOPACK.	_	Replace the SERVO-PACK.	_
b33 hex: Current Detection Error 3	A failure occurred in the current detection circuit.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
<b>bF0 hex:</b> System Alarm 0	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
bF1 hex: System Alarm 1	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
bF2 hex: System Alarm 2	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
bF3 hex: System Alarm 3	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
bF4 hex: System Alarm 4	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
C10 hex: Servomotor Out of Control (Detected when the servo is turned ON.)	The order of phases U, V, and W in the motor wiring is not correct.	Check the Servomotor wiring.	Make sure that the Servo- motor is correctly wired.	-
	There is an error in the setting of Pn080 (2080 hex) = n.□□X□ (Motor Phase Selection).	Check the setting of Pn080 (2080 hex) = n.□□X□.	Set Pn080 (2080 hex) = n.□□X□ to an appropriate value.	page 5-20
	A failure occurred in the encoder.	_	If the motor wiring is correct and an alarm still occurs after turning the power supply OFF and ON again, the Servomotor or linear encoder may be faulty. Replace the Servomotor or linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

#### 15.2.2 Troubleshooting Alarms

#### Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.C20: Phase Detection Error	The linear encoder signal level is too low.	Check the voltage of the linear encoder signal.	Fine-tune the mounting of the scale head. Or, replace the linear encoder.	-
	The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor.	Check the setting of Pn080 = n.□□X□ (Motor Phase Sequence Selection). Check the installation orientation for the linear encoder and Moving Coil.	Change the setting of Pn080 = n.□□X□. Correctly reinstall the linear encoder or Moving Coil.	page 5-20
	The polarity sensor signal is being affected by noise.	_	Correct the FG wiring. Implement countermea- sures against noise for the polarity sensor wiring.	-
	The setting of Pn282 (Linear Encoder Scale Pitch) is not correct.	Check the setting of Pn282 (Linear Encoder Scale Pitch).	Check the specifications of the linear encoder and set a correct value.	page 5-15
A.C21: Polarity Sensor Error	The polarity sensor is protruding from the Magnetic Way of the motor.	Check the polarity sensor.	Correctly reinstall the Moving Coil or Magnetic Way of the motor.	-
	The polarity sensor is not wired correctly.	Check the wiring of the polarity sensor.	Correct the wiring of the polarity sensor.	_
	The polarity sensor failed.	-	Replace the polarity sensor.	_
C22 hex: Phase Information Disagreement	The SERVOPACK phase information is different from the linear encoder phase information.	_	Perform polarity detection.	page 5-25

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction Correction	Reference
C50 hex: Polarity Detection Failure	The parameter set- tings are not correct.	Check the linear encoder specifications and feedback signal status.	The settings of Pn282 (2282 hex) (Linear Encoder Pitch) and Pn080 (2080 hex) = n.□□X□ (Motor Phase Selection) may not match the installation. Set the parameters to correct values.	page 5-15, page 5-20
	There is noise on the scale signal.	Check to make sure that the frame grounds of the Serial Converter Unit and Servomotor are connected to the FG terminal on the SER-VOPACK and that the FG terminal on the SER-VOPACK is connected to the frame ground on the power supply. And, confirm that the shield is properly processed on the Linear Encoder Cable. Check to see if the detection reference is repeatedly output in one direction.	Implement appropriate countermeasures against noise for the Linear Encoder Cable.	_
	An external force was applied to the Moving Coil of the motor.	_	The polarity cannot be properly detected if the detection reference is 0 and the speed feedback is not 0 because of an external force, such as cable tension, applied to the Moving Coil. Implement measures to reduce the external force so that the speed feedback goes to 0. If the external force cannot be reduced, increase the setting of Pn481 (2481 hex) (Polarity Detection Speed Loop Gain).	_
C50 hex: Polarity Detection Failure	The linear encoder resolution is too low.	Check the linear encoder scale pitch to see if it is within 100 μm.	If the linear encoder scale pitch is 100 µm or higher, the SERVOPACK cannot detect the correct speed feedback. Use a linear encoder scale pitch with higher resolution. (We recommend a pitch of 40 µm or less.) Or, increase the setting of Pn485 (2485 hex) (Polarity Detection Reference Speed). However, increasing the setting of Pn485 (2485 hex) will increase the Servomotor movement range that is required for polarity detection.	_

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
C51 hex: Overtravel Detected during Polarity Detection	The overtravel signal was detected during polarity detection.	Check the overtravel position.	Wire the overtravel signals. Execute polarity detection at a position where an overtravel signal would not be detected.	page 4-31
C52 hex: Polarity Detection Not Completed	The servo was turned ON when using an absolute linear encoder, Pn587 (2587 hex) was set to n.□□□0 (Do not detect polarity), and the polarity had not been detected.	_	When using an absolute linear encoder, set Pn587 (2587 hex) to n. \$\square\$ (Detect polarity)	-
C53 hex: Out of Range of Motion for Polarity Detection	The travel distance exceeded the setting of Pn48E (248E hex) (Polarity Detection Range) in the middle of detection.	-	Increase the setting of Pn48E (248E hex) (Polar- ity Detection Range). Or, increase the setting of Pn481 (2481 hex) (Polarity Detection Speed Loop Gain).	-
C54 hex: Polarity Detection Failure 2	An external force was applied to the Servomotor.	_	Increase the setting of Pn495 (2495 hex) (Polarity Detection Confirmation Force Reference). Increase the setting of Pn498 (2498 hex) (Polarity Detection Allowable Error Range). Increasing the allowable error will also increase the motor temperature.	-
C80 hex: Encoder Clear Error or Multiturn Limit Setting Error	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

15

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
C90 hex: Encoder Communications Error	There is a faulty contact in the connector or the connector is not wired correctly for the encoder.	Check the condition of the encoder connector.	Reconnect the encoder connector and check the encoder wiring.	page 4-19
	There is a cable disconnection or short-circuit in the encoder. Or, the cable impedance is outside the specified values.	Check the condition of the Encoder Cable.	Use the Encoder Cable within the specifications.	-
	One of the following has occurred: corrosion caused by improper temperature, humidity, or gas, a short-circuit caused by entry of water drops or cutting oil, or faulty contact in connector caused by vibration.	Check the operating environment.	Improve the operating environmental, and replace the cable. If the alarm still occurs, replace the SERVOPACK.	page 3-2
	A malfunction was caused by noise.	_	Correct the wiring around the encoder by separating the Encoder Cable from the Servomotor Main Circuit Cable or by grounding the encoder.	page 4-5
	A failure occurred in the SERVOPACK.	_	Connect the Servomotor to another SERVOPACK, and turn ON the control power supply. If no alarm occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
C91 hex: Encoder Communications Position Data Acceleration Rate Error	Noise entered on the signal lines because the Encoder Cable is bent or the sheath is damaged.	Check the condition of the Encoder Cable and connectors.	Check the Encoder Cable to see if it is installed correctly.	page 4-8
	The Encoder Cable is bundled with a high- current line or installed near a high- current line.	Check the installation condition of the Encoder Cable.	Confirm that there is no surge voltage on the Encoder Cable.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Check the installation condition of the Encoder Cable.	Properly ground the machine to separate it from the FG of the encoder.	-

#### 15.2.2 Troubleshooting Alarms

#### Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	Noise entered on the signal line from the encoder.	_	Implement countermeasures against noise for the encoder wiring.	page 4-5
	Excessive vibration or shock was applied to the encoder.	Check the operating conditions.	Reduce machine vibration. Correctly install the Servomotor or linear encoder.	_
C92 hex: Encoder Communications Timer Error	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
CA0 hex: Encoder Parame- ter Error	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The encoder is wired incorrectly or there is faulty contact.	Check the wiring of the encoder.	Make sure that the encoder is correctly wired.	page 4-19
Cb0 hex: Encoder Echo- back Error	The specifications of the Encoder Cable are not correct and noise entered on it.	-	Use a shielded twisted- pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm <sup>2</sup> .	-
	The Encoder Cable is too long and noise entered on it.	_	Rotary Servomotors:     The Encoder Cable wiring distance must be 50 m max.     Linear Servomotors:     The Encoder Cable wiring distance must be 20 m max.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Check the condition of the Encoder Cable and connectors.	Properly ground the machine to separate it from the FG of the encoder.	-
	Excessive vibration or shock was applied to the encoder.	Check the operating conditions.	Reduce machine vibration. Correctly install the Servomotor or linear encoder.	-
	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
CC0 hex: Multiturn Limit	The multiturn limit of the encoder is different from that of the SERVOPACK. Or, the multiturn limit of the SERVOPACK has been changed.	Check the setting of Pn205 (2205 hex) (Multiturn Limit).	Change the setting if the alarm occurs.	page 6-37
Disagreement	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code: Alarm Name	Possible Cause	Confirmation	Continued from pro	Reference
Alailli Näille	The cable between the Serial Converter Unit and SERVOPACK is not wired correctly or there is a faulty contact.	Check the wiring of the external encoder.	Correctly wire the cable between the Serial Converter Unit and SERVO-PACK.	page 4-21
CF1 hex: Reception Failed Error in Feed-	A specified cable is not being used between Serial Con- verter Unit and SER- VOPACK.	Check the wiring specifications of the external encoder.	Use a specified cable.	-
back Option Module Commu- nications	The cable between the Serial Converter Unit and SERVOPACK is too long.	Measure the length of the cable that connects the Serial Converter Unit.	The length of the cable between the Serial Converter Unit and SERVO-PACK must be 20 m or less.	-
	The sheath on cable between the Serial Converter Unit and SERVOPACK is broken.	Check the cable that connects the Serial Converter Unit.	Replace the cable between the Serial Converter Unit and SERVO-PACK.	-
CF2 hex: Timer Stopped Error in Feed-	Noise entered the cable between the Serial Converter Unit and SERVOPACK.	_	Correct the wiring around the Serial Converter Unit, e.g., separate I/O signal lines from the Main Circuit Cables or ground.	-
back Option Module Commu- nications	A failure occurred in the Serial Converter Unit.	-	Replace the Serial Converter Unit.	-
	A failure occurred in the SERVOPACK.	-	Replace the SERVO- PACK.	-
	The Servomotor U, V, and W wiring is not correct.	Check the wiring of the Servomotor's Main Circuit Cables.	Make sure that there are no faulty contacts in the wiring for the Servomotor and encoder.	-
d00 hex: Position Devia-	The position command speed is too fast.	Reduce the position command speed and try operating the SER-VOPACK.	Reduce the position reference speed or the reference acceleration rate, or reconsider the electronic gear ratio.	page 5-43
tion Overflow (The setting of Pn520 (2520 hex) (Excessive Posi- tion Error Alarm Level) was exceeded by the position devia- tion while the servo was ON.)	The acceleration of the position reference is too high.	Reduce the reference acceleration and try operating the SERVO- PACK.	Reduce the acceleration of the position reference using an EtherCAT command.	-
	The setting of Pn520 (2520 hex) (Excessive Position Deviation Alarm Level) is too low for the operating conditions.	Check the setting of Pn520 (2520 hex) to see if it is appropriate.	Optimize the setting of Pn520 (2520 hex).	page 8-8
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Code:			Continued from pro	evious page.
Alarm Name	Possible Cause	Confirmation	Correction	Reference
d01 hex: Position Deviation Overflow Alarm at Servo ON	The servo was turned ON after the position deviation exceeded the setting of Pn526 (2526 hex) (Excessive Position Deviation Alarm Level at Servo ON) while the servo was OFF.	Check the position deviation while the servo is OFF.	Optimize the setting of Pn526 (2526 hex).	
d02 hex: Position Deviation Overflow Alarm for Speed Limit at Servo ON	If position deviation remains in the deviation counter, the setting of Pn529 (2529 hex) or Pn584 (2584 hex) (Speed Limit Level at Servo ON) will limit the speed when the servo is turned ON. This alarm occurs if a position reference is input and the setting of Pn520 (2520 hex) (Excessive Position Deviation Alarm Level) is exceeded.	_	Optimize the setting of Pn520 (2520 hex). Or, set Pn529 (2529 hex) or Pn584 (2584 hex) to an appropriate value.	page 8-8
d10 hex: Motor-Load Position Deviation Overflow	The motor direction and external encoder installation orientation are backward.	Check the motor direction and the external encoder installation orientation.	Install the external encoder in the opposite direction, or change the setting of Pn002 (2002 hex) = n.X□□□ (External Encoder Usage) to reverse the direction.	page 10-6
	There is an error in the connection between the load (e.g., stage) and external encoder coupling.	Check the coupling of the external encoder.	Check the mechanical coupling.	-
d30 hex: Position Data Overflow	The position data exceeded ±1,879,048,192.	Check the input reference pulse counter.	Reconsider the operating specifications.	-
E00 hex: EtherCAT Module Interface Initializa- tion Timeout Error	A failure occurred in the SERVOPACK.	-	Replace the SERVO- PACK.	_
E02 hex: EtherCAT Inter- nal Synchroniza- tion Error 1	The EtherCAT transmission cycle fluctuated.	-	Remove the cause of transmission cycle fluctuation at the host controller.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
E03 hex: EtherCAT Mod- ule Interface Communications	Noise caused an error in communications between the SERVO-PACK and EtherCAT Network Module.	-	Implement countermea- sures against noise.	-
Data Error	A failure occurred in the SERVOPACK.	_	Replace the SERVO-PACK.	

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

Alarm Code:			Continued from pr	
Alarm Name	Possible Cause	Confirmation	Correction	Reference
	There is a faulty connection between the SERVOPACK and the Safety Option Module.	Check the connection between the SERVO- PACK and the Safety Option Module.	Correctly connect the Safety Option Module.	-
E71 hex: Safety Option Module Detec- tion Failure	The Safety Option Module was discon- nected.	-	Execute Fn014 (Reset Option Module Configuration Error) from the Digital Operator or SigmaWin+ and then turn the power supply OFF and ON again.	page 15-42
	A failure occurred in the Safety Option Module.	_	Replace the Safety Option Module.	_
	A failure occurred in the SERVOPACK.	-	Replace the SERVO- PACK.	-
	There is a faulty con- nection between the SERVOPACK and the Feedback Option Module.	Check the connection between the SERVO- PACK and the Feed- back Option Module.	Correctly connect the Feedback Option Module.	-
E72 hex: Feedback Option Module Detec- tion Failure	The Feedback Option Module was discon- nected.	_	Reset the Option Module configuration error and turn the power supply to the SERVOPACK OFF and ON again.	page 15-42
	A failure occurred in the Feedback Option Module.	_	Replace the Feedback Option Module.	-
	A failure occurred in the SERVOPACK.	_	Replace the SERVO-PACK.	_
E74 hex: Unsupported	A failure occurred in the Safety Option Module.	_	Replace the Safety Option Module.	_
Safety Option Module Alarm	An unsupported Safety Option Module was connected.	Refer to the manual for the connected Safety Option Module.	Connect a supported Safety Option Module.	_
E75 hex:	A failure occurred in the Feedback Option Module.	_	Replace the Safety Option Module.	_
Unsupported Feedback Option Module Alarm	An unsupported Feedback Option Module was con- nected.	Refer to the catalog for the connected Feed- back Option Module or the SERVOPACK man- ual.	Connect a supported Feedback Option Module.	_
EA0 hex: Command- Option IF Servo Unit Initial Error	A failure occurred in the SERVOPACK.	_	Replace the SERVO- PACK.	-
EA1 hex: Command- Option IF Memory Check Error	A failure occurred in the SERVOPACK.	_	Replace the SERVO-PACK.	_

Continued from previous page.

Alarm Code:	Possible Cause	Confirmation	Correction	
Alarm Name		Confirmation	Correction	Reference
EA2 hex: Command- Option IF Servo Synchronization Error	Fluctuation in the EtherCAT communications synchronization timing (Sync0) caused the synchronization timing in the SERVO-PACK to fluctuate.	_	Turn the power supply OFF and ON again and reestablish communications.	-
	A failure occurred in the SERVOPACK.	-	Repair or replace the SERVOPACK.	-
EA3 hex: Command- Option IF Servo	Noise caused an error in communications in the SERVOPACK.	-	Implement countermea- sures against noise.	-
Data Error	A failure occurred in the SERVOPACK.	_	Replace the SERVO-PACK.	_
Eb1 hex: Safety Function Signal Input Tim- ing Error	The delay between activation of the /HWBB1 and /HWBB2 input signals for the HWBB was ten second or longer.	Measure the time delay between the /HWBB1 and /HWBB2 signals.	The output signal circuits or devices for /HWBB1 and /HWBB2 or the SER-VOPACK input signal circuits may be faulty. Alternatively, the input signal cables may be disconnected. Check to see if any of these items are faulty or have been disconnected.	_
	A failure occurred in the SERVOPACK.	-	Replace the SERVO-PACK.	_
EC8 hex: Gate Drive Error 1 (An error occurred in the gate drive circuit.) EC9 hex: Gate Drive Error 2 (An error occurred in the gate drive circuit.)	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
Ed1 hex: Command Execution Timeout	A timeout error occurred for an Ether-CAT command.	Check the motor status when the command is executed.	Execute the Servo ON command (Enable Operation command) only when the motor is not operating.	-
F10 hex: Power Supply Line Open Phase (The voltage was low for more than one second for phase R, S, or T when the main power supply was ON.)	The three-phase power supply wiring is not correct.	Check the power supply wiring.	Make sure that the power supply is correctly wired.	page 4-11
	The three-phase power supply is unbalanced.	Measure the voltage for each phase of the three-phase power supply.	Balance the power supply by changing phases.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

#### 15.2.2 Troubleshooting Alarms

Continued from previous page.

A1 0 1	Outlinded from previous page.				
Alarm Code: Alarm Name	Possible Cause	Confirmation	Correction	Reference	
F50 hex: Servomotor Main Circuit Cable Dis-	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER-VOPACK.	_	
connection (The Servomotor did not operate or power was not supplied to the Servomotor even though the Servo ON command (Enable Operation command) was input when the Servomotor was ready to receive it.)	The wiring is not correct or there is a faulty contact in the motor wiring.	Check the wiring.	Make sure that the Servo- motor is correctly wired.	page 4-19	
FL-1*3: System Alarm FL-2*3: System Alarm FL-3*3: System Alarm FL-4*3: System Alarm FL-5*3: System Alarm	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_	
CPF00: Digital Operator Communications Error 1	There is a faulty contact between the Digital Operator and the SERVOPACK.	Check the connector contact.	Disconnect the connector and insert it again. Or, replace the cable.	-	
	A malfunction was caused by noise.	_	Keep the Digital Operator or the cable away from sources of noise.	_	
CPF01: Digital Operator Communications Error 2	A failure occurred in the Digital Operator.	_	Disconnect the Digital Operator and then con- nect it again. If an alarm still occurs, the Digital Operator may be faulty. Replace the Digital Oper- ator.	-	
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-	

<sup>\*1.</sup> Detection Conditions

Rotary Servomotor

If either of the following conditions is detected, an alarm will occur.

• Pn533 [min<sup>-1</sup>] × 
$$\frac{\text{Encoder resolution}}{6 \times 10^5} \le 1$$

• Maximum motor speed [min<sup>-1</sup>] 
$$\times$$
 Encoder resolution
Approx. 3.66  $\times$  10<sup>12</sup>  $\ge$  1

Linear Servomotor

If either of the following conditions is detected, an alarm will occur.

$$\frac{\text{Pn585 [mm/s]}}{\text{Linear encoder pitch [$\mu m$]}} \times \frac{\text{Resolution of Serial Converter Unit}}{10} \leq 1$$

$$\frac{\text{Pn385 [100 mm/s]}}{\text{Linear encoder pitch [$\mu m$]}} \times \frac{\text{Resolution of Serial Converter Unit}}{\text{Approx. 6.10} \times 10^{5}} \geq 1$$

<sup>\*2.</sup> Refer to the catalog for details.

<sup>\*3.</sup> These alarms are not stored in the alarm history. They are only displayed on the panel display.

# Maintenance

15

#### 15.2.3 Resetting Alarms

If there is an ALM (Servo Alarm) signal, use one of the following methods to reset the alarm after eliminating the cause of the alarm.



Be sure to eliminate the cause of an alarm before you reset the alarm. If you reset the alarm and continue operation without eliminating the cause of the alarm, it may result in damage to the equipment or fire.

#### Clearing Alarms and Warnings with the Fault Reset Command

Execute the Fault Reset command to clear alarms or warnings.

Refer to the following section for details on the Fault Reset command.

★ Controlword Bits on page 14-21

#### **Resetting Alarms Using the Digital Operator**

Press the **ALARM RESET** Key on the Digital Operator. Refer to the following manual for details on resetting alarms.

Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

15.2.4 Displaying the Alarm History

## 15.2.4 Displaying the Alarm History

The alarm history displays up to the last ten alarms that have occurred in the SERVOPACK.

Note: The following alarms are not displayed in the alarm history: A.E50 (EtherCAT Synchronization Error), A.E60 (Reception Error in EtherCAT Communications), and FL-1 to FL-5.

#### **Preparations**

No preparations are required.

#### **Applicable Tools**

The following table lists the tools that you can use to display the alarm history and the applicable tool functions.


Tool	Function	Reference
Digital Operator	Fn000	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Alarm – Display Alarm	Operating Procedure on page 15-40

#### **Operating Procedure**

Use the following procedure to display the alarm history.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Display Alarm in the Menu Dialog Box. The Alarm Display Dialog Box will be displayed.
- 3. Click the Alarm History Tab.

The following display will appear and you can check the alarms that occurred in the past.



Information

- 1. If the same alarm occurs consecutively within one hour, it is not saved in the alarm history. If it occurs after an hour or more, it is saved.
- 2. You can clear the alarm history by clicking the **Clear** Button. The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF.

This concludes the procedure to display the alarm history.

# Maintenance

15

# 15.2.5 Clearing the Alarm History

You can clear the alarm history that is recorded in the SERVOPACK.

The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF. You must perform the following procedure.

#### **Preparations**

Always check the following before you clear the alarm history.

• The parameters must not be write prohibited.

#### **Applicable Tools**


The following table lists the tools that you can use to clear the alarm history and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn006	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Alarm – Display Alarm	Operating Procedure on page 15-41

#### **Operating Procedure**

Use the following procedure to reset the alarm history.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Display Alarm in the Menu Dialog Box. The Alarm Display Dialog Box will be displayed.
- 3. Click the Alarm History Tab.
- **4.** Click the Clear Button. The alarm history will be cleared.



This concludes the procedure to reset the alarm history.

15.2.6 Resetting Alarms Detected in Option Modules

### 15.2.6 Resetting Alarms Detected in Option Modules

If any Option Modules are attached to the SERVOPACK, the SERVOPACK detects the presence and models of the connected Option Modules. If it finds any errors, it outputs alarms.

You can delete those alarms with this operation.



- This operation is the only way to reset alarms for Option Modules. The alarms are not reset when you reset other alarms or when you turn OFF the power supply to the SERVOPACK.
- Always remove the cause of an alarm before you reset the alarm.

#### **Preparations**

Always check the following before you clear an alarm detected in an Option Module.

• The parameters must not be write prohibited.

#### **Applicable Tools**


The following table lists the tools that you can use to reset Option Module configuration errors and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn014	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Setup – Reset Configuration Error of Option Module	Operating Procedure on page 15-42

#### **Operating Procedure**

Use the following procedure to reset alarms detected in Option Modules.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Reset Option Module Configuration Error in the Menu Dialog Box. The Reset Option Module Configuration Error Dialog Box will be displayed.
- Select the Clear Check Box for the Option Modules from which to clear alarms and the click the Execute Button.




15

4. Click the OK Button.



5. Click the OK Button.



6. Turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to reset alarms detected in Option Modules.

### 15.2.7 Resetting Motor Type Alarms

The SERVOPACK automatically determines the type of motor that is connected to it. If the type of motor that is connected is changed, an A.070 alarm (Motor Type Change Detected) will occur the next time the SERVOPACK is started. If an A.070 alarm occurs, you must set the parameters to match the new type of motor.

An A.070 alarm is reset by executing the Reset Motor Type Alarm utility function.



- This utility function is the only way to reset an A.070 alarm (Motor Type Change Detected).
  The errors are not reset when you reset alarms or turn OFF the power supply to the SER-VOPACK.
- 2. If an A.070 alarm occurs, first set the parameters according to the newly connected motor type and then execute the Reset Motor Type Alarm utility function.

#### **Preparations**

Always check the following before you clear a motor type alarm.

• The parameters must not be write prohibited.

#### Applicable Tools

The following table lists the tools that you can use to clear the motor type alarm and the applicable tool functions.

Tool	Function	Reference
Digital Operator	Fn021	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Alarm – Reset Motor Type Alarm	© Operating Procedure on page 15-44

15.2.7 Resetting Motor Type Alarms

### **Operating Procedure**

Use the following procedure to reset Motor Type alarm.

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Reset Motor Type Alarm in the Menu Dialog Box. The Reset Motor Type Alarm Dialog Box will be displayed.
- **3.** Click the Clear Button. The alarm will be cleared.

This concludes the procedure to reset Motor Type alarms.

# 15.3 Warning Displays

To check a warning that occurs in the SERVOPACK, use one of the following methods. Warnings are displayed to warn you before an alarm occurs.

Panel display on SERVOPACK	If there is a warning, the code will be displayed one character at a time, as shown below.  Example: Alarm A.910  Status display  Not lit. Not lit. Not lit. Not lit. Not lit. Not lit.
Digital Operator	The warning code is displayed.
Statusword (6041 hex)	Bit 7 (warning) in the statusword will change to 1. (Bit 7 is 0 during normal operation.)
Error code (603F hex)	A current warning code is stored in <i>error code</i> (603F hex).
Emergency message	The Controller is notified of any warning that occurs. (Notification may not be possible if EtherCAT communications are unstable.)

This next section provides a list of warnings and the causes of and corrections for warnings.

## 15.3.1 List of Warnings

The warning table gives the warning name and warning meaning in order of the warning codes.

Warning Code	Warning Name	Meaning
900 hex	Position Deviation Overflow	The position deviation exceeded the parameter settings (Pn520 (2520 hex) × Pn51E (251E hex)/100).
901 hex	Position Deviation Overflow Alarm at Servo ON	The position deviation exceeded the parameter settings (Pn526 (2526 hex) × Pn528 (2528 hex)/100) when the servo was turned ON.
910 hex	Overload	This warning occurs before an overload alarm (A.710 or A.720) occurs. If the warning is ignored and operation is continued, an alarm may occur.
911 hex	Vibration	Abnormal vibration was detected during motor operation. The detection level is the same as A.520. Set whether to output an alarm or a warning by setting Pn310 (2310 hex) (Vibration Detection Switch).
912 hex	Internal Temperature Warning 1 (Control Board Temperature Error)	The surrounding temperature of the control PCB is abnormal.
913 hex	Internal Temperature Warning 2 (Power Board Temperature Error)	The surrounding temperature of the power PCB is abnormal.
920 hex	Regenerative Overload	This warning occurs before an A.320 alarm (Regenerative Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.
921 hex	Dynamic Brake Over- load	This warning occurs before an A.731 alarm (Dynamic Brake Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.
923 hex	SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.
930 hex	Absolute Encoder Bat- tery Error	This warning occurs when the voltage of absolute encoder's battery is low.

#### 15.3.2 Troubleshooting Warnings

Continued from previous page.

Warning Code	Warning Name	Meaning
942 hex	Speed Ripple Com- pensation Information Disagreement	The speed ripple compensation information stored in the encoder does not agree with the speed ripple compensation information stored in the SERVOPACK.
971 hex	Undervoltage	This warning occurs before an A.410 alarm (Undervoltage) occurs. If the warning is ignored and operation is continued, an alarm may occur.
9A0 hex	Overtravel	Overtravel was detected while the servo was ON.
9b0 hex	Preventative Mainte- nance Warning	One of the consumable parts has reached the end of its service life.

Note: 1. A warning code is not output unless you set Pn001 (2001 hex) to n.1 \(\sigma \square\) (Output both alarm codes and warning codes).

<sup>2.</sup> Use Pn008 (2008 hex) = n.□X□□ (Warning Detection Selection) to control warning detection. However, the following warnings are not affected by the setting of Pn008 (2008 hex) = n.□X□□ and other parameter settings are required in addition to Pn008 (2008 hex) = n.□X□□.

Warning	Parameters That Must Be Set to Select Warning Detection	Reference
911 hex	Pn310 (2310 hex) = n.□□□X (Vibration Detection Setting)	page 6-46
930 hex	Pn008 (2008 hex) = n. \(\sigma\) (Low Battery Voltage Alarm/Warning Selection)	page 15-3
942 hex	Pn423 (2423 hex) = n.□□X□ (Speed Ripple Compensation Information Disagreement Warning Detection Selection)	page 8-59
971 hex	Pn008 (2008 hex) = n.□□X□ (Function Selection for Undervoltage) (Not affected by the setting of Pn008 (2008 hex) = n.□X□□.)	page 6-15
9A0 hex	Pn00D (200D hex) = n.X□□□ (Overtravel Warning Detection Selection) (Not affected by the setting of Pn008 (2008 hex) = n.□X□□.)	page 5-29
9b0 hex	Pn00F (200F hex) = n.□□□X (Preventative Maintenance Selection)	page 9-15

# 15.3.2 Troubleshooting Warnings

The causes of and corrections for the warnings are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The Servomotor U, V, and W wiring is not correct.	Check the wiring of the Servomotor's Main Circuit Cables.	Make sure that there are no faulty connections in the wiring for the Servomotor and encoder.	_
	A SERVOPACK gain is too low.	Check the SERVO- PACK gains.	Increase the servo gain, e.g., by using autotuning without a host reference.	page 8-23
	The acceleration of the position reference is too high.	Reduce the reference acceleration and try operating the SERVO-PACK.	Reduce the acceleration of the position reference using an EtherCAT command.	-
900 hex: Position Deviation Overflow	The excessive position deviation alarm level (Pn520 (2520 hex) × Pn51E (251E hex)/100) is too low for the operating conditions.	Check excessive position deviation alarm level (Pn520 (2520 hex) × Pn51E (251E hex)/100) to see if it is set to an appropriate value.	Optimize the settings of Pn520 (2520 hex) and Pn51E (251E hex).	page 8-8
	A failure occurred in the SERVO-PACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

15

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
901 hex: Position Deviation Overflow Alarm at Servo ON	The position deviation exceeded the parameter settings (Pn526 (2526 hex) × Pn528 (2528 hex)/100) when the servo was turned ON.	_	Optimize the setting of Pn528 (2528 hex) (Excessive Position Error Warning Level at Servo ON).	-
	The wiring is not correct or there is a faulty contact in the motor or encoder wiring.	Check the wiring.	Make sure that the Servo- motor and encoder are cor- rectly wired.	-
	Operation was performed that exceeded the overload protection characteristics.	Check the motor over- load characteristics and Run command.	Reconsider the load and operating conditions. Or, increase the motor capacity.	-
910 hex: Overload (warning before an A.710 or A.720 alarm occurs)	An excessive load was applied during operation because the Servomotor was not driven because of mechanical problems.	Check the operation reference and motor speed.	Remove the mechanical problem.	-
	The overload warning level (Pn52B (252B hex)) is not suitable.	Check that the overload warning level (Pn52B (252B hex)) is suitable.	Set a suitable overload warning level (Pn52B (252B hex)).	page 5-40
	A failure occurred in the SERVO-PACK.	_	The SERVOPACK may be faulty. Replace the SERVO-PACK.	-
	Abnormal vibration was detected during motor operation.	Check for abnormal motor noise, and check the speed and torque waveforms during operation.	Reduce the motor speed. Or, reduce the servo gain with custom tuning.	page 8-41
911 hex: Vibration	The setting of Pn103 (2103 hex) (Moment of Inertia Ratio) is greater than the actual moment of inertia or was greatly changed.	Check the moment of inertia ratio or mass ratio.	Correct the setting of Pn103 (2103 hex).	page 8-16
	The vibration detection level (Pn312 (2312 hex) or Pn384 (2384 hex)) is not suit- able.	Check that the vibration detection level (Pn312 (2312 hex) or Pn384 (2384 hex)) is suitable.	Set a suitable vibration detection level (Pn312 (2312 hex) or Pn384 (2384 hex)).	page 6-46

#### 15.3.2 Troubleshooting Warnings

Continued from previous page.

\\/	Continued from previous page			
Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surrounding temperature by improving the SERVOPACK installation conditions.	page 3-6
	An overload alarm was reset by turning OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
912 hex: Internal Tempera- ture Warning 1 (Control Board Tem- perature Error)	There was an excessive load or operation was performed that exceeded the regenerative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenerative load ratio to check the regenerative processing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVOPACK.	Check the SERVO- PACK installation con- ditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVO-PACK.	_	The SERVOPACK may be faulty. Replace the SERVO-PACK.	_
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surrounding temperature by improving the SERVOPACK installation conditions.	page 3-6
	An overload alarm was reset by turning OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
913 hex: Internal Tempera- ture Warning 2 (Power Board Tem- perature Error)	There was an excessive load or operation was performed that exceeded the regenerative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenerative load ratio to check the regenerative processing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVOPACK.	Check the SERVO- PACK installation con- ditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVO-PACK.	_	The SERVOPACK may be faulty. Replace the SERVO-PACK.	_

15

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the power supply voltage within the specified range.	-
920 hex: Regenerative Overload (warning before an A.320 alarm occurs)	There is insufficient external regenerative resistance, Regenerative Resistor capacity, or SER-VOPACK capacity, or there has been a continuous regeneration state.	Check the operating conditions and capacity again.	Change the regenerative resistance value, regenerative resistance capacity, or SERVOPACK capacity. Recheck the operating conditions.	_
	There was a continuous regeneration state because a negative load was continuously applied.	Check the load applied to the Servomotor during operation.	Reconsider the system including the servo, machine, and operating conditions.	-
	The Servomotor was rotated by an external force.	Check the operation status.	Implement measures to ensure that the motor will not be rotated by an external force.	-
921 hex: Dynamic Brake Overload (warning before an A.731 alarm occurs)	When the Servo- motor was stopped with the dynamic brake, the rotational or linear kinetic energy exceeded the capacity of the Dynamic Brake Resistor.	Check the power consumed by the DB resistor to see how frequently the DB is being used.	Reconsider the following:  Reduce the Servomotor command speed.  Decrease the moment of inertia or mass.  Reduce the frequency of stopping with the dynamic brake.	-
	A failure occurred in the SERVO-PACK.	_	The SERVOPACK may be faulty. Replace the SERVO-PACK.	-
923 hex: SERVOPACK Built- in Fan Stopped	The fan inside the SERVOPACK stopped.	Check for foreign matter inside the SERVO-PACK.	Remove foreign matter from the SERVOPACK. If an alarm still occurs, the SER- VOPACK may be faulty. Replace the SERVOPACK.	-
930 hex: Absolute Encoder Battery Error (The absolute encoder battery voltage was lower than the spec- ified level.) (Detected only when an abso-	The battery connection is faulty or a battery is not connected.	Check the battery connection.	Correct the battery connection.	page 4-20
	The battery voltage is lower than the specified value (2.7 V).	Measure the battery voltage.	Replace the battery.	page 15-3
lute encoder is con- nected.)	A failure occurred in the SERVO-PACK.	_	The SERVOPACK may be faulty. Replace the SERVO-PACK.	_

#### 15.3.2 Troubleshooting Warnings

Continued from previous page.

Warning Numbers				
Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The speed ripple	_	Reset the speed ripple compensation value on the SigmaWin+.	page 8-59
942 hex: Speed Ripple Compensation Informa-	compensation information stored in the encoder does not agree with the speed	_	Set Pn423 (2423 hex) to n. \$\square\$ 10 (Do not detect A.942 alarms). However, changing the setting may increase the speed ripple.	page 8-59
tion Disagreement	ripple compensa- tion information stored in the SER- VOPACK.	_	Set Pn423 (2423 hex) to n. \$\square\$ (Disable torque ripple compensation). However, changing the setting may increase the speed ripple.	page 8-59
	For a 400-V SER- VOPACK, the AC power supply volt- age dropped below 280 V.	Measure the power supply voltage.	Set the power supply voltage within the specified range.	-
	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.	_
971 hex: Undervoltage	A momentary power interruption occurred.	Measure the power supply voltage.	If you have changed the setting of Pn509 (2509 hex) (Momentary Power Interruption Hold Time), decrease the setting.	page 6-14
	The SERVOPACK fuse is blown out.	_	Replace the SERVOPACK and connect a reactor.	page 4-18
	A failure occurred in the SERVO-PACK.	_	The SERVOPACK may be faulty. Replace the SERVO-PACK.	-
9A0 hex: Overtravel (Over- travel status was detected.)	Overtravel was detected while the servo was ON.	Check the status of the overtravel signals on the input signal monitor.	Even if an overtravel signal is not shown by the input signal monitor, momentary overtravel may have been detected. Take the following precautions.  • Do not specify movements that would cause overtravel from the host controller.  • Check the wiring of the overtravel signals.  • Implement countermeasures against noise.	page 5-29
9b0 hex: Preventative Mainte- nance Warning	One of the consumable parts has reached the end of its service life.	_	Replace the part. Contact your Yaskawa representative for replacement.	page 9-14

# Troubleshooting Based on the Operation and Conditions of the Servomotor

This section provides troubleshooting based on the operation and conditions of the Servomotor, including causes and corrections.

Problem	Possible Cause	Confirmation	Correction	Reference
	The control power supply is not turned ON.	Measure the voltage between control power supply terminals.	Turn OFF the Servo System. Correct the wiring so that the con- trol power supply is turned ON.	-
	The main circuit power supply is not turned ON.	Measure the voltage across the main circuit power input terminals.	Turn OFF the Servo System. Correct the wiring so that the main circuit power supply is turned ON.	-
	The I/O signal connector (CN1) pins are not wired correctly or are disconnected.	Turn OFF the Servo System. Check the wiring condition of the I/O signal connector (CN1) pins.	Correct the wiring of the I/O signal connector (CN1) pins.	page 4-28, page 9-5
	The wiring for the Servomotor Main Circuit Cables or Encoder Cable is disconnected.	Check the wiring conditions.	Turn OFF the Servo System. Wire the cable correctly.	-
	There is an overload on the Servomotor.	Operate the Servomotor with no load and check the load status.	Turn OFF the Servo System. Reduce the load or replace the Ser- vomotor with a Servo- motor with a larger capacity.	-
Servomotor Does Not Start	The type of encoder that is being used does not agree with the setting of Pn002 (2002 hex) = n.□X□□ (Encoder Usage).	Check the type of the encoder that is being used and the setting of Pn002 (2002 hex) = n.□X□□.	Set Pn002 (2002 hex) = n. □X□□ according to the type of the encoder that is being used.	page 6-31
	There is a mistake in the input signal allocations (Pn50A (250A hex), Pn50B (250B hex), Pn511 (2511 hex), and Pn516 (2516 hex)).	Check the input signal allocations (Pn50A (250A hex), Pn50B (250B hex), Pn511 (2511 hex), Pn516 (2516 hex)).	Correctly allocate the input signals (Pn50A (250A hex), Pn50B (250B hex), Pn511 (2511 hex), Pn516 (2516 hex)).	page 6-4, page 9-5
	The Servo ON command (Enable Operation command) was not sent.	Make sure the Servo ON command (Enable Operation command) is set to Operation Enabled.	Set the correct value for the Servo ON com- mand (Enable Opera- tion command).	-
	The torque limit reference is too small.	Check the torque limit reference.	Increase the torque limit reference.	_
	The operation mode is not set.	Check to see if modes of operation (6060 hex) is set.	Set modes of operation (6060 hex) correctly.	_
	A software limit is active.	Check to see if the target position exceeds a software limit.	Specify a target position that is within the software limits.	_
	EtherCAT communications are not established.	Check to see if the Ether- CAT indicator shows the Operational state.	Place the EtherCAT communications in the Operational state.	_
	The P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal is still OFF.	Check the P-OT and N-OT signals.	Turn ON the P-OT and N-OT signals.	page 9-5

Problem	Possible Cause	Confirmation	Continued from pre	Reference
	. 555,5,5 54466	- Community	Turn ON the /HWBB1 and /HWBB2 input sig-	
	The safety input signals (/HWBB1 or /HWBB2) were not turned ON.	Check the /HWBB1 and /HWBB2 input signals.	nals. If you are not using the safety function, connect the Safety Jumper Connector (provided as an accessory) to CN8.	page 9-5
Servomotor	The FSTP (Forced Stop Input) signal is still OFF.	Check the FSTP signal.	Turn ON the FSTP signal.     If you will not use the function to force the motor to stop, set Pn516 (2516 hex) = n.□□□X (FSTP (Forced Stop Input) Signal Allocation) to disable the signal.	page 9-5
Does Not Start	A failure occurred in the SER-VOPACK.	-	Turn OFF the Servo System. Replace the SERVOPACK.	_
	The polarity detection was not executed.	Check the setting of Pn080 (2080 hex) =n.□□□X (Polarity Sensor Selection).	Correct the parameter setting.	page 5-22
		Check the inputs to the Servo ON command (Enable Operation command).	If you are using an incremental linear encoder, send the Servo ON command (Enable Operation command) from the host controller.      If you are using an absolute linear encoder, execute polarity detection.	page 5-23
	There is a mistake in the Servomotor wiring.	Turn OFF the Servo System. Check the wiring.	Wire the Servomotor correctly.	_
	There is a mistake in the wiring of the encoder or Serial Converter Unit.	Turn OFF the Servo System. Check the wiring.	Wire the Serial Converter Unit correctly.	_
	There is a mistake in the linear encoder wiring.	Turn OFF the Servo System. Check the wiring.	Wire the cable correctly.	_
Servomotor Moves Instanta-	The setting of Pn282 (2282 hex) (Linear Encoder Pitch) is not correct.	Check the setting of Pn282 (2282 hex).	Correct the setting of Pn282 (2282 hex).	page 5-15
neously, and Then Stops	The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor.	Check the directions.	Change the setting of Pn080 (2080 hex) = n.□□X□ (Motor Phase Selection). Match the linear encoder direction and motor direction.	page 5-20
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between ±10°.	Correct the settings for the polarity detection-related parameters.	_

15

Continued from previous page.

Problem	Possible Cause	Confirmation	Correction	Reference
Servomotor Speed Is Unstable	There is a faulty connection in the Servomotor wiring.	The connector connections for the power line (U, V, and W phases) and the encoder or Serial Converter Unit may be unstable. Turn OFF the Servo System. Check the wiring.	Tighten any loose terminals or connectors and correct the wiring.	-
	A failure occurred in the SER-VOPACK.	_	Turn OFF the Servo System. Replace the SERVOPACK.	-
Servomotor Moves with- out a Refer- ence Input	The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor.	Check the directions.	Change the setting of Pn080 (2080 hex) = n.□□X□ (Motor Phase Selection).  Match the linear encoder direction and Servomotor direction.	page 5-20
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between ±10°.	Correct the settings for the polarity detection-related parameters.	-
	The setting of Pn001 (2001 hex) = n. \(\sigma\) \(\sigma\) \(Servo OFF or Alarm Group 1 Stopping Method) is not suitable.	Check the setting of Pn001 (2001 hex) = n.□□□X.	Set Pn001 (2001 hex) = n.□□□X correctly.	-
Dynamic Brake Does Not Operate	The Dynamic Brake Resistor is disconnected.	Check the moment of inertia, motor speed, and dynamic brake frequency of use. If the moment of inertia, motor speed, or dynamic brake frequency of use is excessive, the dynamic brake resistance may be disconnected.	Turn OFF the Servo System. Replace the SERVOPACK. To pre- vent disconnection, reduce the load.	_
	There was a failure in the dynamic brake drive circuit.	_	There is a defective component in the dynamic brake circuit. Turn OFF the Servo System. Replace the SERVOPACK.	_

			Continued from pre	vious page.
Problem	Possible Cause	Confirmation	Correction	Reference
	The Servomotor vibrated considerably while performing the tuning-less function with the default settings.	Check the waveform of the motor speed.	Reduce the load so that the moment of inertia ratio or mass ratio is within the allowable value, or increase the load level or reduce the rigidity level in the tuning-less level settings.	page 8-12
	The machine mounting is not secure.	Turn OFF the Servo System. Check to see if there are any loose mounting screws.	Tighten the mounting screws.	-
	The machine mounting is not secure.	Turn OFF the Servo System. Check to see if there is misalignment in the coupling.	Align the coupling.	-
	secure.	Turn OFF the Servo System. Check to see if the coupling is balanced.	Balance the coupling.	-
	The bearings are defective.	Turn OFF the Servo System. Check for noise and vibration around the bearings.	Replace the Servomotor.	_
Abnormal Noise from Servomotor	There is a vibration source at the driven machine.	Turn OFF the Servo System. Check for any foreign matter, damage, or deformation in the machine's moving parts.	Consult with the machine manufacturer.	-
	Noise interference occurred because of incorrect I/O Signal Cable specifications.	Turn OFF the Servo System. Check the I/O Signal Cables to see if they satisfy specifications. Use shielded twisted-pair wire cables or screened twisted-pair cables with conductors of at least 0.12 mm <sup>2</sup> .	Use cables that satisfy the specifications.	-
	Noise interference occurred because an I/O Signal Cable is too long.	Turn OFF the Servo System. Check the lengths of the I/O Signal Cables.	The I/O Signal Cables must be no longer than 3 m.	_
	Noise interference occurred because of incorrect Encoder Cable specifications.	Turn OFF the Servo System. Make sure that the rotary or Linear Encoder Cable satisfies the specifications. Use a shielded twisted-pair wire cable or a screened twisted-pair cable with a conductors of at least 0.12 mm <sup>2</sup> .	Use cables that satisfy the specifications.	-
	Noise interference occurred because the Encoder Cable is too long.	Turn OFF the Servo System. Check the length of the Encoder Cable.	Rotary Servomotors:     The Encoder Cable length must be 50 m max.     Linear Servomotors:     Make sure that the Serial Converter Unit Cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each.  Continued on	_

Continued from previous page.

Problem	Possible Cause	Confirmation	Correction	Reference
	Noise interference occurred because the Encoder Cable is damaged.	Turn OFF the Servo System. Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-
	The Encoder Cable was subjected to excessive noise interference.	Turn OFF the Servo System. Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-current line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Turn OFF the Servo System. Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
Abnormal	There is a SERVOPACK pulse counting error due to noise.	Check to see if there is noise interference on the signal line from the encoder.	Turn OFF the Servo System. Implement countermeasures against noise for the encoder wiring.	-
Noise from Servomotor	The encoder was subjected to excessive vibration or shock.	Turn OFF the Servo System. Check to see if vibration from the machine occurred. Check the Servomotor installation (mounting surface precision, securing state, and alignment). Check the linear encoder installation (mounting surface precision and securing method).	Reduce machine vibration. Improve the mounting state of the Servomotor or linear encoder.	-
	A failure occurred in the encoder.	_	Turn OFF the Servo System. Replace the Servomotor.	_
	A failure occurred in the Serial Converter Unit.	-	Turn OFF the Servo System. Replace the Serial Converter Unit.	_
	A failure occurred in the linear encoder.	-	Turn OFF the Servo System. Replace the linear encoder.	-
	The servo gains are not balanced.	Check to see if the servo gains have been correctly tuned.	Perform autotuning without a host reference.	page 8-23
Servomotor Vibrates at Frequency of Approx. 200 to 400 Hz.	The setting of Pn100 (2100 hex) (Speed Loop Gain) is too high.	Check the setting of Pn100 (2100 hex). The default setting is Kv = 40.0 Hz.	Set Pn100 (2100 hex) to an appropriate value.	-
	The setting of Pn102 (2102 hex) (Position Loop Gain) is too high.	Check the setting of Pn102 (2102 hex). The default setting is Kp = 40.0/s.	Set Pn102 (2102 hex) to an appropriate value.	_
	The setting of Pn101 (2101 hex) (Speed Loop Integral Time Constant) is not appropriate.	Check the setting of Pn101 (2101 hex). The default setting is Ti = 20.0 ms.	Set Pn101 (2101 hex) to an appropriate value.	_
	The setting of Pn103 (2103 hex) (Moment of Inertia Ratio or Mass Ratio) is not appropriate.	Check the setting of Pn103 (2103 hex).	Set Pn103 (2103 hex) to an appropriate value.	-

Problem	Possible Cause	Confirmation	Correction	Reference
	The servo gains are not balanced.	Check to see if the servo gains have been correctly tuned.	Perform autotuning without a host reference.	page 8-23
	The setting of Pn100 (2100 hex) (Speed Loop Gain) is too high.	Check the setting of Pn100 (2100 hex). The default setting is Kv = 40.0 Hz.	Set Pn100 (2100 hex) to an appropriate value.	-
Large Motor	The setting of Pn102 (2102 hex) (Position Loop Gain) is too high.	Check the setting of Pn102 (2102 hex). The default setting is Kp = 40.0/s.	Set Pn102 (2102 hex) to an appropriate value.	-
Speed Overshoot on Starting and Stop-	The setting of Pn101 (2101 hex) (Speed Loop Integral Time Constant) is not appropriate.	Check the setting of Pn101 (2101 hex). The default setting is Ti = 20.0 ms.	Set Pn101 (2101 hex) to an appropriate value.	-
ping	The setting of Pn103 (2103 hex) (Moment of Inertia Ratio or Mass Ratio) is not appropriate.	Check the setting of Pn103 (2103 hex).	Set Pn103 (2103 hex) to an appropriate value.	-
	The torque reference is saturated.	Check the waveform of the torque reference.	Use the mode switch.	_
	The force limits (Pn483 (2483 hex) and Pn484 (2484 hex)) are set to the default values.	The default values of the force limits and Pn483 (2483 hex) = 30% and Pn484 (2484 hex) = 30%.	Set Pn483 (2483 hex) and Pn484 (2484 hex) to appropriate values.	page 6-26

Problem	Possible Cause	Confirmation	Correction	Reference
	Noise interference occurred because of incorrect Encoder Cable specifications.	Turn OFF the Servo System. Check the Encoder Cable to see if it satisfies specifications. Use a shielded twisted-pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm <sup>2</sup> .	Use cables that satisfy the specifications.	-
Absolute Encoder Position Deviation Error (The position that was saved in the host con-	Noise interference occurred because the Encoder Cable is too long.	Turn OFF the Servo System. Check the length of the Encoder Cable.	Rotary Servomotors:     The Encoder Cable length must be 50 m max.     Linear Servomotors:     Make sure that the Serial Converter Unit Cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each.	-
troller when the power was turned OFF is dif- ferent from	Noise interference occurred because the Encoder Cable is damaged.	Turn OFF the Servo System. Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-
the posi- tion when the power was next turned ON.)	The Encoder Cable was subjected to excessive noise interference.	Turn OFF the Servo System. Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-current line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Turn OFF the Servo System. Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
	There is a SERVOPACK pulse counting error due to noise.	Turn OFF the Servo System. Check to see if there is noise interference on the I/O signal line from the encoder or Serial Converter Unit.	Implement counter- measures against noise for the encoder or Serial Converter Unit wiring.	-

Problem	Possible Cause	Confirmation	Correction	Reference
Absolute Encoder Position Deviation Error (The	The encoder was subjected to excessive vibration or shock.	Turn OFF the Servo System. Check to see if vibration from the machine occurred. Check the Servomotor installation (mounting surface precision, securing state, and alignment). Check the linear encoder installation (mounting surface precision and securing method).	Reduce machine vibration. Improve the mounting state of the Servomotor or linear encoder.	-
position that was saved in the host con-	A failure occurred in the encoder.	_	Turn OFF the Servo System. Replace the Servomotor or linear encoder.	-
troller when the power was turned	A failure occurred in the SER-VOPACK.	_	Turn OFF the Servo System. Replace the SERVOPACK.	-
OFF is dif- ferent from the posi-	Host controller multiturn data or absolute encoder position data reading error	Check the error detection section of the host controller.	Correct the error detection section of the host controller.	-
tion when the power was next turned ON.)		Check to see if the host controller is executing data parity checks.	Perform parity checks for the multiturn data or absolute encoder posi- tion data.	_
		Check for noise interference in the cable between the SERVO-PACK and the host controller.	Implement counter- measures against noise and then perform parity checks again for the multiturn data or abso- lute encoder position data.	-

и	ı,
ш	Н

Continued from previous page.

Droblom	Possible Cause	Confirmation	Correction	
Problem	Possible Cause	Commation	Correction	Reference
Overtravel Occurred	The P-OT/N-OT (Forward Drive Prohibit or Reverse Drive Prohibit) signal was input.	Check the external power supply (+24 V) voltage for the input signals.	Correct the external power supply (+24 V) voltage for the input signals.	_
		Check the operating condition of the overtravel limit switches.	Make sure that the overtravel limit switches operate correctly.	_
		Check the wiring of the overtravel limit switches.	Correct the wiring of the overtravel limit switches.	page 5-26
		Check the settings of the overtravel input signal allocations (Pn50A/Pn50B).	Set the parameters to correct values.	page 5-26
	The P-OT/N-OT (Forward Drive Prohibit or Reverse Drive Prohibit) signal malfunctioned.	Check for fluctuation in the external power supply (+24 V) voltage for the input signals.	Eliminate fluctuation from the external power supply (+24 V) voltage for the input signals.	_
		Check to see if the operation of the overtravel limit switches is unstable.	Stabilize the operating condition of the over-travel limit switches.	_
		Check the wiring of the overtravel limit switches (e.g., check for cable damage and loose screws).	Correct the wiring of the overtravel limit switches.	-
	There is a mistake in the allocation of the P-OT or N-OT (Forward Drive Prohibit or Reverse Drive Prohibit) signal in Pn50A (250A hex) = n.X□□□ or Pn50B (250B hex) = n.□□□X.	Check to see if the P-OT signal is allocated in Pn50A (250A hex) = n.X□□□.	If another signal is allocated in Pn50A (250A hex) =n.XDDD, allocate the P-OT signal instead.	- page 5-26
		Check to see if the N-OT signal is allocated in Pn50B (250B hex) = n.□□□X.	If another signal is allocated in Pn50B (250B hex) =n. \(\sigma\) \(\sigma\) \(\sigma\) allocate the N-OT signal instead.	
	The selection of the Servo- motor stopping method is not correct.	Check the servo OFF stopping method set in Pn001 (2001 hex) = n.□□□X or Pn001 (2001 hex) = n.□□□X□.	Select a Servomotor stopping method other than coasting to a stop.	- page 5-27
		Check the torque control stopping method set in Pn001 (2001 hex) = n.□□□X or Pn001 (2001 hex) = n.□□□X□.	Select a Servomotor stopping method other than coasting to a stop.	
Improper Stop Posi- tion for Overtravel (OT) Signal	The limit switch position and dog length are not appropriate.	_	Install the limit switch at the appropriate position.	_
	The overtravel limit switch position is too close for the coasting distance.	_	Install the overtravel limit switch at the appropriate position.	_

Problem	Possible Cause	Confirmation	Continued from pre	Reference
Position Deviation (without Alarm)	Noise interference occurred because of incorrect Encoder Cable specifications.	Turn OFF the Servo System. Check the Encoder Cable to see if is satisfies specifications. Use a shielded twisted-pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm <sup>2</sup> .	Use cables that satisfy the specifications.	-
	Noise interference occurred because the Encoder Cable is too long.	Turn OFF the Servo System. Check the length of the Encoder Cable.	Rotary Servomotors:     The Encoder Cable length must be 50 m max.     Linear Servomotors:     Make sure that the Serial Converter Unit Cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each.	-
	Noise interference occurred because the Encoder Cable is damaged.	Turn OFF the Servo System. Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-
	The Encoder Cable was subjected to excessive noise interference.	Turn OFF the Servo System. Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-current line.	Correct the cable layout so that no surge is applied by high-current lines.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Turn OFF the Servo System. Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
	There is a SERVOPACK pulse counting error due to noise.	Turn OFF the Servo System. Check to see if there is noise interference on the I/O signal line from the encoder or Serial Converter Unit.	Implement counter- measures against noise for the encoder wiring or Serial Converter Unit wiring.	-

			Continued from pre	vious page.
Problem	Possible Cause	Confirmation	Correction	Reference
	The encoder was subjected to excessive vibration or shock.	Turn OFF the Servo System. Check to see if vibration from the machine occurred. Check the Servomotor installation (mounting surface precision, securing state, and alignment). Check the linear encoder installation (mounting surface precision and securing method).	Reduce machine vibration. Improve the mounting state of the Servomotor or linear encoder.	-
Position	The coupling between the machine and Servomotor is not suitable.	Turn OFF the Servo System. Check to see if position offset occurs at the coupling between machine and Servomotor.	Correctly secure the coupling between the machine and Servomotor.	-
Deviation (without Alarm)	Noise interference occurred because of incorrect I/O Signal Cable specifications.	Turn OFF the Servo System. Check the I/O Signal Cables to see if they satisfy specifications. Use a shielded twisted-pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm <sup>2</sup> .	Use cables that satisfy the specifications.	-
	Noise interference occurred because an I/O Signal Cable is too long.	Turn OFF the Servo System. Check the lengths of the I/O Signal Cables.	The I/O Signal Cables must be no longer than 3 m.	-
	An encoder fault occurred. (The pulse count does not change.)	_	Turn OFF the Servo System. Replace the Servomotor or linear encoder.	-
	A failure occurred in the SER-VOPACK.	_	Turn OFF the Servo System. Replace the SERVOPACK.	-
	The surrounding air temperature is too high.	Measure the surrounding air temperature around the Servomotor.	Reduce the surrounding air temperature to 40°C or less.	-
	The surface of the Servomotor is dirty.	Turn OFF the Servo System. Visually check the surface for dirt.	Clean dirt, dust, and oil from the surface.	-
Servomotor Overheated	There is an overload on the Servomotor.	Check the load status with a monitor.	If the Servomotor is overloaded, reduce the load or replace the Servo Drive with a SERVOPACK and Servomotor with larger capacities.	-
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between ±10°.	Correct the settings for the polarity detection-related parameters.	-

# Parameter and Object Lists

16

This chapter provides information on parameters and objects.

16.1	List of Parameters
	16.1.1 Interpreting the Parameter Lists16-216.1.2 List of Parameters16-3
16.2	Object List
16.3	SDO Abort Code List 16-39
16.4	Parameter Recording Table 16-40

(F

#### 16.1.1 Interpreting the Parameter Lists

The types of motors to which the parameter applies.

- All: The parameter is used for both Rotary Servomotors and Linear Servomotors.
- · Rotary: The parameter is used for only Rotary Servomotors.
- Linear: The parameter is used for only Linear Servomotors.

Rotary Servomotor terms are used for parameters that are applicable to all Servomotors. If you are using a Linear Servomotor, you need to interpret the terms accordingly. Refer to the following section for details.

◆ Differences in Terms for Rotary Servomotors and Linear Servomotors on page vii

Indicates when a change to the parameter will be effective.

Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applica- ble Motors	When Enabled	Classi- fication	Refer- ence
	2	Basic Function Selections 0	0000 hex to 10B1 hex	-	0000 hex	All	After restart	Setup	_
		If there are differences i Servomotor and Linear provided for both.  Top row: For Rotary Bottom row: For Lin	Servomotor, in	formation is	· s	etup uning er to the follow	wing two class ring section for cations of SERI 5-3	details.	

	, BO	ittorri row. i	For Linear Servornotors				
		Rotation	n Direction Sylection	D . (			
		Moveme	ent Direction Selection	Reference			
			Use CCW as the forward direction.				
Pn000 (2000 hex)	n.□□□X	0	Use the direction in which the linear encoder counts up as the forward direction.	page 5 14			
			Use CW as the forward direction. (Reverse Rotation Mode)	page 5-14			
		1	Use the direction in which the linear encoder counts down as the forward direction. (Reverse Movement Mode)				
	- DDVD	D	d a superator (Da matala supera				
	n.□□X□	Reserve	d parameter (Do not change.)				
	n.□X□□	Reserve	d parameter (Do not change.)				
		Rotary/L	inear Servomotor Startup Selection When Encoder Is Not Connected	Reference			
	n.X□□□	0	When an encoder is not connected, start as SERVOPACK for Rotary Servomotor.	page 5-13			
	When an encoder is not connected, start as SERVOPACK for Linear Servomotor.						
			,				

#### **List of Parameters** 16.1.2

The following table lists the parameters.

Note: Do not change the following parameters from their default settings.

- Reserved parameters
- Parameters not given in this manual
  Parameters that are not valid for the Servomotor that you are using, as given in the parameter table

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Basic Fund tions 0	ction Selec-	0000 hex to 10B1 hex	-	0000 hex	All	After restart	Setup	_
Pn000 (2000 hex)		n.□□X□ n.□X□	Movement D  Usi Usi Usi Usi Usi Usi For	ection Selection irection Selection Selection Selection Selection Selection Selection irection irection.  The CW as the form of the direction in the direction	ion orward directory or	ection. le linear en ction. (Rev- le linear en dovement ) )	erse Rotation looder counts Mode)	up as the for Mode) down as the	page 5	5-14
		n.X□□□	Ro Ro	tary Servomoto en an encoder Servomotor.	r.				page 5	5-13
	2	Application Selections		0000 hex to 1142 hex	_	0000 hex	All	After restart	Setup	-
		n.□□□X	0 Sto	ing Method for p the motor by p the motor by dynamic brake ast the motor to	applying the applying.	the dynaming dynam	ic brake. ic brake and t		Refere	
			Overtravel S	topping Metho	d				Refere	ence
Pn001 (2001 hex)	n ППХП	n.□□X□	1 Dec the 2 Dec the 3 Dec Pn:	bly the dynamic pping method so celerate the mo maximum torque celerate the mo maximum torque celerate the moson and then so celerate the moson and then lesson are the moson and then lesson are the moson and then lesson are the moson are th	set in Pn00 tor to a st- ue and the tor to a st- ue and the tor to a st- ervo-lock to tor to a st-	on (2001 h op using the servo-loop using the let the roop using the motor.	ex) = n. \(\Pi\) \(\Pi	in Pn406 as in Pn406 as in time set in	page 5	5-27
			Main Circuit	Power Supply	AC/DC In	put Select	ion		Refere	ence
		n.□X□□	1.□X□□  Input AC power as the main circuit power supply using the L1, L2, and L3 terminals (do not use shared converter).  Input DC power as the main circuit power supply using the B1 and ⊖ 2 terminals (use an external converter or the shared converter).						page 5	5-12
		n.X□□□	Reserved pa	rameter (Do no	t change.	)				

Continued from previous page.

Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Application Selections		0000 hex to 4213 hex	_	0001 hex	_	After restart	Setup	-	
			EtherCAT (C Selection	oE) Module Tor	d Usage	Applicable Motors	Refere	ence			
	n.□□□X	0 Re	served setting (	Do not use							
		n.□□□X	1 (Co	able torque limi oE). utomatically set				All	_		
			2 Re	served setting (	Do not use	e.)					
			3 Re	served setting (	Do not use	e.)					
		EtherCAT (C Selection	oE) Module Sp	l Usage	Applicable Motors	Refere	ence				
	n.□□	n.□□X□		sable speed limi oE) during torqu		herCAT	All	_			
Pn002			1 Re	served setting (	Do not use						
(2002 hex)		Encoder Usage						Applicable Motors	Refere	ence	
		n.□X□□		Use the encoder according to encoder specifications.							
			1 Us	e the encoder a	as an incre	mental end	coder.		page 6	5-31	
				e the encoder a coder.	lute	Rotary					
			External End	oder Usage				Applicable Motors	Refere	ence	
			0 Do	not use an exte	ernal enco	der.					
		n.X□□□		e external enco n for CCW moto			ward direc-				
				served setting (				Rotary	page 1	10-6	
				e external enco n for CCW moto			erse direc-	rec-			
			4 Re	served setting (							

Continued from previous page. When Classi- Refer-Enabled fication ence

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer
	2	Application Selections		0000 hex to 105F hex	-	0002 hex	All	Immedi- ately	Setup	page 9-9
	2	Application	Analog Mo	Range  0000 hex to 105F hex  nitor 1 Signal Se  Motor speed (1  Motor speed (1  Speed reference Force reference Position deviation Position amplified pulse unit)  Position reference Reserved setting Load-motor positioning completed: 0 V)  Speed feedforw Speed feedforw Force feedforwa	Unit  -  Plection  V/1,000 m  V/1,000 m  P(1 V/1,000 m)  P(1 V/100 m)  P(2 Speed ()  P(3 (Do not unit or deviation ()  P(4 Speed ()  P(5 Speed ()  P(6 Speed ()  P(7 Speed ()  P(7 Speed ()  P(8 Speed	Setting  0002 hex  nin-1) nm/s) 00 min-1) 00 mm/s) % rated to 6 rated fore freference in (after election (after election) 1 V/1,000 1 V/1,000 use.) ution (0.01 usein) 000 min-1) 000 mm/s 00% rated to	rque) ce) unit) ctronic gear) (( ctronic	Enabled Immediately  0.05 V/enco 0.05 V/linear	der pulse rencoder	ence page 9-9
			0B 0C	Active gain (1st Completion of p pleted: 0 V)	<u> </u>		,	pleted: 5 V,	not com-	
			0D	External encode	er speed (1	V/1,000 r	nin <sup>-1</sup> : value at	the motor s	haft)	
			0E	Reserved setting					- 7	
			0F	Reserved setting	g (Do not ı	use.)				
			10	Main circuit DC	voltage					
			11 to 5F	Reserved setting	gs (Do not	use.)				
	-	n.□X□□		parameter (Do no		,				
		n.X□□□	Reserved p	parameter (Do no	ot change.	)				

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence						
	2	Application Selections	Application Function Selections 7		_	0000 hex	All	Immedi- ately	Setup	page 9-9						
		•		·												
			Analog Mo	nitor 2 Signal Se	election											
			00	Motor speed (1 Motor speed (1												
				Speed reference	•	· ·										
			01	Speed reference												
				Torque reference (1 V/100% rated torque)												
			02	Force reference (1 V/100% rated force)												
			03	Position deviation	n (0.05 V/	reference i	unit)									
											Position amplifier deviation (after electronic gear) (0.05 V/encoder pulse unit)					
		Position amplifier deviation (after electronic gear) (0.05 V/linear electronic gear) (0.05 V/linear electronic gear)														
			0.5	Position referen	ce speed (	1 V/1,000	min <sup>-1</sup> )									
	n.□□XX	05	Position reference speed (1 V/1,000 mm/s)													
		06	Reserved setting (Do not use.)													
Pn007		1.□□XX	07	Load-motor pos	ition devia	ition (0.01	V/reference u	nit)								
(2007 hex)			08	Positioning completed: 0 V)	pletion (po	sitioning c	ompleted: 5	V, positionino	not com-	-						
			09	Speed feedforw	ard (1 V/1	,000 min <sup>-1</sup> )										
			09	Speed feedforw	ard (1 V/1	,000 mm/s	)									
			0A	Torque feedforw	ard (1 V/1	00% rated	torque)									
			UA.	Force feedforwa	ırd (1 V/10	0% rated f	orce)									
			0B	Active gain (1st												
			0C	Completion of p pleted: 0 V)	osition ref	erence dist	tribution (com	pleted: 5 V,	not com-							
			0D	External encode	r speed (1	V/1,000 n	nin <sup>-1</sup> : value at	the motor s	haft)							
			0E	Reserved setting	g (Do not ı	use.)										
			0F	Reserved setting	g (Do not ı	use.)										
			10	Main circuit DC	voltage											
			11 to 5F	Reserved setting	gs (Do not	use.)										
	n.□X□□ Reserved parameter (Do not change.)															
		n.X□□□ Reserved parameter (Do not change.)														

Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Applicatio Selections	n Function 8 8	0000 hex to 7121 hex	_	4000 hex	Rotary	After restart	Setup	-
			L D	Valta e a Alaura	0.0/aa.i.a.a.	Dalaatian			Defens	
		n.□□□X		Voltage Alarm/ tput alarm (A.83			ltago		Refere	nce
		II.UUUX							page 1	5-2
	-		1 Output warning (A.930) for low battery voltage.							
			Function Se	ection for Unde	ervoltage				Refere	nce
Pn008		0 Do	not detect und	ervoltage.						
(2008 hex)			tect undervolta		,	<u>'</u>		page 6	5-15	
				tect undervolta x) and Pn425 (2						
		Warning Det	ection Selectio	n				Refere	nce	
		n.□X□□	0 De	tect warnings.					page	
			1 Do	not detect war	nings exce	ept for A.9	71.		45	
	-	n.X□□□	Reserved pa	rameter (Do no	t change.	)				
	-			,		,				
	2	Applicatio Selections	n Function s 9	0000 hex to 0121 hex	_	0010 hex	All	After restart	Tuning	-
	_									_
	I	n.□□□X	Reserved pa	rameter (Do no	ot change.	)				
		n.□□□X	· ·	rameter (Do no		)			Refere	nce
	Ī		Current Con	·	ction	,			Refere	nce
Pn009	Ī	n.□□□X	Current Con 0 Us	trol Mode Sele	ction ol mode 1.	,			Refere	
Pn009 (2009 hex)	Ī		Current Con 0 Us 1 Us	trol Mode Select	ction ol mode 1. ol mode 2.					
	Ī		Current Con  0 Us  1 Us  2 Re	trol Mode Selece e current control e current control	ction of mode 1. of mode 2. (Do not us					3-69
			Current Con	trol Mode Selecte current controlle current controlle current controlle served settings	ction of mode 1. of mode 2. (Do not us				page 8	nce
		n.□□X□	Current Con	trol Mode Selecte current controller current controller current controller served settings	ction of mode 1. of mode 2. (Do not use) election on 1.				page 8	nce
		n.□□X□	Current Con	trol Mode Selecte current controls e current controls served settings ction Method Selection detection det	ction ol mode 1. ol mode 2. (Do not uselection on 1. on 2.	se.)			page 8	nce

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Application Selections		0000 hex to 0044 hex	-	0001 hex	All	After restart	Setup	_
					<u> </u>					
			Motor Stopp	oing Method fo	r Group 2	Alarms			Refer	ence
				ply the dynamic opping method						
			1 (24	celerate the mo 106 hex) as the 101 hex) = n. I	maximum	torque. Us	se the setting	of Pn001		
		n.□□□X		celerate the mo 106 hex) as the					. page	5-38
		3 Pn	celerate the mo 30A (230A hex)	. Use the	setting of I	Pn001 (2001		1		
				celerate the mo 30A (230A hex)				on time set ir	1	
Pn00A (200A hex)			Stopping Me	ethod for Force	d Stops				Refer	ence
,				ply the dynamic opping method						
	r		1 (24	celerate the mo 106 hex) as the 101 hex) = n.DI	maximum	torque. U	se the setting	of Pn001		
		n.□□X□		celerate the mo 106 hex) as the					. page	6-55
			3 Pn	celerate the mo 30A (230A hex)	. Use the	setting of I	Pn001 (2001		1	
				celerate the mo 30A (230A hex)				on time set ir	1	
		n.□X□□	Reserved pa	rved parameter (Do not change.)						
		n.XDDD	Reserved pa	arameter (Do no	ot change	.)				
				·		·				
	2	Application Selections		0000 hex to 1121 hex	-	0000 hex	All	After restart	Setup	-
			Operator Pa	rameter Displa	v Selectio	n			Refer	ence
		n.□□□X		splay only setup					page	
			1 Dis	splay all parame	eters.				page	
Pn00B				oing Method fo	•				Refer	ence
(200B hex)		n.□□X□		op the motor by	, ,					
			sto	oply the dynami	set in Pn0	001 (2001	nex) = n.□□□	⊐X).	page	5-38
			2 Se	et the stopping	method w	ith Pn00A	(200A hex) =	n.⊔⊔□X.		
		n.□X□□	Reserved pa	arameter (Do no	ot change	.)				
		n.X□□□	Reserved pa	arameter (Do no	ot change	.)				

Classi-

fication

Setup

Applicable

Refer-

ence

Continued from previous page.

When

Enabled

After

restart

After

restart

# Applicable Motors Applicable Motors Applicable Motors

All

Setup

page 5-29

n.□□□X	Reserved parameter (Do not change.)
n.□□X□	Reserved parameter (Do not change.)
n.□X□□	Reserved parameter (Do not change.)
	Overture of Warrian Datastics Colection

0000

hex

ΑII

Reserved parameter (Do not change.)						
Overtrav	el Warning Detection Selection					
0	Do not detect overtravel warnings.					
Detect overtravel warnings.						

Pn00E	2	Reserved parameter (Do not change.)	_	-	0000	All	_	-	_
	2	Application Function Selections F	0000 hex to 2011 hex	_	0000 hex	All	After restart	Setup	_

Setting

Range

0000 hex to 0131 hex

Function Selection for Test without a Motor

Disable tests without a motor.

Enable tests without a motor.

Encoder Resolution for Tests without a Motor

Encoder Type Selection for Tests without a Motor

Use an incremental encoder.

Use an absolute encoder.

Reserved parameter (Do not change.)

0000 hex to

1001 hex

Use 13 bits.

Use 20 bits.

Use 22 bits.

Use 24 bits.

Parameter

No.

Pn00C

Pn00D (200D hex)

Pn00F

Pn021 (2021 hex)

(200F hex)

(200C hex)

Size

2

n.□□□X

n.□□X□

n.□X□□

n.X□□□

2

Name

0

1

2

3

0

1

Application Function Selections D

Application Function Selections C

Setting

Unit

Default

Setting

0000

hex

Applicable

Motors

		Preven	tative	Maintenance V	Varning S	election			Refere	nce
n	n.□□□X	0	Do no	ot detect preve	ntative ma	aintenance	warnings.			
		1	1 Detect preventative maintenance warnings. page 9-15							
n	n.00X0	Reserv	Reserved parameter (Do not change.)							
n	n.□X□□	Reserv	ed par	ameter (Do no	t change.	)				
n	n.X000	Reserv	Reserved parameter (Do not change.)							
)	Reserved		er (Do	_	_	0000	All	-	_	_

Continued from previous page.

Б.					0	0	D ( !!				
Parameter No.	Size	١	Name		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Applications Selections	n Function s 22		0000 hex to 0011 hex	_	0000 hex	All	After restart	Setup	_
			Overtrave	l Rel	ease Method	Selection				Refere	nce
			0 (	Over	travel exists w	hile the P-	OT or N-C	T signal is be	ing input.		
Pn022 (2022 hex)	n	.000X	1 (	curre	travel exists went position of r N-OT signal.					page 5	-30
	n	.DDXD	Reserved	para	ameter (Do not	t change.)					
	n	.DXDD	Reserved	para	ameter (Do not	t change.)					
	n	.X000	Reserved	para	ameter (Do not	t change.)					
	2	Applications	n Function s 23		0000 hex to 0001 hex	_	0000 hex	All	After restart	Setup	-
		- DDDV	D 111 D		D. I. II						
	r	n.□□□X			Relay Usage S					Refere	nce
Pn023			1		the built-in branch		relav			page 5	5-30
(2023 hex)							, rolay.				
	r	n.□□X□	Reserved	para	ameter (Do not	change.)					
	r	n.0X00	Reserved	para	ameter (Do not	change.)					
	r	1.X000	Reserved	para	ameter (Do not	change.)					
	_										
Pn040 (2040 hex)	2	Reserved not chang	parameter ( le.)	(Do	0000 hex to 2111 hex	_	0000 hex	-	-	_	-
	2	Applications Selections	n Function 8 80		0000 hex to 1111 hex	-	0000 hex	Linear	After restart	Setup	ı
			Polarity S	ensc	r Selection					Refere	nce
	n	.000X	0	Use	polarity sensor	r.				page 5	-22
			1	Do r	ot use polarity	sensor.				page	
			Motor Pha	ase S	Sequence Sele	ection				Refere	nce
Pn080	n	.00X0	0	Set a	a phase-A leac	l as a pha	se sequen	ce of U, V, and	d W.	page 5	-20
(2080 hex)			1	Set a	a phase-B lead	as a pha	se sequen	ce of U, V, and	d W.	pago o	
	n.□X□□ Reserved parameter (Do not cha					t change.)					
			Calculatio	n M	ethod for Max	imum Spe	ed or End	oder Output	Pulses	Refere	nce
	n	.X000		O Calculate the encoder output pulse setting for a fixed maximum speed.							
				Calculate the maximum speed for a fixed encoder output pulse setting.						— page 1	0-1

Parameter No.	Size	N	lame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Application Selections			0000 hex to 1111 hex	-	0000 hex	All	After restart	Setup	page 6-18
Pn081		n.□□□X	Phase-C 0 1	Out	se Output Sele put phase-C p put phase-C p	ulses only				s.	
(2081 hex)	]	n.□□X□	Reserved	par	ameter (Do no	t change.	)				
	I	n.□X□□	Reserved	par	ameter (Do no	t change.	)				
	]	n.XDDD	Reserved	par	ameter (Do no	t change.	)				
Pn100 (2100 hex)	2	Speed Loc	op Gain		10 to 20,000	0.1 Hz	400	All	Immedi- ately	Tuning	page 8-76
Pn101 (2101 hex)	2	Speed Loo			15 to 51,200	0.01 ms	2000	All	Immedi- ately	Tuning	page 8-76
Pn102 (2102 hex)	2	Position Lo	oop Gain		10 to 20,000	0.1/s	400	All	Immedi- ately	Tuning	page 8-76
Pn103 (2103 hex)	2	Moment o	f Inertia Ra	tio	0 to 20,000	1%	100	All	Immedi- ately	Tuning	page 8-76
Pn104 (2104 hex)	2	Second Sp Gain	peed Loop		10 to 20,000	0.1 Hz	400	All	Immedi- ately	Tuning	page 8-65
Pn105 (2105 hex)	2	Second Sp Integral Tir	Second Speed Loop Integral Time Constant		15 to 51,200	0.01 ms	2000	All	Immedi- ately	Tuning	page 8-65
Pn106 (2106 hex)	2	Second Po Gain	Second Position Loop Gain		10 to 20,000	0.1/s	400	All	Immedi- ately	Tuning	page 8-65
Pn109 (2109 hex)	2	Feedforwa	eedforward		0 to 100	1%	0	All	Immedi- ately	Tuning	page 8-86
Pn10A (210A hex)	2	Feedforwa Constant	ırd Filter Tir	ne	0 to 6,400	0.01 ms	0	All	Immedi- ately	Tuning	page 8-86
	2	Gain Appli tions	cation Sele	C-	0000 hex to 5334 hex	-	0000 hex	All	-	Setup	-
	Ī		Mode Sw	ritch	ing Selection				When	Refere	ance
			0	Use	the internal to			e condition	Enabled	Tierere	
				Use	el setting: Pn10 the speed refe	erence as		ion (level set-			
			1		: Pn10D (210D the speed refe	- "	the condit	ion (level set-			
		n.□□□X			: Pn181 (2181 the accelerati		ce as the o	condition (leve	Immedi- ately	page 8	3-87
			2	Use	ing: Pn10E (21 the accelerati	on referen	ce as the o	condition (leve			
Pn10B (210B hex)			3	Use	ing: Pn182 (21 the position d	eviation as	s the cond	ition (level set	-		
	3 ting				: Pn10F (210F not use mode						
								When Enabled	Refere	ence	
		n.□□X□	0		control	After		7.70			
					control served settings	(Do not us	se.)		restart	page 8	ס-7 ס
		n.□X□□	Reserved parameter (Do not change.)								
	Ī	n.XDDD	Reserved	par	ameter (Do no	t change.	)				_
											_

	Continued from previous page.									
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn10C (210C hex)	2	Mode Swit for Torque	ching Level Reference	0 to 800	1%	200	All	Immedi- ately	Tuning	page 8-87
Pn10D (210D hex)	2	Mode Swit for Speed	ching Level Reference	0 to 10,000	1 min <sup>-1</sup>	0	Rotary	Immedi- ately	Tuning	page 8-87
Pn10E (210E hex)	2	Mode Swit for Acceler	ching Level ation	0 to 30,000	1 min <sup>-1</sup> / s	0	Rotary	Immedi- ately	Tuning	page 8-87
Pn10F (210F hex)	2	Mode Swit for Position	ching Level n Deviation	0 to 10,000	1 refer- ence unit	0	All	Immedi- ately	Tuning	page 8-87
Pn11F (211F hex)	2	Position In Constant	Position Integral Time Constant		0.1 ms	0	All	Immedi- ately	Tuning	page 8-89
Pn121 (2121 hex)	2	Friction Co Gain	Friction Compensation Gain		1%	100	All	Immedi- ately	Tuning	page 8-65, page 8-68
Pn122 (2122 hex)	2		Second Friction Compensation Gain		1%	100	All	Immedi- ately	Tuning	page 8-65, page 8-68
Pn123 (2123 hex)	2	Friction Co Coefficient	Friction Compensation Coefficient		1%	0	All	Immedi- ately	Tuning	page 8-68
Pn124 (2124 hex)	2		mpensation Correction	-10,000 to 10,000	0.1 Hz	0	All	Immedi- ately	Tuning	page 8-68
Pn125 (2125 hex)	2	Friction Co Gain Corre	ection	1 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-68
Pn131 (2131 hex)	2	Gain Switc	Gain Switching Time 1		1 ms	0	All	Immedi- ately	Tuning	page 8-65
Pn132 (2132 hex)	2	Gain Switching Time 2		0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 8-65
Pn135 (2135 hex)	2	Gain Switc Time 1	Gain Switching Waiting Time 1		1 ms	0	All	Immedi- ately	Tuning	page 8-65
Pn136 (2136 hex)	2	Gain Switc Time 2	hing Waiting	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 8-65
	2	Automatic ing Selection	Gain Switch- ons 1	0000 hex to 0052 hex	-	0000 hex	All	Immedi- ately	Tuning	page 8-65
Pn139 (2139 hex)		n.000X  n.00X0  n.0X00	1 Res 2 Use The swisec  Gain Switchi 0 /CC 1 /CC 2 /NE 3 /NE 4 Pos 5 Pos	ng Selection able automatic served setting ( e automatic gai e gain is switche tching condition and Gain to the ng Condition A DIN (Positioning DIN (Positioning EAR (Near Outp EAR (Near Outp sition reference sition reference rameter (Do no	Do not use n switchin ed automa n A is sative e first gain Completi Completi ut) signal filter outp input is O t change.	g pattern g pattern stically from Sied. The when swite on Output on Output turns ON. turns OFF. ut is 0 and N.	n the first gair gain is switch ching condition ) signal turns ) signal turns	ed automatic on A is not s ON. OFF.	cally from atisfied.	
Pn13D (213D hex)	2	Current Ga	ain Level	100 to 2,000	1%	2000	All	Immedi- ately	Tuning	page 8-70

_					-			linuea irom	·	
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Model Foll- trol-Relate	owing Con- d Selections	0000 hex to 1121 hex	-	0100 hex	All	Immedi- ately	Tuning	-
			Model Follo	wing Control Se	election				Refere	ence
		n.□□□X		o not use model		control.				
				se model followi					page 8	3-76
			Vibration Su	uppression Sele	ction				Refere	ence
		n.□□X□	0 D	o not perform vik	oration sup	opression.				
	'	1.000	1 P	erform vibration	suppression	on for a sp	ecific frequen	су.	page 8	3-76
Pn140			2 P	erform vibration	suppression	on for two	specific frequ	encies.		
(2140 hex)			Vibration Su	Suppression Adjustment Selection						ence
	1	n.0X00	O tio	o not adjust vibra on of autotuning ference, and cus	without a	host refere				
			1 au	djust vibration su utotuning withounce, and custom	t a host re	automationation	cally during ex utotuning with	ecution of a host refer-	— page 8	
			Speed Feed	dforward (VFF)/1	Torque Fee	edforward	(TFF) Selecti	on	Refere	ence
		n.X000		Do not use model following control and speed/torque feedforward together.						
	11.2000		1 U:	se model followii gether.	ng control	and speed	d/torque feedf	orward	page 8	3-30
	togotio.									
Pn141 (2141 hex)	2	Model Foll	owing Con-	10 to 20,000	0.1/s	500	All	Immedi- ately	Tuning	page 8-76
Pn142 (2142 hex)	2	Model Foll	owing Con- correction	500 to 2,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-65
Pn143 (2143 hex)	2	Model Follotrol Bias in Direction	owing Con- the Forward	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-76
Pn144 (2144 hex)	2	Model Follotrol Bias in Direction	owing Con- the Reverse	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-76
Pn145 (2145 hex)	2	Vibration S Frequency	Suppression 1 A	10 to 2,500	0.1 Hz	500	All	Immedi- ately	Tuning	page 8-55
Pn146 (2146 hex)	2	Frequency		10 to 2,500	0.1 Hz	700	All	Immedi- ately	Tuning	page 8-55
Pn147 (2147 hex)	2		owing Con- Feedforward ation	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-76
Pn148 (2148 hex)	2	Second Me ing Contro	odel Follow- I Gain	10 to 20,000	0.1/s	500	All	Immedi- ately	Tuning	page 8-65
Pn149 (2149 hex)	2	Second Model Follow- ing Control Gain Correc- tion		500 to 2,000	0.1%	1000	All	Immedi- ately	Tuning	page 8-65
Pn14A (214A hex)	2	Vibration S Frequency	Suppression 2	10 to 2,000	0.1 Hz	800	All	Immedi- ately	Tuning	page 8-55
Pn14B (214B hex)	2	Vibration S Correction	Suppression 2	10 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-55

Continued from previous page.

		I					Con	tinued from	previous	page.	
Parameter No.	Size	N	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Control-Retions	elated Selec-	0000 hex to 0021 hex	_	0021 hex	All	After restart	Tuning	_	
			Model Follow	ring Control Ty	pe Select	Refere	ence				
	1	n.□□□X	0 Use	model following	ng control	type 1.					
			1 Use	model following	ng control	type 2.			page 8	page 8-86	
Pn14F (214F hex)				ype Selection					Refere	ence	
(2111 110%)	1	n.□□X□		tuning-less ty	•				page 8		
				1 Use tuning-less type 2.							
			2 Use	tuning-less ty	pe 3.					_	
	1	n.0X00	Reserved par	rameter (Do no	t change.	)					
	ı	n.X000	Reserved par	rameter (Do no	t change.	)					
		1		T		•	T	T		T	
	2		nance Con- ed Selections	0000 hex to 0011 hex	-	0010 hex	All	Immedi- ately	Tuning	-	
		1		l	I.		<u> </u>	<u>-</u>	II.	ı	
	-		Anti Posonan	nce Control Se	loction				Refere	2000	
	١,	n.□□□X		not use anti-re		ontrol			neiere	illo <del>e</del>	
				anti-resonanc					page 8	3-50	
	Anti-Resonance Control Adjustment Selection									ence	
Pn160			Do	not adjust anti-	resonance	e control a	utomatically o	during execu	-		
(2160 hex)	1	n.□□X□		0 tion of autotuning without a host reference, autotuning with a h reference, and custom tuning.							
				ust anti-resona					page 8	3-30	
				stotuning without a host reference, autotuning with a host reference, and custom tuning.							
		n.0X00	Reserved par	rameter (Do no	t change.	)			•		
	-			`		,					
	<u> </u>	n.X000	Reserved par	rameter (Do no	ot change.	)					
Pn161		Anti-Reso	nance Fre-					Immedi-	_	page	
(2161 hex)	2	quency	110100116-	10 to 20,000	0.1 Hz	1000	All	ately	Tuning	8-50	
Pn162 (2162 hex)	2	Anti-Resor	nance Gain า	1 to 1,000	1%	100	All	Immedi- ately	Tuning	page 8-50	
Pn163 (2163 hex)	2	Anti-Reso ing Gain	nance Damp-	0 to 300	1%	0	All	Immedi- ately	Tuning	page 8-50	
Pn164 (2164 hex)	2		nance Filter stant 1 Cor-	-1,000 to 1,000	0.01 ms	0	All	Immedi- ately	Tuning	page 8-50	
Pn165 (2165 hex)	2		nance Filter stant 2 Cor-	-1,000 to 1,000	0.01 ms	0	All	Immedi- ately	Tuning	page 8-50	
Pn166 (2166 hex)	2	Anti-Reso ing Gain 2	nance Damp-	0 to 1,000	1%	0	All	Immedi- ately	Tuning	page 8-50	

Continued	from	provious	n
Continued	110111	DIENIOUS	paye

Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Tuning-les Related Se	s Function- elections	0000 hex to 2711 hex	-	1401 hex	All	-	Setup	page 8-12
		n.□□□X		sable tuning-les					Whe Enab	led er
Pn170		n.□□X□	Speed Cont	able tuning-less rol Method e for speed cor					Whe Enab	en led
(2170 hex)				e for speed cor		se host co	ntroller for po	sition contro		
		n.□X□□	Rigidity Level							en led edi-
			0 to 7 Se	0 to 7 Set the rigidity level.						
		n.X□□□	Tuning-less	Load Level					Whe Enab	
			0 to 2 Se	t the load level	for the tun	ing-less fu	nction.		Imme atel	
Pn181	2		tching Level	0 to 10,000	1 mm/s	0	Linear	Immedi-	Tuning	page
(2181 hex) Pn182	2	Mode Swi	Reference tching Level	0 to 30,000	1 mm/	0	Linear	ately Immedi-	Tuning	8-87 page 8-87
(2182 hex) Pn205	2	for Accele  Multiturn L		0 to 65,535	s <sup>2</sup>	65535	Rotary	ately After	Setup	8-87 page 6-36
(2205 hex)	2		ontrol Func-	0000 hex to 2210 hex	_	0010 hex	All	restart After restart	Setup	-
		tion Select	LIOTIS	2210 Hex		riex		restart		
		n.□□□X	Reserved pa	rameter (Do no	t change.	)				
	I	n.□□X□	Reserved pa	eserved parameter (Do not change.)						
	]	n.□X□□	Reserved pa	rameter (Do no	t change.	)				
Pn207			/COIN (Posi	ioning Comple	tion Outp	ut) Signal	Output Timin	g	Refe enc	
(2207 hex)			0 sa	tput when the a me or less than mpleted Width)	the setting					
		or l		tput when the a less than the se ted Width) and	etting of Pr	n522 (2522	hex) (Positio	ning Com-	2000	6-10
			2 or	tput when the a less than the se ted Width) and	etting of Pr	n522 (2522	hex) (Positio		)	
Pn20A (220A hex)	4	Number of External Encoder Scale Pitches		4 to 1,048,576	1 scale pitch/ revolu- tion	32768	Rotary	After restart	Setup	page 10-6
Pn20E (220E hex)	4	Electronic (Numerato	Gear Ratio or)*4	1 to 1,073,741,824	1	1	All	After restart	Setup	page 5-42
Pn210 (2210 hex)	4	Electronic (Denomina	Gear Ratio ator)*4	1 to 1,073,741,824	1	1	All	After restart	Setup	page 5-42
D=010		1	· - · -			I	1		1	1

Number of Encoder Output Pulses

16 to 1,073,741,824

1 P/Rev

2048

Rotary

(2212 hex)

4

Pn212

Continued on next page.

Setup

page 6-23

After restart

Continued from previous page.

						0011	unuea irom	previous	page.
Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Fully-closed Control Selections	0000 hex to 1003 hex	-	0000 hex	Rotary	After restart	Setup	page 10-9
	r	n.□□□X Reserved par	ameter (Do no	ot change.	)				
Pn22A	r	n.□□X□ Reserved par	ameter (Do no	t change.	)				
(222A hex)	r	n.□X□□ Reserved par	rameter (Do no	t change.	)				
	n.X□□□   Fully-closed Control Speed Feedback Selection  0  Use motor encoder speed.  1  Use external encoder speed.								
	2	Position Control Expansion Function Selections	0000 hex to 0001 hex	-	0000 hex	All	After restart	Setup	page 8-71
Pn230 (2230 hex)	Backlash Compensation Direction   0   Compensate forward references.   1   Compensate reverse references.     1   Reserved parameter (Do not change.)								
Pn231 (2231 hex)	4	Backlash Compensation	-500,000 to 500,000	0.1 reference units	0	All	Immedi- ately	Setup	page 8-71
Pn233 (2233 hex)	2	Backlash Compensa- tion Time Constant	0 to 65,535	0.01 ms	0	All	Immedi- ately	Setup	page 8-71
Pn281 (2281 hex)	2	Encoder Output Resolution	1 to 4,096	1 edge/ pitch	20	All	After restart	Setup	page 6-23
Pn282 (2282 hex)	4	Linear Encoder Scale Pitch	0 to 6,553,600	0.01 µm	0	Linear	After restart	Setup	page 5-15
Pn304 (2304 hex)	2	Jogging Speed	0 to 10,000	Rotary: 1 min <sup>-1</sup>	500	Rotary	Immedi- ately	Setup	page 7-7
Pn305 (2305 hex)	2	Soft Start Acceleration Time	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	*1
Pn306 (2306 hex)	2	Soft Start Deceleration Time	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	*1
Pn308 (2308 hex)	2	Speed Feedback Filter Time Constant	0 to 65,535	0.01 ms	0	All	Immedi- ately	Setup	page 8-76
Pn30A (230A hex)	2	Deceleration Time for Servo OFF and Forced Stops	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	page 5-28
Pn30C (230C hex)	2	Speed Feedforward Average Movement Time	0 to 5,100	0.1 ms	0	All	Immedi- ately	Setup	page 8-86

ਜ
ñ

	Continued from previous page.											
Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	Vibration Detection Selections	0000 hex to 0002 hex	-	0000 hex	All	Immedi- ately	Setup	page 6-46			
		Vibration Det	ection Selection	on								
	r	0 Do	not detect vibr	ation.								
Pn310		1 Ou	tput a warning	· ,								
(2310 hex)		2 Ou	tput an alarm (A	4.520) if vil	oration is o	detected.						
	r	n.□□X□ Reserved pa	rameter (Do no	meter (Do not change.)								
	n.□X□□ Reserved parameter (Do not change.)											
	r	n.XDDD Reserved pa	rameter (Do no	t change.	)							
	_	<u> </u>										
Pn311 (2311 hex)	2	Vibration Detection Sensitivity	50 to 500	1%	100	All	Immedi- ately	Tuning	page 6-46			
Pn312 (2312 hex)	2	Vibration Detection Level	0 to 5,000	1 min <sup>-1</sup>	50	Rotary	Immedi- ately	Tuning	page 6-46			
Pn316 (2316 hex)	2	Maximum Motor Speed	0 to 65,535	1 min <sup>-1</sup>	10000	Rotary	After restart	Setup	page 6-17			
Pn324 (2324 hex)	2	Moment of Inertia Cal- culation Starting Level	0 to 20,000	1%	300	All	Immedi- ately	Setup	page 8-30			
Pn383 (2383 hex)	2	Jogging Speed	0 to 10,000	1 mm/s	50	Linear	Immedi- ately	Setup	page 7-7			
Pn384 (2384 hex)	2	Vibration Detection Level	0 to 5,000	1 mm/s	10	Linear	Immedi- ately	Tuning	page 6-46			
Pn385 (2385 hex)	2	Maximum Motor Speed	1 to 100	100 mm/s	50	Linear	After restart	Setup	page 6-17			
Pn401 (2401 hex)	2	First Stage First Torque Reference Filter Time Constant	0 to 65,535	0.01 ms	100	All	Immedi- ately	Tuning	page 8-79			
Pn402 (2402 hex)	2	Forward Torque Limit	0 to 800	1%* <sup>1</sup>	800	Rotary	Immedi- ately	Setup	page 6-26			
Pn403 (2403 hex)	2	Reverse Torque Limit	0 to 800	1% <sup>*l</sup>	800	Rotary	Immedi- ately	Setup	page 6-26			
Pn404 (2404 hex)	2	Forward External Torque Limit	0 to 800	1% <sup>*l</sup>	100	All	Immedi- ately	Setup	page 6-27			
Pn405 (2405 hex)	2	Reverse External Torque Limit	0 to 800	1%* <sup>1</sup>	100	All	Immedi- ately	Setup	page 6-27			
Pn406 (2406 hex)	2	Emergency Stop Torque	0 to 800	1% <sup>*l</sup>	800	All	Immedi- ately	Setup	page 5-27			
Pn407 (2407 hex)	2	Speed Limit during Torque Control	0 to 10,000	1 min <sup>-1</sup>	10000	Rotary	Immedi- ately	Setup	page 6-12			

Continued on next page.

Continued from previous page.

Parameter	Size		Name		Setting	Setting	Default	Applicable	When	Classi-	Refer-	
No.	Si				Range	Unit	Setting	Motors	Enabled	fication	ence	
	2	tion Select	lated Func- tions		0000 hex to 1111 hex	_	0000 hex	All	-	Setup	-	
	Ī		Notch Filt	er S	Selection 1				When Enabled	Refere	nce	
		n.□□□X	0 1	Disa	able first stage	notch filte	r.		Immedi-	page 8	2-79	
			1	Ena	ble first stage	notch filter			ately	page		
			Speed Lin	nit S	Selection				When Enabled	Refere	Reference	
					the smaller of ing of Pn407 (2				,			
		n.□□X□			Use the smaller of the maximum motor speed and the etting of Pn480 (2480 hex) as the speed limit.							
Pn408 (2408 hex)				Use the smaller of the overspeed alarm detect speed and the setting of Pn407 (2407 hex) as speed limit.				After restart	page 6	5-12		
				spe	the smaller of ed and the set ed limit.	the oversp ting of Pn	he overspeed alarm detection ng of Pn480 (2480 hex) as the					
			Notch Filte	Filter Selection 2						Refere	nce	
		n.□X□□	0 1	Disa	Disable second stage notch filter.							
					nable second stage notch filter.					page 8	8-79	
	Ī		Friction C	om	pensation Fun	When Enabled	Refere	nce				
		n.X□□□	0 1	Disa	able friction co	mpensatio	n.		Immedi-	page 8	 3-68	
			1	Enable friction compensation.					ately	pago		
Pn409 (2409 hex)	2	First Stage Frequency	e Notch Filte	r	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-79	
Pn40A (240A hex)	2	First Stage Q Value	Notch Filte	r	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-79	
Pn40B (240B hex)	2	First Stage Depth	Notch Filte	r	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-79	
Pn40C (240C hex)	2	Second St ter Freque	tage Notch I	Fil-	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-79	
Pn40D (240D hex)	2	Second St ter Q Value	tage Notch I	Fil-	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-79	
Pn40E (240E hex)	2	Second St ter Depth	tage Notch I	Fil-	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-79	
Pn40F (240F hex)	2	Second St Torque Re Frequency	econd Stage Second rque Reference Filter		100 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-79	
Pn410 (2410 hex)	2		econd Stage Second orque Reference Filter		50 to 100	0.01	50	All	Immedi- ately	Tuning	page 8-79	
Pn412 (2412 hex)	2	First Stage Torque Re Time Cons	ference Filte	r	0 to 65,535	0.01 ms	100	All	Immedi- ately	Tuning	page 8-65	

Continued	from	provious	nago
COHUHUCU	поп	DIEVIOUS	Daut.

	Continued from pre						<u> </u>						
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	Torque-Re tion Select	lated Func- tions 2	0000 hex to 1111 hex	_	0000 hex	All	Immedi- ately	Setup	page 8-81			
				•			•						
	Ī		Notch Filter	Selection 3									
	1	n.□□□X	0 Di:	sable third stage	e notch filt	er.							
			1 En	able third stage	notch filte	er.							
Pn416			Notch Filter	Selection 4									
(2416 hex)	1	n.□□X□		sable fourth stag									
			1 En	Enable fourth stage notch filter.									
		- 0,000		tch Filter Selection 5  0 Disable fifth stage notch filter.									
		n.□X□□		able fifth stage									
		n.XDDD		arameter (Do no									
	-	11	neserved pa	arameter (DO NC	or change.	·)							
Pn417 (2417 hex)	2	Third Stag Frequency	e Notch Filter	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-81			
Pn418 (2418 hex)	2	Third Stag Q Value	e Notch Filter	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-81			
Pn419 (2419 hex)	2	Third Stag Depth	e Notch Filter	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-81			
Pn41A (241A hex)	2	Fourth Sta ter Freque	ge Notch Fil- ncy	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-81			
Pn41B (241B hex)	2	ter Q Value	-	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-81			
Pn41C (241C hex)	2	Fourth Sta ter Depth	ge Notch Fil-	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-81			
Pn41D (241D hex)	2	Frequency		50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 8-81			
Pn41E (241E hex)	2	Q Value	e Notch Filter	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 8-81			
Pn41F (241F hex)	2	Depth	Notch Filter	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 8-80			
	2	Speed Rip sation Sele	ple Compen- ections	0000 hex to 1111 hex	_	0000 hex	Rotary	-	Setup	9 page 8-59			
	_												
		n.□□□X	Speed Ripp	le Compensatio	n Functio	n Selectio	n		Whe Enab				
				sable speed ripp able speed ripp					Imme atel				
Pn423	Ī		Speed Ripp tion Selection	le Compensatio	n Informa	ition Disag	reement War	ning Detec-	Whe				
(2423 hex)		n.□□X□		etect A.942 alarr					Afte				
			1   DC	THOU GELECT A.9	4∠ alaIIIIS					_			
			Speed Ripp	le Compensatio	n Enable	Condition	Selection		Whe Enabl				
		n.□X□□		eed reference					Afte				
		n.X□□□		arameter (Do no	nt change	)							
			neserveu pa	arameter (D0 ffC	r change.	7							
Pn424	2		nit at Main Cir	0 to 100	1%*1	50	All	Immedi-	Setup	page 6-15			
(2424 hex)		cuit Voltag	e Drob		. , 0			ately Continue	<u> </u>				

Continued from previous page.

Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
Pn425 (2425 hex)	2	Release Ti Limit at Ma Voltage Dr		0 to 1,000	1 ms	100	All	Immedi- ately	Setup	page 6-15		
Pn426 (2426 hex)	2	Torque Fee Average M Time		0 to 5,100	0.1 ms	0	All	Immedi- ately	Setup	page 8-86		
Pn427 (2427 hex)	2	Speed Rip sation Ena	ple Compen- ble Speed	0 to 10,000	1 min <sup>-1</sup>	0	Rotary	Immedi- ately	Tuning	page 8-59		
Pn456 (2456 hex)	2		Sweep Torque Reference Amplitude		1%	15	All	Immedi- ately	Tuning	page 8-92		
	2	Notch Filte Selections	er Adjustment 1	0000 hex to 0101 hex	-	0101 hex	All	Immedi- ately	Tuning	page 8-12, page 8-23, page 8-41		
	_		_									
				Adjustment Sel		and all Cities		. al. with a second				
	r	n.000X	0 tun	not adjust the fing without a hoing.								
Pn460 (2460 hex)				ust the first stanout a host refe								
(2460 flex)	r	n.□□X□	Reserved pa	rameter (Do no	t change.	)						
			Notch Filter	Adjustment Sel	lection 2							
	r	n.□X□□	0 aut	not adjust the sotuning without stom tuning.								
			Adj 1 ing	Adjust the second stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.								
	r	n.X□□□ Reserved parameter (Do not change.)										
Pn480 (2480 hex)	2	Speed Lim Force Con		0 to 10,000	1 mm/s	10000	Linear	Immedi- ately	Setup	page 6-12		
Pn481 (2481 hex)	2	Polarity De Speed Loc	etection op Gain	10 to 20,000	0.1 Hz	400	Linear	Immedi- ately	Tuning	_		
Pn482 (2482 hex)	2	Polarity De Speed Loo Time Cons	op Integral	15 to 51,200	0.01 ms	3000	Linear	Immedi- ately	Tuning	-		
Pn483 (2483 hex)	2	Forward Fo	orce Limit	0 to 800	1%*1	30	Linear	Immedi- ately	Setup	page 6-26		
Pn484 (2484 hex)	2	Reverse Fo	orce Limit	0 to 800	1%*1	30	Linear	Immedi- ately	Setup	page 6-26		
Pn485 (2485 hex)	2	ence Spee		0 to 100	1 mm/s	20	Linear	Immedi- ately	Tuning	-		
Pn486 (2486 hex)	2	Polarity De ence Acce Deceleration		0 to 100	1 ms	25	Linear	Immedi- ately	Tuning	_		
Pn487 (2487 hex)	2	Polarity De stant Spee	etection Con- ed Time	0 to 300	1 ms	0	Linear	Immedi- ately	Tuning	_		
Pn488 (2488 hex)	2	Polarity De ence Waiti	etection Refer- ng Time	50 to 500	1 ms	100	Linear	Immedi- ately	Tuning	-		
Pn48E (248E hex)	2	Polarity De Range	etection	1 to 65,535	1 mm	10	Linear	Immedi- ately	Tuning	-		
Pn490 (2490 hex)	2	Level	etection Load	0 to 20,000	1%	100	Linear	Immedi- ately	Tuning	-		
Pn495 (2495 hex)	2		etection Con- Force Refer-	0 to 200	1%	100	Linear	Immedi- ately	Tuning	_		

Continued from previous page.

Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn498 (2498 hex)	2	Polarity Detection Allowable Error Range	0 to 30	1 deg	10	Linear	Immedi- ately	Tuning	_
Pn49F (249F hex)	2	Speed Ripple Compensation Enable Speed	0 to 10,000	1 mm/s	0	Linear	Immedi- ately	Tuning	page 8-59
Pn502 (2502 hex)	2	Rotation Detection Level	1 to 10,000	1 min <sup>-1</sup>	20	Rotary	Immedi- ately	Setup	page 6-8
Pn503 (2503 hex)	2	Speed Coincidence Detection Signal Output Width	0 to 100	1 min <sup>-1</sup>	10	Rotary	Immedi- ately	Setup	page 6-9
Pn506 (2506 hex)	2	Brake Reference-Servo OFF Delay Time	0 to 50	10 ms	0*5	All	Immedi- ately	Setup	page 5-32
Pn507 (2507 hex)	2	Brake Reference Output Speed Level	0 to 10,000	1 min <sup>-1</sup>	100	Rotary	Immedi- ately	Setup	page 5-32
Pn508 (2508 hex)	2	Servo OFF-Brake Com- mand Waiting Time	10 to 100	10 ms	50	All	Immedi- ately	Setup	page 5-32
Pn509 (2509 hex)	2	Momentary Power Inter- ruption Hold Time	20 to 50,000	1 ms	20	All	Immedi- ately	Setup	page 6-14
	2	Input Signal Selections	0000 hex to FFF2 hex	-	1881 hex	All	After restart	Setup	_

	n.□□□X	Rese	rved parameter (Do not change.)	
	n.□□X□	Rese	rved parameter (Do not change.)	
	n.□X□□	Rese	rved parameter (Do not change.)	
		P-OT	(Forward Drive Prohibit) Signal Allocation	Reference
		0	Enable forward drive when CN1-13 input signal is ON (closed).	
		1	Enable forward drive when CN1-7 input signal is ON (closed).	
		2	Enable forward drive when CN1-8 input signal is ON (closed).	
Pn50A		3	Enable forward drive when CN1-9 input signal is ON (closed).	
(250A hex)		4	Enable forward drive when CN1-10 input signal is ON (closed).	
		5	Enable forward drive when CN1-11 input signal is ON (closed).	
		6	Enable forward drive when CN1-12 input signal is ON (closed).	
	n.X□□□	7	Set the signal to always prohibit forward drive.	2000 5 26
		8	Set the signal to always enable forward drive.	— page 5-26
		9	Enable forward drive when CN1-13 input signal is OFF (open).	
		Α	Enable forward drive when CN1-7 input signal is OFF (open).	
		В	Enable forward drive when CN1-8 input signal is OFF (open).	
		С	Enable forward drive when CN1-9 input signal is OFF (open).	
		D	Enable forward drive when CN1-10 input signal is OFF (open).	
		Е	Enable forward drive when CN1-11 input signal is OFF (open).	
		F	Enable forward drive when CN1-12 input signal is OFF (open).	

	tinued from	COIT			1							
Classi- Reference end	When Enabled	Applicable Motors	Default Setting	Setting Unit	Setting Range	Name	N	Size				
Setup -	After restart	All	8882 hex	-	0000 hex to FFFF hex	nal Selections	Input Sign 2	2				
			I	<u>I</u>								
Deference			Allogation	it\ Cianal	a Driva Brabil	N OT /Daylor		-				
Reference	N (closed)			, 0	se Drive Prohib ble reverse dri	` ,						
					ıble reverse dri							
	,		•		ble reverse dri	-						
	(closed).	it signal is ON	N1-9 inpu	ve when C	ble reverse dri	3 Ena						
	N (closed).	ut signal is Ol	N1-10 inp	ve when C	ıble reverse dri	4 Ena						
	N (closed).	ut signal is Ol	5 Ena									
	N (closed).	ut signal is Ol	N1-12 inp	ve when C	ıble reverse dri	6 Ena						
page 5-26		e drive.	7 Set	n.□□□X								
page 0 20		e drive.	ble reverse	lways ena	the signal to a	8 Set						
	FF (open).	out signal is Ol	N1-13 inp	ve when C	ble reverse dri	9 Ena						
					ble reverse dri							
	,	ŭ			ble reverse dri							
					ble reverse dri	-						
		out signal is Ol										
		out signal is Ol										
	F Enable reverse drive when CN1-12 input signal is OFF (open).											
					ible reverse un	F EIR						
			)		rameter (Do no	1 - 1 - 1	1.00X0	1				
Reference	n		t Input) Sig	ot change.	rameter (Do no	Reserved par	n.□□X□	1				
Reference	n	V (closed).	t Input) Signal is ON	rque Limi	rameter (Do no ord External To ove when CN1-	Reserved par /P-CL (Forward 0 Act	1.00X0					
Reference	n	V (closed).	t Input) Sig signal is ON gnal is ON	rque Limi 13 input s 7 input sig	rameter (Do no ard External To ive when CN1- ive when CN1-	Reserved par  /P-CL (Forward O Act 1 Act	n.□□X□	1				
Reference	n	(closed).	t Input) Signal is ON gnal is ON	rque Limi 13 input s 7 input sig 8 input sig	rameter (Do no ird External To ive when CN1- ive when CN1- ive when CN1-	Reserved par  /P-CL (Forward O Act 1 Act 2 Act	1.00X0	1				
Reference	n	V (closed). (closed). (closed). (closed).	t Input) Signal is ON gnal is ON gnal is ON gnal is ON	rque Limi 13 input s 7 input siç 8 input siç 9 input siç	rameter (Do no ord External To ive when CN1- ive when CN1- ive when CN1- ive when CN1-	Reserved par  /P-CL (Forward O Act 1 Act 2 Act 3 Act	n.00X0					
Reference	n	V (closed). (closed). (closed). (closed). V (closed).	t Input) Siç ignal is ON gnal is ON gnal is ON gnal is ON	rque Limi 13 input s 7 input siç 8 input siç 9 input siç 10 input s	rameter (Do no ord External To ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1-	Reserved par  /P-CL (Forward O Act     1 Act     2 Act     3 Act     4 Act	n.□□X□	1				
Reference	n	V (closed). (closed). (closed). (closed). V (closed). V (closed).	t Input) Signal is ON gnal is ON signal is ON	rque Limi 13 input si 7 input si 8 input si 9 input si 10 input s 11 input s	rameter (Do no ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1-	Reserved pare	1.00X0	1				
Reference	n	V (closed). (closed). (closed). (closed). V (closed). V (closed).	t Input) Signal is ON gnal is ON signal is ON	rque Limi 13 input si 7 input si 8 input si 9 input si 10 input s 11 input s	rameter (Do no ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1-	Reserved pare						
Reference  page 6-27	n	V (closed). (closed). (closed). (closed). V (closed). V (closed).	t Input) Signal is ON gnal is ON gnal is ON gnal is ON gnal is ON signal is ON	rque Limi 13 input siç 8 input siç 9 input siç 10 input s 11 input s 12 input s ys active.	rameter (Do no rrd External To ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1-	Reserved par	n.00X0					
	n	V (closed). (closed). (closed). (closed). V (closed). V (closed). V (closed). V (closed). V (closed).	t Input) Signal is ON gnal is ON	rque Limir 13 input sig 8 input sig 9 input sig 10 input sig 11 input sig 12 input sig 12 input sig 12 input sig 13 input sig	rameter (Do no ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1-	Reserved par						
	n	V (closed). (closed). (closed). (closed). V (closed). V (closed). V (closed). V (closed).	t Input) Signal is ON gnal is ON gnal is ON gnal is ON gnal is ON gignal is ON	rque Limir 13 input sig 8 input sig 9 input sig 10 input sig 11 input sig 12 input sig 12 input sig 12 input sig 13 input signification	rameter (Do no ive when CN1- ive when CN1-	Reserved pare						
	n	V (closed). (closed). (closed). (closed). V (closed). V (closed). V (closed). V (closed). V (closed). V (closed).	t Input) Signal is ON gnal is OF	rque Limi 13 input si 7 input si 8 input si 9 input si 10 input s 11 input s 12 input s ys active. ys inactive 13 input s 7 input si	rameter (Do no rive when CN1- rive when CN1-	Reserved pare  /P-CL (Forward   0						
	n	N (closed). (closed). (closed). (closed). N (closed). N (closed). N (closed). N (closed). N (closed). N (closed).	t Input) Signal is ON gnal is OF gnal is OFF	rque Limi 13 input sig 8 input sig 9 input sig 10 input s 11 input s 12 input s ys active. ys inactive 13 input s 7 input sig	rameter (Do no ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- ive when CN1- signal is alway is signal is alway ive when CN1- ive when CN1-	Reserved pare						
	n	N (closed). (closed). (closed). (closed). N (closed). N (closed). N (closed). N (closed). N (closed). N (closed). FF (open). F (open). F (open). F (open).	t Input) Signal is ON gnal is ON gnal is ON gnal is ON gnal is ON gignal is ON gnal is OFF	rque Limi 13 input si 7 input si 8 input si 9 input si 10 input s 11 input s 12 input s 13 input s 14 input s 15 input s 16 input s 17 input s 18 input si 19 input si	rameter (Do no ive when CN1- ive when CN1-	Reserved pare						
	n	V (closed). (closed). (closed). (closed). V (closed).	t Input) Signal is ON gnal is ON gnal is ON gnal is ON gnal is ON gignal is ON gignal is ON gignal is ON gignal is OF gnal is OFF	rque Limir 13 input sig 8 input sig 9 input sig 10 input sig 11 input sig 12 input sig 13 input sig 14 input sig 15 input sig 16 input sig 17 input sig 18 input sig 19 input sig 10 input sig 10 input sig	rameter (Do no red External To ve when CN1-ve when CN1	Reserved par  /P-CL (Forward O Act						
	n	V (closed). (closed). (closed). (closed). V (closed).	t Input) Signal is ON gnal is OF gnal is OFF gnal is	rque Limit 13 input sig 8 input sig 10 input sig 11 input sig 12 input sig 12 input sig 13 input sig 15 input sig 16 input sig 16 input sig 10 input sig 10 input sig 11 input	rameter (Do no red External To red External To red when CN1-red when C	Reserved pare  /P-CL (Forward   0						
		V (closed). (closed). (closed). (closed). V (closed).	t Input) Signal is ON gnal is ON gnal is ON gnal is ON gnal is ON gignal is ON gignal is ON gignal is ON gignal is OF gnal is OFF gnal is	rque Limir 13 input sig 8 input sig 9 input sig 10 input sig 11 input sig 12 input sig 13 input sig 14 input sig 15 input sig 16 input sig 17 input sig 18 input sig 19 input sig 10 input sig 11 input sig	rameter (Do no red External To ve when CN1-ve when CN1	Reserved par						

Continued from previous page.

| Setting | Setting | Default | Applicable | When | Classi- | Refer-

Davasastas	4			0-44:	0 - 44 :	Defects		tinued from	<u>'</u>			
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	Output Sig	ınal Selec-	0000 hex to 6666 hex	-	0000 hex	All	After restart	Setup	-		
		•			•					•		
			/COIN (Pos	sitioning Comple	tion Outp	ut) Signal	Allocation		Refere	ence		
			· ·	isabled (the abo	•	, ,						
			1 (	Output the signal	from the C	N1-1 or C	N1-2 output t	erminal.				
		n.□□□X	2 (	Output the signal	from the C	N1-23 or	CN1-24 outpu	ut terminal.				
			3 (	Output the signal	from the C	N1-25 or	CN1-26 outpu	ut terminal.	page 6	6-10		
			4 (	Output the signal	from the C	N1-27 or	CN1-28 outpu	ut terminal.				
			5 (	Output the signal	from the C	N1-29 or	CN1-30 outpu	ut terminal.				
Pn50E (250E hex)			6 F	Reserved setting	(Do not us	e.)						
(230L Hex)			/V-CMP (S	peed Coinciden	oincidence Detection Output) Signal Allocation					ence		
		n.□□X□	The allocations are the same as the /COIN (Positioning Completion) signal allocations.									
			/TGON (Ro	tation Detection	Output) S	Signal Allo	cation		Refere	ence		
		n.□X□□	The allocations are the same as the /COIN (Positioning Comple-									
				ervo Ready) Sigr		ion			page 6-8  Reference			
		n.X□□□	O to 6	The allocations are the same as the /COIN (Positioning Comple-								
			-							<del></del>		
	2	Output Sig	ınal Selec-	0000 hex to 6666 hex	_	0100 hex	All	After restart	Setup	-		
		- I			1	I.	l					
	i		/CLT (Torqu	ue Limit Detection	on Output)	Signal All	ocation		Refere	nce		
			· · · · ·	isabled (the abo	. ,				Ticicic	1100		
				Output the signal				erminal.				
			2 (	Output the signal	from the C	N1-23 or	 CN1-24 outpu	ut terminal.				
		n.□□□X	3 (	Output the signal	from the C	N1-25 or	CN1-26 outpu	ut terminal.	page 6	6-30		
			4 (	Output the signal	from the C	N1-27 or	CN1-28 outpu	ut terminal.				
				Output the signal			CN1-30 outpu	ut terminal.				
Pn50F (250F hex)			6 F	Reserved setting	(Do not us	e.)						
(2001 116X)			/VLT (Spee	d Limit Detectio	n) Signal /	Allocation			Refere	ence		
		n.□□X□		he allocations ar Output) signal allo		e as the /C	LT (Torque Lir	mit Detection	page 6	6-12		
			/BK (Brake	Output) Signal	Allocation				Refere	ence		
		n.□X□□		The allocations ar Output) signal allo		e as the /C	LT (Torque Lir	mit Detection	page 5	5-32		
			/WARN (W	arning Output) S	Signal Allo	cation			Refere	ence		
		n.X□□□		The allocations are the same as the /CLT (Torque Limit Detection Output) signal allocations.					page	6-7		
									'			

Continued from previous page.

Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	Output Sig	gnal Selec-	0000 hex to 0666 hex	_	0000 hex	All	After restart	Setup	_			
		•		•	•				•				
	Ī		/NEAR (Nea	r Output) Signa	I Allocatio	n			Refere	ence			
			0 Di	sabled (the abov	ve signal o	utput is no	ot used).						
			1 Ou	tput the signal	from the C	N1-1 or C	N1-2 output t	erminal.					
		n.□□□X		tput the signal									
Pn510				tput the signal			· · · · · · · · · · · · · · · · · · ·		page 6	6-11			
(2510 hex)				itput the signal			•						
				itput the signal			CN1-30 outpu	ut terminal.					
	6 Reserved setting (Do not use.)												
		n.□□X□	Reserved pa	arameter (Do no	t change.	)							
		n.□X□□ Reserved parameter (Do not change.)											
		n.X□□□	Reserved pa	arameter (Do no	t change.	)							
	2	Input Sign	al Selections	0000 hex to FFFF hex	_	6543 hex	All	After restart	Setup	page 6-4			
					_		-		_				
	Ī	n.□□□X	Reserved pa	arameter (Do no	ot change.	)							
			/Prohe1 (Pro	bbe 1 Latch Inp	ut) Signal	Allocation							
			i i	tive when CN1-									
				tive when CN1-			, ,						
				tive when CN1-						<del></del>			
		n.□□X□	7 Th	e signal is alway	ys inactive								
Pn511			8 Th	e signal is alwa	ys inactive								
(2511 hex)			D Ac	tive when CN1-	10 input s	ignal is OF	F (open).						
				tive when CN1-	11 input s	ignal is OF	F (open).						
			F Ac	tive when CN1-	12 input s	ignal is OF	F (open).						
		=\/==	`	be 2 Latch Inp	, ,								
		n.□X□□		e allocations are tions.	e the same	e as the /P	robe1 (Probe	1 Latch Inpu	ıt) signal a	ıllo-			
	Ī		/Home (Hon	ne Switch Input	) Signal A	llocation							
		n.X000		e allocations are tions.	e the same	e as the /P	robe1 (Probe	1 Latch Inpu	ıt) signal a	illo-			
	_									-			
									_				

Parameter No.	Size	1	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Output Si Settings 1	gnal Inverse	0000 hex to 1111 hex	-	0000 hex	All	After restart	Setup	page 6-5
		n.□□□X	0 The	I Inversion for signal is not in	verted.	d CN1-2 T	Terminals			
Pn512		n.□□X□	Output Signa 0 The	signal is invert  I Inversion for signal is not in signal is invert	CN1-23 a	nd CN1-2	4 Terminals			
(2512 hex)		n.□X□□	Output Signa 0 The	I Inversion for signal is not in signal is invert	CN1-25 a	nd CN1-2	6 Terminals			
		n.X□□□	0 The	I Inversion for signal is not ir signal is invert	verted.	nd CN1-2	8 Terminals			
	2	Output Si Settings 2	gnal Inverse	0000 hex to 0011 hex	-	0000 hex	All	After restart	Setup	page 6-5
Pn513 (2513 hex)	r	n.00X n.00X n.0X n.0X n.X	<u> </u>	gnal is not inve gnal is inverted meter (Do not meter (Do not	change.)	d CN1-30	Terminals		Refere	
	2	Output Si tions 4	gnal Selec-	0000 hex to 0666 hex	-	0000 hex	All	After restart	Setup	-
		n.□□□X	Reserved par	ameter (Do no	t change.	)				
		n.□□X□	Reserved par	ameter (Do no	t change.	)				
Pn514 (2514 hex)		n.□X□□	/PM (Preventative Maintenance Output) Signal Allocation  0 Disabled (the above signal output is not used).  1 Output the signal from the CN1-1 or CN1-2 output terminal.  2 Output the signal from the CN1-23 or CN1-24 output terminal.						page S	
	n.X□□□ Reserved parameter (Do not change.)									

Continued from previous page.

Parameter No.	Size	ı	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Input Sigr 7	nal Selections	0000 hex to FFFF hex	-	8888 hex	All	After restart	Setup	_	
		•		•	•						
			FSTP (Forced	d Stop Input) Si	gnal Alloc	ation			Refere	ence	
			0 Er	nable drive wher	n CN1-13	input signa	al is ON (close	ed).			
				nable drive wher			•	<u> </u>			
				nable drive wher			`	,			
				nable drive wher		·	•	<u>,                                      </u>			
				nable drive wher			•				
				nable drive wher							
			0,	et the signal to a	)						
	n.	.000X		op).	page	6-55					
Pn516 (2516 hex)				Set the signal to always enable drive (always disable forcing the motor to stop).						0 00	
				nable drive wher			` '	<u> </u>			
				nable drive wher				'			
				nable drive wher		·					
				nable drive wher		·					
				nable drive wher		·					
				nable drive wher		· ·					
	n	.00X0		rameter (Do not							
				`	, o						
	n.	.DXDD	Reserved par	rameter (Do not change.)							
	n.	.X000	Reserved par	ameter (Do not	change.)						
Pn51B (251B hex)	4	Motor-Los Deviation Detection		0 to 1,073,741,823	1 refer- ence unit	1000	Rotary	Immedi- ately	Setup	page 10-8	
Pn51E	2	Position [	Deviation Over- ning Level	10 to 100	1%	100	All	Immedi- ately	Setup	page 15-45	
(251E hex) Pn520			Deviation Over-	1 to	1 refer-			Immedi-		page 8-8,	
(2520 hex)	4	flow Alarr		1,073,741,823	ence unit	5242880	All	ately	Setup	page 15-5	
DnF00		D111 1		0.11	1 refer-			les			
Pn522 (2522 hex)	4	Width	ng Completed	0 to 1,073,741,824	ence unit	7	All	Immedi- ately	Setup	6-10	
Pn524 (2524 hex)	4	Near Sigr	nal Width	1 to 1,073,741,824	1 refer- ence unit	1073741824	All	Immedi- ately	Setup	page 6-11	
Pn526 (2526 hex)	4		Deviation Over- n Level at I	1 to 1,073,741,823	1 refer- ence unit	5242880	All	Immedi- ately	Setup	page 8-8	
Pn528 (2528 hex)	2		Deviation Over- ning Level at I	10 to 100	1%	100	All	Immedi- ately	Setup	page 8-8	
Pn529 (2529 hex)	2	Speed Lir Servo ON	mit Level at I	0 to 10,000	1 min <sup>-1</sup>	10000	Rotary	Immedi- ately	Setup	page 8-8	
Pn52A (252A hex)	2	Multiplier closed Ro	per Fully- otation	0 to 100	1%	20	Rotary	Immedi- ately	Tuning	page 10-8	
Pn52B (252B hex)	2	Overload	Warning Level	1 to 100	1%	20	All	Immedi- ately	Setup	page 5-40	
Pn52C (252C hex)	2	Base Cur at Motor Detection		10 to 100	1%	100	All	After restart	Setup	page 5-40	

fication

Classi- Refer-

Continued	from	previous	page.

When

Enabled

	2	Program J Related Se		0000 hex to 0005 hex	_	0000 hex	All	Immedi- ately	Setup	page 7-13			
			Program Jo	gging Operation	n Pattern								
				Vaiting time in Proposition Value va		orward by t	ravel distance	e in Pn531) ×	Number	of			
			1 (\	Vaiting time in Pr	n535 → Re 536	everse by t	ravel distance	e in Pn531) ×	Number	of			
			2   n	Vaiting time in Proposition of the Value of	536 1535 → Re	,		,					
Pn530 (2530 hex)		n.□□□X	3   'n	(Waiting time in Pn535 → Reverse by travel distance in Pn531) × Number of movements in Pn536 → Forward by travel distance in Pn531) × Number of movements in Pn536 → Forward by travel distance in Pn531 → Waiting time									
			4 ir	Vaiting time in Pr Pn535 → Rever n536									
			5 ir	Vaiting time in Pr Pn535 → Forwa n536	n535 → Re ard by trav	everse by t el distance	ravel distance e in Pn531) ×	e in Pn531 → Number of m	Waiting to	ime s in			
	١,	n.□□X□	Reserved r	arameter (Do no	ot change.	)							
	-			`		,							
		n.□X□□	Reserved p	arameter (Do no	ot change.	)							
		n.X□□□	Reserved p	arameter (Do no	t change.	)							
Pn531 (2531 hex)	4	Program J Distance	ogging Trave	1 to 1,073,741,824	1 refer- ence unit	32768	All	Immedi- ately	Setup	page 7-13			
Dn522		D			Doton			1					

Setting

Range

Setting

Unit

Default

Setting

Applicable

Motors

Parameter

No.

Size

Name

Pn531 (2531 hex)	4	Program Jogging Travel Distance	1 to 1,073,741,824	1 refer- ence unit	32768	All	Immedi- ately	Setup	page 7-13
Pn533 (2533 hex)	2	Program Jogging Move- ment Speed	1 to 10,000	Rotary: 1 min <sup>-1</sup>	500	Rotary	Immedi- ately	Setup	page 7-13
Pn534 (2534 hex)	2	Program Jogging Acceleration/Deceleration Time	2 to 10,000	1 ms	100	All	Immedi- ately	Setup	page 7-13
Pn535 (2535 hex)	2	Program Jogging Wait- ing Time	0 to 10,000	1 ms	100	All	Immedi- ately	Setup	page 7-13
Pn536 (2536 hex)	2	Program Jogging Number of Movements	0 to 1,000	Times	1	All	Immedi- ately	Setup	page 7-13
Pn550 (2550 hex)	2	Analog Monitor 1 Offset Voltage	-10,000 to 10,000	0.1 V	0	All	Immedi- ately	Setup	page 9-6
Pn551 (2551 hex)	2	Analog Monitor 2 Offset Voltage	-10,000 to 10,000	0.1 V	0	All	Immedi- ately	Setup	page 9-6
Pn552 (2552 hex)	2	Analog Monitor 1 Mag- nification	-10,000 to 10,000	× 0.01	100	All	Immedi- ately	Setup	page 9-6
Pn553 (2553 hex)	2	Analog Monitor 2 Mag- nification	-10,000 to 10,000	× 0.01	100	All	Immedi- ately	Setup	page 9-6
Pn55A (255A hex)	2	Power Consumption Monitor Unit Time	1 to 1,440	1 min	1	All	Immedi- ately	Setup	_
Pn560 (2560 hex)	2	Residual Vibration Detection Width	1 to 3,000	0.1%	400	All	Immedi- ately	Setup	page 8-55
Pn561 (2561 hex)	2	Overshoot Detection Level	0 to 100	1%	100	All	Immedi- ately	Setup	page 8-23, page 8-34
Pn581 (2581 hex)	2	Zero Speed Level	1 to 10,000	1 mm/s	20	Linear	Immedi- ately	Setup	page 6-8
Pn582 (2582 hex)	2	Speed Coincidence Detection Signal Output Width	0 to 100	1 mm/s	10	Linear	Immedi- ately	Setup	page 6-9

		Continued from p										
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
Pn583 (2583 hex)	2	Brake Refe put Speed	erence Out- I Level	0 to 10,000	1 mm/s	10	Linear	Immedi- ately	Setup	page 5-32		
Pn584 (2584 hex)	2	Speed Lim Servo ON	nit Level at	0 to 10,000	1 mm/s	10000	Linear	Immedi- ately	Setup	page 8-10		
Pn585 (2585 hex)	2	Program J ment Spec	logging Move- ed	1 to 10,000	1 mm/s	50	Linear	Immedi- ately	Setup	page 7-13		
Pn586 (2586 hex)	2	Motor Rur Ratio	nning Cooling	0 to 100	1%/ Max. speed	0	Linear	Immedi- ately	Setup	-		
	2		etection Selection for inear Encoder	0000 hex to 0001 hex	-	0000 hex	Linear	Immedi- ately	Setup	-		
Pn587 (2587 hex)	r	n.000X n.00X0 n.0X00	0 Do 1 Det Reserved par	ction Selection not detect pola ect polarity. rameter (Do no rameter (Do no rameter (Do no	arity. et change.) et change.)	)	r Encoder		Refere			
				1	1	T	T		•	1		
Pn600 (2600 hex)	2	Regenerat Capacity*2	ive Resistor	Resistor Depends on model.*3 10 W 0 All Immediately								
Pn601 (2601 hex)	2		Brake Resis- ble Energy :ion	0 to 65,535	10 J	0	All	After restart	Setup	page 5-56		
Pn603 (2603 hex)	2	Regenerat tance	ive Resis-	0 to 65,535	10 mΩ	0	All	Immedi- ately	Setup	page 5-55		
Pn604 (2604 hex)	2	Dynamic E tance	Brake Resis-	0 to 65,535	10 mΩ	0	All	After restart	Setup	page 5-56		
	2	ZONE Out Selection	put Signal 1	0000 hex to 5555 hex	_	0000 hex	All	After restart	Setup	-		
PnBA0 (2752 hex)	1	n.000X	0 Dis 1 Ou 2 Ou 3 Ou 4 Ou 5 Ou  /ZONE1 (ZOI 0 to 5 The put  /ZONE2 (ZOI 0 to 5 The put  /ZONE3 (ZOI	NE Signal 1 Ou abled (the above tput the signal of tput the signal of e allocations are of signal allocations are of signal allocations.	ve signal of from the Confrom	utput is not only in the control of	ot used). N1-2 output to CN1-24 output to CN1-26 output CN1-28 output CN1-30 output con CNEO (ZONE) ONEO (ZONE) ONEO (ZONE)	ut terminal. ut terminal. ut terminal. ut terminal. Signal 1 Out	Refere	3-60 ence 3-60		
	1	n.X000		e allocations are ) signal allocati		e as the /Z	ONE0 (ZONE	Signal 1 Out	page 6	6-60		
									'			

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	ZONE Out Selection 2		0000 hex to 0005 hex	-	0000 hex	All	After restart	Setup	_
PnBA1 (2753 hex)	1	n.□□□X	0 Di 1 Ou 2 Ou 3 Ou 4 Ou	ONE Signal Outsabled (the above the signal struct the signal structure.	ve signal of from the Cofrom the Cofford the	utput is no N1-1 or C N1-23 or ( N1-25 or ( N1-27 or (	ot used). N1-2 output t CN1-24 outpu CN1-26 outpu CN1-28 outpu	ut terminal. ut terminal. ut terminal.	Refere	
	r	n.00X0 n.0X00	Reserved pa	arameter (Do no arameter (Do no arameter (Do no	t change.	)				

- \*1. Set a percentage of the motor rated torque.
- \*2. Normally set this parameter to 0. If you use an External Regenerative Resistor, set the capacity (W) of the External Regenerative Resistor.
- st3. The upper limit is the maximum output capacity (W) of the SERVOPACK.
- \*4. With EtherCAT (CoE), this is automatically set when the power supply is turned ON.
- \*5. The default setting is 32 for a SERVOPACK with built-in Servomotor brake control.

## 16.2 Object List

Index	Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parame- ter No.*2
1000 hex	0	Device type	UDINT	RO	No	No	0x00020192	-	-	-	-
1001 hex	0	Error register	USINT	RO	No	No	-	-	-	-	-
1008 hex	0	Manufacturer device name	STRING	RO	No	No	_	_	_	_	-
100A hex	0	Manufacturer soft- ware version	STRING	RO	No	No	_	_	_		-
	Store par	ameters field						1			
	0	Largest subindex supported	USINT	RO	No	No	4	-	-	-	-
	1	Save all parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	-	PnC00*3
1010 hex	2	Save communication parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	_	PnC02*3
	3	Save application parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	_	PnC04*3
	4	Save manufacturer defined parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	_	PnC06*3
	Restore d	efault parameters									
	0	Largest subindex supported	USINT	RO	No	No	4	_	_	-	-
	1	Restore all default parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	_	PnC08*3
1011 hex	2	Restore communication default parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	_	PnC0A*3
	3	Restore application default parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	_	PnC0C*3
	4	Restore manufac- turer defined default parameters	UDINT	RW	No	No	0x00000001	0x00000000	0xFFFFFFF	-	PnC0E*3
	Identity of	bject					l				
	0	Number of entries	USINT	RO	No	No	4	-	-	-	_
1010 hav	1	Vendor ID	UDINT	RO	No	No	0x539	-	-	-	_
1018 hex	2	Product code	UDINT	RO	No	No	0x02200401*4	-	-	-	_
	3	Revision number	UDINT	RO	No	No	-	-	-	-	-
	4	Serial number	UDINT	RO	No	No	0	-	-	-	_
	Sync erro	r settings					i				
10F1 hex	0	Number of entries	USINT	RO	No	No	2	-	-	-	-
*5	1	Reserved	UDINT	RO	No	No	0	-	-	-	-
	2	Sync error counter limit	UDINT	RW	No	No	9	0	15	_	PnCCC
	1st receiv	e PDO mapping	ı					I	T	I	
	0	Number of objects in this PDO	USINT	RW	No	Yes	8	0	8	-	PnCA0
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60400010	0	0xFFFFFFF	-	PnC20
	2	Mapping entry 2	UDINT	RW	No	Yes	0x607A0020	0	0xFFFFFFF	-	PnC22
1600 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0x60FF0020	0	0xFFFFFFF	-	PnC24
	4	Mapping entry 4	UDINT	RW	No	Yes	0x60710010	0	0xFFFFFFF	-	PnC26
	5	Mapping entry 5	UDINT	RW	No	Yes	0x60720010	0	0xFFFFFFF	-	PnC28
	6	Mapping entry 6	UDINT	RW	No	Yes	0x60600008	0	0xFFFFFFF	-	PnC2A
	7	Mapping entry 7	UDINT	RW	No	Yes	0x00000008	0	0xFFFFFFF	-	PnC2C
	8	Mapping entry 8	UDINT	RW	No	Yes	0x60B80010	0	0xFFFFFFFF Continued		PnC2E

ď

Index	Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parame- ter No.*2
	2nd recei	ve PDO mapping									
	0	Number of objects in this PDO	USINT	RW	No	Yes	2	0	8	-	PnCA1
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60400010	0	0xFFFFFFF	-	PnC30
	2	Mapping entry 2	UDINT	RW	No	Yes	0x607A0020	0	0xFFFFFFF	-	PnC32
1601 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC34
	4	Mapping entry 4	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC36
	5	Mapping entry 5	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC38
	6	Mapping entry 6	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC3A
	7	Mapping entry 7	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC3C
	8	Mapping entry 8	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC3E
	3rd receiv	ve PDO mapping	•			•	•	•	•	•	•
	0	Number of objects in this PDO	USINT	RW	No	Yes	2	0	8	_	PnCA2
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60400010	0	0xFFFFFFF	-	PnC40
	2	Mapping entry 2	UDINT	RW	No	Yes	0x60FF0020	0	0xFFFFFFF	-	PnC42
1602 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC44
	4	Mapping entry 4	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC46
	5	Mapping entry 5	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC48
	6	Mapping entry 6	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC4A
	7	Mapping entry 7	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC4C
	8	Mapping entry 8	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC4E
	4th receiv	ve PDO mapping									
	0	Number of objects in this PDO	USINT	RW	No	Yes	2	0	8	-	PnCA3
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60400010	0	0xFFFFFFF	-	PnC50
	2	Mapping entry 2	UDINT	RW	No	Yes	0x60710010	0	0xFFFFFFF	-	PnC52
1603 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC54
	4	Mapping entry 4	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC56
	5	Mapping entry 5	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC58
	6	Mapping entry 6	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC5A
	7	Mapping entry 7	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC5C
	8	Mapping entry 8	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC5E
	1st transr	mit PDO mapping									
	0	Number of objects in this PDO	USINT	RW	No	Yes	8	0	8		PnCA4
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60410010	0	0xFFFFFFF	-	PnC60
	2	Mapping entry 2	UDINT	RW	No	Yes	0x60640020	0	0xFFFFFFF	-	PnC62
1A00 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0x60770010	0	0xFFFFFFF	-	PnC64
	4	Mapping entry 4	UDINT	RW	No	Yes	0x60F40020	0	0xFFFFFFF	-	PnC66
	5	Mapping entry 5	UDINT	RW	No	Yes	0x60610008	0	0xFFFFFFF	-	PnC68
	6	Mapping entry 6	UDINT	RW	No	Yes	0x00000008	0	0xFFFFFFF	_	PnC6A
	7	Mapping entry 7	UDINT	RW	No	Yes	0x60B90010	0	0xFFFFFFF	-	PnC6C
	8	Mapping entry 8	UDINT	RW	No	Yes	0x60BA0020	0	0xFFFFFFF	-	PnC6E

								Cor	tinued from	previo	ous page.
Index	Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parame- ter No.*2
	2nd trans	mit PDO mapping									
	0	Number of objects in this PDO	USINT	RW	No	Yes	2	0	8	-	PnCA5
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60410010	0	0xFFFFFFF	-	PnC70
	2	Mapping entry 2	UDINT	RW	No	Yes	0x60640020	0	0xFFFFFFF	-	PnC72
1A01 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC74
	4	Mapping entry 4	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC76
	5	Mapping entry 5	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC78
	6	Mapping entry 6	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC7A
	7	Mapping entry 7	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC7C
	8 3rd transr	Mapping entry 8 mit PDO mapping	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC7E
	0	Number of objects in this PDO	USINT	RW	No	Yes	2	0	8	_	PnCA6
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60410010	0	0xFFFFFFF	_	PnC80
	2	Mapping entry 2	UDINT	RW	No	Yes	0x60640020	0	0xFFFFFFF	_	PnC82
1A02 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0	0	0xFFFFFFF	_	PnC84
TAOL TICK	4	Mapping entry 4	UDINT	RW	No	Yes	0	0	0xFFFFFFF	_	PnC86
	5	Mapping entry 5	UDINT	RW	No	Yes	0	0	0xFFFFFFF	_	PnC88
	6	Mapping entry 6	UDINT	RW	No	Yes	0	0	0xFFFFFFF	_	PnC8A
	7	Mapping entry 7	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC8C
	8	Mapping entry 8	UDINT	RW	No	Yes	0	0	0xFFFFFFF	_	PnC8E
	4th transr	mit PDO mapping				1					
	0	Number of objects in this PDO	USINT	RW	No	Yes	3	0	8	-	PnCA7
	1	Mapping entry 1	UDINT	RW	No	Yes	0x60410010	0	0xFFFFFFF	-	PnC90
	2	Mapping entry 2	UDINT	RW	No	Yes	0x60640020	0	0xFFFFFFF	-	PnC92
1A03 hex	3	Mapping entry 3	UDINT	RW	No	Yes	0x60770010	0	0xFFFFFFF	_	PnC94
	4	Mapping entry 4	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC96
	5	Mapping entry 5	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC98
	6	Mapping entry 6	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC9A
	7	Mapping entry 7	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC9C
	8	Mapping entry 8	UDINT	RW	No	Yes	0	0	0xFFFFFFF	-	PnC9E
	Sync Mar	nager communication ty	pe								
	0	Number of used Sync Manager chan- nels	USINT	RO	No	No	4	-	_	-	_
1C00 hex	1	Communication type sync manager 0	USINT	RO	No	No	1	-	-	_	PnCB0
1000 flex	2	Communication type sync manager 1	USINT	RO	No	No	2	ı	_	_	PnCB1
	3	Communication type sync manager 2	USINT	RO	No	No	3	-	-	_	PnCB2
	4	Communication type sync manager 3	USINT	RO	No	No	4	_	-	_	PnCB3
1C10 hex	0	Sync Manager PDO assignment 0	USINT	RO	No	No	0	-	_	-	-
1C11 hex	0	Sync Manager PDO assignment 1	USINT	RO	No	No	0	-	_		_
	Sync Mar	nager PDO assignment	2			1			T	1	T
10101	0	Number of assigned PDOs	USINT	RW	No	Yes	1	0	2	_	PnCB5
1C12 hex	1	Index of assigned RxPDO 1	UINT	RW	No	Yes	0x1601	0x1600	0x1603	-	PnCB6
	2	Index of assigned RxPDO 2	UINT	RW	No	Yes	0x1600	0x1600	0x1603	_	PnCB7

								Cor	ntinued from	previo	ous page.
Index	Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parameter No.*2
	Sync Mar	nager PDO assignment	3						T	1	
	0	Number of assigned PDOs	USINT	RW	No	Yes	1	0	2	-	PnCBB
1C13 hex	1	Index of assigned TxPDO 1	UINT	RW	No	Yes	0x1A01	0x1A00	0x1A03	-	PnCBC
	2	Index of assigned TxPDO 2	UINT	RW	No	Yes	0x1A00	0x1A00	0x1A03	_	PnCBD
	Sync Mar	nager channel 2 synchro	onization								
	0	Number of synchro- nization parameters	USINT	RO	No	No	12	_	_	-	-
•	1	Synchronization type	UINT	RO	No	No	-	_	-	-	PnCC0
•	2	Cycle time	UDINT	RO	No	No	-	_	_	_	PnCC2
•	3	Shift time	UDINT	RO	No	No	250000	_	_	_	PnCC4
•	4	Synchronization types supported	UINT	RO	No	No	0x0005	-	-	_	-
1C32 hex	5	Minimum cycle time	UDINT	RO	No	No	62500	_	-	-	_
	6	Calc and copy time	UDINT	RO	No	No	62500	_	_	-	_
	7	Reserved	UDINT	RO	No	No	0	_	_	-	_
	8	Reserved	UINT	RO	No	No	0	_	_	_	_
	9	Delay time	UDINT	RO	No	No	0	_	_	_	_
	10	Sync0 cycle time	UDINT	RO	No	No	_	_	_	_	PnCC6
	11	Reserved	UDINT	RO	No	No	0	_	_	_	_
•	12	SM2 event miss count	UDINT	RO	No	No	-	-	-	-	PnCC8
	Sync Mar	nager channel 3 synchr	onization					1	I		
	0	Number of synchro- nization parameters	USINT	RO	No	No	10	_	_	-	_
•	1	Synchronization type	UINT	RO	No	No	-	_	_	_	-
•	2	Cycle time	UDINT	RO	No	No	-	_	_	_	-
	3	Shift time	UDINT	RW	No	Yes	0	0	Sync0 event cycle - 12,500	-	PnCCA
1C33 hex	4	Synchronization types supported	UINT	RO	No	No	0x0025	-	_	-	-
	5	Minimum cycle time	UDINT	RO	No	No	62500	_	-	-	_
	6	Calc and copy time	UDINT	RO	No	No	62500	_	_	-	_
	7	Reserved	UDINT	RO	No	No	0	_	_	-	_
	8	Reserved	UINT	RO	No	No	0	_	_	-	_
	9	Delay time	UDINT	RO	No	No	0	_	_	-	_
	10	Sync0 cycle time	UDINT	RO	No	No	_	_	_	-	_
2000 hex to 26FF hex	0	SERVOPACK parameters (Pn000 (2000 hex) to Pn6FF (26FF hex))	_	-	-	-	-	-	_	-	Pn000 - Pn6FF
2700 hex	0	User parameter Configuration	UDINT	RW	No	No	0	0	0xFFFFFFF	_	PnB00
	Position u	Ŭ.	I.			1		T.	1	1	I.
	0	Number of entries	USINT	RO	No	No	2	_	_	_	_
2701 hex	1	Numerator	UDINT	RW	No	Yes	1	1	1073741823	_	PnB02
	2	Denominator	UDINT	RW	No	Yes	1	1	1073741823	_	PnB04
	Velocity u	ser unit	1	1		1		1	I	I	1
	0	Number of entries	USINT	RO	No	No	2	_	_	_	_
2702 hex	1	Numerator	UDINT	RW	No	Yes	1	1	1073741823	_	PnB06
	2	Denominator	UDINT	RW	No	Yes	1	1	1073741823	_	PnB08

					PDO			COI	ntinued from	previo	ous page.
Index	Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parame- ter No.*2
	Accelerat	ion user unit						1			
07001	0	Number of entries	USINT	RO	No	No	2	_	-	-	_
2703 hex	1	Numerator	UDINT	RW	No	Yes	1	1	1073741823	_	PnB0A
	2	Denominator	UDINT	RW	No	Yes	1	1	1073741823	_	PnB0C
	Torque us	ser unit				'					
0704 h	0	Number of entries	USINT	RO	No	No	2	-	-	-	_
2704 hex	1	Numerator	UDINT	RW	No	Yes	1	1	1073741823	-	PnB94
	2	Denominator	UDINT	RW	No	Yes	10	1	1073741823	-	PnB96
	SERVOPA	ACK adjusting comman	d								
	0	Number of entries	USINT	RO	No	No	3	-	-	-	-
2710 hex	1	Command	STRING	RW	No	No	0	0	0xFF	-	-
	2	Status	USINT	RO	No	No	_	_	_	-	-
	3	Reply	STRING	RO	No	No	-	_	-	-	_
	Interpolat	ion data configuration f	or 1st pro	ofile		1					
	0	Number of entries	USINT	RO	No	No	9	_	_	_	-
	1	Maximum buffer size	UDINT	RO	No	No	254	_	_	_	_
	2	Actual buffer size	UDINT	RW	No	No	254	_	_	_	_
	3	Buffer organization	USINT	RW	No	No	0	0	1	_	PnCEC
	4	Buffer position	UINT	RW	Yes	No	1	1	254	-	PnCED
2730 hex	5	Size of data record	USINT	RO	No	No	1	1	1	_	_
	6	Buffer clear	USINT	RO	No	No	0	0	1	_	-
	7	Position data definition	USINT	RW	Yes	No	1	0	1	_	PnCEE
	8	Position data polarity	USINT	RW	Yes	No	0	0	1	-	PnCEF
	9	Behavior after reaching buffer position	USINT	RW	Yes	No	0	0	1	_	PnCF0
	Interpolat	ion data configuration f	or 2nd pi	ofile							
	0	Number of entries	USINT	RO	No	No	9	_	_	-	-
	1	Maximum buffer size	UDINT	RO	No	No	254	_	_	-	-
	2	Actual buffer size	UDINT	RW	No	No	254	_	_	-	-
	3	Buffer organization	USINT	RW	No	No	0	0	1	-	PnCF1
0704.1	4	Buffer position	UINT	RW	Yes	No	1	1	254	_	PnCF2
2731 hex	5	Size of data record	USINT	RO	No	No	1	1	1	_	_
	6	Buffer clear	USINT	RO	No	No	0	0	1	_	_
	7	Position data definition	USINT	RW	Yes	No	1	0	1	_	PnCF3
	8	Position data polarity	USINT	RW	Yes	No	0	0	1	_	PnCF4
	9	Behavior after reaching buffer position	USINT	RW	Yes	No	0	0	1	_	PnCF5
2732 hex	0	Interpolation profile select	USINT	RW	Yes	No	0	0	1	_	PnCF6
	Interpolat	ion data read/write poir	nter posit	ion mo	nitor						
	0	Number of entries	USINT	RO	No	No	2	-	-	-	-
2741 hex	1	Interpolation data read pointer position	UINT	RO	Yes	No	-	1	254		PnCF7
	2	Interpolation data write pointer position	UINT	RO	Yes	No	-	1	254	-	PnCF8

Continued from previous page.

Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parameter No.*2
ZONE tab	le positive side bounda	ary positio	n (ZOI	NE P)			ı			
0	Number of entries	USINT	RO	No	No	16	_	-	-	-
1	ZONE ID0	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA00
2	ZONE ID1	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA04
3	ZONE ID2	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA08
4	ZONE ID3	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA0C
5	ZONE ID4	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA10
6	ZONE ID5	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA14
7	ZONE ID6	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA18
8	ZONE ID7	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA1C
9	ZONE ID8	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA20
10	ZONE ID9	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA24
11	ZONE ID10	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA28
12	ZONE ID11	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA2C
13	ZONE ID12	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA30
14	ZONE ID13	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA34
15	ZONE ID14	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA38
16	ZONE ID15	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA3C
	dex  ZONE tab  0  1  2  3  4  5  6  7  8  9  10  11  12  13  14  15	dex         Name           ZONE table positive side bounds           0         Number of entries           1         ZONE ID0           2         ZONE ID1           3         ZONE ID2           4         ZONE ID3           5         ZONE ID4           6         ZONE ID5           7         ZONE ID6           8         ZONE ID7           9         ZONE ID8           10         ZONE ID9           11         ZONE ID10           12         ZONE ID11           13         ZONE ID12           14         ZONE ID13           15         ZONE ID14	dex         Name         Type           ZONE table positive side boundary position         0         Number of entries         USINT           1         ZONE ID0         DINT           2         ZONE ID1         DINT           3         ZONE ID2         DINT           4         ZONE ID3         DINT           5         ZONE ID4         DINT           6         ZONE ID5         DINT           7         ZONE ID6         DINT           8         ZONE ID7         DINT           9         ZONE ID8         DINT           10         ZONE ID9         DINT           11         ZONE ID10         DINT           12         ZONE ID11         DINT           13         ZONE ID12         DINT           14         ZONE ID13         DINT           15         ZONE ID14         DINT	dex         Name         Type         cess           ZONE table positive side boundary position (ZOI 0 Number of entries USINT RO 1 ZONE ID0 DINT RW         USINT RW           1         ZONE ID0 DINT RW           2         ZONE ID1 DINT RW           3         ZONE ID2 DINT RW           4         ZONE ID3 DINT RW           5         ZONE ID4 DINT RW           6         ZONE ID5 DINT RW           7         ZONE ID6 DINT RW           8         ZONE ID7 DINT RW           9         ZONE ID8 DINT RW           10         ZONE ID9 DINT RW           11         ZONE ID10 DINT RW           12         ZONE ID11 DINT RW           13         ZONE ID12 DINT RW           14         ZONE ID13 DINT RW           15         ZONE ID14 DINT RW	SubindexNameData TypeAccess PingZONE table positive side boundary position(ZONE P)0Number of entriesUSINTRONo1ZONE ID0DINTRWNo2ZONE ID1DINTRWNo3ZONE ID2DINTRWNo4ZONE ID3DINTRWNo5ZONE ID4DINTRWNo6ZONE ID5DINTRWNo7ZONE ID6DINTRWNo8ZONE ID7DINTRWNo9ZONE ID8DINTRWNo10ZONE ID9DINTRWNo11ZONE ID10DINTRWNo12ZONE ID11DINTRWNo13ZONE ID12DINTRWNo14ZONE ID13DINTRWNo15ZONE ID14DINTRWNo	Name	Name	Name	Saung to personal part   Cess   Propering   Saung to personal part   Cess   Propering   Cess   Ces	Subn-dex

Name		Continued from previous page							ous page.			
	Index		Name			Мар-			Lower Limit	Upper Limit	Unit	
		ZONE tab	le negative side bound	lary positi	ion (ZC	NE N)						
1   2008   DINT   RW   No   Yes   0   -2147483648   2147483647   Pinh   Pinh		0	Number of entries	USINT	RO	No	No	16	_	-	_	_
2   200E   DI   ONT   RW   No   Yes   0   2147483648   2147483647   Ph.ADA		1	ZONE ID0	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA02
A		2	ZONE ID1	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA06
1		3	ZONE ID2	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA0A
2751 hex   6   20NE IDS   DINT   RW   No   Yes   0   2147483648   2147483647   Post   Dint   PinA16		4	ZONE ID3	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA0E
7   20NE IDS		5	ZONE ID4	DINT	RW	No	Yes	0	-2147483648	2147483647	unit	PnA12
2751 hex   B		6	ZONE ID5	DINT	RW	No	Yes	0	-2147483648	2147483647	unit	PnA16
Part		7	ZONE ID6	DINT	RW	No	Yes	0	-2147483648	2147483647	unit	PnA1A
10   ZONE IDB   DINT   RW   No   Yes   0   -2147483648   2147483647   Post   PnA26	2751 hex	8	ZONE ID7	DINT	RW	No	Yes	0	-2147483648	2147483647	unit	PnA1E
10   20NE ID9   DINT   RW   No   Yes   0   -2147483648   2147483647   Unit   PRAZE		9	ZONE ID8	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA22
12   ZONE   DINT   RW   No   Yes   0		10	ZONE ID9	DINT	RW	No	Yes	0	-2147483648	2147483647	unit	PnA26
12   20Ne   DINT   RW   No   Yes   0   -2147483648   2147483647   Pois.   Pon.   Pon		11	ZONE ID10	DINT	RW	No	Yes	0	-2147483648	2147483647	Pos. unit	PnA2A
13   ZONE ID12   DINT   RW   No   Yes   0   -2147483648   2147483647   Pros. Unit   Prina.		12	ZONE ID11	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA2E
14   20NE ID13		13	ZONE ID12	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA32
15   ZONE ID14		14	ZONE ID13	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA36
2752 hex   0   ZONE output signal selection 1   USINT   RW   No   Yes   0   0000   0xFFFF   - PnBA0		15	ZONE ID14	DINT	RW	No	Yes	0	-2147483648	2147483647		PnA3A
2753 hex   0   Selection 1   USINT   RW   No   Yes   0   0000   0x000F   - PnBA1		16		DINT	RW	No	Yes	0	-2147483648	2147483647		PnA3E
Interpolation data record for 1st profile   0   Number of entries   USINT   RO   No   No   0   254   -   -   -   -	2752 hex	0	selection 1	USINT	RW	No	Yes	0	0000	0xFFFF	-	PnBA0
27C0 hex   0	2753 hex	0	ZONE output signal selection 2	USINT	RW	No	Yes	0	0000	0x000F	_	PnBA1
1 to 254		<u> </u>									ı	
Interpolation data record for 2nd profile	27C0 hex	0		USINT	RO	No	No	254	-	-	-	_
27C1 hex   0   Number of entries   USINT   RO   No   No   254   -   -   -   -   -       1 to 254   1st set-point to 254 set-point   DINT   RW   No   No   0   -2147483648   2147483647   -   -       27E0 hex   -   Diag. mode   UINT   RW   No   No   0   0   0   0     603F hex   0   Error code   UINT   RO   Yes   No   -   -   -   -   PnB10     6040 hex   0   Controlword   UINT   RW   Yes   No   0   0   0     6041 hex   0   Statusword   UINT   RO   Yes   No   -   -   -   PnB11     605A hex   0   Quick stop option   Code   UINT   RW   No   Yes   2   0   4   -   PnB13     605B hex   0   Disable operation option code   INT   RW   No   Yes   1   0   1   -   PnB15     605D hex   0   Halt option code   INT   RW   No   Yes   1   0   4   -   PnB16     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   -   PnB17     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   -   PnB17     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   -   PnB17     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   -   PnB17     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   -   PnB17     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   0   -   PnB17     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   0   0   0   0     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   0   0   0   0     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   0   0   0   0     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   0   0   0   0     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   0   0   0   0   0     605E hex   0   Fault reaction option code   INT   RW   No   Yes   0   0   0   0   0   0   0   0   0			254 set-point		RW	No	No	0	-2147483648	2147483647	_	-
1 to 254		-		r ·				0=1	1	T		
27E0 hex         -         Diag. mode         UINT         RW         No         No         0         0         0xFFFF         -         PnCFE           603F hex         0         Error code         UINT         RO         Yes         No         -         -         -         -         -         PnB10           6040 hex         0         Controlword         UINT         RO         Yes         No         -         -         -         -         PnB11           6041 hex         0         Statusword         UINT         RO         Yes         No         -         -         -         -         PnB12           605A hex         0         Quick stop option code         INT         RW         No         Yes         2         0         4         -         PnB13           605B hex         0         Shutdown option code         INT         RW         No         Yes         0         0         1         -         PnB14           605C hex         0         Disable operation option code         INT         RW         No         Yes         1         0         4         -         PnB16           605E hex         0 <t< td=""><td>27C1 hex</td><td>0</td><td></td><td>USINT</td><td>RO</td><td>INO</td><td>INO</td><td>254</td><td>-</td><td>_</td><td>-</td><td>_</td></t<>	27C1 hex	0		USINT	RO	INO	INO	254	-	_	-	_
603F hex         0         Error code         UINT         RO         Yes         No         -         -         -         -         PnB10           6040 hex         0         Controlword         UINT         RW         Yes         No         0         0         0xFFFF         -         PnB11           6041 hex         0         Statusword         UINT         RO         Yes         No         -         -         -         -         -         PnB12           605A hex         0         Quick stop option code         INT         RW         No         Yes         2         0         4         -         PnB13           605B hex         0         Shutdown option code         INT         RW         No         Yes         0         0         1         -         PnB14           605C hex         0         Disable operation option code         INT         RW         No         Yes         1         0         1         -         PnB15           605D hex         0         Halt option code         INT         RW         No         Yes         0         0         0         -         PnB17		1 to 254	254 set-point to	DINT	RW	No	No	0	-2147483648	2147483647	-	_
6040 hex         0         Controlword         UINT         RW         Yes         No         0         0         0xFFFF         -         PnB11           6041 hex         0         Statusword         UINT         RO         Yes         No         -         -         -         -         -         PnB12           605A hex         0         Quick stop option code         INT         RW         No         Yes         2         0         4         -         PnB13           605B hex         0         Shutdown option code         INT         RW         No         Yes         0         0         1         -         PnB14           605C hex         0         Disable operation option code         INT         RW         No         Yes         1         0         1         -         PnB15           605D hex         0         Halt option code         INT         RW         No         Yes         1         0         4         -         PnB16           605E hex         0         Fault reaction option code         INT         RW         No         Yes         0         0         0         -         PnB17	27E0 hex	_	Diag. mode	UINT	RW	No	No	0	0	0xFFFF	_	PnCFE
6041 hex         0         Statusword         UINT         RO         Yes         No         -         PnB13           605B hex         0         Shutdown option code         INT         RW         No         Yes         0         0         1         -         PnB14           605C hex         0         Disable operation option code         INT         RW         No         Yes         1         0         1         -         PnB15           605D hex         0         Halt option code         INT         RW         No         Yes         0         0         0         -         PnB17 <td>603F hex</td> <td>0</td> <td>Error code</td> <td>UINT</td> <td>RO</td> <td>Yes</td> <td>No</td> <td>-</td> <td>-</td> <td>-</td> <td>_</td> <td>PnB10</td>	603F hex	0	Error code	UINT	RO	Yes	No	-	-	-	_	PnB10
605A hex         0         Quick stop option code         INT         RW         No         Yes         2         0         4         -         PnB13           605B hex         0         Shutdown option code         INT         RW         No         Yes         0         0         1         -         PnB14           605C hex         0         Disable operation option code         INT         RW         No         Yes         1         0         1         -         PnB15           605D hex         0         Halt option code         INT         RW         No         Yes         1         0         4         -         PnB16           605E hex         0         Fault reaction option code         INT         RW         No         Yes         0         0         0         -         PnB17	6040 hex	0	Controlword	UINT	RW	Yes	No	0	0	0xFFFF	-	PnB11
605B hex         0         Code occupies         INT         RW         No         Yes         2         0         4         -         Prib is           605B hex         0         Shutdown option code occupies         INT         RW         No         Yes         0         0         1         -         PnB14           605C hex         0         Disable operation option code         INT         RW         No         Yes         1         0         1         -         PnB15           605D hex         0         Halt option code         INT         RW         No         Yes         1         0         4         -         PnB16           605E hex         0         Fault reaction option code         INT         RW         No         Yes         0         0         0         -         PnB17	6041 hex	0	Statusword	UINT	RO	Yes	No			_	_	PnB12
605C hex         0         Disable operation option code         INT         RW         No         Yes         1         0         1         -         PnB15           605D hex         0         Halt option code         INT         RW         No         Yes         1         0         4         -         PnB16           605E hex         0         Fault reaction option code         INT         RW         No         Yes         0         0         0         -         PnB17	605A hex	0		INT	RW	No	Yes	2	0	4	_	PnB13
605D hex         0         Halt option code         INT         RW         No         Yes         1         0         4         -         PnB16           605E hex         0         Fault reaction option code         INT         RW         No         Yes         0         0         0         -         PnB17	605B hex	0		INT	RW	No	Yes	0	0	1	_	PnB14
605E hex 0 Fault reaction option code INT RW No Yes 0 0 0 - PnB17	605C hex	0	Disable operation option code	INT	RW	No	Yes	1	0	1	_	PnB15
ouse riex o code . IIVI RVV No res o o - PIBI7	605D hex	0	Halt option code	INT	RW	No	Yes	1	0	4	-	PnB16
6060 hex         0         Modes of operation         SINT         RW         Yes         0         0         10         -         PnB18	605E hex	0		INT	RW	No	Yes	0	0	0	_	PnB17
	6060 hex	0	Modes of operation	SINT	RW	Yes	Yes	0	0	10	_	PnB18

16

Continued from previous page.

					DDO					p. 0	ao pago.
Index	Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parame- ter No.*2
6061 hex	0	Modes of operation display	SINT	RO	Yes	No	0	_	_	-	PnB19
6062 hex	0	Position demand value	DINT	RO	Yes	No	-	-	_	Pos. unit	PnB20
6063 hex	0	Position actual inter- nal value	DINT	RO	Yes	No	-	-	_	Inc	PnB22
6064 hex	0	Position actual value	DINT	RO	Yes	No	-	-	_	Pos. unit	PnB24
6065 hex	0	Following error window	UDINT	RW	No	Yes	5242880	0	1073741823	Pos. unit	PnB26
6066 hex	0	Following error time out	UINT	RW	No	Yes	0	0	65535	ms	PnB28
6067 hex	0	Position window	UDINT	RW	No	Yes	30	0	1073741823	Pos. unit	PnB2A
6068 hex	0	Position window time	UINT	RW	No	Yes	0	0	65535	ms	PnB2C
606B hex	0	Velocity demand value	DINT	RO	Yes	No	_	_	_	Vel. Unit	PnB2E
606C hex	0	Velocity actual value	DINT	RO	Yes	No	_	_	_	Vel. Unit	PnB30
606D hex	0	Velocity window	UINT	RW	No	Yes	20000	0	65535	Vel. Unit	PnB32
606E hex	0	0 Velocity window time		RW	No	Yes	0	0	65535	ms	PnB34
6071 hex	0	0 Target torque		RW	Yes	No	0	-32768	32767	0.1	PnB36
6072 hex	0	Max torque	UINT	RW	Yes	No	Motor max torque	0	65535	0.1 %	PnB38
6074 hex	0	Max current	INT	RO	Yes	No	_	_	_	0.1 %	PnB3A
6076 hex	0	Motor rated torque	UDINT	RO	No	No	_	_	_	mN m, mN	PnB3C
6077 hex	0	Torque actual value	INT	RO	Yes	No	_	_	_	0.1 %	PnB3E
607A hex	0	Target position	DINT	RW	Yes	No	0	-2147483648	2147483647	Pos. unit	PnB40
607C hex	-	Home offset	DINT	RW	No	Yes	0	-536870912	536870911	Pos. unit	PnB46
	Software	position limit	T			T	T	T		1	
	0	Number of entries	USINT	RO	No	No	2	-	_	_	_
607D hex	1	Min position limit	DINT	RW	No	Yes	0	-536870912	536870911	Pos. unit	PnB48
	2	Max position limit	DINT	RW	No	Yes	0	-536870912	536870911	Pos. unit	PnB4A
607F hex	0	Max profile velocity	UDINT	RW	Yes	Yes	2147483647	0	4294967295	Vel. Unit	PnB4C
6081 hex	0	Profile velocity	UDINT	RW	Yes	Yes	0	0	4294967295	Vel. Unit	PnB4E
6083 hex	0	Profile acceleration	UDINT	RW	Yes	Yes	1000	0	4294967295	Acc. Unit	PnB50
6084 hex	0	Profile deceleration	UDINT	RW	Yes	Yes	1000	0	4294967295	Acc. Unit	PnB52
6085 hex	0	Quick stop decelera- tion	UDINT	RW	Yes	Yes	1000	0	4294967295	Acc. Unit	PnB54
6086 hex	0	Motion profile type	INT	RW	Yes	Yes	0	32768	32767	-	PnB98
6087 hex	0	Torque slope	UDINT	RW	Yes	Yes	1000	0	4294967295	0.1 %/s	PnB56
6098 hex	0	Homing method	SINT	RW	Yes	No	35	0	35	-	PnB58

								001	itinuea trom	previo	us page.
Index	Subin- dex	Name	Data Type	Ac- cess	PDO Map- ping	Saving to EEPROM*1	Default Value	Lower Limit	Upper Limit	Unit	Parameter No.*2
	Homing s	peeds									
	0	Number of entries	USINT	RO	No	No	2	_	-	-	-
6099 hex	1	Speed during search for switch	UDINT	RW	Yes	Yes	500000	0	4294967295	Vel. Unit	PnB5A
	2	Speed during search for zero	UDINT	RW	Yes	Yes	100000	0	4294967295	Vel. Unit	PnB5C
609A hex	0	Homing acceleration	UDINT	RW	Yes	Yes	1000	0	4294967295	Acc. Unit	PnB5E
	Profile jer	k									
60A4 hex	0	Number of entries	USINT	RO	No	No	1	_	_	-	-
	1	Profile jerk1	UDINT	RW	No	Yes	25	0	50	%	PnB9A
60B1 hex	0	Velocity offset	DINT	RW	Yes	No	0	-2147483648	2147483647	Vel. Unit	PnB60
60B2 hex	0	Torque offset	INT	RW	Yes	No	0	-32768	32767	0.1 %	PnB62
60B8 hex	0	Touch probe function	UINT	RW	Yes	No	0	0	0xFFFF	_	PnB64
60B9 hex	0	Touch probe status	UINT	RO	Yes	No	-	-	-	-	PnB66
60BA hex	0	Touch probe pos1 pos value	DINT	RO	Yes	No	-	-	-	Pos. unit	PnB68
60BC hex	0	Touch probe pos2 pos value	DINT	RO	Yes	No	-	-	_	Pos. unit	PnB6A
60C0 hex	0	Interpolation sub mode select	INT	RW	No	No	0	-3	0	_	PnB92
	Interpolat	ion data record									
60C1 hex	0	Number of entries	USINT	RO	No	No	1	_	-	-	_
ooo i nox	1	Interpolation data record	DINT	RW	Yes	No	0	-2147483648	2147483647	Pos. unit	PnB70
	Interpolat	ion time period							l		
	0	Number of entries	USINT	RO	No	No	2	-	-	-	_
60C2 hex	1	Interpolation time period value	USINT	RW	No	No	125	1	250	_	PnB6E
	2	Interpolation time index	SINT	RW	No	No	-6	-6	-3	_	PnB6F
60E0 hex	0	Positive torque limit value	UINT	RW	Yes	Yes	8000	0	65535	0.1	PnB80
60E1 hex	0	Negative torque limit value	UINT	RW	Yes	Yes	8000	0	65535	0.1	PnB82
	Additiona	l position actual value									_
60E4 hex	0	Number of entries	USINT	RO	No	No	1	_	-	-	_
002 1 110X	1	External encoder position	DINT	RO	Yes	Yes	0	-	-	-	-
60F4 hex	0	Following error actual value	DINT	RO	Yes	No	-	-	-	Pos. unit	PnB84
60FC hex	0	Position demand internal value	DINT	RO	Yes	No	-	_	-	Inc	PnB86
60FD hex	0	Digital inputs	UDINT	RO	Yes	No	-	_	-	-	PnB88
	Digital ou	tputs									
60FE hex	0	Number of entries	USINT	RO	No	No	2	-	_	_	_
our E nex	1	Physical outputs	UDINT	RW	Yes	No	0	0	0xFFFFFFF	-	PnB8A
	2	Bit mask	UDINT	RW	No	Yes	0x000C0000	0	0xFFFFFFF	-	PnB8C
60FF hex	0	Target velocity	DINT	RW	Yes	No	0	-2147483648	2147483647	Vel. Unit	PnB8E
6502 hex	0	Supported drive modes	UDINT	RO	No	No	0x03ED	_	_	_	PnB90

<sup>\*1.</sup> Write "Save" to object 1010 hex to save all of the current parameter data to EEPROM.

If the objects are modified by the Digital Operator or SigmaWin+, the data will be directly saved in EEPROM.

<sup>\*2.</sup> The parameter numbers given in the table are the parameter numbers that are used with the Digital Operator and SigmaWin+.

<sup>\*3.</sup> These parameters cannot be written by the Digital Operator.

<sup>\*4.</sup> For SGD7S-□□□DA0: 0x02200401.
\*5. Both 10F1 hex and 1F01 hex have the same function. You can set either object.

# 16.3 SDO Abort Code List

The following table gives the SDO abort codes for SDO communications errors.

Value	Meaning
0x05 03 00 00	Toggle bit did not change.
0x05 04 00 00	SDO protocol timeout
0x05 04 00 01	Client/server command specifier is not valid or is unknown.
0x05 04 00 05	Out of memory
0x06 01 00 00	Unsupported access to an object
0x06 01 00 01	Attempt to read to a write-only object
0x06 01 00 02	Attempt to write to a read-only object
0x06 02 00 00	The object does not exist in the object directory.
0x06 04 00 41	The object cannot be mapped to the PDO.
0x06 04 00 42	The number and length of the objects to be mapped would exceed the PDO length.
0x06 04 00 43	General parameter incompatibility
0x06 04 00 47	General internal incompatibility in the device
0x06 06 00 00	Access failed due to a hardware error.
0x06 07 00 10	Data type does not match: length of service parameter does not match.
0x06 07 00 12	Data type does not match: service parameter too long.
0x06 07 00 13	Data type does not match: service parameter too short.
0x06 09 00 11	Subindex does not exist.
0x06 09 00 30	Value range of parameter was exceeded (only for write access).
0x06 09 00 31	Value of parameter that was written is too high.
0x06 09 00 32	Value of parameter that was written is too low.
0x06 09 00 36	The maximum value is less than the minimum value.
0x08 00 00 00	General error
0x08 00 00 20	Data cannot be transferred or stored to the application.
0x08 00 00 21	Data cannot be transferred or stored to the application because of local control.
0x08 00 00 22	Data cannot be transferred or stored to the application because of the present device state.

# 16.4 Parameter Recording Table

Use the following table to record the settings of the parameters.

PROBOD   CROOD   PROBOD   Basic Function Selections 0   After restart   Application Function Selections 1   Application Function Selections 2   After restart   Application Function Selections 2   After restart   Application Function Selections 2   Application Function Selections 3   Application Function Selections 6   Immediately   Im	Parameter No.	Default Setting		Name	When Enabled
Pn001   C2001 hex   hex   hex   hex   After restart   Application Function Selections 2   After restart   C2006 hex   hex   Application Function Selections 2   After restart   Immediately   Immedi			Basic	Function Selections 0	After restart
Production   Pro	Pn001				After restart
Cause   Caus					After restart
Pn008					Immediately
Atter restart   Pn009					Immediately
Atter restart   Pn00A   Cool   Pn00B   Cool   Pn00B   Pn00B   Pn00B   Pn00B   Pn00B   Pn00B   Pn00B   Pn00B   Pn10B   Pn10B					After restart
Refer restart   Refer restart					After restart
POOC   COOC   Pooc					After restart
Cauch   Cauc					After restart
Canon Dear   Nex   Tions D   After restart					After restart
After restart   After restart					After restart
Coulomb   Pax					After restart
Atter restart   Find   Find	-				After restart
Company   Comp					After restart
Caton hex   Caton hex   Caton hex   Caton hex   Pn101   Caton hex   Pn102   Caton hex   Pn102   Caton hex   Pn103   Caton hex   Pn104   Caton hex   Pn105   Caton hex   Pn106   Caton hex   Pn106   Caton hex   Pn109   Caton hex   Pn104   Caton hex   Pn105   Caton hex   Pn106   Caton hex   Pn106   Caton hex   Pn109   Caton hex   Pn109   Caton hex   Pn109   Caton hex   Pn109   Caton hex   Pn108   Caton he					After restart
Pn102		400	Speed	d Loop Gain	Immediately
Position Loop Gain   Immediately		2000			Immediately
(2103 hex) 100   Moment of Inertia Ratio   Immediately   Pn104 (2104 hex) 400   Second Speed Loop Gain   Immediately   Pn105 (2105 hex) 2000   Second Speed Loop Integral Time Constant   Pn106 (2106 hex) 400   Second Position Loop Gain   Immediately   Pn109 (2109 hex) 0   Feedforward   Immediately   Pn10A (210A hex) 0   Feedforward Filter Time   Immediately   Pn10B   0000   Gain Application Selections   *		400	Position	on Loop Gain	Immediately
Pn105   2000   Second Speed Loop Gain   Immediately		100	Mome	ent of Inertia Ratio	Immediately
(2105 hex) 2000  Pn106 (2106 hex) 400  Second Position Loop Gain Immediately  Pn109 (2109 hex) 0  Pn10A (210A hex) 0  Pn10B 0000  Gain Application Selections *		400	Secon	nd Speed Loop Gain	Immediately
(2106 hex) 400  Pn109 (2109 hex) 0  Feedforward Immediately  Pn10A (210A hex) 0  Pn10B 0000  Second Position Loop Gain Immediately  Feedforward Immediately  Feedforward Filter Time Constant Immediately		2000	Secor gral T	nd Speed Loop Inte- ime Constant	Immediately
Pn10A (210A hex)  Pn10B 0000  Peedforward Immediately  Feedforward Filter Time Constant  Feedforward Filter Time Immediately  Feedforward Filter Time Constant  Feedforward Filter Time Immediately  Feedforward Filter Time Constant  Feedforward Filter Time Immediately		400	Secon	nd Position Loop Gain	Immediately
(210A hex) Constant Immediately Pn10B 0000  Gain Application Selections *		0	Feedf	orward	Immediately
1 Gain Application Scienting 1		0			Immediately
	Pn10B (210B hex)	0000 hex	Gain A	Application Selections	*

Continued from previous page.

		Continued from p	revious page.
Parameter No.	Default Setting	Name	When Enabled
Pn10C (210C hex)	200	Mode Switching Level for Torque Reference	Immediately
Pn10D (210D hex)	0	Mode Switching Level for Speed Reference	Immediately
Pn10E (210E hex)	0	Mode Switching Level for Acceleration	Immediately
Pn10F (210F hex)	0	Mode Switching Level for Position Deviation	Immediately
Pn11F (211F hex)	0	Position Integral Time Constant	Immediately
Pn121 (2121 hex)	100	Friction Compensation Gain	Immediately
Pn122 (2122 hex)	100	Second Friction Compensation Gain	Immediately
Pn123 (2123 hex)	0	Friction Compensation Coefficient	Immediately
Pn124 (2124 hex)	0	Friction Compensation Frequency Correction	Immediately
Pn125 (2125 hex)	100	Friction Compensation Gain Correction	Immediately
Pn131 (2131 hex)	0	Gain Switching Time 1	Immediately
Pn132 (2132 hex)	0	Gain Switching Time 2	Immediately
Pn135 (2135 hex)	0	Gain Switching Waiting Time 1	Immediately
Pn136 (2136 hex)	0	Gain Switching Waiting Time 2	Immediately
Pn139 (2139 hex)	0000 hex	Automatic Gain Switching Selections 1	Immediately
Pn13D (213D hex)	2000	Current Gain Level	Immediately
Pn140 (2140 hex)	0100 hex	Model Following Control- Related Selections	Immediately
Pn141 (2141 hex)	500	Model Following Control Gain	Immediately
Pn142 (2142 hex)	1000	Model Following Control Gain Correction	Immediately
Pn143 (2143 hex)	1000	Model Following Control Bias in the Forward Direc- tion	Immediately
Pn144 (2144 hex)	1000	Model Following Control Bias in the Reverse Direc- tion	Immediately
Pn145 (2145 hex)	500	Vibration Suppression 1 Frequency A	Immediately
Pn146 (2146 hex)	700	Vibration Suppression 1 Frequency B	Immediately
Pn147 (2147 hex)	1000	Model Following Control Speed Feedforward Com- pensation	Immediately
Pn148 (2148 hex)	500	Second Model Following Control Gain	Immediately
Pn149 (2149 hex)	1000	Second Model Following Gain Control Correction	Immediately

		Continued from	previous page.
Parameter No.	Default Setting	Name	When Enabled
Pn14A (214A hex)	800	Vibration Suppression 2 Frequency	Immediately
Pn14B (214B hex)	100	Vibration Suppression 2 Correction	Immediately
Pn14F (214F hex)	0021 hex	Control-Related Selections	After restart
Pn160 (2160 hex)	0010 hex	Anti-Resonance Control- Related Selections	Immediately
Pn161 (2161 hex)	1000	Anti-Resonance Frequency	Immediately
Pn162 (2162 hex)	100	Anti-Resonance Gain Correction	Immediately
Pn163 (2163 hex)	0	Anti-Resonance Damping Gain	Immediately
Pn164 (2164 hex)	0	Anti-Resonance Filter Time Constant 1 Correction	Immediately
Pn165 (2165 hex)	0	Anti-Resonance Filter Time Constant 2 Correction	Immediately
Pn166 (2166 hex)	0	Anti-Resonance Damping Gain 2	Immediately
Pn170 (2170 hex)	1401 hex	Tuning-less Function- Related Selections	*
Pn181 (2181 hex)	0	Mode Switching Level for Speed Reference	Immediately
Pn182 (2182 hex)	0	Mode Switching Level for Acceleration	Immediately
Pn205 (2205 hex)	65535	Multiturn Limit	After restart
Pn207 (2207 hex)	0010 hex	Position Control Function Selections	After restart
Pn20A (220A hex)	32768	Number of External Scale Pitches	After restart
Pn20E (220E hex)	1	Electronic Gear Ratio (Numerator)	After restart
Pn210 (2210 hex)	1	Electronic Gear Ratio (Denominator)	After restart
Pn212 (2212 hex)	2048	Number of Encoder Output Pulses	After restart
Pn22A (222A hex)	0000 hex	Fully-closed Control Selections	After restart
Pn230 (2230 hex)	0000 hex	Position Control Expansion Function Selections	After restart
Pn231 (2231 hex)	0	Backlash Compensation	Immediately
Pn233 (2233 hex)	0	Backlash Compensation Time Constant	Immediately
Pn281 (2281 hex)	20	Encoder Output Resolution	After restart
Pn282 (2282 hex)	0	Linear Encoder Pitch	After restart
Pn304 (2304 hex)	500	Jogging Speed	Immediately
Pn305 (2305 hex)	0	Soft Start Acceleration Time	Immediately
		Continued	on next page.

Continued from previous page.

		 Continued from p	revious page.
Parameter No.	Default Setting	Name	When Enabled
Pn306 (2306 hex)	0	Soft Start Deceleration Time	Immediately
Pn308 (2308 hex)	0	Speed Feedback Filter Time Constant	Immediately
Pn30A (230A hex)	0	Deceleration Time for Servo OFF and Forced Stops	Immediately
Pn30C (230C hex)	0	Speed Feedforward Average Movement Time	Immediately
Pn310 (2310 hex)	0000 hex	Vibration Detection Selections	Immediately
Pn311 (2311 hex)	100	Vibration Detection Sensitivity	Immediately
Pn312 (2312 hex)	50	Vibration Detection Level	Immediately
Pn316 (2316 hex)	10000	Maximum Motor Speed	After restart
Pn324 (2324 hex)	300	Moment of Inertia Calculation Starting Level	Immediately
Pn383 (2383 hex)	50	Jogging Speed	Immediately
Pn384 (2384 hex)	10	Vibration Detection Level	Immediately
Pn385 (2385 hex)	50	Maximum Motor Speed	After restart
Pn401 (2401 hex)	100	First Stage First Torque Reference Filter Time Constant	Immediately
Pn402 (2402 hex)	800	Forward Torque Limit	Immediately
Pn403 (2403 hex)	800	Reverse Torque Limit	Immediately
Pn404 (2404 hex)	100	Forward External Torque Limit	Immediately
Pn405 (2405 hex)	100	Reverse External Torque Limit	Immediately
Pn406 (2406 hex)	800	Emergency Stop Torque	Immediately
Pn407 (2407 hex)	10000	Speed Limit during Torque Control	Immediately
Pn408 (2408 hex)	0000 hex	Torque-Related Function Selections	*
Pn409 (2409 hex)	5000	First Stage Notch Filter Frequency	Immediately
Pn40A (240A hex)	70	First Stage Notch Filter Q Value	Immediately
Pn40B (240B hex)	0	First Stage Notch Filter Depth	Immediately
Pn40C (240C hex)	5000	Second Stage Notch Filter Frequency	Immediately
Pn40D (240D hex)	70	Second Stage Notch Filter Q Value	Immediately
Pn40E (240E hex)	0	Second Stage Notch Filter Depth	Immediately

		Continued from p	revious page.
Parameter No.	Default Setting	Name	When Enabled
Pn40F (240F hex)	5000	Second Stage Second Torque Reference Filter Fre- quency	Immediately
Pn410 (2410 hex)	50	Second Stage Second Torque Reference Filter Q Value	Immediately
Pn412 (2412 hex)	100	First Stage Second Torque Reference Filter Time Con- stant	Immediately
Pn416 (2416 hex)	0000 hex	Torque-Related Function Selections 2	Immediately
Pn417 (2417 hex)	5000	Third Stage Notch Filter Frequency	Immediately
Pn418 (2418 hex)	70	Third Stage Notch Filter Q Value	Immediately
Pn419 (2419 hex)	0	Third Stage Notch Filter Depth	Immediately
Pn41A (241A hex)	5000	Fourth Stage Notch Filter Frequency	Immediately
Pn41B (241B hex)	70	Fourth Stage Notch Filter Q Value	Immediately
Pn41C (241C hex)	0	Fourth Stage Notch Filter Depth	Immediately
Pn41D (241D hex)	5000	Fifth Stage Notch Filter Frequency	Immediately
Pn41E (241E hex)	70	Fifth Stage Notch Filter Q Value	Immediately
Pn41F (241F hex)	0	Fifth Stage Notch Filter Depth	Immediately
Pn423 (2423 hex)	0000 hex	Speed Ripple Compensation Selections	*
Pn424 (2424 hex)	50	Torque Limit at Main Circuit Voltage Drop	Immediately
Pn425 (2425 hex)	100	Release Time for Torque Limit at Main Circuit Voltage Drop	Immediately
Pn426 (2426 hex)	0	Torque Feedforward Average Movement Time	Immediately
Pn427 (2427 hex)	0	Speed Ripple Compensation Enable Speed	Immediately
Pn456 (2456 hex)	15	Sweep Torque Reference Amplitude	Immediately
Pn460 (2460 hex)	0101 hex	Notch Filter Adjustment Selections 1	Immediately
Pn480 (2480 hex)	10000	Speed Limit during Force Control	Immediately
Pn481 (2481 hex)	400	Polarity Detection Speed Loop Gain	Immediately
Pn482 (2482 hex)	3000	Polarity Detection Speed Loop Integral Time Constant	Immediately
Pn483 (2483 hex)	30	Forward Force Limit	Immediately
Pn484 (2484 hex)	30	Reverse Force Limit	Immediately

_		Continued from p	
Parameter No.	Default Setting	Name	When Enabled
Pn485 (2485 hex)	20	Polarity Detection Reference Speed	Immediately
Pn486 (2486 hex)	25	Polarity Detection Reference Acceleration/Deceleration Time	Immediately
Pn487 (2487 hex)	0	Polarity Detection Constant Speed Time	Immediately
Pn488 (2488 hex)	100	Polarity Detection Reference Waiting Time	Immediately
Pn48E (248E hex)	10	Polarity Detection Range	Immediately
Pn490 (2490 hex)	100	Polarity Detection Load Level	Immediately
Pn495 (2495 hex)	100	Polarity Detection Confirmation Force Reference	Immediately
Pn498 (2498 hex)	10	Polarity Detection Allowable Error Range	Immediately
Pn49F (249F hex)	0	Speed Ripple Compensation Enable Speed	Immediately
Pn502 (2502 hex)	20	Rotation Detection Level	Immediately
Pn503 (2503 hex)	10	Speed Coincidence Detection Signal Output Width	Immediately
Pn506 (2506 hex)	0	Brake Reference-Servo OFF Delay Time	Immediately
Pn507 (2507 hex)	100	Brake Reference Output Speed Level	Immediately
Pn508 (2508 hex)	50	Servo OFF-Brake Com- mand Waiting Time	Immediately
Pn509 (2509 hex)	20	Momentary Power Interruption Hold Time	Immediately
Pn50A (250A hex)	1881 hex	Input Signal Selections 1	After restart
Pn50B (250B hex)	8882 hex	Input Signal Selections 2	After restart
Pn50E (250E hex)	0000 hex	Output Signal Selections 1	After restart
Pn50F (250F hex)	0100 hex	Output Signal Selections 2	After restart
Pn510 (2510 hex)	0000 hex	Output Signal Selections 3	After restart
Pn511 (2511 hex)	6543 hex	Input Signal Selections 5	After restart
Pn512 (2512 hex)	0000 hex	Output Signal Inverse Settings 1	After restart
Pn513 (2513 hex)	0000 hex	Output Signal Inverse Settings 2	After restart
Pn514 (2514 hex)	0000 hex	Output Signal Selections 4	After restart
Pn516 (2516 hex)	8888 hex	Input Signal Selections 7	After restart
Pn51B (251B hex)	1000	Motor-Load Position Deviation Overflow Detection Level	Immediately

		Continued from	previous page.
Parameter No.	Default Setting	Name	When Enabled
Pn51E (251E hex)	100	Position Deviation Over-flow Warning Level	Immediately
Pn520 (2520 hex)	5242880	Position Deviation Over-flow Alarm Level	Immediately
Pn522 (2522 hex)	7	Positioning Completed Width	Immediately
Pn524 (2524 hex)	1073741824	Near Signal Width	Immediately
Pn526 (2526 hex)	5242880	Position Deviation Over- flow Alarm Level at Servo ON	Immediately
Pn528 (2528 hex)	100	Position Deviation Over- flow Warning Level at Servo ON	Immediately
Pn529 (2529 hex)	10000	Speed Limit Level at Servo ON	Immediately
Pn52A (252A hex)	20	Multiplier per Fully-closed Rotation	Immediately
Pn52B (252B hex)	20	Overload Warning Level	Immediately
Pn52C (252C hex)	100	Base Current Derating at Motor Overload Detection	After restart
Pn530 (2530 hex)	0000 hex	Program Jogging-Related Selections	Immediately
Pn531 (2531 hex)	32768	Program Jogging Travel Distance	Immediately
Pn533 (2533 hex)	500	Program Jogging Movement Speed	Immediately
Pn534 (2534 hex)	100	Program Jogging Acceleration/Deceleration Time	Immediately
Pn535 (2535 hex)	100	Program Jogging Waiting Time	Immediately
Pn536 (2536 hex)	1	Program Jogging Number of Movements	Immediately
Pn550 (2550 hex)	0	Analog Monitor 1 Offset Voltage	Immediately
Pn551 (2551 hex)	0	Analog Monitor 2 Offset Voltage	Immediately
Pn552 (2552 hex)	100	Analog Monitor 1 Magnification	Immediately
Pn553 (2553 hex)	100	Analog Monitor 2 Magnification	Immediately
Pn55A (255A hex)	1	Power Consumption Monitor Unit Time	Immediately
Pn560 (2560 hex)	400	Residual Vibration Detection Width	Immediately
Pn561 (2561 hex)	100	Overshoot Detection Level	Immediately
Pn581 (2581 hex)	20	Zero Speed Level	Immediately
Pn582 (2582 hex)	10	Speed Coincidence Detection Signal Output Width	Immediately
Pn583 (2583 hex)	10	Brake Reference Output Speed Level	Immediately

Immediately

After restart

After restart

Dynamic Brake Resistance

Zone Output Signal Selec-

Zone Output Signal Selec-

tion 1

tion 2

	70
-	-
-	80

Parameter No.	Default Setting			Name	When Enabled
Pn584 (2584 hex)	10000			Speed Limit Level at Servo ON	Immediately
Pn585 (2585 hex)	50			Program Jogging Move- ment Speed	Immediately
Pn586 (2586 hex)	0			Motor Running Cooling Ratio	Immediately
Pn587 (2587 hex)	0000 hex			Polarity Detection Execution Selection for Absolute Linear Encoder	Immediately
Pn600 (2600 hex)	0			Regenerative Resistor Capacity	Immediately
Pn601 (2601 hex)	0			Dynamic Brake Resistor Allowable Energy Con- sumption	Immediately
Pn603 (2603 hex)	0			Regenerative Resistance	Immediately

Pn604

(2604 hex) PnBA0

(2752 hex)

(2753 hex)

PnBA1

0

0000

hex

0000

hex

<sup>\*</sup> The enable timing depends on the digit that is changed. Refer to the following sections for details. 

\*\* 16.1 List of Parameters on page 16-2\*

# **Appendices**

The appendix provides information on interpreting panel displays, and tables of corresponding SERVOPACK and SigmaWin+ function names.

17.1	Interp	reting Panel Displays17-2
	17.1.1 17.1.2 17.1.3 17.1.4 17.1.5 17.1.6	Interpreting Status Displays17-2Alarm and Warning Displays17-2Hard Wire Base Block Active Display17-2Overtravel Display17-2Forced Stop Display17-2EtherCAT Communications Indicators17-3
17.2	Corresp	onding SERVOPACK and SigmaWin+ Function Names 17-5
	17.2.1 17.2.2	Corresponding SERVOPACK Utility Function Names

#### 17.1.1 Interpreting Status Displays

## 17.1 Interpreting Panel Displays

You can check the Servo Drive status on the panel display of the SERVOPACK.

Also, if an alarm or warning occurs, the alarm or warning number will be displayed.

### 17.1.1 Interpreting Status Displays

The status is displayed as described below.

Display	Meaning
8	/TGON (Rotation Detection) Signal Display Lit if the Servomotor speed is higher than the setting of Pn502 or Pn581 and not lit if the speed is lower than the setting. (The default set- ting is 20 min <sup>-1</sup> or 20 mm/s.)
8	Base Block Display Lit during the base block state (servo OFF). Not lit while the servo is ON.

Display	Meaning			
	Reference Input Display Lit while a reference is being input.			
	Connected Display Lit while there is a connection.			

## 17.1.2 Alarm and Warning Displays

If there is an alarm or warning, the code will be displayed one character at a time, as shown below.

Example: Alarm A.E60

$$\leftarrow$$
 Status Display  $\longrightarrow$  Not lit.  $\longrightarrow$   $\longleftarrow$  Not lit.  $\longrightarrow$   $\longleftarrow$  Not lit.  $\longrightarrow$   $\longleftarrow$  Not lit.  $\longrightarrow$   $\longleftarrow$  Not lit.  $\longrightarrow$ 

## 17.1.3 Hard Wire Base Block Active Display

If a hard wire base block (HWBB) is active, the display will change in the following order.

$$-$$
Status Display  $\longrightarrow$  Not lit.  $\longrightarrow$   $\longrightarrow$  Not lit.  $\longrightarrow$  Not lit.  $\longrightarrow$  Not lit.  $\longrightarrow$  Not lit.  $\longrightarrow$ 

### 17.1.4 Overtravel Display

If overtravel has occurred, the display will change in the following order.


⑤ Forward Overtravel (P-OT)②Status Display → P

9	Reverse Overtravel (N-O1)
	Status Display—   T

3 Forward and Reverse Overtravel
Status Display P n

### 17.1.5 Forced Stop Display

During a forced stop, the following display will appear.



## 17.1.6 EtherCAT Communications Indicators

### **RUN**

The RUN indicator shows the status of EtherCAT communications.

	Indicator	Description
Status	Pattern	Description
Off	Never lit.	EtherCAT (CoE) communications are in INIT state.
Blinking	On Off 200 ms 200 ms	EtherCAT (CoE) communications are in PRE-OPERATIONAL state.
Single flash	On 1000 ms 200 ms	EtherCAT (CoE) communications are in SAFE-OPERATIONAL state.
On	Always lit.	EtherCAT (CoE) communications are in OPERATIONAL state.
Flickering	Off Off	EtherCAT (CoE) communications have been started but are not yet in INIT state.

### **ERR**

The ERR indicator shows the error status of EtherCAT communications.

Indicator Description				
Status	Pattern	Description		
Off	Never lit.	EtherCAT communications are being performed.		
Flickering	On Off	A boot error occurred.		
Blinking	On Off 200 ms 200 ms	A change in state requested by the master could not be made due to register or object settings.		
Single flash	On 1000 ms 200 ms	A synchronization error occurred and EtherCAT (CoE) communications automatically went to SAFE-OPERATIONAL state.		
Double flash	On	An application (Sync Manager) watchdog timeout error occurred.		
On	Always lit.	A PDI watchdog timeout error occurred.		

### 17.1.6 EtherCAT Communications Indicators

## Link/Activity

The Link/Activity indicators show whether Communications Cables are connected to the CN6A and CN6B connectors and whether communications are active.

	Indicator	Description	
Status	Pattern	Description	
Off	Never lit.	A Communications Cable is not connected and the EtherCAT (CoE) controller is not running.	
Flickering	On Off	Data communications are in progress.	
On	Always lit.	A Communications Cable is connected, but data communications are not being performed.	

## 17.2 Corresponding SERVOPACK and SigmaWin+ Function Names

This section gives the names and numbers of the utility functions and monitor display functions used by the SERVOPACKs and the names used by the SigmaWin+.

## 17.2.1 Corresponding SERVOPACK Utility Function Names

SigmaWin+			SERVOPACK		
Button in Menu Dialog Box	Function Name	Fn No.	Function Name		
	Origin Search	Fn003	Origin Search		
	Absolute Encoder Reset	Fn008	Reset Absolute Encoder		
	Adjust the Apples Meniter Output	Fn00C	Adjust Analog Monitor Output Offset		
	Adjust the Analog Monitor Output	Fn00D	Adjust Analog Monitor Output Gain		
	Adjust the Meter Current Detec	Fn00E	Autotune Motor Current Detection Signal Offset		
	Adjust the Motor Current Detection Signal Offsets	Fn00F	Manually Adjust Motor Current Detection Signal Offset		
Catura	Multiturn Limit Setting	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm		
Setup	Reset Option Module Configuration Error	Fn014	Reset Option Module Configuration Error		
	Initialize Vibration Detection Level	Fn01B	Initialize Vibration Detection Level		
	Set Origin	Fn020	Set Absolute Linear Encoder Origin		
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm		
	Software Reset	Fn030	Software Reset		
	Polarity Detection	Fn080	Polarity Detection		
	Tuning-less Level Setting	Fn200	Tuning-less Level Setting		
	Easy FFT	Fn206	Easy FFT		
	Initialize	Fn005	Initializing Parameters		
Parameters	Write Prohibition Setting	Fn010	Write Prohibition Setting		
	Setup Wizard	_	_		
	Autotuning without Host Reference	Fn201	Advanced Autotuning without Reference		
	Autotuning with Host Reference	Fn202	Advanced Autotuning with Reference		
Tuning	Custom Tuning	Fn203	One-Parameter Tuning		
	Adjust Anti-resonance Control	Fn204	Adjust Anti-resonance Control		
	Vibration Suppression	Fn205	Vibration Suppression		
	Moment of Inertia Estimation	_	-		
		Fn011	Display Servomotor Model		
		Fn012	Display Software Version		
Monitoring	Product Information	Fn01E	Display SERVOPACK and Servomotor IDs		
		Fn01F	Display Servomotor ID from Feedback Option Module		
Test Opera-	Jog	Fn002	Jog		
tion	Jog Program	Fn004	Jog Program		
Alarms	Display Alarm	Fn000	Display Alarm History		
, liaitio	Diopiay / with	Fn006	Clear Alarm History		
Solutions	Mechanical Analysis	_	_		

# 17.2.2 Corresponding SERVOPACK Monitor Display Function Names

SigmaWin+			SERVOPACK		
Button in Menu Dialog Box	Name [Unit]	Un No.	Name [Unit]		
	Motor Speed [min <sup>-1</sup> ]	Un000	Motor Speed [min <sup>-1</sup> ]		
	Speed Reference [min <sup>-1</sup> ]	Un001	Speed Reference [min <sup>-1</sup> ]		
	Torque Reference [%]	Un002	Torque Reference [%] (percentage of rated torque)		
Motion Monitor	Rotary Servomotors:     Rotational Angle 1 [encoder pulses]     (number of encoder pulses from origin within one encoder rotation)     Linear Servomotors:     Electrical Angle 1 [linear encoder pulses]     (linear encoder pulses from the polarity origin)	Un003	Rotary Servomotors:     Rotational Angle 1 [encoder pulses]     (number of encoder pulses from origin within one encoder rotation displayed in decimal)     Linear Servomotors:     Electrical Angle 1 [linear encoder pulses]     (linear encoder pulses from the polarity origin displayed in decimal)		
	<ul> <li>Rotary Servomotors: Rotational Angle 2 [deg] (electrical angle from origin within one encoder rotation)</li> <li>Linear Servomotors: Electrical Angle 2 [deg] (electrical angle from polarity origin)</li> </ul>	Un004	<ul> <li>Rotary Servomotors: Rotational Angle 2 [deg] (electrical angle from polarity origin)</li> <li>Linear Servomotors: Electrical Angle 2 [deg] (electrical angle from polarity origin)</li> </ul>		
	Input Reference Pulse Speed [min <sup>-1</sup> ]	Un007	Input Reference Pulse Speed [min <sup>-1</sup> ] (displayed only during position control)		
	Position Deviation [reference units]	Un008	Position Error Amount [reference units] (displayed only during position control)		
	Accumulated Load Ratio [%]	Un009	Accumulated Load Ratio [%] (percentage of rated torque: effective torque in cycles of 10 seconds)		
	Regenerative Load Ratio [%]	Un00A	Regenerative Load Ratio [%] (percentage of processable regenerative power: regenerative power consumption in cycles of 10 seconds)		
	Input Reference Pulse Counter [reference units]	Un00C	Input Reference Pulse Counter [reference units]		
	Feedback Pulse Counter [encoder pulses]	Un00D	Feedback Pulse Counter [encoder pulses]		

	SigmaWin+	SERVOPACK		
Button in Menu Dialog Box	Name [Unit]	Un No.	Name [Unit]	
	Fully-closed Loop Feedback Pulse Counter [external encoder resolu- tion]	Un00E	Fully-closed Loop Feedback Pulse Counter [external encoder resolution]	
	Upper Limit Setting of Motor Maximum Speed/Upper Limit Setting of Encoder Output Resolution	Un010*1	Upper Limit Setting of Motor Maximum Speed/ Upper Limit Setting of Encoder Output Resolu- tion	
	Total Operation Time [100 ms]	Un012	Total Operation Time [100 ms]	
	Feedback Pulse Counter [reference units]	Un013	Feedback Pulse Counter [reference units]	
	Current Backlash Compensation Value [0.1 reference units]	Un030	Current Backlash Compensation Value [0.1 reference units]	
	Backlash Compensation Value Setting Limit [0.1 reference units]	Un031	Backlash Compensation Value Setting Limit [0.1 reference units]	
Motion	Power Consumption [W]	Un032	Power Consumption [W]	
Monitor	Consumed Power [0.001 Wh]	Un033	Consumed Power [0.001 Wh]	
	Cumulative Power Consumption [Wh]	Un034	Cumulative Power Consumption [Wh]	
	Energy Consumption of the Dynamic Brake Resistor [%]	Un03B	Energy Consumption of the Dynamic Brake Resistor [%] (The percentage of the setting of Pn601 (Dynamic Brake Resistor Allowable Energy Consumption) is displayed.)	
	Absolute Encoder Multiturn Data	Un040	Absolute Encoder Multiturn Data	
	Position within One Rotation of Absolute Encoder [encoder pulses]	Un041	Position within One Rotation of Absolute Encoder [encoder pulses]	
	Lower Bits of Absolute Encoder Position [encoder pulses]	Un042	Lower Bits of Absolute Encoder Position [encoder pulses]	
	Upper Bits of Absolute Encoder Position [encoder pulses]	Un043	Upper Bits of Absolute Encoder Position [encoder pulses]	
Status	Polarity Sensor Signal Monitor	Un011	Polarity Sensor Signal Monitor	
Monitor	Active Gain Monitor	Un014	Effective Gain Monitor (gain settings 1 = 1, gain settings 2 = 2)	
Input Signal Monitor	Input Signal Monitor	Un005	Input Signal Monitor	
Output Signal Monitor	Output Signal Monitor	Un006	Output Signal Monitor	
	Installation Environment Monitor – SERVOPACK	Un025	SERVOPACK Installation Environment Monitor [%]	
	Installation Environment Monitor – Servomotor*2	Un026*2	Servomotor Installation Environment Monitor [%]	
Convice	Service Life Prediction Monitor – Built-in Fan	Un027	Built-in Fan Remaining Life Ratio [%]	
Service Life Monitor	Service Life Prediction Monitor – Capacitor	Un028	Capacitor Remaining Life Ratio [%]	
	Service Life Prediction Monitor – Surge Prevention Circuit	Un029	Surge Prevention Circuit Remaining Life Ratio [%]	
	Service Life Prediction Monitor – Dynamic Brake Circuit	Un02A	Dynamic Brake Circuit Remaining Life Ratio [%]	
	Service Life Prediction Monitor – Built-in Brake Relay	Un036	Built-in Brake Relay Remaining Life Ratio [%]	
			Continued on next page.	

### 17.2.2 Corresponding SERVOPACK Monitor Display Function Names

Continued from previous page.

SigmaWin+		SERVOPACK		
Button in Menu Dialog Box	Name [Unit]	Un No.	Name [Unit]	
Product Informa- tion	Motor – Resolution	Un084	Linear Encoder Pitch (Scale pitch = Un084 × 10 <sup>Un085</sup> [pm])	
	IVIOLOI – NESOIULIOII		Linear Encoder Pitch Exponent (Scale pitch = Un084 × 10 <sup>Un085</sup> [pm])	
	_	Un020	Rated Motor Speed [min <sup>-1</sup> ]	
_	-	Un021	Maximum Motor Speed [min <sup>-1</sup> ]	

<sup>\*1.</sup> You can use Un010 to monitor the upper limit setting for the maximum motor speed or the upper limit setting for

You can use Only to monitor the upper limit setting for the maximum motor speed or the upper limit setting for the encoder output resolution. You can monitor the upper limit of the encoder output resolution setting (Pn281) for the current maximum motor speed setting (Pn385), or you can monitor the upper limit of the maximum motor speed setting for the current encoder output resolution setting.

Select which signal to monitor with Pn080 = n.XDDDD (Calculation Method for Maximum Speed or Divided Output Puters)

put Pulses).

- If Pn080 = n.0□□□, the encoder output resolution (Pn281) that can be set is displayed.
  If Pn080 = n.1□□□, the maximum motor speed (Pn385) that can be set is displayed in mm/s.
- \*2. This applies to the following motors. The display will show 0 for all other models. SGM7J, SGM7A, SGM7P, SGM7G, and SGMCV

B backlash compensation - - - - - 8-71

	$Index \rangle$
--	-----------------

Symbols			base block (BB)	vii
PKK   Parker   signs			battery	
A   A   Co   A   A	Symbols		replacement	15-3
CCLT (Torque Limit Detection) signal			block diagram	2-8
CCUT (Torque Limit Detection) signal				
COIN	/CLT	6-30		
ACOIN (Positioning Completion) signal - 6-10   clearing alarm history - 15-41	/CLT (Torque Limit Detection) signal	6-30		
A-WBB1	/COIN	6-10	•	
N-CL   4-19   N-CL   6-27   CN3   4-19   N-CL   Reverse External Torque Limit) signal   6-27   CN5   4-41   N-CL (Reverse External Torque Limit) signal   6-27   CN5   4-43   N-CL (Reverse External Torque Limit) signal   6-27   CN5   4-43   N-CL (Reverse External Torque Limit) signal   6-11   CN66   4-39   N-CAR (Near) signal   6-11   CN66   4-39   N-CAR (Near) signal   6-27   CN7   4-41   N-CL (Forward External Torque Limit) signal   6-27   CN8   4-35   CN8   4-35   S-RDY   6-9   Coasting to a stop   5-37   Coasting to a stop   5-37   Coefficient of speed fluctuation   2-27   COMP   6-9   Communications connectors   2-6   COMP   Computer Connector   2-40   COMP   Computer Connector   2-40   COMP   COMP	/COIN (Positioning Completion) signal	6-10	clearing alarm history	15-41
N-CL   6-27   CN3	/HWBB1	4-36	CN1	4-28
N.C.L (Reverse External Torque Limit) signal   6-27	/HWBB2	4-36	CN2	4-19
NNEAR         6-11         CN6A         4-39           NNEAR (Near) signal         6-11         CN6B         4-39           /P-CL         -6-27         CN7         4-41           /P-CL (Forward External Torque Limit) signal         6-27         CN8         4-35           /S-RDY         6-9         coasting- 5-37         5-37           /S-RDY (Servo Ready) signal         6-8         coefficient of speed fluctuation         2-7           /TGON (Rotation Detection) signal         6-8         coefficient of speed fluctuation         2-7           /YCMP         6-9         communications connectors         2-6           /Y-CMP (Speed Coincidence Detection) signal         6-9         Computer Connector         4-41           /YLT         6-12         Computer Connector         4-41           /YLT (Speed Limit Detection) signal         6-12         Conntrolword (6040 hex)         11-15           /YLT (Speed Limit Detection) signal         6-12         Controlword (6040 hex)         14-21           /YLT (Speed Limit Detection) signal         6-12         Controlword (6040 hex)         14-21           /YLT (Speed Limit Detection) signal         6-12         Controlword (6040 hex)         14-21           /YLT (Speed Limit Detection) signal signal         6-12 <td>/N-CL</td> <td>6-27</td> <td>CN3</td> <td> 4-41</td>	/N-CL	6-27	CN3	4-41
//NEAR         -6-11         CN6A         -4-39           //NEAR (Near) signal         -6-11         CN6B         -4-39           //P-CL         -6-27         CN7         -4-41           //P-CL (Forward External Torque Limit) signal         -6-27         CN8         -4-35           //S-RDY         6-9         coasting         -5-37           //S-RDY (Servo Ready) signal         6-8         coasting to a stop         -5-37           //S-RDY (Servo Ready) signal         6-8         coefficient of speed fluctuation         -2-7           //GON (Rotation Detection) signal         6-8         communications connectors         -2-6           //CMP (Speed Coincidence Detection) signal         6-9         compatible adjustment functions         -8-86           //CMP (Speed Limit Detection) signal         6-12         compatible adjustment functions         -8-86           //LT         -6-12         connecting a safety function device         11-15           //LT         -6-12         connecting a safety function device         11-15           //LT         -6-12         connecting a safety function device         11-15           //LM (Serva Clamit) Detection) signal         -6-12         controll office to connector         -4-6           //LMARN         -6-7 </td <td>/N-CL (Reverse External Torque Limit) signal</td> <td>6-27</td> <td>CN5</td> <td> 4-41</td>	/N-CL (Reverse External Torque Limit) signal	6-27	CN5	4-41
A			CN6A	4-39
P-CL   -6-27   CN74-41     P-CL   CForward External Torque Limit) signal   -6-27   CN84-41     P-CL   CForward External Torque Limit) signal   -6-27   CN84-41     P-CL   CForward External Torque Limit) signal   -6-27   coasting5-37     S-RDY   Servo Ready) signal   -6-8   coasting to a stop5-37     TGON   (Rotation Detection) signal   -6-8   coefficient of speed fluctuation2-7     COMP   -6-8   coefficient of speed fluctuation2-7     COMP   -6-8   communications connectors   -2-6     CM-CMP (Speed Coincidence Detection) signal   -6-9   Computer Connector   -4-41     VLT   CSpeed Limit Detection) signal   -6-12   Controlword (6040 hex)   -14-12     VMARN   -6-7   Communications connector   -4-41     ALCO   -6-37   ABNARN (Warning) signal   -6-12   Controlword (6040 hex)   -14-12     ACCO   -6-37   ABNARN (Warning) signal   -6-13   Courrent control mode selection   -8-69     current gain level setting   -8-65   Current control mode selection   -8-69     current gain level setting   -8-65   Cyclic Synchronous Position Mode   -13-12, 14-41     Cyclic Synchronous Position Mode   -13-12, 14-41     Cyclic Synchronous Position Mode   -13-12, 14-41     Cyclic Synchronous Velocity Mode   -13-18, 14-42     Cyclic Synchronous Velocity Mod	/NEAR (Near) signal	6-11	CN6B	4-39
S-RDY   6-9     Coasting -     5-37     S-RDY (Servo Ready) signal   6-8     Coasting to a stop   5-37     TGON			CN7	4-41
S-RDY (Servo Ready) signal   6-8   coasting to a stop   5-37	/P-CL (Forward External Torque Limit) signal	6-27	CN8	4-35
ACCO - ACCO - Accorder         6-37 absolute encoder - desiring - seriesting			coasting	5-37
ACCO - Account control modes election origin offset - resetting - wiring - daditional adjustment functions - daditional adjustment functions - daditional adjustment functions - dark mode - daplicable communications connectors - 2-6         Acceleration (2703 hex) - 14-18         Acceleration (2703 hex) - 14-18         Acceleration (2703 hex) - 14-18         Acceleration (2703 hex) - 14-13         Acceleration (2703 hex) - 12-8, 12-10         Accel	/S-RDY (Servo Ready) signal	6-8	coasting to a stop	5-37
ACO         6-3           ACCO         6-3           ACCO         6-3           Acco         6-3           Acco         6-3           origin offset         6-3           origin offset         5-42           resetting         5-42           acceleration reference unit         14-18           Accolardion of Justine original original origin offset         14-18           Accolardion origin offset         6-37           consetting         3-3           dadditional adjustment functions         8-65           Acceleration User Unit (2703 hex)         14-18           Analog Monitor Connector         4-41           Alm         6-7           analog monitor factors         9-10           analog monitor factors         9-10           automatic detection of connected motor         5-13           diagnostic output circuits         4-36           diagnostic output circuits         4-36           diagnostic tools         4-30           automatic detection of connected motor         5-13           diagnostic tools         4-30           dautomatic onto filters         8-31           autotuning with a host reference         8-34				
N/-CMP         6-9         compatible adjustment functions-         8-86           N/-CMP (Speed Coincidence Detection) signal         6-9         Computer Connector         4-41           //LT (Speed Limit Detection) signal         6-12         connecting a safety function device         11-15           //LT (Speed Limit Detection) signal         6-12         Controlword (6040 hex)-         14-21           //LT (Speed Limit Detection) signal         6-12         Controlword (6040 hex)-         14-21           //LT (Speed Limit Detection) signal         6-12         Controlword (6040 hex)-         14-21           //LT (Speed Limit Detection) signal         6-17         Controlword (6040 hex)-         14-21           //LT (Speed Limit Detection) signal         6-7         Current control mode selection         4-5           //LT (Speed Limit Detection) signal         6-7         Current control mode selection         8-69           //LT (Speed Limit Detection) signal         6-7         Current control mode selection         8-69           //LT (Speed Limit Detection) signal         6-87         Current control mode selection         8-69           //LT (Speed Limit Detection) signal         6-87         Current control mode selection         9-10           //LT (Speed Limit Detection) signal         6-83         Cyclic Synchronous Position Mode <td></td> <td></td> <td></td> <td></td>				
ACCO - ABSOLUTION OF Setting - ABSOLUTE OF SETTING OF				
VVLT         -6-12         connecting a safety function device         11-15           VVLT (Speed Limit Detection) signal         -6-12         Controlword (6040 hex)         14-21           WARN (Warning) signal         6-7         current control mode selection         8-69           A         current gain level setting         8-69           CV         -6-37         custom tuning         8-41           CV         -5-14         Cyclic Sync Torque Mode         13-20           Origin offset         5-52         Cyclic Synchronous Position Mode         13-12, 14-41           Cyclic Synchronous Velocity Mode         13-12, 14-41         Cyclic Synchronous Velocity Mode         13-18, 14-42           Cyclic Synchronous Velocity Mode         13-18, 14-42         Cyclic Synchronous Velocity Mode         13-18, 14-42           Cyclic Synchronous Velocity Mode         13-18, 14-42         Cyclic Synchronous Velocity Mode         13-18, 14-42           DC mode         10 pc power supply input         4-11         Cyclic Synchronous Velocity Mode         13-18, 14-42           DC power supply input         4-12         DC power supply input         4-12         DC power supply input         4-12         DC power supply input         4-14         Accelerating to a stop         5-37         detection timing for Overload Alarms (A.720) <td></td> <td></td> <td></td> <td></td>				
VVLT (Speed Limit Detection) signal         -6-12         Controlword (6040 hex)				
A         6-7         countermeasures against noise         4-5           A         Current control mode selection         8-69           A         Current gain level setting         8-70           Custom tuning         8-41           CW         5-14           Cyclic Sync Torque Mode         13-20           Orgin offset         5-52           resetting         5-54           wiring         4-20           acceleration User Unit (2703 hex)         14-18           Acceleration User Unit (2703 hex)         14-18           additional adjustment functions         8-65           alarm reset possibility         15-5           ALM         6-7           ALM (Servo Alarm) signal         6-7           Analog Monitor Connector         4-41           analog monitor factors         9-10         detection timing for Overload Alarms (A.720)         5-40           applicable communications standards         2-6         device control         5-31           automatic detection of connected motor         5-13         diagnostic output circuits         4-36           automatic of pain switching         8-65         diagnostic tools         8-90           automatic of pain switching         8-65				
A.CCO				
A.CCO				
A.CCO	7 VVAI IIV (VVai i III) ji signai	0 1		
A.CCO 6-37	Α			
Absolute encoder 6-31		6-37	•	
origin offset 5-52 resetting 5-49 wiring 5-49 wiring 4-20         Cyclic Synchronous Position Mode - 13-12, 14-41           acceleration reference unit 4-20         - 4-20           acceleration User Unit (2703 hex) 14-18 additional adjustment functions 8-65 plant reset possibility 15-5 plant reset possibility reset plant reset possibility 15-5 plant reset possibility 15-5 plant reset possibility reset plant reset possibilit	absolute encoder	6-31		_
Cyclic Synchronous Velocity Mode	origin offset	5-52		
wiring	resetting	5-49		·
Acceleration User Unit (2703 hex) 14-18 additional adjustment functions 8-65 alarm reset possibility	wiring	4-20	Cyclic Synchronous velocity Mode	13-10, 14-42
Acceleration User Unit (2703 hex)	acceleration reference unit	14-18	D	
additional adjustment functions 8-65 alarm reset possibility 15-5 ALM 6-7 ALM (Servo Alarm) signal 6-7 Analog Monitor Connector 4-41 anti-resonance control 8-50 applicable communications standards 8-50 automatic detection of connected motor 5-13 automatic gain switching 8-65 automatic notch filters 8-31 autotuning with a host reference 8-34 autotuning without a host reference 8-23 digital liputs and outputs 13-22, 14-47 deriminals 4-11 br Reactor terminals 4-11 wiring 4-11 decelerating to a stop 5-37 detection timing for Overload Alarms (A.720) 5-41 detection timing for Overload Warnings (A.910) 5-40 device control 5-40 diagnostic output circuits 4-36 diagnostic tools 8-90 autotuning with a host reference 8-34 digital liputs (60FD hex) 14-47 digital inputs and outputs 13-22, 14-47	Acceleration User Unit (2703 hex)	14-18		- 12-8, 12-10
alarm reset possibility 15-5  ALM 6-7  ALM (Servo Alarm) signal 6-7  Analog Monitor Connector 4-11  Analog monitor factors 9-10  anti-resonance control 8-50  applicable communications standards 2-6  automatic detection of connected motor 5-13  automatic gain switching 8-65  automatic notch filters 8-31  autotuning with a host reference 8-34  autotuning without a host reference 8-23  DC Reactor  terminals 4-11  decelerating to a stop 4-18  detection timing for Overload Alarms (A.720) 5-41  detection timing for Overload Warnings (A.910) 5-40  device control 13-3  diagnostic output circuits 4-36  diagnostic tools 4-36  diagnostic tools 13-22  Digital Inputs (60FD hex) 14-47  digital inputs and outputs 13-22, 14-47	additional adjustment functions	8-65		,
ALM (Servo Alarm) signal 6-7  Analog Monitor Connector 4-41  anti-resonance control 8-50  applicable communications standards 2-6  automatic gain switching 8-65  automatic notch filters 8-31  autotuning with a host reference 8-34  autotuning without a host reference 8-23  Analog Monitor Connector 4-18  decelerating to a stop 4-18  decelerating to a stop 5-41  detection timing for Overload Warnings (A.910) 5-40  detection timing for Overload Warnings (A.910) 5-40  device control 13-3  diagnostic output circuits 4-36  diagnostic tools 8-90  digital I/O signals 13-22  autotuning without a host reference 8-23  digital inputs and outputs 13-22, 14-47				
Analog Monitor Connector	ALM	6-7	terminals	4-11
Analog Monitor Connector	ALM (Servo Alarm) signal	6-7	wiring	4-18
analog monitor factors			decelerating to a stop	5-37
anti-resonance control			detection timing for Overload Alarms (A.720) -	5-41
applicable communications standards 2-6 device control 13-3 automatic detection of connected motor 5-13 diagnostic output circuits 4-36 automatic gain switching 8-65 diagnostic tools 8-90 automatic notch filters 8-31 digital I/O signals 13-22 autotuning with a host reference 8-34 digital inputs (60FD hex) 14-47 digital inputs and outputs 13-22, 14-47			detection timing for Overload Warnings (A.910	)) 5-40
automatic detection of connected motor 5-13 diagnostic output circuits 4-36 automatic gain switching 8-65 diagnostic tools 8-90 automatic notch filters			device control	13-3
automatic gain switching				
automatic notch filters				
autotuning with a host reference 8-34 autotuning without a host reference 8-23 digital inputs and outputs 13-22, 14-47				
autotuning without a host reference				
· ·				
		3 20		

DINT	1-5	G	
Disable Operation Option Code (605C hex)	14-26	gain switching	8-65
displaying alarm history	15-40	grounding	4-8
Distributed Clocks	2-6	group 1 alarms	5-38
drive profile	2-6, 13-3	group 2 alarms	5-38
dynamic brake applied	5-37		
Dynamic Brake Resistor		Н	
allowable energy consumption	5-56	Halt Option Code (605D hex)	
connections		hard wire base block (HWBB)	
resistance	5-56	detecting errors in HWBB signal	· 11-7
dynamic brake stopping	5-37	HWBB input signal specifications	
		hard wire base block (HWBB) state	
E		resetting	
EasyFFT		holding brake	5-32
EDM1	11-11	Home Offset (607C hex)	· - 14-31
EDM1 (External Device Monitor) signal	11-11	homing 13-1-	4, 14-31
electronic gear	5-42	Homing Acceleration (609A hex)	- 14-32
emergency messages	12-11	Homing Method (6098 hex) 13-1-	4, 14-31
encoder divided pulse output	- 6-18, 10-7	Homing Mode	· - 14-31
setting	6-23	Homing Speeds (6099 hex)	
signals	6-18	HWBB 11	
encoder resolution	- 5-43, 6-23	detecting errors in HWBB signal	•
Error Code (603F hex)	14-21	HWBB input signal specifications	
estimating the moment of inertia	8-16	HWBB state	
EtherCAT commands		resetting	· 11-6
EtherCAT communications			
EtherCAT state machine		1	
event cycle		I/O signals	0.4
events		allocations	
event cycle	14-14	functions	
reception events	14-15	names	
sync events	12-8	wiring example	
SYNC0 event	12-8		
trigger events	13-23	indicators	
example of PDO data exchange timing in DC n	node12-10	initializing the vibration detection level	0-40
External Regenerative Resistor	5-55	input signals allocations	6-/
external torque limits	6-27	INT	
		internal torque limits	
F			
Fault Reaction Option Code (605E hex)		Interpolated Position Mode 13-9, 13-1	
feedback pulse counter		interpolated positioning	- 13-12
feedforward	- 8-32, 8-86	Interpolation Data Read/Write Pointer Position  Monitor (2741 hex)	1/1_//
feedforward compensation	8-86	Interpolation Data Record (60C1 hex)	
FG	4-8	Interpolation Data Record for 1st Profile (27C0 hex)	
FMMU	2-6		
Following Error Actual Value (60F4 hex)	14-34	Interpolation Data Record for 2nd Profile (27C1 hex)	
Following Error Time Out (6066 hex)		interpolation position reference	
Following Error Window (6065 hex)	14-33	interpolation position reference cycle	
forward direction		interpolation processing	
forward rotation		Interpolation Profile Select (2732 hex)	
Free-Run mode		interpolation speed exceeded	
friction compensation		Interpolation Submode Select (60C0 hex)	
fully-closed system		Interpolation Time Period (60C2 hex)	- 14-36
- ,			


I-P control	8-83	О	
<u>.</u>		object dictionary	
J		object dictionary list	14-3
jogging	/-/	object list	16-30
1		operation for momentary power interruptions	6-14
<b>L</b> limiting torque €	S-26	operation modes	- 13-5, 14-27
linear encoder	5-20	origin search	7-19
feedback resolution 5	5-44	output phase form	6-19
scale pitch setting 5		overload warnings	5-40
wiring example		overtravel	5-26
Linear Servomotor		release method selection	5-30
Linear Servomotor Overheat Protection Input		warnings	5-29
line-driver output circuits		_	
list of alarms		Р	
list of parameters		PAO	,
list of warnings 15		parameter settings recording table	16-40
		parameters	5.0
M		classification	
mailbox	2-6	initializing parameter settings notation (numeric settings)	
Main Circuit Cable	- vii	notation (numeric settings) notation (selecting functions)	
manual tuning	8-76	setting methods	
Manufacturer Interpolation Data Configuration		write prohibition setting	
for 1st Profile (2730 hex) 12	4-36	PBO	
Manufacturer Interpolation Data Configuration		PCO	•
for 2nd Profile (2731 hex) 14		PDO mapping objects	•
Max. Profile Velocity (607F hex)		PDO mappings	
Max. Torque (6072 hex) 14		default settings	
mechanical analysis	8-90	object dictionary	
mode switching (changing between proportional and PI control)	0 07	object dictionary list	
		setting procedure	
Modes of Operation (6060 hex) 14		photocoupler input circuits	
Modes of Operation Display (6061 hex) 14		photocoupler output circuits	
Momentary Power Interruption Hold Time 6		physical layer	
monitor factors		Pl control	
Motion Monitor	9-3	polarity detection	
motor current detection signal automatic adjustment	8 50	polarity sensor	
manual adjustment		Position Actual Internal Value (6063 hex)	
offset		Position Actual Value (6064 hex)	
motor direction setting		Position Demand Internal Value (60FC hex)	
motor maximum speed		Position Demand Value (6062 hex)	
motor overload detection level 5		position integral	
Motor Rated Torque (6076 hex)		position loop gain	
multiturn limit		position reference unit	
Multiturn Limit Disagreement 6		Position User Unit (2701 hex)	
Multitum Limit Disagreement	J-01	Position Window (6067 hex)	
N			
Negative Torque Limit Value (60E1 hex) 14	4-44	Position Window Time (6068 hex) positioning completed width	
Noise Filter			
Noise Filter connection precautions		Positive Torque Limit Value (60E0 hex)	
N-OT		P-OT	
N-OT (Reverse Drive Prohibit) signal 5		P-OT (Forward Drive Prohibit) signal process data	
notch filters		process data	2-0

Profile Acceleration (6083 hex)	14-30	SERVOPACK	vii
Profile Deceleration (6084 hex)	14-30	inspections and part replacement	
Profile Position Mode 13-6		part names	
Profile Torque Mode	13-19	ratings	
Profile Velocity (6081 hex)		specifications	
Profile Velocity Mode 13-17		status displays	
program jogging		setting the origin	5-52
operation pattern		setting the position deviation overflow alarm level	el 8-8
		setting the position deviation overflow alarm leve	
Q		at servo ON	
Quick Stop		setting the vibration detection level	
Quick Stop command		setup parameters	
Quick Stop Deceleration (6085 hex)		SG	
Quick Stop Option Code (605A hex)	14-25	Shutdown Option Code (605B hex)	
_		SigmaWin+	
R		signal allocations	
Receive PDO Mapping		sink circuits	
reception events		SINT	
reference unit		Slave Information IF	
Regenerative Resistor		software limits	
connection		Software Position Limit (607D hex)	
Regenerative Resistor capacity		software reset	
resetting alarms		source circuits	
resetting alarms detected in Option Modules		speed detection method selection	8-70
reverse direction		speed limit during torque control	6-12
risk assessment		speed loop gain	8-78
Rotary Servomotor	Vii	speed loop integral time constant	8-78
0		speed reference unit	14-18
S Conferts Foundation Circumsta	4.05	state machine control commands	13-4
Safety Function Signals		Status Monitor	9-3
application examples		Statusword (6041 hex)	13-4, 14-23
monitoring		stopping by applying the dynamic brake	5-37
precautions		stopping method for servo OFF	
verification test		storage humidity	
safety input circuits		storage temperature	
scale pitch		STRING	
selecting the phase sequence	- 5-15	Supported Drive Modes (6502 hex)	
for a Linear Servomotor	5-20	surrounding air humidity	
selecting torque limits		surrounding air temperature	
SEMI F47 function		switching condition A	
Serial Communications Connector		Sync Error Settings (10F1 hex)	
Serial Converter Unit		sync events	
Servo Drive		Sync Manager Communication Objects	
servo gains		Sync Manager Communication Type (1C00 hex)	
servo lock		Sync Manager PDO Assignment	14-10
servo OFF		(1C10 hex to 1C13 hex)	14-13
servo ON		Sync Manager Synchronization	
Servo Oin		(1C32 hex and 1C33 hex)	14-14
Servomotor		SYNC0 event	12-8
		synchronization with distributed clocks	12-8
Servomotor stopping method for alarms	D-JÖ	SyncManager	2-6

T
Target Position (607A hex) 14-29
Target Torque (6071 hex)
Target Velocity (60FF hex) 14-42
test without a motor
TH4-28
three-phase, 400-VAC power supply input 4-11
time required to brake
time required to release brake5-32
Torque Actual Value (6077 hex) 14-43
Torque Demand Value (6074 hex) 14-43
torque limit function14-44
torque limits 13-21
Torque Offset (60B2 hex)14-41
torque reference filter8-79
Torque Slope (6087 hex) 14-43
touch probe 13-23
example of execution procedure 13-24
Touch Probe 1 Position Value (60BA hex) 14-46
Touch Probe 2 Position Value (60BC hex) 14-46
touch probe function 14-45
Touch Probe Function (60B8 hex) 14-45
Touch Probe Status (60B9 hex) 14-45
Transmit PDO Mapping 14-11
trial operation
EtherCAT (CoE) Communications
trigger events 13-23
troubleshooting alarms15-11
troubleshooting warnings 15-46
tuning parameters 5-4
tuning-less
load level
rigidity level
tuning-less function8-12
U
UDINT 1-5
UINT 1-5
USINT 1-5
V
Velocity Actual Value (606C hex) 14-42
Velocity Demand Value (606B hex) 14-42
Velocity Offset (60B1 hex) 14-41
Velocity User Unit (2702 hex) 14-18
Velocity Window (606D hex)14-42
Velocity Window Time (606E hex) 14-42
vibration suppression8-55
W
writing parameters 5-16

## **Revision History**

The revision dates and numbers of the revised manuals are given on the bottom of the back cover.



Date of Publication	Rev. No.	Section	Revised Contents
January 2017	<6>	1.5.1, 1.6.1, 1.6.2, 2.1.1, 2.1.2, 2.1.3, 2.2.1, 2.2.2, 2.3.1, 3.3, 3.4.2, 4.3.1, 4.3.2, 4.3.4, 5.12	Addition: Information on SGD7S-210D to -370D
		4.4.3	Addition: Specifications for diodes to prevent reverse current flow
		5.10.3, 6.13.2	Deletion: Torque from the parameter table for Pn406
		6.14.2, 16.2	Addition: Parameter numbers related to object 2751 hex
		Back cover	Revision: Address
November 2016	<5>	All chapters	Partly revised.
June 2016	<4>	2.1.1	Revision: Value of continuous output current (Model: SGD7S-170D)
May 2016	<3>	1.5.1, 1.6.1, 1.6.2, 2.1.1, 2.1.2, 2.3.2, 3.3, 3.4.2, 4.3.4, 5.12, 15.2.2	Addition: Information on SGD7S-170D
		1.5.1, 2.1.2, 4.2, 4.3.1, 4.4.4, 5.11.3, 5.11.5, 15.2.2, 16.1.2	Addition: Information on Servomotor brake control
		All chapters	Partly revised.
March 2016	<2>	Preface	Revision: Information on Servomotor UL standards and EU Directives
		1.2.6	Revision: Information on torque user unit
		1.5.1, 1.5.2	Revision: Information on interpreting SERVOPACK and Servomotor model numbers
		1.7, 9.5	Addition: Information on alarm tracing
		2.1.1	Revision: Information on control power supply
		2.2	Addition: Connector numbers (CN101, CN102, CN115, and CN201)
		3.4.2	Revision: Information on installing more than one SERVOPACK
		4.3.3	Revision: Time for turning the power supply OFF and ON again (from 100 ms to 1 s)
		4.5.2	Revision: Illustration of I/O signal connectors
		5.14.4, 14.5	Revision: Setting range for torque reference units
		11.1.1	Revision: Description of safety functions
		14.2	Revision: Precaution on Store Parameters Field (1010 hex)
		14.1, 16.2	Revision: Data types for 27C0 hex and 27C1 hex
		16.1.2, 16.4	Deletion: Pn52D
		16.4	Addition: Supplemental description of enable timing
October 2015	<1>	All chapters	Partly revised.
		6.14	Addition: Information on ZONE outputs
		Back cover	Revision: Address
June 2015		_	First edition

# $\Sigma$ -7-Series AC Servo Drive $\Sigma$ -7S SERVOPACK with 400V-Input Power and EtherCAT (CoE) Communications References **Product Manual**

#### **IRUMA BUSINESS CENTER (SOLUTION CENTER)**

480, Kamifujisawa, Iruma, Saitama, 358-8555, Japan Phone 81-4-2962-5151 Fax 81-4-2962-6138 http://www.yaskawa.co.jp

### YASKAWA AMERICA, INC.

2121, Norman Drive South, Waukegan, IL 60085, U.S.A. Phone 1-800-YASKAWA (927-5292) or 1-847-887-7000 Fax 1-847-887-7310 http://www.yaskawa.com

#### YASKAWA ELÉTRICO DO BRASIL LTDA.

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil Phone 55-11-3585-1100 Fax 55-11-3585-1187 http://www.yaskawa.com.br

#### YASKAWA EUROPE GmbH

185, Hauptstraβe, Eschborn, 65760, Germany Phone 49-6196-569-300 Fax 49-6196-569-398 http://www.yaskawa.eu.com

#### YASKAWA ELECTRIC KOREA CORPORATION

35F, Three IFC, 10 Gukjegeumyung-ro, Yeongdeungpo-gu, Seoul, 07326, Korea Phone 82-2-784-7844 Fax 82-2-784-8495 http://www.yaskawa.co.kr

YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.
151, Lorong Chuan, #04-02A, New Tech Park, 556741, Singapore Phone 65-6282-3003 Fax 65-6289-3003 http://www.yaskawa.com.sg

### YASKAWA ELECTRIC (THAILAND) CO., LTD.

59, 1st-5th Floor, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok, 10310, Thailand Phone 66-2-017-0099 Fax 66-2-017-0799 http://www.yaskawa.co.th

YASKAWA ELECTRIC (CHINA) CO., LTD. 22F, One Corporate Avenue, No.222, Hubin Road, Shanghai, 200021, China Phone 86-21-5385-2200 Fax 86-21-5385-3299 http://www.yaskawa.com.cn

PASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE
Room 1011, Tower W3 Oriental Plaza, No.1, East Chang An Ave.,
Dong Cheng District, Beijing, 100738, China
Phone 86-10-8518-4086 Fax 86-10-8518-4082

#### YASKAWA ELECTRIC TAIWAN CORPORATION

9F, 16, Nanking E. Rd., Sec. 3, Taipei, 104, Taiwan Phone 886-2-2502-5003 Fax 886-2-2505-1280

### **YASKAWA**

YASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply. Specifications are subject to change without notice for ongoing product modifications and improvements

© 2015-2017 YASKAWA ELECTRIC CORPORATION

MANUAL NO. SIEP S800001 80G <6> Published in Japan January 2017 16-12-12 Original instructions